
Aluminum K1 3-Phase Delta Primary Series J

DOE 2016 3-Phase Dry Type Ventilated Transformer

Standard Temp Rise - 150° C



- ALL UNITS ARE UL LISTED AND ARE DESIGNED IN ACCORDANCE WITH ANSI C89.2 AMD NEMA ST-20 STANDARDS.
- 2. THESE TRANSFORMERS UTILIZE A UL RECOGNIZED 220°C INSULATION SYSTEM.
- 3. TRANSFORMERS ARE DRY TYPE, CLASS AA, VENTILATED ENCLOSURE FOR INDOOR OR OUTDOOR USE.
- 4. FOR LIFTING OTHER THAN WITH FORK TRUCK, REMOVE TOP COVER AND USE CORE CLAMPS.
- 5. PAINT COLOR IS ANSI #61 GRAY.
- 6. FULL WIDTH COPPER ELECTROSTATIC SHIELD (OPTIONAL).
- 7. 6" REQUIRED CLEARENCE FROM THE WALLS.
- 8. HV/LV TERMINALS ARE TOP FRONT TERMINATED.
- 9. NET. WEIGHTS ARE APPROXIMATE.
- 10. MEETS DOE-2016 EFFICIENCY 10 CFR PART 431

Siemens Industry, Inc.

GENERAL PURPOSE TRANSFORMERS
THREE-PHASE, 600 VOLTS CLASS, 60 HZ.

J201

REV.

Quick Reference for J Series Transformers

Aluminium D16 Drawings and Wiring Diagrams

AL	3 Phase Primary/ Secondary	Primary	Secondary	Reference Wiring diagram (Tap = diagram #)
AL	3B1	208	240D/120	Y=T208K, M=T208L
AL	3B3	208	208Y/120	Y=T208B, M=T208F, N=T208I
AL	3B5	208	480Y/277	Y=T208D, M=T208G, N=T208J
AL	3C3	240	208Y/120	Y=T240B, M=T240F, N=T240I
AL	3C5	240	480Y/277	Y=T240D, M=T240E, N=T240H
AL	3F1	480	240D/120	Y=T480G, T=T480N
AL	3F3	480	208Y/120	Y=T480E, T=T480M
AL	3F5	480	480Y/277	Y=T480J, T=T480P
AL	3F6	480	380Y/219	T=T480K
AL	3G3	600	208Y/120	T=T600G
AL	3G5	600	480Y/277	T=T600I

Alluminium Reference Code / Table Drawing

Table Diawing			
K-factor	Temp Rise degrees C		
Std = K1 K4 K13 K20	150 (Std.)	115	80
K1	J201	J202	J203
K4	J209	J210	J211
K13	J212	J213	J228
K20	J214	J215	J230


Copper D16 Drawings and Wiring Diagrams

CU	3 Phase Primary/ Secondary	Primary	Secondary	Reference Wiring diagram (Tap = diagram #)
CU	3B1	208	240D/120	Y=T208K, M=T208L
CU	3B3	208	208Y/120	Y=T208B, M=T208F, N=T208I
CU	3B5	208	480Y/277	Y=T208D, M=T208G, N=T208J
CU	3C3	240	208Y/120	Y=T240B, M=T240F, N=T240I
CU	3C5	240	480Y/277	Y=T240D, M=T240E, N=T240H
CU	3F1	480	240D/120	Y=T480G, T=T480N
CU	3F3	480	208Y/120	Y=T480E, T=T480M
CU	3F5	480	480Y/277	Y=T480J, T=T480P
CU	3F6	480	380Y/219	T=T480K
CU	3G3	600	208Y/120	T=T600G
CU	3G5	600	480Y/277	T=T600I

Copper Reference Code / Table Drawing


K-factor Temp Rise degrees C			
Total Prince Congress of	Temp Rise degrees C		
Std = K1 K4 K13 150 K20 (Std.) 115 80			
K1 J216 J217 J218			
K4 J221 J222 J223			
K13 J224 J225 J229			
K20 J226 J227 J231			

T208A Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
208	1	X1, X2, X3
198	2	X1, X2, X3
187	3	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
480		H1, H2, H3
277		Between H0 and

T208B Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
218	1	H1, H2, H3
213	2	H1, H2, H3
208	3	H1, H2, H3
203	4	H1, H2, H3
198	5	H1, H2, H3
192	6	H1, H2, H3
187	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T208D Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
218	1	X1, X2, X3
213	2	X1, X2, X3
208	3	X1, X2, X3
203	4	X1, X2, X3
198	5	X1, X2, X3
192	6	X1, X2, X3
187	7	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
480		H1, H2, H3
277 1 Phase		Between H0 and H1 or H2 or H3

T208F Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
218	1	H1, H2, H3
208	2	H1, H2, H3
198	3	H1, H2, H3
187	4	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T208G Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
218	1	X1, X2, X3
208	2	X1, X2, X3
198	3	X1, X2, X3
187	4	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
480		H1, H2, H3
277 1 Phase		Between H0 and H1 or H2 or H3

T208H Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
208	1	H1, H2, H3
198	2	H1, H2, H3
187	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T208I Wiring Diagram & Connections*




	SECONDARY	
	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
208	1	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T208J Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
208	1	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
480		H1, H2, H3
277 1 Phase		Between H0 and H1 or H2 or H3

T208K Wiring Diagram & Connections*




Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
218	1	X1, X2, X3
213	2	X1, X2, X3
208	3	X1, X2, X3
203	4	X1, X2, X3
198	5	X1, X2, X3
192	6	X1, X2, X3
187	7	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
240		H1, H2, H3
120 1 Phase		H1 and H4 or H2 and H4

T208L Wiring Diagram & Connections*




Connections			
	Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
	218	1	H1, H2, H3
	208	2	H1, H2, H3
	198	3	H1, H2, H3
	187	4	H1, H2, H3
	Sec. Volts		Secondary Lines Connect To
	240		H1, H2, H3
	120 1 Phase		H1 and H4 or H2 and H4

T240A Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
240	1	H1, H2, H3
228	2	H1, H2, H3
216	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 phase		Between X0 and X1 or X2 or X3

T240B Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
252	1	H1, H2, H3
246	2	H1, H2, H3
240	3	H1, H2, H3
234	4	H1, H2, H3
228	5	H1, H2, H3
222	6	H1, H2, H3
216	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T240D Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
252	1	X1, X2, X3
246	2	X1, X2, X3
240	3	X1, X2, X3
234	4	X1, X2, X3
228	5	X1, X2, X3
222	6	X1, X2, X3
216	7	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
480		H1, H2, H3
277 1 Phase		Between H0 and H1 or H2 or H3

T240E Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
252	1	X1, X2, X3
240	2	X1, X2, X3
228	3	X1, X2, X3
216	4	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
480		H1, H2, H3
277 1 Phase		Between H0 and H1 or H2, or H3

T240F Wiring Diagram & Connections'




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
252	1	H1, H2, H3
240	2	H1, H2, H3
228	3	H1, H2, H3
216	4	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2, or X3

T240G Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
240	1	X1, X2, X3
228	2	X1, X2, X3
216	3	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
480		H1, H2, H3
277 1 phase		Between X0 and H1 or H2 or H3

T240H Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
240	1	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
480		H1, H2, H3
277 1 Phase		Between H0 and H1 or H2 or H3

T240I Wiring Diagram & Connections*




	Connections		
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To	
240	1	H1, H2, H3	
Sec. Volts		Secondary Lines Connect To	
208		X1, X2, X3	
120 1 Phase		Between X0 and X1 or X2 or X3	

T460A Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
483	1	H1, H2, H3
472	2	H1, H2, H3
460	3	H1, H2, H3
448	4	H1, H2, H3
437	5	H1, H2, H3
425	6	H1, H2, H3
414	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
220		X1, X2, X3
127 1 Phase		Between X0 and X1 or X2 or X3

T480A Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
480	1	H1, H2, H3
456	2	H1, H2, H3
432	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 phase		Between X0 and X1 or X2 or X3

T480B Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
480	1	H1, H2, H3
456	2	H1, H2, H3
432	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
240		X1 X2 X3

T480C Wiring Diagram & Connections*




SECONDARY		
	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
480	1	H1, H2, H3
456	2	H1, H2, H3
432	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3
277 1 phase		Between X0 and X1 or X2 or X3

T480D Wiring Diagram & Connections*




	Connections	
Primary Volts	Interconnect	Supply Lines Connect To
480	H1 & 6 H2 & 4 H3 & 5	H1, H2, H3
456	H1 & 9 H2 & 7 H3 & 8	H1, H2, H3
432	H1 & 12 H2 & 10 H3 & 11	H1, H2, H3
Sec. Volts		Load Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T480E Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
444	6	H1, H2, H3
432	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T480F Wiring Diagram & Connections




	SECONDANT	
	Connections	
Primary Volts	On Each Coil Jumper Between Taps	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3

T480G Wiring Diagram & Connections*




Primary Volts Jumper Taps To Connect To South Telescond		Connections	
492 2 H1, H2, H3 480 3 H1, H2, H3 468 4 H1, H2, H3 456 5 H1, H2, H3 444 6 H1, H2, H3 432 7 H1, H2, H3 Sec. Secondary Lines Volts Connect To 240 X1, X2, X3 120 X1 and X4 or	Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
480 3 H1, H2, H3 488 4 H1, H2, H3 456 5 H1, H2, H3 444 6 H1, H2, H3 432 7 H1, H2, H3 58c. Secondary Lines Volts Connect To 240 X1, X2, X3 120 Y1 A1 AV A or	504	1	H1, H2, H3
468 4 H1, H2, H3 456 5 H1, H2, H3 444 6 H1, H2, H3 432 7 H1, H2, H3 Sec. Secondary Lines Volts Connect To 240 X1, X2, X3 120 X1 and X4 or	492	2	H1, H2, H3
456 5 H1, H2, H3 444 6 H1, H2, H3 432 7 H1, H2, H3 Sec. Secondary Lines Volts Connect To 240 X1, X2, X3 120 X1 and X4 or	480	3	H1, H2, H3
444 6 H1, H2, H3 432 7 H1, H2, H3 Sec. Secondary Lines Volts Connect To 240 X1, X2, X3 120 X1 and X4 or	468	4	H1, H2, H3
432 7 H1, H2, H3 Sec. Secondary Lines Volts Connect To 240 X1, X2, X3 120 X1 and X4 or	456	5	H1, H2, H3
Sec. Volts Secondary Lines Connect To 240 X1, X2, X3 120 X1 and X4 or		6	
Volts Connect To 240 X1, X2, X3 120 X1 and X4 or	432	7	H1, H2, H3
120 X1 and X4 or	Sec. Volts		Secondary Lines Connect To
	240		X1, X2, X3

T480I Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
444	6	H1, H2, H3
432	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
380		X1, X2, X3
220 1 Phase		Between X0 and X1 or X2 or X3

T480J Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
444	6	H1, H2, H3
432	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3
277 1 Phase		Between X0 and X1 or X2 or X3

T480K Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
380		X1, X2, X3
220 1 Phase		Between X0 and X1 or X2 or X3

Group T480L Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Between Taps	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
444	6	H1, H2, H3
432	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
400		X1, X2, X3
231 1 Phase		Between X0 and X1 or X2 or X3

T480M Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T480N Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
240		X1, X2, X3
120 1 Phase		X1 and X4 or X2 and X4

T480P Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3
277 1 Phase		Between X0 and X1 or X2 or X3

T480Q Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
444	6	H1, H2, H3
432	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3

T480R Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
480	1	H1, H2, H3
456	2	H1, H2, H3
432	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
600		X1, X2, X3

T480T Wiring Diagram & Connections*




Connections	
On Each Coil Jumper Taps To	Primary Lines Connect To
1	X1, X2, X3
2	X1, X2, X3
3	X1, X2, X3
4	X1, X2, X3
5	X1, X2, X3
6	X1, X2, X3
7	X1, X2, X3
	Secondary Lines Connect To
	H1, H2, H3
	On Each Coil Jumper Taps To 1 2 3 4 5






	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	H1, H2, H3
492	2	H1, H2, H3
480	3	H1, H2, H3
468	4	H1, H2, H3
456	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
400		X1, X2, X3
231 1 Phase		Between X0 and X1 or X2 or X3

T480V Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Connect To
504	1	X1, X2, X3
492	2	X1, X2, X3
480	3	X1, X2, X3
468	4	X1, X2, X3
456	5	X1, X2, X3
Sec. Volts		Secondary Lines Connect To
600		H1, H2, H3

T600A Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
600	1	H1, H2, H3
570	2	H1, H2, H3
540	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 phase		Between X0 and X1 or X2 or X3

T600B Wiring Diagram & Connections*




	SECONDARY	
	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
630	1	H1, H2, H3
615	2	H1, H2, H3
600	3	H1, H2, H3
585	4	H1, H2, H3
570	5	H1, H2, H3
555	6	H1, H2, H3
540	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T600D Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
630	1	H1, H2, H3
615	2	H1, H2, H3
600	3	H1, H2, H3
585	4	H1, H2, H3
570	5	H1, H2, H3
555	6	H1, H2, H3
540	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
240		X1, X2, X3
120 1 Phase		X1 and X4 or X2 and X4

T600E Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
600	1	H1, H2, H3
570	2	H1, H2, H3
540	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
240		X1. X2. X3

T600F Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
630	1	H1, H2, H3
615	2	H1, H2, H3
600	3	H1, H2, H3
585	4	H1, H2, H3
570	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
240		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T600G Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
630	1	H1, H2, H3
615	2	H1, H2, H3
600	3	H1, H2, H3
585	4	H1, H2, H3
570	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
208		X1, X2, X3
120 1 Phase		Between X0 and X1 or X2 or X3

T600H Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps to	Primary Lines Connect To
600	1	H1, H2, H3
570	2	H1, H2, H3
540	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3
277 1 Phase		Between X0 and X1 or X2 or X3






	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
630	1	H1, H2, H3
615	2	H1, H2, H3
600	3	H1, H2, H3
585	4	H1, H2, H3
570	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3
277 1 Phase		Between X0 and X1 or X2 or X3

T600J Wiring Diagram & Connections*




	Connections	
Primary Volts	Jumper Taps To	Primary Lines Connect To
600	1	H1, H2, H3
570	2	H1, H2, H3
540	3	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3

T600K Wiring Diagram & Connections*




	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
630	1	H1, H2, H3
615	2	H1, H2, H3
600	3	H1, H2, H3
585	4	H1, H2, H3
570	5	H1, H2, H3
555	6	H1, H2, H3
540	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3

T600L Wiring Diagram & Connections*



	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
630	1	H1, H2, H3
615	2	H1, H2, H3
600	3	H1, H2, H3
585	4	H1, H2, H3
570	5	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3

T600M Wiring Diagram & Connections*



	Connections	
Primary Volts	On Each Coil Jumper Taps To	Primary Lines Between Lines
630	1	H1, H2, H3
615	2	H1, H2, H3
600	3	H1, H2, H3
585	4	H1, H2, H3
570	5	H1, H2, H3
555	6	H1, H2, H3
540	7	H1, H2, H3
Sec. Volts		Secondary Lines Connect To
480		X1, X2, X3
277 1 Phase		Between X0 and X1 or X2 or X3