



I/O-Link Device Library

Release v3.02



Allen-Bradley

by ROCKWELL AUTOMATION

Reference Manual

Original Instructions

Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT Identifies information that is critical for successful application and understanding of the product.

These labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.



ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

The following icon may appear in the text of this document.



Identifies information that is useful and can help to make a process easier to do or easier to understand.

..... **Table of Contents 3**

Preface23
 Device Object Libraries Overview 23
 Application Code Manager 23
 Other Application Code Libraries 24
 Software and Firmware Upgrades 25
 Rockwell Automation® Services and Support 25

**Rockwell Automation® IO-Link
 Device Library**

Chapter 1
 Compatibility 27
 Compatible Software 27
 Compatible Hardware 27
 Summary of Changes 28
 Footprint 28
 Additional Resources 30

Library Components

Chapter 2
 IO-Link Device Instructions 31
 Library Folders and Files 33
 Visualization Files 36
 Studio 5000 View Designer Visualization Files 36
 Basic Faceplate Attributes 37
 Common Status Banner 37
 Faceplate Navigation 38
 Faceplate Revision Notes 38
 Launch Buttons 39
 Library Versions 41
 State Model 42
 Interfaces 42
 Data Types 43
 raC_UDT_ItfAD_IOLinkSensor_CtrlSet 43
 raC_UDT_ItfAD_IOLinkSensor_CtrlCmd 43
 raC_UDT_ItfAD_IOLinkSensor_CtrlSts 44
 raC_UDT_ItfAD_IOLinkDevices 45
 raC_UDT_ItfAD_IOLinkSensorInf 45
 raC_UDT_Event 46
 raC_UDT_LookupMember_STR0082 46
 raC_UDT_Dropdown 46
 raC_UDT_HEX_Code_LookupMember 47
 Application Code Manager 47
 Architectural Overview 47

Using the Library

Chapter 3
 Install the Library 49

Download the Library	49
Download & Install Studio 5000® Application Code Manager	49
Register Libraries in Studio 5000® Application Code Manager . . .	50
Importing Logic into Studio 5000® Projects	52
Import Library Objects Wizard	52
Import Rung Logic (4IOL, 8IOL Masters).	54
Import Rung Logic (5032 Master)	59
Using Studio 5000 View Designer®	63
Using View Designer Project Files	63
Configuring View Designer Objects	64
Using FactoryTalk® View Studio	64
Import FactoryTalk View Visualization Files	64
Configuring FactoryTalk View Objects	65
Library Upgrades	66
Add-On Instruction Upgrades	66
FactoryTalk View Upgrades	73
Studio 5000 View Designer® Upgrades	73

Chapter 4

Using Application Code Manager

Overview of Application Code Manager	75
Creating a New Project	75
Adding & Configuring Device Objects.	78
Adding IO-Link Master I/O Module	78
Adding IO-Link Device Instructions	80
Adding IO-Link Master Device Object	84
Configuring Displays	89
Generating Displays	91
Importing Displays into FactoryTalk View Studio	91
Generating Controller Files	92
Exporting Attachments	93

Chapter 5

Using the IO-Link Device Library with Other Application Code Libraries

Application Code Libraries	95
--------------------------------------	----

Chapter 6

42AF - RightSight Photoelectric Sensor (raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL, raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032)

Overview	97
Functional Description	97
Required Files	98
Controller Files	98
FactoryTalk View HMI Files	98
Studio 5000 View Designer HMI Files	99
Studio 5000 Application Code Manager Files	99
Device Definition (raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL).	100
Device Definition (raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032)	100
Operations	102

Execution	102
Add-On Instruction I/O Data (raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL)	103
InOut Data	103
Input Data	103
Output Data	105
Add-On Instruction I/O Data (raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032)	107
InOut Data	107
Input Data	107
Output Data	109
Programming Example	111
Graphic Symbols	113
FactoryTalk View ME/SE Graphic Symbols	113
Studio 5000 View Designer Graphic Symbols	114
Faceplates	114
Home	114
Health Tab	116
Trend Tab	117
Configure Tab	117
Fault Warning Tab	121
Application Code Manager	122
Definition Objects: raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL, raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032	122
Implementation Objects: raC_LD_Dvc_42AF_4IOL, raC_LD_Dvc_42AF_8IOL	123
Implementation Objects: raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032	
Linked Libraries	123
Configured HMI Content	124
Attachments	124

Chapter 7

42EF - RightSight Photoelectric Sensor (raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL, raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032)	
Overview	125
Functional Description	125
Required Files	126
Controller Files	126
FactoryTalk View HMI Files	127
Studio 5000 View Designer HMI Files	127
Studio 5000 Application Code Manager Files	127
Device Definition (raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL)	128
Device Definition (raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032)	129
Operations	130
Execution	130
Add-On Instruction I/O Data (raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL)	132

InOut Data.....	132
Input Data.....	132
Output Data.....	133
Add-On Instruction I/O Data (raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032).....	135
InOut Data.....	135
Input Data.....	135
Output Data.....	137
Programming Example.....	139
Graphic Symbols.....	141
FactoryTalk View ME/SE Graphic Symbols.....	141
Studio 5000 View Designer Graphic Symbols.....	142
Faceplates.....	142
Home.....	142
Health Tab.....	144
Trend Tab.....	145
Configure Tab.....	145
Fault Warning Tab.....	148
Application Code Manager.....	149
Definition Objects: raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL, raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032.....	149
Implementation Objects: raC_LD_Dvc_42EF_4IOL, raC_LD_Dvc_42EF_8IOL	
Implementation Objects: raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032.....	150
Linked Libraries.....	151
Configured HMI Content.....	151
Attachments.....	151

Chapter 8

42JT - VisiSight Photoelectric Sensor (raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL, raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032)

Overview.....	153
Functional Description.....	153
Required Files.....	153
Controller Files.....	154
FactoryTalk View HMI Files.....	154
Studio 5000 View Designer HMI Files.....	155
Studio 5000 Application Code Manager Files.....	155
Device Definition (raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL).....	156
Device Definition (raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032).....	156
Operations.....	158
Execution.....	158
Add-On Instruction I/O Data (raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL).....	159
InOut Data.....	159
Input Data.....	159

Output Data.....	160
Add-On Instruction I/O Data (raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032)	160
InOut Data.....	160
Input Data.....	162
Output Data.....	162
Programming Example.....	164
Graphic Symbols.....	166
FactoryTalk View ME/SE Graphic Symbols.....	166
Studio 5000 View Designer Graphic Symbols.....	167
Faceplates.....	167
Home.....	167
Configure Tab.....	168
Fault Warning Tab.....	172
Application Code Manager.....	174
Definition Objects: raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL, raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032	174
Implementation Objects: raC_LD_Dvc_42JT_4IOL, raC_LD_Dvc_42JT_8IOL.....	174
Implementation Objects: raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032	175
Linked Libraries	175
Configured HMI Content	176
Attachments	176

Chapter 9

871FM - Mini Flat Pack Sensor (raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL, raC_Dvc_871FM_Type1_5032, raC_Dvc_871FM_Type2_5032)

Overview.....	177
Functional Description.....	177
Required Files	177
Controller Files.....	178
FactoryTalk View HMI Files	178
Studio 5000 View Designer HMI Files	179
Studio 5000 Application Code Manager Files.....	179
Device Definition (raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL)	179
Device Definition (raC_Dvc_871FM_Type1_5032, raC_Dvc_871FM_Type2_5032)	180
Operations	182
Execution.....	182
Add-On Instruction I/O Data (raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL)	183
InOut Data.....	183
Input Data.....	183
Output Data.....	184
Add-On Instruction I/O Data (raC_Dvc_871FM_Type1_5032, raC_Dvc_871FM_Type2_5032)	185
InOut Data.....	185
Input Data.....	185

Output Data.....	187
Programming Example.....	189
Graphic Symbols.....	190
FactoryTalk View ME/SE Graphic Symbols.....	190
Studio 5000 View Designer Graphic Symbols.....	191
Faceplates.....	191
Home.....	191
Health Tab.....	193
Trend Tab.....	194
Configure Tab.....	194
Fault Warning Tab.....	196
Application Code Manager.....	198
Definition Objects: raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL, raC_Dvc_871FM_Type1_5032, raC_Dvc_871FM_Type2_5032.....	198
Implementation Objects: raC_LD_Dvc_871FM_4IOL, raC_LD_Dvc_871FM_8IOL.....	198
Implementation Objects: raC_LD_Dvc_871FM_Type1_5032, raC_LD_Dvc_871FM_Type2_5032.....	199
Linked Libraries.....	199
Configured HMI Content.....	199
Attachments.....	200

Chapter 10

871C - Mini Tubular Sensor (raC_Dvc_871C_4IOL, raC_Dvc_871C_8IOL, raC_Dvc_871C_5032)

Overview.....	201
Functional Description.....	201
Required Files.....	201
Controller Files.....	202
FactoryTalk View HMI Files.....	202
Studio 5000 View Designer HMI Files.....	203
Studio 5000 Application Code Manager Files.....	203
Device Definition (raC_Dvc_871C_4IOL, raC_Dvc_871C_8IOL).....	204
Device Definition (raC_Dvc_871C_5032).....	204
Operations.....	206
Execution.....	206
Add-On Instruction I/O Data (raC_Dvc_871C_4IOL, raC_Dvc_871C_8IOL).....	207
InOut Data.....	207
Input Data.....	207
Output Data.....	207
Add-On Instruction I/O Data (raC_Dvc_871C_5032).....	209
InOut Data.....	209
Input Data.....	209
Output Data.....	209
Programming Example.....	211
Graphic Symbols.....	212
FactoryTalk View ME/SE Graphic Symbols.....	212
Studio 5000 View Designer Graphic Symbols.....	213
Faceplates.....	213

Home	213
Health Tab	214
Configure Tab	215
Fault Warning Tab	217
Application Code Manager	218
Definition Objects: raC_Dvc_871C_4IOL, raC_Dvc_871C_8IOL ..	219
Implementation Objects: raC_LD_Dvc_871C_4IOL, raC_LD_Dvc_871C_8IOL, raC_LD_Dvc_871C_5032	219
Implementation Objects: raC_LD_Dvc_871C_5032	219
Linked Libraries	220
Configured HMI Content	220
Attachments	221

Chapter 11

871TM - Tubular Stainless Steel Sensor (raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL, raC_Dvc_871TM_5032)

Overview	223
Functional Description	223
Required Files	223
Controller Files	224
FactoryTalk View HMI Files	224
Studio 5000 View Designer HMI Files	225
Studio 5000 Application Code Manager Files	225
Device Definition (raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL)	226
Device Definition (raC_Dvc_871TM_5032)	226
Operations	228
Execution	228
Add-On Instruction I/O Data (raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL)	229
InOut Data	229
Input Data	229
Output Data	229
Add-On Instruction I/O Data (raC_Dvc_871TM_5032)	231
InOut Data	231
Input Data	231
Output Data	231
Programming Example	233
Graphic Symbols	234
FactoryTalk View ME/SE Graphic Symbols	234
Studio 5000 View Designer Graphic Symbols	235
Faceplates	235
Home	235
Configure Tab	236
Fault Warning Tab	238
Application Code Manager	239
Definition Objects: raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL, raC_Dvc_871TM_5032	239
Implementation Objects: raC_LD_Dvc_871TM_4IOL, raC_LD_Dvc_871TM_8IOL, raC_LD_Dvc_871TM_5032	240

Implementation Objects: raC_LD_Dvc_871TM_5032	
Linked Libraries	240
Configured HMI Content	241
Attachments	241

Chapter 12

45CRM - Color Registration Mark Sensor (raC_Dvc_45CRM_4IOL, raC_Dvc_45CRM_8IOL, raC_Dvc_45CRM_5032)

Overview	243
Functional Description	243
Required Files	243
Controller Files	244
FactoryTalk View HMI Files	244
Studio 5000 View Designer HMI Files	245
Studio 5000 Application Code Manager Files	245
Device Definition (raC_Dvc_45CRM_4IOL, raC_Dvc_45CRM_8IOL)	245
Device Definition (raC_Dvc_45CRM_Type1_5032, raC_Dvc_45CRM_Type2_5032)	246
Operations	248
Execution	248
Add-On Instruction I/O Data (raC_Dvc_45CRM_4IOL, raC_Dvc_45CRM_8IOL)	249
InOut Data	249
Input Data	249
Output Data	250
Add-On Instruction I/O Data (raC_Dvc_45CRM_5032)	250
InOut Data	250
Input Data	251
Output Data	251
Programming Example	253
Graphic Symbols	254
Studio 5000 View Designer Graphic Symbols	254
Faceplates	255
Home	255
Configure Tab	256
Fault Warning Tab	260
Application Code Manager	262
Definition Objects: raC_Dvc_45CRM_4IOL, raC_Dvc_45CRM_8IOL, raC_Dvc_45CRM_5032	262
Implementation Objects: raC_LD_Dvc_45CRM_4IOL, raC_LD_Dvc_45CRM_8IOL	262
Implementation Objects: raC_LD_Dvc_45CRM_5032	262
Linked Libraries	263
Configured HMI Content	263
Attachments	264

836P - Solid-State Pressure Sensor (raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL, raC_Dvc_836P_Type1_5032, raC_Dvc_836P_Type2_5032)	Chapter 13	
	Overview	266
	Functional Description	266
	Required Files	266
	Controller Files	267
	FactoryTalk View HMI Files	270
	Studio 5000 View Designer HMI Files	270
	Studio 5000 Application Code Manager Files	271
	Device Definition (raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL)	271
	Device Definition (raC_Dvc_836P_Type1_5032, raC_Dvc_836P_Type2_5032)	272
	Operations	274
	Execution	274
	Add-On Instruction I/O Data (raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL)	275
	InOut Data	275
	Input Data	275
	Output Data	277
	Add-On Instruction I/O Data (raC_Dvc_836P_Type1_5032, raC_Dvc_836P_Type2_5032)	279
	InOut Data	279
	Input Data	279
	Output Data	280
	Programming Example	282
	Graphic Symbols	283
	FactoryTalk View ME/SE Graphic Symbols	284
	Studio 5000 View Designer Graphic Symbols	284
	Faceplates	284
	Home	284
	Health Tab	285
	Trend Tab	287
	Configure Tab	287
	Fault Warning Tab	291
	Application Code Manager	292
	Definition Objects: raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL, raC_Dvc_836P_Type1_5032, raC_Dvc_836P_Type2_5032	292
	Implementation Objects: raC_LD_Dvc_836P_4IOL, raC_LD_Dvc_836P_8IOL	293
	Implementation Objects: raC_LD_Dvc_836P_Type1_5032, raC_LD_Dvc_836P_Type2_5032	293
	Linked Libraries	294
	Configured HMI Content	294
	Attachments	294

Chapter 14		
837T - Solid-State Temperature Sensor (raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL, raC_Dvc_837T_Type1_5032, raC_Dvc_837T_Type2_5032)	Overview	297
	Functional Description	297
	Required Files	297
	Controller Files	298
	FactoryTalk View HMI Files	298
	Studio 5000 View Designer HMI Files	299
	Studio 5000 Application Code Manager Files	299
	Device Definition (raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL)	299
	Device Definition (raC_Dvc_837T_Type1_5032, raC_Dvc_837T_Type2_5032)	300
	Operations	302
	Execution	302
	Add-On Instruction I/O Data (raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL)	303
	InOut Data	303
	Input Data	303
	Output Data	305
	Add-On Instruction I/O Data (raC_Dvc_837T_Type1_5032, raC_Dvc_837T_Type2_5032)	307
	InOut Data	307
	Input Data	307
	Output Data	308
	Programming Example	310
	Graphic Symbols	311
	FactoryTalk View ME/SE Graphic Symbols	312
	Studio 5000 View Designer Graphic Symbols	312
	Faceplates	312
	Home	313
	Health Tab	313
	Trend Tab	315
	Configure Tab	315
	Fault Warning Tab	319
	Application Code Manager	320
	Definition Objects: raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL, raC_Dvc_837T_Type1_5032, raC_Dvc_837T_Type2_5032	320
	Implementation Objects: raC_LD_Dvc_837T_4IOL, raC_LD_Dvc_837T_8IOL	321
Implementation Objects: raC_LD_Dvc_837T_Type1_5032, raC_LD_Dvc_837T_Type2_5032	321	
Linked Libraries	322	
Configured HMI Content	322	
Attachments	322	

856T - 856T Control Tower Stack Light (raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL, raC_Dvc_856T_5032)	Chapter 15	
	Overview	325
	Functional Description	325
	Required Files	325
	Controller Files	325
	FactoryTalk View HMI Files	326
	Studio 5000 View Designer HMI Files	326
	Studio 5000 Application Code Manager Files	327
	Device Definition (raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL)	327
	Device Definition (raC_Dvc_856T_5032)	328
	Operations	329
	Execution	330
	Add-On Instruction I/O Data (raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL)	331
	InOut Data	331
	Input Data	331
	Output Data	334
	Add-On Instruction I/O Data (raC_Dvc_856T_5032)	336
	InOut Data	336
	Input Data	336
	Output Data	338
	Programming Example	341
	Graphic Symbols	342
	FactoryTalk View ME/SE Graphic Symbols	342
	Studio 5000 View Designer Graphic Symbols	343
	Faceplates	343
	Home	343
	Health Tab	344
	Configure Tab	345
	Fault Warning Tab	349
	Application Code Manager	351
	Definition Objects: raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL, raC_Dvc_856T_5032	351
	Implementation Objects: raC_LD_Dvc_856T_4IOL, raC_LD_Dvc_856T_8IOL	351
	Implementation Objects: raC_LD_Dvc_856T_5032	351
	Linked Libraries	352
	Configured HMI Content	352
	Attachments	353
873P - Analog Output Ultrasonic Sensor (raC_Dvc_873P_4IOL, raC_Dvc_873P_8IOL, raC_Dvc_873P_Type1_5032, raC_Dvc_873P_Type2_5032)	Chapter 16	
	Overview	355
	Functional Description	355
	Required Files	355
	Controller Files	356
	FactoryTalk View HMI Files	357
	Studio 5000 View Designer HMI Files	358
	Studio 5000 Application Code Manager Files	358

Device Definition (raC_Dvc_873P_4IOL, raC_Dvc_873P_8IOL) 358

Device Definition (raC_Dvc_873P_Type1_5032, raC_Dvc_873P_Type2_5032) 359

Operations 361

 Execution 361

Add-On Instruction I/O Data (raC_Dvc_873P_4IOL, raC_Dvc_873P_8IOL) 362

 InOut Data 362

 Input Data 362

 Output Data 364

Add-On Instruction I/O Data (raC_Dvc_873P_Type1_5032, raC_Dvc_873P_Type2_5032) 366

 InOut Data 366

 Input Data 366

 Output Data 367

Programming Example 370

Graphic Symbols 371

 FactoryTalk View ME/SE Graphic Symbols 372

 Studio 5000 View Designer Graphic Symbols 372

Faceplates 372

 Home 373

 Health Tab 373

 Trend Tab 374

 Configure Tab 375

 Fault Warning Tab 379

Application Code Manager 380

 Definition Objects: raC_Dvc_873P_4IOL, raC_Dvc_873P_8IOL, raC_Dvc_873P_Type1_5032, raC_Dvc_873P_Type2_5032 380

 Implementation Objects: raC_LD_Dvc_873P_4IOL, raC_LD_Dvc_873P_8IOL 381

 Implementation Objects: raC_LD_Dvc_873P_Type1_5032, raC_LD_Dvc_873P_Type2_5032

 Linked Libraries 381

 Configured HMI Content 382

 Attachments 382

Chapter 17

1694 - 1694 Modular Electronic Circuit Protector (raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL, raC_Dvc_1694_5032)

Overview 383

Functional Description 383

Required Files 383

 Controller Files 384

 FactoryTalk View HMI Files 384

 Studio 5000 View Designer HMI Files 385

 Studio 5000 Application Code Manager Files 385

Device Definition (raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL) 385

Device Definition (raC_Dvc_1694_5032) 386

Operations 388

Execution	388
Add-On Instruction I/O Data(raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL)	389
InOut Data	389
Input Data	389
Output Data	390
Add-On Instruction I/O Data(raC_Dvc_1694_5032)	390
InOut Data	390
Input Data	392
Output Data	392
Programming Example	394
Graphic Symbols	395
FactoryTalk View ME/SE Graphic Symbols	395
Studio 5000 View Designer Graphic Symbols	396
Faceplates	396
Home	396
I/O Tab	397
Configure Tab	398
Fault Warning Tab	401
Application Code Manager	402
Definition Objects: raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL, raC_Dvc_1694_5032	402
Implementation Objects: raC_LD_Dvc_1694_4IOL, raC_LD_Dvc_1694_8IOL	402
Implementation Objects: raC_LD_Dvc_1694_5032	403
Linked Libraries	404
Configured HMI Content	404
Attachments	404

Chapter 18

45DMS - Distance Measurement Sensor (raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL, raC_Dvc_45DMS_Type1_5032, raC_Dvc_45DMS_Type2_5032)	
Overview	405
Functional Description	405
Required Files	405
Controller Files	406
FactoryTalk View HMI Files	406
Studio 5000 View Designer HMI Files	407
Studio 5000 Application Code Manager Files	407
Device Definition (raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL)	407
Device Definition (raC_Dvc_45PLA_Type1_5032, raC_Dvc_45PLA_Type2_5032)	408
Operations	410
Execution	410
Add-On Instruction I/O Data (raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL)	411
InOut Data	411
Input Data	411
Output Data	413

Add-On Instruction I/O Data (raC_Dvc_45DMS_Type1_5032, raC_Dvc_45DMS_Type2_5032)	415
InOut Data.....	415
Input Data.....	415
Output Data.....	416
Programming Example.....	418
Graphic Symbols.....	420
FactoryTalk View ME/SE Graphic Symbols	420
Studio 5000 View Designer Graphic Symbols.....	421
Faceplates	421
Home	421
Health Tab.....	422
Trend Tab.....	423
Configure Tab.....	424
Fault Warning Tab.....	427
Application Code Manager.....	428
Definition Objects: raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL, raC_Dvc_45DMS_Type1_5032, raC_Dvc_45DMS_Type2_5032 ...	429
Implementation Objects: raC_LD_Dvc_45DMS_4IOL, raC_LD_Dvc_45DMS_8IOL.....	429
Implementation Objects: raC_LD_Dvc_45DMS_Type1_5032, raC_LD_Dvc_45DMS_Type2_5032.....	429
Linked Libraries	430
Configured HMI Content	430
Attachments	431

Chapter 19

46CLR - ColorSight True Color Sensor (raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL, raC_Dvc_46CLR_5032)

Overview.....	433
Functional Description	433
Required Files	433
Controller Files	434
FactoryTalk View HMI Files	434
Studio 5000 View Designer HMI Files	435
Studio 5000 Application Code Manager Files.....	435
Device Definition (raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL)	435
Device Definition (raC_Dvc_46CLR_5032)	436
Operations	438
Execution.....	438
Add-On Instruction I/O Data (raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL)	439
InOut Data.....	439
Input Data	439
Output Data.....	442
Add-On Instruction I/O Data (raC_Dvc_46CLR_5032)	444
InOut Data.....	444
Input Data	444
Output Data.....	447
Programming Example.....	449

Graphic Symbols	450
FactoryTalk View ME/SE Graphic Symbols	450
Studio 5000 View Designer Graphic Symbols	451
Faceplates	451
Home	451
Health Tab	453
Trend Tab	455
Configure Tab	455
Application Code Manager	459
Definition Objects: raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL, raC_Dvc_46CLR_5032	460
Implementation Objects: raC_LD_Dvc_46CLR_4IOL, raC_LD_Dvc_46CLR_8IOL	460
Implementation Objects: raC_LD_Dvc_46CLR_5032	460
Linked Libraries	461
Configured HMI Content	461
Attachments	462

Chapter 20

875L - Capacitive Sensors (raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL, raC_Dvc_875L_5032)

Overview	463
Functional Description	463
Required Files	463
Controller Files	464
FactoryTalk® View HMI Files	464
Studio 5000 View Designer HMI Files	464
Studio 5000 Application Code Manager Files	465
Device Definition (raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL)	465
Device Definition (raC_Dvc_875L_5032)	466
Operations	467
Execution	467
Add-On Instruction I/O Data (raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL)	468
InOut Data	468
Input Data	468
Output Data	471
Add-On Instruction I/O Data (raC_Dvc_875L_5032)	473
InOut Data	473
Input Data	473
Output Data	475
Programming Example	478
Graphic Symbols	479
FactoryTalk View ME/SE Graphic Symbols	479
Studio 5000 View Designer Graphic Symbols	480
Faceplates	480
Home	481
Health Tab	482
Trend Tab	483
Configure Tab	484

Fault Warning Tab.	489
Application Code Manager.	491
Definition Objects: raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL, raC_Dvc_875L_5032.	491
Implementation Objects: raC_LD_Dvc_875L_4IOL, raC_LD_Dvc_875L_8IOL.	491
Implementation Objects: raC_LD_Dvc_875L_5032	
Linked Libraries.	492
Configured HMI Content.	493
Attachments.	493

Chapter 21

46DFA - Small Aperture Fiber-optic Amplifier (raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL, raC_Dvc_46DFA_5032)

Overview.	495
Functional Description.	495
Required Files.	495
Controller Files.	496
FactoryTalk View HMI Files.	496
Studio 5000 View Designer HMI Files.	496
Studio 5000 Application Code Manager Files.	497
Device Definition (raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL).	497
Device Definition (raC_Dvc_46DFA_5032).	498
Operations.	500
Execution.	500
Add-On Instruction I/O Data (raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL).	501
InOut Data.	501
Input Data.	501
Output Data.	503
Add-On Instruction I/O Data (raC_Dvc_46DFA_5032).	505
InOut Data.	505
Input Data.	505
Output Data.	507
Programming Example.	509
Graphic Symbols.	510
FactoryTalk View ME/SE Graphic Symbols.	510
Studio 5000 View Designer Graphic Symbols.	511
Faceplates.	511
Home.	511
Health Tab.	513
Trend Tab.	513
Configure Tab.	514
Application Code Manager.	520
Definition Objects: raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL, raC_Dvc_46DFA_5032.	520
Implementation Objects: raC_LD_Dvc_46DFA_4IOL, raC_LD_Dvc_46DFA_8IOL.	521
Implementation Objects: raC_LD_Dvc_46DFA_5032.	521
Linked Libraries.	522

Configured HMI Content	522
Attachments	522

Chapter 22

45PLA - Polarized Light Array Photoelectric Sensor (raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL, raC_Dvc_45PLA_5032)

Overview	525
Functional Description	525
Required Files	526
Controller Files	526
FactoryTalk View HMI Files	526
Studio 5000 View Designer HMI Files	527
Studio 5000 Application Code Manager Files	527
Device Definition (raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL)	527
Device Definition (raC_Dvc_45PLA_5032)	528
Operations	530
Execution	530
Add-On Instruction I/O Data (raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL)	531
InOut Data	531
Input Data	531
Output Data	533
Add-On Instruction I/O Data (raC_Dvc_45PLA_5032)	535
InOut Data	535
Input Data	535
Output Data	537
Programming Example	539
Graphic Symbols	540
FactoryTalk View ME/SE Graphic Symbols	540
Studio 5000 View Designer Graphic Symbols	541
Faceplates	541
Home	541
.....	542
Health Tab	542
Trend Tab	544
Configure Tab	544
Fault Warning Tab	549
Application Code Manager	550
Definition Objects: raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL, raC_Dvc_45PLA_5032	550
Implementation Objects: raC_LD_Dvc_45PLA_4IOL, raC_LD_Dvc_45PLA_8IOL	551
Implementation Objects: raC_LD_Dvc_45PLA_5032	551
Linked Libraries	552
Configured HMI Content	552
Attachments	552

Chapter 20

IO-Link HUB

Overview	555
Required Files	555

FactoryTalk View HMI Files	555
Studio 5000 View Designer HMI Files	556
Graphic Symbols	556
FactoryTalk View ME/SE Graphic Symbols	556
Configuring FactoryTalk View Objects	557
Studio 5000 View Designer Graphic Symbols	558
Faceplates	560
1732IL_IB16M12	560
1732IL_10X6M12	561
1732IL-16CFGM12M12L	562

Chapter 21

IO-Link Master (raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster, raC_Dvc_5032_8IOLMaster)

Overview	565
Functional Description	565
Required Files	565
Controller Files	566
FactoryTalk View HMI Files	566
Studio 5000 View Designer HMI Files	567
Studio 5000 Application Code Manager Files	567
Device Definition (raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster)	567
Device Definition (raC_Dvc_5032_8IOLMaster)	568
Operations	570
Execution	570
Add-On Instruction I/O Data (raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster)	571
InOut Data	571
Output Data	571
Programming Example	572
Graphic Symbols	572
FactoryTalk View ME/SE Graphic Symbols	573
Studio 5000 View Designer Graphic Symbols	574
Faceplates (raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster) ..	574
Home	575
Located	576
Fault Warning Tab	577
Faceplates (raC_Dvc_5032_8IOLMaster)	577
Home	578
Locate	580
Fault Warning Tab	583
Application Code Manager	585
Definition Objects: raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster	585
Implementation Objects: raC_LD_Dvc_1734_4IOLMaster, raC_LD_Dvc_1732E_8IOLMaster	586
Implementation Objects: raC_LD_Dvc_5032_8IOLMaster	587
Linked Libraries	587
Configured HMI Content	588

Attachments 588

Device Object Libraries Overview

Our Device Object Libraries enable you to easily interface with Rockwell Automation intelligent devices like drives, motion, network switches, sensors, IO and more. The libraries contain tested, documented, and lifecycle-managed objects which can be used with machine builder, process, and packaged libraries or as standalone components. Device objects include HMI faceplates for FactoryTalk View ME/SE and Studio 5000 View Designer® software and provide a user interface that seamlessly integrates with the products.

HMI faceplates are standard display files that provide a common user interface. These are HMI pop-up screens used to display detailed information related to a specific instruction or device. In systems that follow ISA 101.1 design guidelines, faceplates are often referred to as Level 4 displays.

Pre-configured Device Objects include an Add-On Instruction Rung and an HMI Faceplate providing the following benefits:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Detailed Device Data Collection and Delivery
- Enhanced Device Status and Diagnostics
- Common Control Interfaces maximizing Flexible Automation Device Selection & Application Code Reuse

Device Object Use Cases:

- Basic Device Maintenance and Diagnostics
- Virtual Device Operations for Startup and Commissioning
- Operator and Program Control for Velocity Machine and Process Applications



Device Object Libraries may be downloaded from the [Product Compatibility and Download Center](#). Search for "Library".

Application Code Manager

Studio 5000 Application Code Manager is a tool that can be used with Device Object Libraries to streamline project and machine development. This bulk coding tool allows you to easily design and standardize functionality with reusable application code.

Enable more efficient project development with reusable libraries of code:

- Quickly create and deploy projects through our Application Content Libraries
- Import Rockwell provided application content libraries to expedite system development
- Build your own reusable code that can be managed and deployed across your entire enterprise

- Easily configure objects in bulk with reusable code to increase application development, no additional programming is necessary
- Consolidate content for Studio 5000 Logix Designer, FactoryTalk View Studio, FactoryTalk Alarms & Events, FactoryTalk Historian to configure an object a single time and generate content for each of those software packages.

See the section on [Using the Library with Application Code Manager](#) for more details.

Other Application Code Libraries

This Device Object Library may be used in harmony with other Application Code Libraries including other Device Object Libraries (Network, IO, Power, Safety Device Libraries) or Application Libraries (PlantPax Process Objects library, Machine Builder Libraries). All libraries are intended to follow similar design philosophies to provide a consistent experience for operators and maintenance staff.

A complete list of Application Code Libraries from Rockwell Automation follows.

Item	Description
PlantPax Process Library	Rockwell Automation Library of Process Objects provides application templates, Endress + Hauser library objects, Application Code Manager library objects, and tools and utilities for PlantPax DCS applications. Includes the following: <ul style="list-style-type: none"> • Graphics for built-in instructions • HMI images and Help files • Logix diagnostic objects • Process objects • Control strategies • Sequencer objects • PlantPax Configuration Tools for Tags, Alarms and Historian • Color Change • Historian -- Asset Framework template and objects
Machine Builder Libraries	Tested, documented and life-cycle managed library objects and faceplates for use with Studio 5000® Application Code Manager for use primarily with OEM and discrete machine applications.
Common Application Libraries	Commonly used application library objects and faceplates for use with Studio 5000® Application Code Manager including basic functions like unit conversion and data collection.
Independent Cart Technology Libraries	ICT Libraries for iTRAK and MagneMotion including MagneMover LITE and QuickStick for Studio 5000® Application Code Manager
I/O Device Library	Provides objects for Rockwell Automation 1756, 1769, 1734, 1794, 1738, 1732E, 1719, 5069, 5094 I/O modules including pre-configured status and diagnostic faceplates
IO-Link Device Library	Provides IO-Link master and sensor objects including pre-configured status and diagnostic faceplates
Network Device Library	Provides objects for Stratix® switch and Device Level Ring network objects
Power Device Library	Provides objects for discrete, velocity, motion, and power monitor devices
Safety Device Library	Provides safety objects to interface with safety I/O
Condition Monitoring Device Library	Provides Dynamix™ -1444 module and machinery Condition Monitoring applications such as motors and pumps. This includes FactoryTalk View® SE HMI faceplates and Studio 5000® Application Code Manager implementations.
Electrical Protection Device Library	Provides a standard to represent protection devices within your electrical distribution system

Libraries can be accessed from the [Product Compatibility and Download Center](#).

Software and Firmware Upgrades

When you update software or firmware revisions, we recommend that you verify the impact on performance and memory utilization before implementing the upgrade on the production system. For FactoryTalk® View or ControlLogix® platforms, we recommend that you review the release notes and verify the impact of the upgrade on performance and memory utilization.

You can also verify the compatibility of the upgrade with the installed software and operating systems in use on your system. See the [Product Compatibility and Download Center](#).

Rockwell Automation® Services and Support

System Support offers technical assistance that is tailored for control systems. Some of the features include the following:

- Highly experienced team of engineers with training and systems experience
- Use of online remote diagnostic tools
- Access to otherwise restricted TechConnectSM Knowledgebase content
- 24-hour, 7 days per week, 365 days per year of phone-support coverage upgrade option

For more information, contact your local distributor or Rockwell Automation representative or see <http://www.rockwellautomation.com/support>.

You can view or download publications at <http://www.rockwellautomation.com/literature>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Rockwell Automation® IO-Link Device Library

The IO-Link Device Library is a tested, documented, and life cycle managed object library. The Device Library provides pre-configured status and diagnostic faceplates and AOI sets for Rockwell Automation® IO-Link Master & Sensors devices. The IO-Link Device Objects may be used with Machine Builder, Process, and Packaged Libraries or as standalone components. IO-Link Device Library add-on instructions objects collect, process, and deliver data between hardware devices and application logic.

The IO-Link Device Library includes Add-On Instructions (AOIs) and HMI Faceplates for Allen-Bradley IO-Link Sensor and Master products.

This document includes the functional requirements of the IO-Link Sensor and IO-Link Master device objects.



The IO-Link Device Library may be downloaded from the [Product Compatibility and Download Center](#). Search for IO-Link Device Library.

Compatibility

Compatible Software

- Studio 5000® Logix Designer v30.02.00, v31.02.00, v32.02.01, v33.00.00, v34.01.00, v35.00.00, v36.00.00 for PAC Application Development
- Studio 5000® Application Code Manager v4.0 and later for bulk code configuration
- Studio 5000 View Designer® v8.00 and later for PanelView 5000 Application Development
- FactoryTalk® View Studio v10.00.01 and later for PanelView Plus Application Development and FactoryTalk® View SE Application Development

Compatible Hardware

- PanelView 5500 with v8 or later firmware
- PanelView Plus with v10 or later firmware
- ControlLogix 5580 or ControlLogix 5570 controller with v30.011 or later firmware
- 1732E-8IOLM12R ArmorBlock 8-Channel IO-Link Master Module with v3.012 or later firmware
- 1734-4IOL/K POINT I/O 4-Channel IO-Link Master Module with v1.011 or later firmware

- 5032-8IOLM12DR 8 IO Link Channel, 8 Configurable Channel, 4 Pin Power, M12 Master Module with 2.011 or later firmware.
- 5032-8IOLM12M12LDR 8 IO Link Channel, 8 Configurable Channel, M12L Power, M12 Master Module with 2.011 or later firmware
- 5032-8IOLM12P5DR 8 IO Link Channel, 8 Configurable Channel, 5Pin Power, M12 Master Module with 2.011 or later firmware.
- 1694 Modular Electronic Circuit Protector
- 42AF Long Range General Purpose Sensor
- 42EF RightSight General Purpose Sensor
- 42JT Visi Sight Sensor
- 45CRM Color Registration Mark Sensor
- 45DMS Distance Measurement Sensor
- 46CLR ColorSight True Color Sensor
- 836P Solid-State Pressure Sensor
- 837T Solid-State Temperature Sensor
- 856T Control Tower Stack Light
- 871C Mini Tubular Sensor
- 871FM Mini Flat Pack Sensor
- 871TM Tubular Stainless Steel Sensor
- 873P Analog Output Ultrasonic Sensor
- 875L Capacitive Sensor
- 46DFA Small Aperture Fiber-Optic Amplifier
- 45PLA Polarized Light Array Photoelectric Sensor

Summary of Changes

This publication contains the following new or updated information. This list includes substantive updates only and is not intended to reflect all changes.

Topic	Page
Added 5032 IO-Link Master support	all

Footprint

Each instruction requires memory footprint within the Logix controller. The following characteristics apply:

- **Definition:** Estimated memory required to store the object definition, including all dependents
- **Instance:** Estimated memory required per object instantiated.
- **Execution (L85E):** Estimated execution time / scan footprint evaluated in 1756-L85E PAC

Device Object Footprint

Device Object	Definition (kB)	Instance (kB)	Execution (µs)
raC_Dvc_1734_4IOLMaster	28.14	4.552	52
raC_Dvc_1732E_8IOLMaster	29.5	9.648	61
raC_Dvc_5032_8IOLMaster	33.088	10.388	30
raC_Dvc_42AF_4IOL	77.612	7.76	58
raC_Dvc_42AF_8IOL	81.628	7.848	69
raC_Dvc_42AF_Type1_5032	70.86	8.88	55
raC_Dvc_42AF_Type2_5032	71.508	8.88	57
raC_Dvc_42AF_Type3_5032	65.384	8.864	56
raC_Dvc_42EF_4IOL	66.328	7.264	96

Device Object Footprint

Device Object	Definition (kB)	Instance (kB)	Execution (µs)
raC_Dvc_42EF_8IOL	68.808	7.352	96
raC_Dvc_42EF_Type1_5032	60.364	7.568	56
raC_Dvc_42EF_Type2_5032	60.404	7.568	58
raC_Dvc_42EF_Type3_5032	60.484	7.576	59
raC_Dvc_42JT_4IOL	66.612	8.156	94
raC_Dvc_42JT_8IOL	68.912	8.244	97
raC_Dvc_42JT_Type1_5032	61.012	9.376	50
raC_Dvc_42JT_Type2_5032	58.628	7.712	49
raC_Dvc_42JT_Type3_5032	61.136	7.72	52
raC_Dvc_45CRM_4IOL	67.784	7.368	86
raC_Dvc_45CRM_8IOL	69.576	7.444	92
raC_Dvc_45CRM_5032	64.84	7	45
raC_Dvc_45DMS_4IOL	113.684	11.168	81
raC_Dvc_45DMS_8IOL	115.652	11.256	88
raC_Dvc_45DMS_Type1_5032	100.88	10.576	63
raC_Dvc_45DMS_Type2_5032	100.964	14.688	65
raC_Dvc_46CLR_4IOL	173.884	15.42	112
raC_Dvc_46CLR_8IOL	185.268	17.42	118
raC_Dvc_46CLR_5032	140.42	9.088	100
raC_Dvc_836P_4IOL	127.376	10.512	110
raC_Dvc_836P_8IOL	132.376	10.6	132
raC_Dvc_836P_Type1_5032	103.332	9.936	70
raC_Dvc_836P_Type2_5032	110.64	9.968	75
raC_Dvc_837T_4IOL	107.56	9.52	104
raC_Dvc_837T_8IOL	113.472	9.608	120
raC_Dvc_837T_Type1_5032	82.148	8.952	55
raC_Dvc_837T_Type2_5032	89.956	8.984	58
raC_Dvc_856T_4IOL	172.500	19.552	92
raC_Dvc_856T_8IOL	174.476	20.532	98
raC_Dvc_856T_5032	179.052	16.888	90
raC_Dvc_871C_4IOL	54.412	5.92	85
raC_Dvc_871C_8IOL	55.532	7.048	82
raC_Dvc_871C_5032	47.1	6.376	65
raC_Dvc_871FM_4IOL	56.4	6.696	84
raC_Dvc_871FM_8IOL	59.808	6.784	92
raC_Dvc_871FM_Type1_5032	53.7	7.008	40
raC_Dvc_871FM_Type2_5032	53.7	7.008	40
raC_Dvc_871TM_4IOL	57.26	7.688	79
raC_Dvc_871TM_8IOL	59.136	7.756	84
raC_Dvc_871TM_5032	44.9	4.988	35
raC_Dvc_873P_4IOL	109.148	9.084	97
raC_Dvc_873P_8IOL	112.428	9.26	105
raC_Dvc_873P_Type1_5032	94.092	10.216	60
raC_Dvc_873P_Type2_5032	91.268	10.208	64
raC_Dvc_1694_4IOL	104.256	9.172	95
raC_Dvc_1694_8IOL	106.684	9.26	98
raC_Dvc_1694_5032	114.508	10.26	70
raC_Dvc_875L_4IOL	149.48	23.496	74
raC_Dvc_875L_8IOL	151.832	23.672	88
raC_Dvc_875L_5032	154.1	18.52	90
raC_Dvc_46DFA_4IOL	93.828	17.944	21

Device Object Footprint

Device Object	Definition (kB)	Instance (kB)	Execution (µs)
raC_Dvc_46DFA_8IOL	97.56	19.216	49
raC_Dvc_46DFA_5032	99.492	11.984	60
raC_Dvc_45PLA_4IOL	96.66	16.512	45
raC_Dvc_45PLA_8IOL	101.08	16.6	121
raC_Dvc_45PLA_5032	102.08	10	70

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation®.

Resource	Description
Rockwell Automation® Library of Process Objects Reference Manual PROCES-RM200	Describes the Add-On Instructions, PlantPAx instructions, and associated faceplates that are available to develop applications.
1732E 8IOL IO-Link Master Module User Manual 1732E-UM007B	Provides installation instructions, wiring diagrams, configuration, and specifications.
1734 4IOL IO-Link Master User Manual 1734-UM020B	Provides installation instructions, wiring diagrams, configuration, and specifications.
5032 8IOL IO-Link Master Module User Manual 5032-UM001B	Provides installation instructions, wiring diagrams, configuration, and specifications.
42AF RightSight Photoelectric Sensors User Manual 42AF-UM001A	Provides installation instructions, wiring diagrams, configuration, and specifications.
42EF RightSight Photoelectric Sensors User Manual 42EF-UM001A	Provides installation instructions, wiring diagrams, configuration, and specifications.
42JT VisiSight Photoelectric Sensors User Manual 42JT-UM001B	Provides installation instructions, wiring diagrams, configuration, and specifications.
45CRM Color Registration Mark Sensors Quick Reference 45CRM-QR001A	Provides quick reference information about feature, IO-Link parameter definition, Teach Procedure.
46CLR ColorSight IO-Link Quick Reference 46CLR-QR001C	Provides quick reference information about feature, IO-Link parameter definition, Teach Procedure.
836P Solid-state Pressure Switches User Manual 836P-UM001A	Provides installation instructions, wiring diagrams, configuration, and specifications.
837T Solid-state Temperature User Manual 837T-UM001A	Provides installation instructions, wiring diagrams, configuration, and specifications.
856T Control Tower IO-Link Class B Light and Sound Module Controller User Manual 856T-UM001C	Provides installation instructions, wiring diagrams, configuration, and specifications.
871C Miniature Inductive Sensors User Manual 871C-UM001A	Provides installation instructions, wiring diagrams, configuration, and specifications.
871FM Miniature Metal Flat Pack Inductive Sensors User Manual 871FM-UM002A	Provides installation instructions, wiring diagrams, configuration, and specifications.
871TM Long-range Inductive Sensors User Manual 871TM-UM002D	Provides installation instructions, wiring diagrams, configuration, and specifications.
873P Ultrasonic Sensors User Manual 873P-UM001B	Provides installation instructions, wiring diagrams, configuration, and specifications.
1694 Electronic Circuit Protection Module Installation Instructions 1694-IN001	Provides installation instructions, wiring diagrams, configuration, and specifications.
1732IL ArmorBlock 16-Channel IO-Link Hub User Manual 1732IL-UM001D	Provides installation instructions, wiring diagrams, configuration, and specifications.
875L Capacitive Sensors User Manual 875-UM001B	Provides installation instructions, wiring diagrams, configuration, and specifications.
46DFA Small Aperture Fiber Optic Amplifier 46DFA-QR001A	Provides installation instructions, wiring diagrams, configuration, and specifications.
45PLA Polarized Light Array Sensors 45PLA-QR001A	Provides installation instructions, wiring diagrams, configuration, and specifications.
Application Code Manager User Manual LOGIX-UM003	Studio 5000® Application Code Manager user manual.

Library Components

The IO-Link Device Library is a tested, documented, and life cycle managed object library. The Device Library provides pre-configured status and diagnostic faceplates and AOI sets for Allen-Bradley IO-Link Sensors and IO-Link Master Modules. The IO-Link Device Objects may be used with Machine Builder, Process, and Packaged Libraries or as standalone components. IO-Link Device Library add-on instructions objects collect, process, and deliver data between hardware devices and application logic.

IO-Link Device Instructions

The IO-Link Device Library includes instructions to interface with IO-Link Sensors and IO-Link Master Modules. Each sensor instruction is provided with variations for use with each master module. For example the 42AF Sensor has instructions [raC_Dvc_42AF_4IOL](#) for use with the 1734-4IOL POINT I/O 4-Channel IO-Link Master Module, [raC_Dvc_42AF_8IOL](#) for use with the 1732E-8IOLM12R ArmorBlock 8-Channel IO-Link Master Module and [raC_Dvc_42AF_Type1_5032](#) for use with the 5032-8IOLM12M12LDR/A, 5032-8IOLM12DR, 5032-8IOLM12P5DR 8-Channel IO-Link Master Module. The master module instructions and faceplates are optional for module diagnostics and device summary but can be used independently from the sensor instructions and faceplates.

The instructions included are as follows:

IO-Link Master Modules:

- [1732E-8IOLM12R ArmorBlock 8-Channel IO-Link Master Module](#)
- [1734-4IOL/K POINT I/O 4-Channel IO-Link Master Module](#)
- [5032-8IOLM12DR 8-Channel IO-Link Master Module](#)
- [5032-8IOLM12M12LDR 8-Channel IO-Link Master Module](#)
- [5032-8IOLM12P5DR 8-Channel IO-Link Master Module](#)

IO-Link Sensors:

- [42AF](#) Long Range General Purpose Sensor
- [42EF](#) RightSight General Purpose Sensor
- [42JT](#) Visi Sight Sensor
- [45CRM](#) Color Registration Mark Sensor
- [46CLR](#) ColorSight True Color Sensor
- [871C](#) Mini Tubular Sensor
- [871FM](#) Mini Flat Pack Sensor
- [871TM](#) Tubular Stainless Steel Sensor
- [1694](#) Modular Electronic Circuit Protector
- [45DMS](#) Distance Measurement Sensor

- [836P](#) Solid-State Pressure Sensor
- [837T](#) Solid-State Temperature Sensor
- [856T](#) Control Tower Stack Light
- [873P](#) Analog Output Ultrasonic Sensor
- [875L](#) Capacitive Sensor
- [46DFA](#) Small Aperture Fiber-Optic Amplifier Sensor
- [45PLA](#) Polarized Light Array Photoelectric Sensor

There is one type of instruction in this library:

- Device (Dvc): instruction used for devices (e.g. 42AF Sensor).

IO-Link Device Instructions

Instruction	Compatible Master	Version	Category	Instruction Description
raC_Dvc_1734_4IOLMaster	POINT I/O 1734-4IOL	3.02	IO-Link Master	POINT I/O 1734-4IOL 4-Channel IO-Link Master Module
raC_Dvc_1732E_8IOLMaster	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Master	ArmorBlock 1732E-8IOLM12R 8-Channel IO-Link Master Module
raC_Dvc_5032_8IOLMaster	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	3.02	IO-Link Master	5032 8-Channel IO-Link Master Module
raC_Dvc_42AF_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	42AF Long Range General Purpose Sensor
raC_Dvc_42AF_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	42AF Long Range General Purpose Sensor
raC_Dvc_42AF_Type1_5032	5032-8IOLM12DR Or	3.02	IO-Link Sensor	42AF Long Range General Purpose Sensor
raC_Dvc_42AF_Type2_5032	5032-8IOLM12M12LDR/A Or	3.02	IO-Link Sensor	42AF Long Range General Purpose Sensor
raC_Dvc_42AF_Type3_5032	5032-8IOLM12P5DR	3.02	IO-Link Sensor	42AF Long Range General Purpose Sensor
raC_Dvc_42EF_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	42EF RightSight General Purpose Sensor
raC_Dvc_42EF_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	42EF RightSight General Purpose Sensor
raC_Dvc_42EF_Type1_5032	5032-8IOLM12DR Or	3.02	IO-Link Sensor	42EF RightSight General Purpose Sensor
raC_Dvc_42EF_Type2_5032	5032-8IOLM12M12LDR/A Or	3.02	IO-Link Sensor	42EF RightSight General Purpose Sensor
raC_Dvc_42EF_Type3_5032	5032-8IOLM12P5DR	3.02	IO-Link Sensor	42EF RightSight General Purpose Sensor
raC_Dvc_42JT_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	42JT Visi Sight Sensor
raC_Dvc_42JT_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	42JT Visi Sight Sensor
raC_Dvc_42JT_Type1_5032	5032-8IOLM12DR Or	3.02	IO-Link Sensor	42JT Visi Sight Sensor
raC_Dvc_42JT_Type2_5032	5032-8IOLM12M12LDR/A Or	3.02	IO-Link Sensor	42JT Visi Sight Sensor
raC_Dvc_42JT_Type3_5032	5032-8IOLM12P5DR	3.02	IO-Link Sensor	42JT Visi Sight Sensor
raC_Dvc_45CRM_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	45C CRM Color Registration Mark Sensor
raC_Dvc_45CRM_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	45CRM Color Registration Mark Sensor
raC_Dvc_45CRM_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	45CRM Color Registration Mark Sensor
raC_Dvc_45DMS_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	45DMS Distance Measurement Sensor
raC_Dvc_45DMS_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	45DMS Distance Measurement Sensor
raC_Dvc_45DMS_Type1_5032	5032-8IOLM12DR Or	3.02	IO-Link Sensor	45DMS Distance Measurement Sensor
raC_Dvc_45DMS_Type2_5032	5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	45DMS Distance Measurement Sensor
raC_Dvc_46CLR_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	46CLR ColorSight True Color Sensor
raC_Dvc_46CLR_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	46CLR ColorSight True Color Sensor
raC_Dvc_46CLR_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	46CLR ColorSight True Color Sensor
raC_Dvc_836P_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	836P Solid-state pressure sensors
raC_Dvc_836P_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	836P Solid-state pressure sensors 755
raC_Dvc_836P_Type1_5032	5032-8IOLM12DR Or	3.02	IO-Link Sensor	836P Solid-state pressure sensors 755
raC_Dvc_836P_Type2_5032	5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	836P Solid-state pressure sensors 755
raC_Dvc_837T_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	827T Solid-state temperature sensors

IO-Link Device Instructions

Instruction	Compatible Master	Version	Category	Instruction Description
raC_Dvc_837T_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	837T Solid-state temperature sensors
raC_Dvc_837T_Type1_5032	5032-8IOLM12DR Or	3.02	IO-Link Sensor	837T Solid-state temperature sensors
raC_Dvc_837T_Type2_5032	5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	837T Solid-state temperature sensors
raC_Dvc_856T_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	856T Control Tower Stack Light
raC_Dvc_856T_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	856T Control Tower Stack Light
raC_Dvc_856T_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	856T Control Tower Stack Light
raC_Dvc_871C_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	871C Mini Tubular Sensor
raC_Dvc_871C_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	871C Mini Tubular Sensor
raC_Dvc_871C_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	871C Mini Tubular Sensor
raC_Dvc_871FM_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	871FM Mini Flat Pack Sensor
raC_Dvc_871FM_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	871FM Mini Flat Pack Sensor
raC_Dvc_871FM_Type1_5032	5032-8IOLM12DR Or	3.02	IO-Link Sensor	871FM Mini Flat Pack Sensor
raC_Dvc_871FM_Type2_5032	5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	871FM Mini Flat Pack Sensor
raC_Dvc_871TM_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	871TM Tubular Stainless Steel Sensor
raC_Dvc_871TM_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	871TM Tubular Stainless Steel Sensor
raC_Dvc_871TM_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	871TM Tubular Stainless Steel Sensor
raC_Dvc_873P_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	873P Analog Output Ultrasonic Sensors
raC_Dvc_873P_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	873P Analog Output Ultrasonic Sensors
raC_Dvc_873P_Type1_5032	5032-8IOLM12DR Or	3.02	IO-Link Sensor	873P Analog Output Ultrasonic Sensors
raC_Dvc_873P_Type2_5032	5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	873P Analog Output Ultrasonic Sensors
raC_Dvc_1694_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link ECP	1694 Modular Electronic Circuit Protectors
raC_Dvc_1694_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link ECP	1694 Modular Electronic Circuit Protectors
raC_Dvc_1694_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link ECP	1694 Modular Electronic Circuit Protectors
raC_Dvc_875L_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	875L Capacitive Sensors
raC_Dvc_875L_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	875L Capacitive Sensors
raC_Dvc_875L_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	875L Capacitive Sensors
raC_Dvc_46DFA_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	46DFA Small Aperture Fiber Optic Amplifier Sensors
raC_Dvc_46DFA_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	46DFA Small Aperture Fiber Optic Amplifier Sensors
raC_Dvc_46DFA_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	46DFA Small Aperture Fiber Optic Amplifier Sensors
raC_Dvc_45PLA_4IOL	POINT I/O 1734-4IOL	3.02	IO-Link Sensor	45PLA Polarized Light Array Sensors
raC_Dvc_45PLA_8IOL	ArmorBlock 1732E-8IOLM12R	3.02	IO-Link Sensor	45PLA Polarized Light Array Sensors
raC_Dvc_45PLA_5032	5032-8IOLM12DR Or 5032-8IOLM12M12LDR/A Or 5032-8IOLM12P5DR	3.02	IO-Link Sensor	45PLA Polarized Light Array Sensors

Library Folders and Files

When you extract the library from the downloaded .zip folder, you will find the following folder and file structure. Note that some items are generalized with *TYPE* (e.g. Dvc, Opr, Tec) and *OBJECT* (e.g. 45DMS, 46CLR, etc). The major and minor versions are represented by X and Y respectively.

Level 1	Level 2	Level 3	File Type	Description
Application Example				
		IOLinkApplication_ACM_v3_02.xlsx	XLXS	ApplicationCodeManagerProject
		IOLinkApplication_v3_02.ACD	ACD	Logix Designer Example Project
		IOLinkApplication_ME_v3_02.apa	APA	FT View ME Project Archive
		IOLinkApplication_SE_v3_02.apa	APA	FT View SE Project Archive
	IOLinkApplication_VD_3_02.vpd	VPD	View Designer Project File	
ApplicationCodeManagerLibraries			Folder	Application Code Manager files
		Attachments (.HZ1 and .txt files)	Folder	ACM Object Attachments
		(RA-LIB)_Device_Asset-Control_GROUP_raC_Dvc_OBJECT_(X.Y).HSL4	HSL4	ACM Asset-Control Object
		(RA-LIB)_Device_Device_GROUP_raC_Dvc_OBJECT_(X.Y).HSL4	HSL4	ACM Device Object
HMI - FactoryTalk View ME			Folder	FactoryTalk View ME files
	Displays - gfx		Folder	FT View ME display files
		(raC-X_YY-ME) raC_TYPE_OBJECT-faceplate.gfx	GFX	Object Faceplate display
	Global Objects - ggfx		Folder	FT View ME Global Object files
		(raC-X-ME) Graphic Symbols - LIBRARY.ggfx	GGFX	Graphic Symbol/Launch Button global objects
(raC-X-ME) Toolbox - LIBRARY.ggfx		GGFX	Toolbox global objects	
HMI - FactoryTalk View SE			Folder	FactoryTalk View SE files
	Displays - gfx		Folder	FT View SE display files
		(raC-X_YY-SE) raC_TYPE_OBJECT-faceplate.gfx	GFX	Object Faceplate display
	Global Objects - ggfx		Folder	FT View SE Global Object files
		(raC-X-SE) Graphic Symbols - LIBRARY.ggfx	GGFX	Graphic Symbol/Launch Button global objects
(raC-X-SE) Toolbox - LIBRARY.ggfx		GGFX	Toolbox global objects	
HMI - ViewDesigner - vpd			Folder	View Designer Files
		(raC-X_YY-VD) raC_Dvc_IO-Link.vpd	VPD	Object faceplate and graphic symbol/launch buttons
		raC_Dvc_1732IL_Hubs.vpd	VPD	Object faceplate and graphic symbol/launch buttons
HMI FactoryTalk View Images - png			Folder	FT View ME/SE image files
		images.png	PNG	FTView ME/SE images
Reference Manuals			Folder	Manuals
		DEVICE-RM300C-EN-P.pdf	PDF	Reference manual
Studio 5000 Logix Designer Files - L5X			Folder	Studio 5000 AOI and RUNG import files
		raC_TYPE_OBJECT_X.YY_RUNG.L5X	L5X	Object rung import
		raC_TYPE_OBJECT_X.YY_AOI.L5X	L5X	Object AOI import
Videos			Folder	How-to and Operational Overview Videos
		How_To_Import_and_Configure_TYPE_Objects_in_FTViewME.mp4	MP4	How-to Video
		How_To_Import_and_Configure_TYPE_Objects_in_LogixDesigner.mp4	MP4	How-to Video
		How_To_Import_and_Configure_TYPE_Objects_in_LogixDesigner (5032 Master).mp4	MP4	How-to Video
		How_To_Configure_TYPE_Objects_in_ViewDesigner.mp4	MP4	How-to Video
		How_To_Import_and_Configure_TYPE_Objects_in_ACM.mp4	MP4	How-to Video
		How_To_Import_and_Configure_TYPE_Objects_in_ACM (5032 Master).mp4	MP4	How-to Video
		Operational_Overview_of_TYPE_Objects_Faceplate.mp4	MP4	Operational Overview video
		Operational_Overview_of_TYPE_Objects_Faceplate (5032 Master).mp4	MP4	Operational Overview video

FTViewStudio_IOLinkLibrary_Tags_3_00.CSV	CSV	FTView ME HMI Tags
ReadMe.txt	TXT	Explanation of setup.cmd
Setup.cmd	CMD	Application Code Manager setup script to register library



See the files in the *Application Example* folder to see a functional application that uses all of the IO-Link Device Library instructions. These files are referenced in the Programming Examples for each instruction. The files include a Studio 5000 Logix Designer® controller file, a Studio 5000® Application Code Manager project back-up, and an HMI projects for FactoryTalk® View ME/SE Local Station and Studio 5000 View Designer®.

Visualization Files

Each Add-On Instruction has associated visualization files that provide a common user interface. The IO-Link Device Library supports two HMI options each with their own files supplied:

- FactoryTalk® View Machine Edition
- FactoryTalk® View Site Edition
- Studio 5000 View Designer®

FactoryTalk View Visualization Files

You must import these files in the following order:

- Images (.png files)
- Global Objects(.ggfx file type)
- HMI faceplates (.gfx file type)

File Type Abbreviations	FactoryTalk View SE	FactoryTalk View ME	Description
Images (.png)	All .png files in the <i>HMI FactoryTalk View Images - png</i> folder. IMPORTANT: FactoryTalk View application renames PNG files when they are imported with a .bmp file extension, but the files retain a .png format.		Common icons that are used in the Global Objects and standard displays for all objects.
Global objects (.ggfx)	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	Graphic symbols or launch buttons used to open faceplate displays from other displays.
	(raC-3-SE) Toolbox - IO-Link Device.ggfx	(raC-3-ME) Toolbox - IO-Link Device.ggfx	Common objects used across multiple device faceplates.
Standard displays (.gfx)	(raC-3_XX-SE) precedes name of the display.	(raC-3_XX-ME) precedes name of the display.	e.g. (raC-3_02-ME) raC_Dvc_45DMS-Faceplate.gfx

Global object files contain Graphic Symbols that are created once and referenced multiple times on multiple displays in an application. When changes are made to a global object, all instances in the application are automatically updated.

Global objects serve two purposes:

- Toolbox files contain common elements that are used to build faceplate displays.
- Graphic Symbols files contain device symbols or launch buttons that you can use to build your application displays. Select the symbol to open the corresponding faceplate display.

Standard display files, commonly called faceplates, provide a common user interface.

Studio 5000 View Designer Visualization Files

View Designer project files are supplied that contain faceplates and launch buttons for the IO-Link Device Library. The devices are distributed over multiple View Designer Project files grouped by category for PowerDiscrete, PowerVelocity, PowerMotion, and PowerMonitor devices. These files are found in the *HMI - ViewDesigner - vpd* folder. Inside of the VPD file you will find a the required display files inside of the *User-Defined Screens* folder.

Display Type	View Designer Screen	Description
Screen	Toolbox	Graphic symbols or launch buttons used to open faceplate/pop-up displays from other displays.
Pop-Up	raC_Dvc_ precedes name of the pop-up.	Faceplate display for specific device. e.g. raC_Dvc_45DMS_FP


Basic Faceplate Attributes

Faceplates consist of tabs, and each tab consists of one or more pages. The Home tab is displayed when the faceplate is initially opened. The faceplate provides the means for operators, maintenance personnel, engineers, and others to interact with a device or instruction instance, which includes a view of its status and values. Faceplates may also manipulate an instruction through its commands and settings. Select the appropriate icon on the left of the faceplate to access a specific tab. This section provides an overview of the faceplate attributes that are common across the objects. More details are supplied in the individual section for each object.

Common Status Banner

At the top of all device object faceplates there is a common status banner which provides the following information:

- Ready (green LED icon) or Not Ready (yellow LED icon) status
- Faulted (banner will show Not Ready with fault message)
- Communication Loss



Item	Description
1	Ready state displays green LED icon and grey background.
2	Faulted state shows yellow LED icon and Not Ready status.
3	Fault message for latest fault present. Will also display "Virtual" if virtual mode is enabled.
4	Faulted state shows yellow border around banner.

Faceplate Navigation

All device object faceplates have navigation tabs on the left side of the faceplate. Navigation tabs may vary based on device type. The active tab will show as a light grey, while an inactive tab will show as a dark grey.



Active Tab



Inactive Tab

The common tabs are shown below.



Home Tab



Health Tab



Trend Tab




Fault Tab




Configuration Tab

Faceplate Revision Notes

By clicking on the open space near the bottom left corner of the faceplate you can momentarily view revision notes and details of the active faceplate. This may be useful in troubleshooting or when communicating with Rockwell Automation Tech Support.



1





46CLR
Revision 2.03
(raC-2_03-ME) raC_Dvc_46CLR-Faceplate
Copyright © Rockwell Automation, Inc. All Rights Reserved

Item	Description
1	Click near the bottom right corner to temporarily open up the revision notes dialogue
2	Revision number
3	Faceplate display name






Launch Buttons


Launch buttons are provided in Global Display (GGFX) files for FactoryTalk View® ME/SE projects. There are two types of launch buttons are provided, shown in below Table. These are used to open HMI faceplate displays or pop-ups.

Launch Button Style	Image Examples	Usage
Basic Text Button		Simple launch button with diagnostic information.
Graphical Button		Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed.

Diagnostic Icons

Diagnostic icons may be displayed on the graphic buttons for compatible modules. Safety modules are designated with a small guard icon.



Icon	Image	Visible Condition
Communications Failure		Connection Faulted
Fault		Any device fault active (module hardware issue)
Warning		Any device warning active (maintenance required)
Not Ready		Device Not Ready
IO-Link Identification		Always Visible



Item	Description	Options
1	Device label. Set to tag.@Description by default. Set to Global Parameter #104 for custom label.	
Device Fault/Warning Status		
2	Warning	
	Fault	
Device communication failure/Virtual Mode status		
3	Communication Failure	
4	Device live data variable	- 42AF, 42EF, 42JT, 45PLA, 45CRM, 46CLR, 46DFA, 871C, 871FM, 871TM, 875L: Triggered/Not Triggered Status - 45DMS, 873P: Distance (mm) - 836P: Pressure (Units as per Configuration) - 837T: Temperature (Units as per Configuration) - 856T, 1694, IO-Link Master: Not Applicable
5	IO-Link Identification	
6	Device not ready status	

Library Versions


Each library object has a revision x.yy where: x is the Major Revision number and yy is the Minor Revision number. Each release of the library comes with release notes that describe the changes that were made since the last release. You can find the revision number of the object in a number of locations as shown below.

Component	Example																												
<p>The Add-On Instruction in Logix Designer application has revision information visible when the instruction is selected in the Controller Organizer.</p>	<table border="1"> <tr><td>Class</td><td>Standard</td></tr> <tr><td>Description</td><td>Photoelectric Sensor 42AF Device Object With</td></tr> <tr><td>Revision</td><td>v2.3 .00</td></tr> <tr><td>Revision Note</td><td>Updates:...</td></tr> <tr><td>Vendor</td><td>Rockwell Automation</td></tr> <tr><td>Data Type Size</td><td>2324 bytes</td></tr> <tr><td>Created</td><td>9/21/2018 12:13:47 AM</td></tr> <tr><td>Created By</td><td>Not Available</td></tr> <tr><td>Edited</td><td>6/2/2022 4:07:41 AM</td></tr> <tr><td>Edited By</td><td>Not Available</td></tr> <tr><td>Signature ID</td><td><none></td></tr> <tr><td>Protection Type</td><td>Source Key</td></tr> <tr><td>Protection Name</td><td>Unknown Protection</td></tr> <tr><td>Protection Permissions</td><td>+View, Use</td></tr> </table>	Class	Standard	Description	Photoelectric Sensor 42AF Device Object With	Revision	v2.3 .00	Revision Note	Updates:...	Vendor	Rockwell Automation	Data Type Size	2324 bytes	Created	9/21/2018 12:13:47 AM	Created By	Not Available	Edited	6/2/2022 4:07:41 AM	Edited By	Not Available	Signature ID	<none>	Protection Type	Source Key	Protection Name	Unknown Protection	Protection Permissions	+View, Use
Class	Standard																												
Description	Photoelectric Sensor 42AF Device Object With																												
Revision	v2.3 .00																												
Revision Note	Updates:...																												
Vendor	Rockwell Automation																												
Data Type Size	2324 bytes																												
Created	9/21/2018 12:13:47 AM																												
Created By	Not Available																												
Edited	6/2/2022 4:07:41 AM																												
Edited By	Not Available																												
Signature ID	<none>																												
Protection Type	Source Key																												
Protection Name	Unknown Protection																												
Protection Permissions	+View, Use																												
<p>The Add-On Instruction Definition General tab shows the revision number along with basic revision notes. Refer to the release notes for complete revision notes.</p>																													
<p>The faceplate in FactoryTalk View software has revision information visible when the pointer is clicked just inside the lower left corner of the faceplate.</p>																													
<p>The revision number is shown in the file names for GFX, VPD, ACM.HSL4, AOI.L5X, and RUNG.L5X files.</p>	<ul style="list-style-type: none"> ☐ (raC-2_03-ME) raC_Dvc_42AF-Faceplate.gfx ☐ (RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_42AF_4IOL_(2.3).HSL4 ☐ (RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_42AF_8IOL_(2.3).HSL4 ☐ (RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42AF_4IOL_(2.3).HSL4 ☐ (RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42AF_8IOL_(2.3).HSL4 ☐ raC_Dvc_42AF_4IOL_2.02_AOI.L5X ☐ raC_Dvc_42AF_4IOL_2.02_RUNG.L5X ☐ raC_Dvc_42AF_8IOL_2.02_AOI.L5X ☐ raC_Dvc_42AF_8IOL_2.02_RUNG.L5X 																												

State Model

The following section will discuss the state model for Device Object. The figure below shows the core logic states.

By default, each state is active for a minimum of 256us to allow for evaluation of state outside of the ADO instance in the user program



Interfaces

Device object interfaces are intended to provide the application programmer a class based harmonized interface for interacting with the device object from user code. Standard control interfaces are used for passing device inputs (Inp), device configuration (Cfg), Settings (Set), Commands (Cmd) and Status (Sts).

The following IO-Link Common Control Interface tags are the primary device program tags to read and write to when interfacing to IO-Link devices. The value of using these tags in your specific application code is that you may use a number of different IO-Link devices such as 42AF, 45DMS, etc without having to update your application device interface tags.

For detailed information on specific interfaces, please refer to the appropriate section in this manual. A list of interface UDTs used in this library follows. Note that *OBJECT* used in the Inp interfaces is replaced with the specific IO-Link sensor device object (e.g. 42AF).

Interface Class	Object Class	Object Sub-Class	Interface Type	Interface Name (UDT)
Control	IO-Link	IO-Link Devices	Setting	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
			Command	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
			Status	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
			Information	raC_UDT_ItfAD_IOLinkSensor_Inf
			Information	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
			Interfacing	raC_UDT_ItfAD_IOLinkDevices
		IO-Link Master	Config	raC_UDT_ItfAD_4IOL_Master_Cfg
			Config	raC_UDT_ItfAD_8IOL_Master_Cfg
			Information	raC_UDT_IOLinkMaster_5032_Diag_Assembly
		IO-Link Device	Input	raC_UDT_ItfAD_OBJECT_Inp_4IOL
			Input	raC_UDT_ItfAD_OBJECT_Inp_8IOL
			Input	raC_UDT_ItfAD_OBJECT_Inp_5032
			Config	raC_UDT_IOLink_OBJECT_Cfg

Data Types

The following IO-Link Common Control Interface tags are the primary device program tags to read and write to when interfacing to IO-Link devices. The value of using these tags in your specific application code is that you may use a number of different IO-Link devices such as 42EF, 45DMS, etc without having to update your application device interface tags.

raC_UDT_ItfAD_IOLinkSensor_CtrlSet

This is the IO-Link Sensor Common Control Interface User-Defined Data Type for device settings. Its members provide application program access to allow or inhibit commands and settings from the device faceplate or other external sources. The table below shows member names, descriptions, and tag data types.

For example, to inhibit write commands from the device faceplate or other external sources write a 1 to the `_InstanceName_CtrlSet.InhibitCmd` program tag from your application program. This would prevent a Locate, Reset count, Reset Duration commands from the device faceplate.

Member	Description	Data Type
InhibitCmd	1 = Inhibit user Commands from HMI Faceplate, 0 = Allow Control	BOOL
InhibitSet	1 = Inhibit user Settings from HMI Faceplate, 0 = Allow	BOOL
InhibitCfg	1 = Inhibit user Configuration parameters from HMI Faceplate; 0=Allow	BOOL
Setpoint	Trigger Setpoint	INT

raC_UDT_ItfAD_IOLinkSensor_CtrlCmd

This is the IO-Link Sensor Common Control Interface User-Defined Data Type for device commands. Its members provide application program access to common device commands.

Only write to these common command members to control the device. If you write directly to the device's output command tags directly unexpected device operation could occur.

The table below shows member names, descriptions, and tag data types. Note: Physical & Virtual members are not currently used in the Add-On Instruction and are reserved for future use.

Member	Description	Data Type
bCmd	Bir Overlay (Visible) covering all subsequent boolean members.	INT
ResetWarn	Reset device warning [No warning reset]	BOOL
ResetFault	Reset device trip or fault[No Fault reset,- Automatic fault reset only]	BOOL
ResetCounter	Reset counter value [1=Reset]	BOOL
Locate	Flash sensor LEDs [1=flash]	BOOL
Physical	Operate as a physical device	BOOL
Virtual	Virtual mode not implemented	BOOL

raC_UDT_ItfAD_IOLinkSensor_CtrlSts

This is the IO-Link Sensor Common Control interfacing Status tag. By configuring these tags, we can read various status from the device like Ready, Connected, and Available etc. The below table shows detailed information of members used in this UDT tags. Note: Physical & Virtual members are not currently used in the Add-On Instruction and are reserved for future use.

Input	Description	Data Type
eState	Enumerated state value: 0 = Unused 1 = Initializing 2 = Disconnected 3 = Disconnecting 4 = Connecting 5 = Idle 6 = Configuring 7 = Available	DINT
FirstWarning	First Warning Event Data	raC_UDT_Event
FirstFault	First Fault Event Data	raC_UDT_Event
eCmdFail	Not Applicable	DINT
bSts	Enumerated state value 0 = Connected 1 = Available 2 = Warning 3 = Faulted 4 = Ready 5 = Active	DINT
Connected	1 = PAC to device connection has been established	BOOL
Available	1 = The device is available for interaction with the user program	BOOL
Warning	1 = A warning is active on the device	BOOL
Faulted	1 = A fault is active on the device	BOOL
Physical	1 = Operating as a physical device	BOOL
Virtual	1 = Operating as a virtual device[Not an output device]	BOOL

Input	Description	Data Type
Counter	Displays the sensor counter value when enabled	DINT
Data	Primary sensor data value	REAL
EU	Data Engineering Unit	STR0020
Triggered	Bitwise Sensor Trigger Status	INT
Signal_Strength	0-65535 Signal strength value reflected by the target	DINT
AppSensorName	Application Specific Name	STR0032



The *Triggered* INT value is a bitwise representation of the sensors triggered status bits. The number of trigger statuses may vary depending on the sensor type up to 16 statuses. You may reference individual bits by using syntax such as *Triggered.0* to *Triggered.15* for the sensor's connected Trigger no.1 and so on up to 16 triggers respectively.

raC_UDT_ItfAD_IOLinkDevices

This is the IO-Link Device/Sensor interfacing data which provide the command and status related information to the IO-Link Master. The members inside are array of 8 elements. First element of array describe the Sensor status & command data which is connected to Channel 'o' of Master.

The below table shows detailed information of members used in this UDT tag.

Member	Description	Data Type
Ref_Ctrl_Sts	Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts[8]
Ref_Ctrl_Cmd	Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd[8]

raC_UDT_ItfAD_IOLinkSensorInf

This is the IO-Link Device/Sensor interfacing data which provide the Sensor type information to the IO-Link Master. The members inside are array of 8 elements.

The below table shows detailed information of members used in this UDT tag.

Member	Description	Data Type
bTriggerPresent	Bitwise Trigger Availability Status	INT[8]
bDataInfo	Bitwise Data Information Availability Status (0 = Data, 1 = Signal Strength, 2 = Counter, 3 = Locate, 4 = ASN)	SINT[8]
bEnable	IO-Link Sensor present on respective channel e.g. bEnable.0 = 1: IO-Link Sensor present on channel 0	DINT
Inf_Lib	Library identifier for HMI navigation	STR0032[8]
Inf_Type	Type identifier for HMI navigation	STR0032[8]

raC_UDT_ItfAD_IOLinkSensorInf_5032

This is the IO-Link Device/Sensor interfacing data which provide the Sensor type information to the 5032 IO-Link Master. The members inside are array of 7 elements.

The below table shows detailed information of members used in this UDT tag.

Member	Description	Data Type
bTriggerPresent	Bitwise Trigger Availability Status	INT[8]
bDataInfo	Bitwise Data Information Availability Status (0 = Data, 1 = Signal Strength, 2 = Counter, 3 = Locate, 4 = ASN)	SINT[8]
bEnable	IO-Link Sensor present on respective channel e.g. bEnable.0 = 1: IO-Link Sensor present on channel 0	DINT
Inf_Lib	Library identifier for HMI navigation	STR0032[8]
Inf_Type	Type identifier for HMI navigation	STR0032[8]
bDisconnect	IO-Link Sensor Connection fault Status e.g. bDisconnect.0 = 1: IO-Link Sensor not connected.	DINT
bFault	IO-Link Sensor fault present on respective channel e.g. bFault.0 = 1: IO-Link Sensor fault present on channel 0	DINT

raC_UDT_Event

Member	Description	Data Type
Type	Event type: 1 = Status 2 = Warning 3 = Fault 4...n = User	DINT
ID	User definable event ID.	DINT
Category	Userdefinablecategory(Electrical,Mechanical,Materials,Utility,etc.).	DINT
Action	User definable event action code.	DINT
Value	User definable event value or fault code.	DINT
Message	Event message text.	STRING
EventTime_L	Timestamp (Date/Time format).	LINT
EventTime_D	Timestamp (Y,M,D,h,m,s,us).	DINT[7]

raC_UDT_LookupMember_STR0082

Member	Description	Data Type
Code	Stores the value of device fault code	DINT
Desc	Stores the Messages related to fault code	STRING

raC_UDT_Dropdown

This is the IO-Link Sensor Common Control Interface User-Defined Data Type for dropdown.

The below table shows detailed information of members used in this UDT tag.

Input	Description	Data Type
Slider_Min	Slider Minimum	SINT
Slider_Max	Slider Maximum	SINT
Total_Item_Count	Total Length of Dropdown	SINT
List_Shift	Slider Value for Total Length of Dropdown	SINT
List_Select	Slider Value for Visible rows of Dropdown	SINT
Selected	Slider Value as per Total Count of Dropdown	SINT
Selected_Item	Selected Item from Dropdown	INT
Animation_Active	Dropdown List Visible	INT
Set_Up	Slider Up Command	BOOL
Set_Down	Slider Down Command	BOOL
Trigger_Tag	After Selection Trigger Bit	BOOL
List_Display	Dropdown List Item	STR0020[5]
List_Item	Enter Dropdown item names. e.g. Option0, Option1...etc	STR0020[16]

raC_UDT_HEX_Code_LookupMember

Member	Description	Data Type
Time_Base	Time Base Selection: 0.1, 0.4, 1.6 & 6.4	REAL
Multiplier	Multiplier Number: 0 to 63	SINT
Hex_Code	Hex Code	INT


Application Code Manager

Architectural Overview

Device libraries, as with most Application Code Libraries are divided into 2 logical groups: either Asset-Control Object or Device Implement Object.

Asset-Control Objects contain the asset definition of an object and any associated content which belongs to the asset. This includes controller tags, add-on instructions, data types, and attachments such as HMI content and documentation. These are found under the *(RA-LIB) Device > Asset-Control* folder and have names like *raC_Dvc_xxxx* where *xxxx* is the device name.

Device Implement Objects contain an instance of an asset-control object and provide all related configuration of the asset. The Device implement type is the application code (e.g. programming rung). This includes the required controller tags, programs, modules, and FactoryTalk View ME/SE symbols. These are found under the *(RA-LIB) Device > Device* folder and have names like *raC_LD_Dvc_xxxx* where *xxxx* is the device name. LD stands for ladder logic.



Using the Library

Install the Library

Download the Library

For the latest compatible software information and to download the Rockwell Automation Library, see the [Product Compatibility and Download Center](#).

Search “Device Library” or filter on Application Content to quickly find the library.

The screenshot displays the Rockwell Automation Device Library interface. At the top, there is a search bar containing the text "Device Library". To the right of the search bar are two dropdown menus labeled "All Categories" and "All Families", followed by a search icon. Below the search bar, there are three main sections:

- Search Results:** A list of device libraries. The "IO-Link Device Library" is highlighted in pink. The description for this library reads: "The IO-Link Device Library is a tested, documented & life-cycle managed library of Device Objects for IO-Link Master and Sensor devices. The library provides pre-configured status, diagnostic, and configuration HMI faceplates for FactoryTalk® View ME/SE or Studio 5000 View Designer® and Add-On Instructions (AOI). Use with Studio 5000® Application Code Manager. (1734-4IOL, 1732E-8IOLM12R, 1694, 42AF, 42EF, 42JT, 45CRM, 45DMS, 45PLA, 46CLR, 46DFA, 836P, 837T, 856T, 871C, 871FM, 871TM, 873P, 875L) (Accessories/Engineering Libraries)".
- Download Links:** A list of download links for various device libraries, each with a red minus sign icon and a download icon. The items are:
 - Condition Monitoring Device Library 1.01.00
 - IO Device Library 5.04.00
 - IO-Link Device Library 3.1.00
 - Mettler Toledo Device Library 1.00.00
 - Network Device Library 12.03.01
 - Power Device Library 3.05.00
 - Safety Device Library 1.04.00

Download & Install Studio 5000® Application Code Manager

Studio 5000® Application Code Manager is free to install from Rockwell Automation’s [Product Compatibility and Download Center](#).

Search “Application Code Manager” and select the item to download.

FIND DOWNLOADS ?

The screenshot shows the 'FIND DOWNLOADS' interface. On the left, a search bar contains 'Application Code Manager'. Below it, search filters are set to 'All Categories' and 'All Families'. The search results are displayed in a list with the following items:

- Independent Cart Technology Libraries**: *ICT Libraries for iTRAK and MagneMotion including MagneMover LITE, QuickStick for Application Code Manager (ACM) (Application Content/Engineering Libraries)*
- Machine Builder Libraries**: *Tested, documented and life-cycle managed library objects and faceplates for use with Studio 5000 Application Code Manager (ACM) (Application Content/Engineering Libraries)*
- Process Library**: *RA Library of Process Objects, Application Templates, Application Code Manager Library, Tools & Utilities, and Integration with Endress+Hauser Devices (pre-5.00) (Process Solutions/PlantPAx)*
- Studio 5000 Application Code Manager**: *Engineering design productivity tool focused on rapid automation application development leveraging (ACM) (Software/Software)*

At the bottom of the search results, it says '5 items found' and a 'MOVE SELECTIONS' button is visible. On the right-hand pane, the selected item 'Studio 5000 Application Code Manager 4.02.00' is shown with a download icon highlighted. Below this pane, it says '1 selection' and 'COMPARE' and 'DOWNLOADS' buttons are visible.

Extract the downloaded .zip file by running the `4.xx.00-Studio5000_ACM-DVD.exe` executable file. This will extract a new folder containing a `Setup.exe` file which can be run to begin product installation.

Follow the prompts from the splash screen until installation is complete. Note that a SQL server is required for Application Code Manager. SQL Server Express is offered for free and is included in the Application Code Manager installer.

Register Libraries in Studio 5000® Application Code Manager

It is recommended that you use Studio 5000® Application Code Manager or the Studio 5000® “Import Library Objects” Plug-In Wizard to import device library objects into a Logix 5000 controller project. To use the library in Application Code Manager you must first register the libraries.




Using Studio 5000® Application Code Manager is not mandatory although it is highly recommended to reduce the likelihood of configuration errors and simplify the workflow. Alternatively, you can import the RUNG.L5X files directly into a Studio 5000® project.



The *Lite* version of Studio 5000® Application Code Manager is free of charge and can be downloaded from the Product Compatibility and Download Centre. None of the features included in the Standard (paid) version are required to use Device Object Libraries.

Register Complete Library Automatically

To automatically register the entire library, find and run the *setup.cmd* file in the root folder of the library files. You will see a windows console appear as the script runs. When it is complete it will display “Deployment Complete”. Enter “Y” to exist the console.



```

C:\WINDOWS\system32\cmd.exe

-- Be patient, the duration of this process varies based on library size
-- Script Complete

:: -----
:: Registering Libraries
:: -----


-- Be patient, the duration of this process varies based on library size
-- Registration Complete

-----
Deployment Complete
-----
Exit deployment? [Y]?

```

Register Individual Library Objects Manually

As an alternative to registering the entire library using the *setup.cmd* script, you can manually register one or multiple library objects in Studio 5000® Application Code Manager. Open up Application Code Manager and view the Registered Libraries panel on the right. Right-click on *Registered Libraries* and select *Register*. Browse to the *ApplicationCodeManagerLibraries* folder within the library files and select any HSL4 files that you would like to register. Note you may select more than one at a time. Once you complete registering the desired objects they will be shown under the *(RA-LIB) Device* solution folder.



Importing Logic into Studio 5000® Projects

There are multiple methods to using the logic in a Studio 5000 application. For projects that are being developed from scratch using Application Code Manager along with other Application Code Libraries such as the PlantPAx Process Objects Library or the Machine Builder Library, you can continue to use the Device Object Libraries in Application Code Manager. For existing applications where devices are being added, it is recommended to use the Studio 5000 Plug-In “Import Library Objects” Wizard. Alternatively you can import the RUNG.L5X files into your program and configure them manually.



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: “How_To_Import_and_Configure_IO-Link_Device_Objects_in_LogixDesigner.mp4”



It is not recommended to simply import the AOI.L5X files and attempt to build your own logic rung. Doing so will increase the likelihood of configuration errors and likely miss logic that is required outside of the Add-On Instruction.

AOI files should only be imported when updating an existing application from a previous version of a Device Object Library to a newer one.


Below is a table to capture recommendations on when to use which tool or workflow when importing and configuring device objects.

Tool/Workflow	Description of when to use	Software Requirements
Application Code Manager (full application)	Project is developed from scratch using Application Code Manager along with PlantPAx or Machine Builder libraries.	Studio 5000 Logix Designer® Studio 5000® Application Code Manager (Lite)
Studio 5000 Plug-In “Import Library Objects” Wizard	Application Code Manager is installed but not required for the entire project. Application has already been developed but some Device Objects need to be added.	Studio 5000 Logix Designer® Studio 5000® Application Code Manager (Lite)
Import RUNG.L5X File	Application Code Manager is not installed. Application has already been developed but some Device Objects need to be added. Familiar with rung import workflow.	Studio 5000 Logix Designer®
Import AOI.L5X File	Updating existing application that contains an older version of a Device Object AOI.	Studio 5000 Logix Designer®

Import Library Objects Wizard


The most simple way to import a Device Object into an existing application is to use the Studio 5000 Plug-In “Import Library Objects” wizard. This plug-in requires Application Code Manager to be installed but does not require it to be open or have a project created.

Right click on an item (e.g. Controller, Task, Program, etc) in the Controller Organizer and select *Plug-Ins > Import Library Objects...*



This will launch a small wizard version of Application Code Manager inside of your Studio 5000 Logix Designer® Project. In the Registered Libraries panel on the left, find your desired object under *Registered Libraries* > (RA-LIB) Device > Device, then follow below steps:

- Add IO-Link Master H/W Module Object.
- Add desired IO-Link sensor AOI Objects.
- Add IO-Link Master AOI Object.



Perform the following configuration:

- Enter a **name** and **description**. Maximum name length can be 22 characters. Note that other parameters such as the RoutineName, TagName, etc will auto-complete based on these fields.

- Assign the **Task** and **Program**.
- Assign the **Master Reference** by typing or browsing to the instance of the IO-Link Master Module in the controller project (e.g. 1734-4IOL, 1732E-8IOLM12R or 5032-8IOLM12M12LDR/A)
- Enter the **Module Name** as per Sensor used in Application.
- Select the **Sensor Type** as per IODD used in Application (i.e. Type1, Type2 Or Type3).
- Select a **ChannelNumber** which is the IO-Link Master Module channel which the IO-Link sensor or device is connected to.
- The HMI Configuration options are not used in the Plug-In Wizard and can be ignored.
- Click next or click on the *Linked Libraries* tab. Click the *Auto Create* button to automatically create all of the required linked libraries.



You can manually create new linked libraries or point to existing linked libraries if necessary. You may need to do this if you would like to use an older version of library objects when multiple versions are installed in Application Code Manager.

- On the following screen you can select the desired Merge Actions. Generally these can be left with the default actions.
 - Add: used when AOIs don't previously exist in application
 - Overwrite: usually preferred. Used when AOIs previously exist but may or may not be the same revision.
 - Use Existing: used when AOIs previously exist in the application and you do not wish to overwrite the existing items.
- Click next and you can now see any new logic and modules that will be created.
- Click Finish to complete the import.


Import Rung Logic (4IOL, 8IOL Masters)

An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code. To use pre-engineered logic, import each desired RUNG.L5X file into a controller project.


1. In the Studio 5000 Logix Designer® application, open a new or existing project.

IMPORTANT Add-On Instruction definitions can be imported, but not updated, online.

2. Choose or create a new ladder routine to open. Right-click in the routine ladder and choose Import Rungs...




3. Select the desired RUNG and Select Import. The file will have a name like *raC_Dvc_42AF_4IOL_3.02_RUNG.L5X*.




Both “RUNG” and “AOI” .L5X files are provided. Import the RUNG file to get all required additional tags, data types, and message configurations.


4. An *Import Configuration* dialogue window will open and display generic Import names which include “_InstanceName”. Click the *Find/Replace...* button and replace all instances of “_InstanceName” with your desired device name (e.g. “PhotoSensor101”).




- Click the *Find/Replace...* button and replace of “Instance_Description” with your desired description e.g. “Object Detection 101”).



- Click the *Find/Replace...* button and replace of “_AdapterName” with your desired Adapter Module Name e.g. “Rack01”.



- Click the *Find/Replace...* button and replace of “_ModuleName” with your desired IO-Link Master Module Name e.g. (“PointIO_4IOL_Master”).



- You will need to point the new object to the correct AdapterName module in your project. You can type in or browse for the correct input (:I) tags in your project. In this example our module is called Rack01:I:I

which is the 1734-4IOL module installed in slot 1 of a POINT I/O rack called Rack01.

Import Configuration - raC_Dvc_42AF_4IOL_3.00_RUNG.L5X

Find: Find/Replace...

Find Within: Import Name, Final Name, Description, Parameter

Import Content:

- Programs
 - MainProgram
 - MainRoutine (Rungs)
 - References
 - Tags
 - Add-On Instruction:
 - Data Types
 - Other Components
 - Errors/Warnings


	Import Name	Operation	Final Name
*	_InstanceName_CtrlSet	Create	Photosensor101_CtrlSet
*	_InstanceName_CtrlSts	Create	Photosensor101_CtrlSts
*	_InstanceName_Inp_I	Create	Photosensor101_Inp_I
*	_InstanceName_Msg_Sensor_Data	Create	Photosensor101_Msg_Sensor_Data
*	_InstanceName_Read_Index	Create	Photosensor101_Read_Index
*	_InstanceName_Read_SubIndex	Create	Photosensor101_Read_SubIndex
*	_InstanceName_Write_Index	Create	Photosensor101_Write_Index
*	_InstanceName_Write_SubIndex	Create	Photosensor101_Write_SubIndex
*	_ModuleName_CtrlInf	Create	PointIO_4IOL_Master_CtrlInf
*	_ModuleName_CtrlIf	Create	PointIO_4IOL_Master_CtrlIf
*	raC_Dvc_42AF_InfTable	Create	raC_Dvc_42AF_InfTable
*	AdapterName:1:I	Use Existing	Rack01:1:I

Enter Name Filter... Show: All Tags


Name
▶ Rack01:1:C
▶ Rack01:1:I
▶ Rack01:1
▶ Rack01:0

Name: Rack01:1:C
Data Type: AB:1734_4IOL1:C:0
Description:

- Click “OK” on the “Import Configuration dialog box”. The rung will now be imported into your ladder routine.



- Browse the tags and assign it to the input parameters of the imported AOI Rung. For 'Inp_ChNumber' give the channel no. of Master where sensor is connected.




Import Rung Logic (5032 Master)

An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code. To use pre-engineered logic, import each desired RUNG.L5X file into a controller project.


- In the Studio 5000 Logix Designer® application, open a new or existing project.

IMPORTANT Add-On Instruction definitions can be imported, but not updated, online.

- Choose or create a new ladder routine to open. Right-click in the routine ladder and choose Import Rungs...




- Select the desired RUNG and Select Import. The file will have a name like *raC_Dvc_42AF_4IOL_3.02_RUNG.L5X*.




Both “RUNG” and “AOI” .L5X files are provided. Import the RUNG file to get all required additional tags, data types, and message configurations.


- An *Import Configuration* dialogue window will open and display generic Import names which include “_InstanceName”. Click the *Find/Replace...* button and replace all instances of “_InstanceName” with your desired device name (e.g. “Sensor_42EF_Type1”).




- Click the *Find/Replace...* button and replace of “_Instance_Description” with your desired description (e.g. “Object Detection 101”).




- Click the *Find/Replace...* button and replace of “_MasterName” with your desired 5032 IO-Link Master Module Name (e.g. “Mod_Master_5032_1”).



- Click the *Find/Replace...* button and replace of “_ModuleName” with your desired IO-Link Sensor Module Name e.g. (“Mod_42AF_Type1”).



- Click “OK” on the “Import Configuration dialog box”. The rung will now be imported into your ladder routine.



Using Studio 5000 View Designer®

Using View Designer Project Files


Studio 5000 View Designer® may be used for HMI development for PanelView 5000 applications. Open up your Studio 5000 View Designer® project alongside a second application instance running the required VSD file in the library folder *HMI - ViewDesigner - vpd*.



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: “How_To_Import_and_Configure_TYPE_-Objects_in_LogixDesigner.mp4” and “How_To_Configure_TYPE_Objects_in_ViewDesigner.mp4”

You will notice there are two screens available under the *User-Defined Screens* folder:

- Toolbox: This has the graphic symbol launch buttons for the faceplate.
- raC_Dvc_XXXXX_FP: This is a faceplate pop-up screen.



To include these files in your project, perform the following steps:


- Copy the entire faceplate _FP screen from the supplied View Designer project to your project application.
- Open the Toolbox screen and copy the desired graphic symbol and paste it into a screen in your project application.



Configuring View Designer Objects

To link the launch button to the faceplate, highlight the button and view the *Events* tab of within the *Properties* pane. Set an Event to *Open popup on release* with the following settings:

- Key: Touch Release
- Open Popup: Select desired faceplate screen
- AOI_Tag (Property Configuration): Browse to AOI backing tag for the device object in your controller file




Using FactoryTalk® View Studio

Import FactoryTalk View Visualization Files

There are several components to import for the visualization files. You import files from the downloaded Rockwell Automation library files via FactoryTalk View ME/SE. All image and display items can be imported either by right-clicking in FactoryTalk View on the Graphic sub-folder (e.g. Displays, Global Objects, Images) or simply dragging and dropping the files into the application.



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: "How_To_Import_and_Configure_TYPE_Objects_in_LogixDesigner.mp4" and "How_To_Import_and_Configure_TYPE_Objects_in_FTViewME.mp4"



Import files in this order:

1. Import HMI Images files.

Select all the images in the `\HMI FactoryTalk View Images - png` folder and Open.

2. Import Global Object files


Select the global object (.ggfx) files from the `\HMI - FactoryTalk View ME\Global Objects - gfx` folder

3. Import HMI Faceplates

Select the faceplate (.gfx) files from the `\HMI - FactoryTalk View ME\Displays - gfx` folder

Configuring FactoryTalk View Objects

Once the files have been imported into the FactoryTalk View Studio project, you can begin using them in your application. Open the *Global Display (raC-3-ME) Graphic Symbols - IO-Link Device*. Copy the desired launch button style and paste it into a display in your application where you would like to open the faceplate. For more information on graphic symbols, refer to the Graphic Symbols section of the specific device type chapter in this manual.



To configure the graphic symbol launch button, right-click and select *Global Object Parameter Values*. The Global Object Parameter values for the Backing Tag (#102) and Navigation Button Label (#104) are mandatory while the display position values (#120, #121) are optional. You can browse for the tag in your controller project by clicking '...' or manually type them in. These parameters may vary depending on the graphic symbol used, please refer to the Graphic Symbols section of the device type for detailed information.

- Launch Button Parameter Configuration e.g. (IO-Link Sensor Faceplate Navigation).

	Name	Value	Tag	Description
1	#102	{:[shortcut]Program:IOLink_Program.raC_Dvc_42AF}	...	Backing Tag
2	#104	raC_Dvc_42AF	...	Navigation Button Label
3	#120		...	Display's left position (e.g. 100) (optional)
4	#121		...	Display's top position (e.g. 100) (optional)

- Launch Button Parameter Configuration e.g. (IO-Link Master Faceplate Navigation).

	Name	Value	Tag	Description
1	#102	{:[PAC]Program:MainProgram.Master8IOL_2}	...	Add-On Instruction Backing Tag
2	#104	Master	...	Custom button label. Leave blank to use Tag.@Description
3	#110	{:[PAC]Program:MainProgram._836P_1001}	...	CH0 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel)
4	#111	0	...	CH1 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel)
5	#112	{:[PAC]Program:MainProgram._45DMS_1001}	...	CH2 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel)
6	#113	0	...	CH3 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel)
7	#114	{:[PAC]Program:MainProgram._871FM_1002}	...	CH4 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel)
8	#115	0	...	CH5 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel)
9	#116	{:[PAC]Program:MainProgram._42AF_1001}	...	CH6 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel)
10	#117	0	...	CH7 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel)
11	#120		...	Display's left position (e.g. 100) (optional)
12	#121		...	Display's top position (e.g. 100) (optional)



These Global Object Parameter Values are automatically configured when you use Studio 5000® Application Code Manager to design and configure your project. Refer to [Using Studio 5000® Application Code Manager](#) for more information.

Library Upgrades

Add-On Instruction Upgrades


There are two methods to upgrading existing device object add-on instructions in a project. You can do this either by using the Studio 5000 Plug-In *Import Library Objects* Wizard or by importing individual add-on instruction AOI.L5X files. Both methods are described in the following sections.

Note that all updates to Add-On Instructions must be done with Studio 5000 Logix Designer in OFFLINE mode and a download to the controller is required.


Upgrades Using Studio 5000 Plug-In to Import Library Objects

If Studio 5000 Application Code Manager is installed, you can use the Studio 5000 Plug-In *Import Library Objects* Wizard to update existing Add-On Instructions. For complete information on Studio 5000 Application Code Manager, refer to the section [Using Application Code Manager](#).


Right-click in your controller organizer or within a routine to access *Plug-Ins > Import Library Objects...*




The *Library Object Import Wizard* dialogue window will open. Under *Registered Libraries* expand *(RA-LIB) Device > Asset-Control* and find the desired object and version. Drag the object into the *Object Configuration* window on the right.




In the *Merge Actions* window, select the *Action* for the *AddOnIntructionDefinition* to *Overwrite*. This will update any existing instance of the object to the newer version. You may also choose to overwrite any other *DataTypes* or *Tags*. Review the release notes of the latest library release to understand what may be impacted. Click next and finish to complete the process.




- After Importing the AOI. The AOI references in the routine are affected and need to reconfigure it.



a. Drag and drop the tags from Unknown parameter to specific parameter




b. Right click on AOI definition and Remove all unknown parameter.




- c. Assign and create new tags for Ref_Ctrl_Inf & Ref_Ctrl_Itf. The tag name, data type and scope should be

Tag Name	Data Type	Scope
Master_4IOL_CtrlInf	raC_UDT_ItfAD_IOLinkSensor_Inf	Controller
Master_4IOL_CtrlItf	raC_UDT_ItfAD_IOLinkDevices	Controller




- d. Change the Data type for Ref_Ctrl_Set, Ref_Ctrl_Cmd and Ref_Ctrl_Sts parameter Tags using Right Click and select Edit tag properties. The tag data type should be



Tag Name	Required Data Type
AF_4002_CtrlSet	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
AF_4002_CtrlCmd	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
AF_4002_CtrlSts	raC_UDT_ItfAD_IOLinkSensor_CtrlSts




- In order to ensure the HMI faceplate still works properly you will need to update the object's library information stored in the Inf_Lib tag. In the *Controller Organizer* pane under *Assets > Add-On Instructions* expand the device object that was updated. Double-click on *Parameters and Local Tags* to open up the instructions tags.



- In the *Add-On Instruction Parameters and Local Tags* window, you may notice that the Inf_Lib tag in the add-on instruction definition matches the new library revision number. Click on the down-arrow to the right of the copy button and select *Copy Specified Values...*




- In the *Copy Default Values* window, be sure to **first uncheck all Parameters and Local Tags** by clicking the +/- box in the top right. Failure to do so may result in overwriting settings in the existing objects.
- Check only *Inf_Lib* in the *Local Tag* area. On the right, all affected objects should be selected. Click OK.
- You can now confirm that the *Inf_Lib* tag has been updated to the current library (e.g. 'raC-3_00') by changing the *Data Context* dropdown to a specific device object.




Upgrades by Importing AOI.L5X Files

To upgrade or migrate a project that uses a previous library version to a newer one, the add-on instruction L5X files are supplied. To perform an upgrade to an object perform the following steps:

- Open the controller file. Note changes must be done offline.
- In the *Controller Organizer* pane right-click on *Assets > Add-On Instructions* and select *Import Add-On Instruction*. Navigate to the AOI.L5X file in the *Studio 5000 Logix Designer Files - L5X* and Open.



- You will be prompted that there is an existing version of the instruction that is different. Choose *Overwrite* as the operation and select OK once you have read and understood the warnings. Your existing logic will be updated with the new add-on instruction. Verify that your code compiles and test adequately.



- After Importing the AOI. The AOI references in the routine are affected and need to reconfigure it. Follow the steps from [Link](#)

FactoryTalk View Upgrades

To upgrade a device object in a FactoryTalk View ME application, simply import the new faceplate .gfx display file into the application. If any global objects or images have been added or modified, you may need to import these as well. Any unused displays from previous versions may be removed or deleted from the application.

Note that the reference to the faceplate version is set in the Add-On Instruction Local Tag *Inf_Lib* so there does not need to be other modifications to the HMI application.

Studio 5000 View Designer® Upgrades

To upgrade a device object in a Studio 5000 View Designer application, simply import the open the new View Designer .vpd file and copy the raC_Dvc_xxxxx_FP pop-up screen into the existing application. Find any graphic symbol launch buttons in the application that open the faceplate, and update the Action to open the new pop-up screen. Any unused pop-up screens from previous versions may be removed or deleted from the application.

Using Application Code Manager

Overview of Application Code Manager

Studio 5000® Application Code Manager is a tool that enables more efficient project development with libraries of reusable code. Application Code Manager creates modular objects with customizable configuration parameters using the reusable content. Application Code Manager can also create the associated visualization, historical and alarming elements for a project.

Studio 5000 Application Code Manager can be easily used along with Rockwell Automation application code libraries such as the PlantPax Process Objects Library, Machine Builder Library, and Device Object Libraries. For more information on Studio 5000 Application Code Manager, refer to the [Application Code Manager User Manual](#).



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: "How_To_Import_and_Configure_TYPE_Objects_in_ACM.mp4" or "How_To_Import_and_Configure_TYPE_Objects_in_ACM (5032 Master).mp4"

Creating a New Project

Begin by opening Application Code Manager.





Note: the last project (if any) is opened by default; otherwise a blank screen is displayed.

Create a New Project or open an existing project. Navigate to *File > New > Project*.


Select the desired project type (e.g. *(RA-LIB) ACM 2.00 Project - Basic_Project*) and fill in the *Name* and *Description*.

To add a new controller to a project, in the *Controller Preview* window, right-click on *Controllers* and select *Add New...*




Select the desired controller type (e.g. *ControlLogix_Controller*, *GuardLogix_Controller*, *CompactLogix_Controller*, etc). Enter a *Name* and *Description* for the controller. Select the appropriate Chassis and Processor configurations.

You can also configure the HMI *AreaPath* and/or *AreaPathME* parameters which will be referenced if you use Application Code Manager to generate FactoryTalk® View ME displays with graphic symbol launch buttons.



You can now add in any desired tasks and programs to your controller. Right-Click on the *Tasks* folder underneath your controller in the *Controller Preview* and *Add New Task*. Similarly, right-click on any Task and select *Add New Program*. Complete the desired parameters for Tasks and Programs such as name, type, period, etc.



Adding & Configuring Device Objects

Prior to adding in any Device Objects, ensure you have registered the library in Application Code Manager. Refer to [Registering Libraries in Studio 5000 Application Code Manager](#) for details.




In Case of 4IOL and 8IOL Masters, When using Studio 5000 Application Code Manager with the IO-Link Device Library, note that you can add IO-Link master module hardware and IO-Link Device Objects; however you must manually add IO-Link sensors/devices to the IO-Link Master Modules after generating the controller code.

Adding IO-Link Master I/O Module

If not already done you may need to add IO-Link Master I/O modules (4IOL, 8IOL or 5032) to your Controller I/O Configuration. This will allow you to link tags in the IO-Link Device Library objects to IO-Link Master Module hardware. Alternatively, you can replace or link these at a later time.


In the *Controller Preview* pane you find the *I/O Configuration* folder underneath your controller. You may add 1732E ArmorBlock IO-Link Master modules directly to the *Ethernet* network or add a remote 1734 POINT I/O rack with a 1734-4IOL IO-Link Master module in the desired slot or add a 5032 8IOL Master Module to the *Ethernet* network. Right-click the desired location and select *Add New*.



You may choose to click on the *Category* filter to easily sort and find *IO-Link I/O*. Selected the desired IO-Link I/O module and click *Next*.



In Case of 1734-4IOL IO-Link Master module, user need to add a remote 1734 POINT I/O rack, then Right Click on Configured Rack and then choose to click on the *Category* filter to easily sort and find *IO-Link I/O*. Selected the desired IO-Link I/O module and click *Next*.



For ArmorBlock modules assign a *Name*, *IPAddress*, and *RPI*. For POINT I/O modules assign the desired *MasterName*, *Slot* and *RPI* parameters for the module. Click *Finish* to complete.

Object Configuration Wizard

Name: PointIO_IOLinkMaster

Description: 4 Channel IO-Link Master

Catalog Number: 1734-4IOL (2.3) - Published

Solution: (RA-LIB) Device

Parameters

▼ **Module Configuration**

MasterName	PointIO_IOLinkMaster
Slot	3
RPI	20
ChassisName	Rack01

Module Configuration

Cancel

Object Configuration Wizard

Name: ArmorBlock_IOLinkMaster

Description: 8 Channel IO-Link Master

Catalog Number: 1732E-8IOLM12R (2.3) - Published

Solution: (RA-LIB) Device


Parameters

▼ **Module Configuration**

MasterName	ArmorBlock_IOLinkMaster
IPAddress	192.168.1.50
RPI	20


Module Configuration

Cancel << Previous Next >> Finish



Adding IO-Link Device Instructions


To add a Device Object into a project, right-click on a Program and *Add New...*



- In the *Object Configuration Wizard* dialogue window you can click on the *Category* heading to group objects by category and find *IO-Link*. Select the desired IO-Link Device object (e.g. *raC_Dvc_42AF_8IOL*) and click *Next*.




Note that, 8IOL device objects (e.g. *raC_LD_Dvc_42AF_8IOL*) must be paired with the 8IOL Master, 4IOL objects (e.g. *raC_LD_Dvc_42AF_4IOL*) must be paired with the 4IOL Master and 5032 Objects (e.g. *raC_LD_Dvc_42AF_Type1*) must be paired with 5032 Master.



- Fill in all of the required configuration parameters for the device object. The following example shows a configuration of the raC_LD_42AF_8IOL object.

Perform the following configuration:

- Enter a **name** and **description**. Maximum name length can be 22 characters. Note that other parameters such as the RoutineName, TagName, etc will auto-complete based on these fields.
- Assign the **Task** and **Program**.
- Select a **ChannelNumber** which is the IO-Link Master Module channel that the IO-Link sensor or device is connected to.
- Assign the **MasterName** by typing or browsing to the instance of the IO-Link Master Module in the controller project (e.g. 1734-4IOL or 1732E-8IOLM12R)



- The configuration should now be complete with no red X's.

Object Configuration Wizard

Name: PhotoSensor101

Description: raC_Dvc_42AF Device Object

Catalog Number: raC_LD_Dvc_42AF_8IOL (2.3) - Published

Solution: (RA-LIB) Device

Task: Task

Parameters Linked Libraries

00 General

RoutineName	PhotoSensor101
TagName	PhotoSensor101
TagDescription	raC_Dvc_42AF Device Object
ChannelNumber	3

01 Module

MasterName	ArmorBlock_IOLinkMaster
------------	-------------------------

HMI Configuration

SEAssocDisplay	
MEAssocDisplay	

01 Module

Cancel << Previous

- For HMI Configuration refer to [Configuring Displays](#).
- Click on the *Linked Libraries* tab. Click the *Auto Create* button to automatically create all of the required linked libraries.

Object Configuration Wizard

Name: PhotoSensor101

Description: raC_Dvc_42AF Device Object

Catalog Number: raC_LD_Dvc_42AF_8IOL (2.3) - Published

Solution: (RA-LIB) Device

Task: Task Program: Program

Parameters **Linked Libraries** **Auto Create**

Linked Libraries

raC_Dvc_42AF_8IOL	* raC_Dvc_42AF_8IOL
-------------------	---------------------


Cancel << Previous Next >> Finish

- Click Finish to complete the object configuration.


For specific devices details, refer to the appropriate chapter in this manual.

Adding IO-Link Master Device Object


You can optionally add an IO-Link Master Module device object (e.g. raC_Dvc_8IOL_Master, raC_Dvc_4IOL_Master, raC_Dvc_5032_Master) to your project. This provides hardware diagnostic information for the master and includes an HMI faceplate to summarize data from each connected sensor. To add an IO-Link Master Object into a project, right-click on a Program and *Add New...*




In the *Object Configuration Wizard* dialogue window you can click on the *Category* heading to group objects by category and find *IO-Link*. Select the desired IO-Link Master object (e.g. raC_LD_Dvc_1732E_8IOLMaster or raC_LD_Dvc_1734_4IOLMaster or raC_LD_Dvc_5032_8IOLMaster) and click *Next*.




- Assign your desired *Name* and *Description* fields.




- Type in or browse for the IO-Link Sensor/Device objects that are connected to any applicable channels (*Cho*, *Chi*, etc). Browse by clicking the ellipses ‘...’ to open the *Select a Reference* window. The center pane will list all IO-Link category objects in your project. Double-click or highlight the desired device and click *Finish*. Continue to process until you have completed all applicable channels. Note that 8IOL device objects (e.g. raC_LD_Dvc_42AF_8IOL) must be paired with the 8IOL Master, 4IOL objects (e.g. raC_LD_Dvc_42AF_4IOL) must be paired with the 4IOL Master and 5032 Device Objects (e.g. raC_LD_Dvc_5032_8IOLMaster) must be paired with the 5032 Master.




- Type in or browse for the *MasterName*. This is the I/O module (e.g. 1734-4IOL or 1732E-8IOLM12R) instance that was previously created in the I/O configuration. Browse by clicking the ellipses ‘...’ to open the *Select a Reference* window. In the left window pane, select the instance of the I/O module. Double-click or highlight the desired device and click *Finish*.



- For HMI Configuration refer to [Configuring Displays](#).
- Once you have completed all sections you can continue.




- Click on the *Linked Libraries* tab and click *Auto Create*. Complete by clicking *Finish*.



Configuring Displays

Application Code Manager can be used to automatically configure graphic symbol launch buttons for device objects In FactoryTalk View ME or SE. Note that Application Code Manager is not compatible with Studio 5000 View Designer applications.

First you must add Displays to your project. Under the *System View* panel expand *HMI* and right-click on *Displays* to select *Add*. Choose the type of display (e.g. *FTViewME* or *FTViewSE* depending on your project requirements).



Object Configuration Wizard

Select a library

Filter: Show All Revisions Show All Libraries

Solution	LibraryType	Category	CatalogNumber	Family	ContentType	Class	Status	SchemaVersion	Owner
Display (4 items)									
(RA-LIB) ACM 2.00	HMI	Display	FTViewME (2.2)	Project		Standard	Published	2.0.0	Rockwell Aut
(RA-LIB) ACM 2.00	HMI	Display	FTViewSE (2.2)	Project		Standard	Published	2.0.0	Rockwell Aut
(RA-LIB) Machine	HMI	Display	FwkB_DisplayME (1.3)	Logix	Task	Standard	Published	2.0.0	RockwellAutr
(RA-LIB) Machine	HMI	Display	FwkB_DisplaySE (1.3)	Logix	Task	Standard	Published	2.0.0	Rockwell Aut

In the display object parameter configuration, you must select the *DisplayTemplate* type to match the version of FactoryTalk View application that you are using.

Name: FTViewME_Panel

Description:

Catalog Number: FTViewME (2.2) - Published


Solution: (RA-LIB) ACM 2.00

Parameters | Displays


01 - HMI Configuration

DisplayTemplate	(RA-TPL)_ACM_2.00_HMI_Display_FTViewME_10.0_(1.0).xml
BatchImportTemplate	(RA-TPL)_ACM_2.00_HMI_Display_FTViewME_7.0_(1.0).xml
MaxSymbolWidth	(RA-TPL)_ACM_2.00_HMI_Display_FTViewME_8.1_(1.0).xml
MaxSymbolHeight	(RA-TPL)_ACM_2.00_HMI_Display_FTViewME_8.2_(1.0).xml
	(RA-TPL)_ACM_2.00_HMI_Display_FTViewME_9.0_(1.0).xml
	(RA-TPL)_ACM_2.00_HMI_Display_FTViewME_10.0_(1.0).xml
	(RA-TPL)_ACM_2.00_HMI_Display_FTViewME_11.0_(1.0).xml

Navigate to the *Displays* tab where you can right-click and *Add New* display.




Set the desired name and display parameters. Generally all display parameters aside from *Name* can be left as default since this will often be used as a temporary display where object launch buttons are copied from.



Return to your device object configuration and view the *HMI Configuration* section of the parameters. You can browse or type in the *HMI_Server_Name.HMI_Display_Name*.






If you browse for the display, select the desired display server in the left panel, then click on the *Display* tab in the right panel and select the specific display. Click finish.

This workflow can be followed for either FactoryTalk View ME or SE depending on the project requirements.


Generating Displays

Once you have assigned displays to all of the device objects, you can generate the displays. In the *System View* highlight the desired display server under *HMI* > *Display* and right-click to select *Generate Displays* > *All Displays* or select individual displays. Choose a place to save the generated files and take note of it.



Importing Displays into FactoryTalk View Studio

To import the configured displays, open your FactoryTalk View ME/SE project in FactoryTalk View Studio. Right-click on *Graphic* > *Displays* and select *Import and Export...*



Follow the required prompts:

- Import graphic information into displays
- Choose whether or not to backup displays
- Choose either a *Single display import file* (must have an existing or blank display to import into) or *Multiple displays batch import file* if *All Displays* was used to Generate Displays.
- If this is the first time it is recommended to import *Multiple displays batch import file* and then *Create new objects on the display*.
- If you have done this before and are updating the imported display after modifying your Application Code Manager project, you can choose *Update existing objects on the display*.
- Browse for the BatchImport.xml file or individual display.xml file.

Open up the newly imported display. Notice that there are graphic symbol launch buttons labeled and configured for each item that was configured in Application Code Manager.



Right-click on the object and select *Global Object Parameters* to view that all of the parameters have been pre-configured for you.

	Name	Value	Tag	Description
1	#102	{::[shortcut]Program:IOLink_Program.raC_Dvc_42AF}	...	Backing Tag
2	#104	raC_Dvc_42AF	...	Navigation Button Label
3	#120		...	Display's left position (e.g. 100) (optional)
4	#121		...	Display's top position (e.g. 100) (optional)


OK Cancel Help

You may not copy and paste this graphic symbol onto any other display in your application.


Generating Controller Files

Once you have completed configuring your project in Studio 5000 Application Code Manager, you can generate the controller file for use in Studio 5000 Logix Designer.

In the *Controller Preview* pane right-click on the controller name within the *Controllers* folder and select *Generate Controller*.



In the *Logix Code Generation* dialogue window you will need to check *Create ACD*. You may also need to check *Overwrite Existing* if this is not the first time generating the controller code.




Once the controller file is generated, you can navigate to the location set in *Save Path* and open your file. Note that all of the configuration that was done in Application Code Manager is now shown in your Logix Designer ACD file.

Exporting Attachments

Application Code Libraries not only contain Logix code, but also contain Visualization collateral and associated documentation. Every Asset library contains at least a reference manual (RM). Those libraries which have associated Visualization content also have all required global objects (GO), images, static displays and View Designer applications added as attachments. In this manner the user can generate only the necessary visualization and documentation for the objects included in the project.

In Application Code Manager, all of the attachments are associated with the device objects in the *(RA-LIB) Device > Asset-Control* folder. These can be accessed both through the full Application Code Manager software, or via the Studio 5000 Plug-In “Import Library Objects”.

To access the attached files, right click on the objects (e.g. *raC_Dvc_42AF_8IOL*) and select *Extract Attached Files*.



Select the destination folder on your computer, and select OK. An Extract Attachments dialog will show the extraction status.

The extracted folder will contain the following:

- Reference Manual
- Required Images
- View Designer Faceplate Files
- FactoryTalk View Machine Edition Display
- FactoryTalk View Machine Edition Global Objects
- FactoryTalk View Site Edition Display
- FactoryTalk View Site Edition Global Objects

Using the IO-Link Device Library with Other Application Code Libraries

Application Code Libraries

The IO-Link Device Library is can be used alongside other Application Code Libraries.

The IO Device Library is recommended to be used along with the IO-Link Device Library if Studio 5000 Application Code Manager is used for project development. This will allow you to add IO-Link Master modules to the controller I/O Configuration..

The Machine Builder Library and PlantPAx Process Object Library application-level library objects may be used in the same applications with the device-level objects in the IO-Link Device Library. At this time there are no direct dependencies or interaction points between these libraries. They may be used independently from one another but within the same application.

Other libraries utilize the common device interface UDTs to interact with device level objects. In the case of the IO-Link Device Library you may programmatically reference the Status (Sts), Command (Cmd), and Setting (set) interfaces of the instructions. This is covered in detail in [Interfaces](#) section of this document.

42AF - RightSight Photoelectric Sensor (raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL, raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032)

Overview

The 42AF RightSight Photoelectric Sensor device object (raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL, raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor diagnostics
- Sensor configuration and parameters
- Process data trending
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: "Operational_Overview_of_42AF_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Setpoint:** Setpoint will allow the operators to enter the signal value required for the sensor output to turn ON upon target detection.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).
- **Teach:** Offers the different teach functions.

Functional Description

The 42AF RightSight Photoelectric Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with Five versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
42AF	POINT I/O 1734-4IOL	42AF-B1MAB1-xx, 42AF-B1MAB2-xx, 42AF-B1MAC1-xx, 42AF-N1MAC1-xx, 42AF-P2MAB1-xx, 42AF-R1MAB1-xx	raC_Dvc_42AF_4IOL_3.02_AOI.L5X	raC_Dvc_42AF_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	42AF-B1MAB1-xx, 42AF-B1MAB2-xx, 42AF-B1MAC1-xx, 42AF-N1MAC1-xx, 42AF-P2MAB1-xx, 42AF-R1MAB1-xx	raC_Dvc_42AF_8IOL_3.02_AOI.L5X	raC_Dvc_42AF_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	42AF-B1MAB1-xx, 42AF-B1MAB2-xx	raC_Dvc_42AF_Type1_5032_3.02_AOI.L5X	raC_Dvc_42AF_Type1_5032_3.02_RUNG.L5X
		42AF-B1MAC1-xx, 42AF-N1MAC1-xx	raC_Dvc_42AF_Type2_5032_3.02_AOI.L5X	raC_Dvc_42AF_Type2_5032_3.02_RUNG.L5X
		42AF-P2MAB1-xx, 42AF-R1MAB1-xx	raC_Dvc_42AF_Type3_5032_3.02_AOI.L5X	raC_Dvc_42AF_Type3_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
42AF	Display	(raC-3_02-ME) raC_Dvc_42AF-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_42AF-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
42AF	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
42AF	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42AF_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42AF_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42AF_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42AF_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42AF_Type1_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42AF_5032_(3.2)
		(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42AF_Type2_5032_(3.2)	
	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42AF_Type3_5032_(3.2)		

Device Definition (raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...



2. Specify the Application Specific Name e.g. *CapDetect_101*
3. Select the Process Data Input as *Triggered, Margin, Proximity, Gain, Signal*.

Change Channel Configuration


Channel	Mode	Vendor	Device	Application Specific Name	Electronic Keying	Process Data Input	Data Storage
0	IO-Link	Allen-Bradley	42AF-P2MAB1-D4	CapDetect_100	Exact M...	Triggered,Margin,Proximity,Gain,Signal	Enable ADC
1	IO-Link	Allen-Bradley	42AF-P2MAB1-D4	CapDetect_101	Exact M...	Triggered,Margin,Proximity,Gain,Signal	Enable ADC
2	IO-Link						
3	IO-Link						
4	IO-Link						
5	IO-Link						
6	IO-Link						
7	IO-Link						

Discover Devices... Path: Unable to display. Project has not been online yet. OK Cancel

Device Definition (raC_Dvc_42AF_Type1_503 2, raC_Dvc_42AF_Type2_5032 , raC_Dvc_42AF_Type3_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link for Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 42AF, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 42AF Sensor.



3. Configure the parameters of sensor from configuration tab from AOP of the 42AF sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data

(raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_42AF_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_Ctrl_Inf	IO-Link Device Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	IO-Link Device Command, Status	raC_UDT_ItfAD_IOLinkDevices
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STRO082[20]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_42AF_Inp_4IOL Or raC_UDT_ItfAD_42AF_Inp_8IOL

Input Data

Input	Function/Description	Data Type
Cfg_AlignmentMode	Alignment Mode; 0 = Disabled, 1 = Enabled, 2 = Enabled for 120s, 3 = Enabled for 240s	SINT
Cfg_OutputPolarityInverted	Output Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	SINT
Cmd_ResetCount	Counter Reset Command	BOOL
Cmd_ResetDurations	Duration Reset Command	BOOL
Cmd_TeachCancel	Duration Reset Command	BOOL
Cmd_TeachPrecision_ShowTarget	Teach Precision Show Target Command	BOOL
Cmd_TeachStatic_Background	Teach Static Background Command	BOOL
Cmd_TeachStatic_ShowTarget	Teach Static Show Target Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity Alarm of Sensor	BOOL

Input	Function/Description	DataType
Inp_ChxSignalStrength	Signal Strength of Sensor	DINT
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Set_Setpoint	Enter Setpoint Value To Turn ON Sensor Output	DINT
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Val_AlignmentModeEnable	Alignment Mode Status; 0 = Disabled, 1 = Enabled, 2 = Enabled for 120s, 3 = Enabled for 240s	INT
Val_Contrast	Sensor Contrast Level	INT
Val_NotTriggeredDuration	Sensor Output OFF Duration	INT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_OperatingHrsSincePowerUp	Operating Hours Since Power Up	DINT
Val_OutputPolarityInverted	Output Polarity Status, 0 = Not Inverted, 1 = Inverted	INT
Val_PercentSP	Setpoint in Percent	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Setpoint	Setpoint Value To Turn ON Sensor Output	DINT
Val_TeachStep	Teach Step	INT
Val_TemperatureCurrent	Internal Temperature Of Sensor	SINT
Val_TemperatureMaxSinceInception	Maximum Temperature Since Inception	SINT
Val_TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	SINT
Val_TemperatureMinSinceInception	Minimum Temperature Since Inception	SINT
Val_TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	SINT

Output	Function/Description	Data Type
Val.Trigger_Counter	Sensor Counter Value	SINT
Val.TriggeredDuration	Sensor Output ON Duration	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_42AF_Type1_5032, 2, raC_Dvc_42AF_Type2_5032 , raC_Dvc_42AF_Type3_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_42AF_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_Ctrl_Inf	IO-Link Device Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	IO-Link Device Command, Status	raC_UDT_ItfAD_IOLinkDevices
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_42AF_Inp_5032
Cfg_C	Device Object Configuration	raC_UDT_IOLink_42AF_Type1_Cfg or raC_UDT_IOLink_42AF_Type2_Cfg or raC_UDT_IOLink_42AF_Type3_Cfg

Input Data

Input	Function/Description	Data Type
Cfg_AlignmentMode	Alignment Mode; 0 = Disabled, 1 = Enabled, 2 = Enabled for 120s, 3 = Enabled for 240s	SINT
Cfg_OutputPolarityInverted	Output Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	SINT
Cmd_ResetCount	Counter Reset Command	BOOL
Cmd_ResetDurations	Duration Reset Command	BOOL
Cmd_TeachCancel	Duration Reset Command	BOOL
Cmd_TeachPrecision_ShowTarget	Teach Precision Show Target Command	BOOL
Cmd_TeachStatic_Background	Teach Static Background Command	BOOL
Cmd_TeachStatic_ShowTarget	Teach Static Show Target Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT

Input	Function/Description	Data Type
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity Alarm of Sensor	BOOL
Inp_ChxSignalStrength	Signal Strength of Sensor	DINT
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Set_Setpoint	Enter Setpoint Value To Turn ON Sensor Output	DINT
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_AlignmentModeEnable	Alignment Mode Status; 0 = Disabled, 1 = Enabled, 2 = Enabled for 120s, 3 = Enabled for 240s	INT
Val_Contrast	Sensor Contrast Level	INT
Val_NotTriggeredDuration	Sensor Output OFF Duration	INT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_OperatingHrsSincePowerUp	Operating Hours Since Power Up	DINT
Val_OutputPolarityInverted	Output Polarity Status, 0 = Not Inverted, 1 = Inverted	INT
Val_PercentSP	Setpoint in Percent	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Setpoint	Setpoint Value To Turn ON Sensor Output	DINT
Val_TeachStep	Teach Step	INT
Val_TemperatureCurrent	Internal Temperature Of Sensor	SINT
Val_TemperatureMaxSinceInception	Maximum Temperature Since Inception	SINT
Val_TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	SINT
Val_TemperatureMinSinceInception	Minimum Temperature Since Inception	SINT
Val_TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	SINT


Output	Function/Description	Data Type
Val.Trigger_Counter	Sensor Counter Value	SINT
Val.TriggeredDuration	Sensor Output ON Duration	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 42AF device object connected to channel #3 of a POINT I/O 1734-4IOL IO-Link Master module named *Point_IO_4IOLMaster* in slot #1 of a POINT I/O adapter named *Rack01*.




The following example uses the 42AF device object connected to channel #4 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*



The following example uses the 42AF Sensor Type 1 device object connected to channel #0 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Masters5032*



The following example uses the 42AF Sensor Type 2 device object connected to channel #2 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Masters5032*



The following example uses the 42AF Sensor Type 3 device object connected to channel #4 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master5032*





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {::[PAC]Program::IOLinkProgram_InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_LightSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {::[PAC]Program::IOLinkProgram_InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_42AF_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Name	Usage	Alias For	Base Tag	Data Type	Description
▶ Sensor_42JT_Type1_Cfg_C	Local			raC_UDT_IOLink_42JT_Type1_Cfg	Sensor_42JT_Type1 Configuration Interface
▶ Sensor_42JT_Type1	Local			raC_Dvc_42JT_Type1_5032	Sensor_42JT_Type1
▶ Sensor_42EF_Type3_Inp_I	Local			raC_UDT_IOLink_42EF_Inp_5032	Sensor_42EF_Type3 Input Interface
▶ Sensor_42EF_Type3_Cfg_C	Local			raC_UDT_IOLink_42EF_Type3_Cfg	Sensor_42EF_Type3 Configuration Interface
▶ Sensor_42EF_Type3	Local			raC_Dvc_42EF_Type3_5032	Sensor_42EF_Type3
▶ Sensor_42EF_Type2_Inp_I	Local			raC_UDT_IOLink_42EF_Inp_5032	Sensor_42EF_Type2 Input Interface
▶ Sensor_42EF_Type2_Cfg_C	Local			raC_UDT_IOLink_42EF_Type2_Cfg	Sensor_42EF_Type2 Configuration Interface
▶ Sensor_42EF_Type2	Local			raC_Dvc_42EF_Type2_5032	Sensor_42EF_Type2
▶ Sensor_42EF_Type1_Inp_I	Local			raC_UDT_IOLink_42EF_Inp_5032	Sensor_42EF_Type1 Input Interface
▶ Sensor_42EF_Type1_Cfg_C	Local			raC_UDT_IOLink_42EF_Type1_Cfg	Sensor_42EF_Type1 Configuration Interface
▶ Sensor_42EF_Type1	Local			raC_Dvc_42EF_Type1_5032	Sensor_42EF_Type1
▶ Sensor_42AF_Type3_Inp_I	Local			raC_UDT_IOLink_42AF_Inp_5032	Sensor_42AF_Type3 Input Interface
▶ Sensor_42AF_Type3_Cfg_C	Local			raC_UDT_IOLink_42AF_Type3_Cfg	Sensor_42AF_Type3 Configuration Interface
▶ Sensor_42AF_Type3	Local			raC_Dvc_42AF_Type3_5032	Sensor_42AF_Type3
▶ Sensor_42AF_Type2_Inp_I	Local			raC_UDT_IOLink_42AF_Inp_5032	Sensor_42AF_Type2 Input Interface
▶ Sensor_42AF_Type2_Cfg_C	Local			raC_UDT_IOLink_42AF_Type2_Cfg	Sensor_42AF_Type2 Configuration Interface
▶ Sensor_42AF_Type2	Local			raC_Dvc_42AF_Type2_5032	Sensor_42AF_Type2
▶ Sensor_42AF_Type1_Inp_I	Local			raC_UDT_IOLink_42AF_Inp_5032	Sensor_42AF_Type1 Input Interface
▶ Sensor_42AF_Type1_Cfg_C	Local			raC_UDT_IOLink_42AF_Type1_Cfg	Sensor_42AF_Type1 Configuration Interface
▶ Sensor_42AF_Type1	Local			raC_Dvc_42AF_Type1_5032	Sensor_42AF_Type1

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Signal Strength (%) Sparkline Trend The spark line shows the signal strength value over last 30 seconds
6	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function.
7	Process Data - Triggered Duration (ms): Displays the amount of time that the sensor output has been ON. To show the trigger duration on faceplate, required to make Timer Mode Enabled setting in AOP in Logix Designer. - Not Triggered Duration (ms): Displays the amount of time that the sensor output has been OFF. To show the trigger duration on faceplate, required to make Timer Mode Enabled setting in AOP in Logix Designer. - Trigger Counter: Displays the sensor counter value when enabled. The counter value increments every time the sensor is triggered this process data element can count up to 65535 and can be reset via reset count button from config tab. Refer to Appendix B for additional information about index. To show the trigger count on faceplate, required to make Counter Mode Enabled setting in AOP in Logix Designer. - Signal Strength (%): Signal Strength provides the raw measurement value of the amount of light reflected from the target. - Contrast: Displays the difference between the light signal levels that the sensor read the last time the output was ON versus the last time the output was OFF. - Gain: Displays the excess gain above the sensor threshold to ensure reliable detection of the target.



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Internal Temperature Bar Graph Green Indicators: Min/Max since inception (lifetime) Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Internal Temperature Current Value
3	Operating Hours Since Inception (lifetime)
4	Operating Hours Since Power Up



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.


Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. One trend is displayed for Setpoint and Signal Strength.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Setpoint & Signal strength.



Configure Tab


The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Trigger Settings
- Local Settings
- Teach Settings
- Configuration Apply Settings



In case of 5032 Master, “[Config Apply](#)” Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Parameter Settings

Setpoint - Allows operators to enter the signal value required for the sensor output to turn ON (threshold) upon target detection. That means that the sensor signal level must be higher than the threshold for the output to turn ON. The default value for this parameter is 1000 with acceptable values between 1000 and 65535.

Output Polarity - Polarity changes the sensor output to operate as Not Inverted (Light Operate) and Inverted (Dark Operate). Click on output polarity drop-down selector object to switch between Light On & Dark On.

Alignment Mode - This parameter changes the sensor user interface to operate in alignment mode. The alignment mode uses the green and orange LEDs of the sensor to visually indicate the strength of the light signal that is reflected back from the object. Click on alignment mode drop-down selector object to switch between Enable & Disable

Trigger Settings

Reset Count - Allows users to reset the counter function, it will reset the sensor counts to zero.

Reset Duration - Allows users to reset the timer function, it will reset Duration Triggered & Duration Not Triggered time.

Local Settings


Disable/Enable LEDs - This parameter allows operators to turn OFF or turn ON the User Interface LEDs (green and orange LEDs). This parameter is ideal for applications where turning OFF the LEDs is desired to accommodate the application.

Local Teach Parameters - This section allow user to lock / unlock device local parameterization. Touch Lock/Unlock Toggle switch to Lock Local Parameterization

Teach Settings

Teach Settings display includes the Teach Methods, Teach Command & Teach Cancel buttons. Touch on the Teach Settings navigation button to access the Teach Settings tab.

- Teach tab includes the following functions.
- Teach mode selection dropdown menu
- Teach procedure flow buttons
- Teach Cancel Button



Teach mode - This parameter selects the desired mode.

Static Teach - The first method is Static Teach, which is intended for applications where the web can be stopped, or for more challenging applications.

4. Place the target in front of the sensor and send the command to **“Static Teach - Show Target”**.

5. Show the background where the target will be present and then send the command **“Static Teach - Show Background”**.
6. To cancel the procedure, you can send the **“Teach Cancel”** command at any point.


Precision Teach - The Precision Teach is intended for applications where the precise setting of the distance is more critical. This teach method is also recommended for contrast applications.

1. Place the target in front of the sensor and send the command to **“Precision Teach – Show Target”**.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description_Test,
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_42AF_4IOL, raC_Dvc_42AF_8IOL, raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_42AF_410L, raC_LD_Dvc_42AF_810L

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_Dvc_42AF_Type1_5032, raC_Dvc_42AF_Type2_5032, raC_Dvc_42AF_Type3_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 42AF), This name depends upon the TagName assigned to object.
SensorType	42AF-B1MAB1-xx	42AF-B1MAB1-xx	42AF-B1MAB1-xx	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.

Parameter Name	Default Value	Instance Name	Definition	Description
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_42AF_4IOL	raC_Dvc_42AF_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_42AF_8IOL	raC_Dvc_42AF_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_42AF_Type1_5032 Or raC_Dvc_42AF_Type2_5032 Or raC_Dvc_42AF_Type3_5032	raC_Dvc_42AF_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_42AF	Faceplate ME	(raC-3_xx-ME) raC_Dvc_42AF-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_42AF	Faceplate SE	(raC-3_xx-SE) raC_Dvc_42AF-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

42EF - RightSight Photoelectric Sensor (raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL, raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032)

Overview

The 42EF RightSight Photoelectric Sensor device object (raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL, raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor diagnostics
- Sensor configuration and parameters
- Process data trending
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_42EF_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Setpoint:** Setpoint will allow the operators to enter the signal value required for the sensor output to turn ON upon target detection.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).

Functional Description

The 42EF RightSight Photoelectric Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with five versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
42EF	POINT I/O 1734-4IOL	42EF-D2JBAK-xx, 42EF-D2KBAK-xx, 42EF-D2MPAK-xx, 42EF-P2JBB-xx, 42EF-P2KBB-xx, 42EF-P2MPB-xx, 42EF-R2JBBT-xx, 42EF-R2JBB-xx, 42EF-R2KBBT-xx, 42EF-R2KBB-xx, 42EF-R2MNB-xx, 42EF-R2MNB-xx, 42EF-R2MPBT-xx, 42EF-R2MPB-xx, 42EF-S1JBA-xx, 42EF-S1KBA-xx, 42EF-S1MPA-xx	raC_Dvc_42EF_4IOL_3.02_AOI.L5X	raC_Dvc_42EF_4IOL_3.01_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	42EF-D2JBAK-xx, 42EF-D2KBAK-xx, 42EF-D2MPAK-xx, 42EF-P2JBB-xx, 42EF-P2KBB-xx, 42EF-P2MPB-xx, 42EF-R2JBBT-xx, 42EF-R2JBB-xx, 42EF-R2KBBT-xx, 42EF-R2KBB-xx, 42EF-R2MNB-xx, 42EF-R2MNB-xx, 42EF-R2MPBT-xx, 42EF-R2MPB-xx, 42EF-S1JBA-xx, 42EF-S1KBA-xx, 42EF-S1MPA-xx	raC_Dvc_42EF_8IOL_3.02_AOI.L5X	raC_Dvc_42EF_8IOL_3.01_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	42EF-D2JBAK-xx, 42EF-D2KBAK-xx, 42EF-D2MPAK-xx, 42EF-P2JBB-xx, 42EF-P2KBB-xx, 42EF-P2MPB-xx, 42EF-S1JBA-xx, 42EF-S1KBA-xx, 42EF-S1MPA-xx 42EF-R2JBB-xx, 42EF-R2KBBT-xx, 42EF-R2KBB-xx, 42EF-R2MNB-xx, 42EF-R2MNB-xx, 42EF-R2MPBT-xx, 42EF-R2MPB-xx 42EF-R2JBBT-xx	raC_Dvc_42EF_Type1_5032_3.02_AOI.L5X raC_Dvc_42EF_Type2_5032_3.02_AOI.L5X raC_Dvc_42EF_Type3_5032_3.02_AOI.L5X	raC_Dvc_42EF_Type1_5032_3.02_RUNG.L5X raC_Dvc_42EF_Type2_5032_3.02_RUNG.L5X raC_Dvc_42EF_Type3_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
42EF	Display	(raC-3_02-ME) raC_Dvc_42EF-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_42EF-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
42EF	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
42EF	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42EF_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42EF_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42EF_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42EF_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42EF_Type1_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42EF_5032_(3.2)
		(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42EF_Type2_5032_(3.2)	
	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42EF_Type3_5032_(3.2)		

Device Definition (raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...



2. Specify the Application Specific Name e.g. *CapDetect_101*
3. Select the Process Data Input as *Triggered, Margin, Proximity, Gain, Signal*.


Channel	Mode	Vendor	Device	Application Specific Name	Electronic Keying	Process Data Input	Data Storage
0	IO-Link	Allen-Bradley	42EF-D2KBAK-A2	CapDetect_100	Exact M...	Triggered,Margin,Proximity,Gain,Signal	Enable ADC
1	IO-Link	Allen-Bradley	42EF-P2JBB-A2	CapDetect_101	Exact M...	Triggered,Margin,Proximity,Gain,Signal	Enable ADC
2	IO-Link						
3	IO-Link						
4	IO-Link						
5	IO-Link						
6	IO-Link						
7	IO-Link						

Discover Devices... Path: Unable to display. Project has not been online yet. OK Cancel

Device Definition (raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link for Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 42EF, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 42EF Sensor.

- └─ I/O Configuration
 - └─ 1756 Backplane, 1756-A7
 - └─ Ethernet
 - └─ 1756-L85E Master_5032_Test_Cases
 - └─ 5032-8IOLM12M12LDR/A Mod_Master_5032_1
 - └─ IO-Link
 - 0 42AF-B1MAB1-xx (224) Mod_42AF_Type1
 - 2 42AF-B1MAC1-xx (220) Mod_42AF_Type2
 - 4 42AF-P2MAB1-xx (208) Mod_42AF_Type3
 - 6 42EF-D2JBAK-xx (105) Mod_42EF_Type1**
 - 8 42EF-R2KBB-xx (119) Mod_42EF_Type2**
 - 10 42EF-R2JBBT-xx (118) Mod_42EF_Type3**
 - 12 42JT-B2LAT1-xx (1) Mod_42JT_Type1
 - 14 42JT-F5LET1-xx (11) Mod_42JT_Type2

3. Configure the parameters of sensor from configuration tab from AOP of the 42EF sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.

Condition	Description
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data

(raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_42EF_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_Ctrl_Inf	IO-Link Device Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	IO-Link Device Command, Status	raC_UDT_ItfAD_IOLinkDevices
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STRO082[20]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_42EF_Inp_4IOL Or raC_UDT_ItfAD_42EF_Inp_8IOL

Input Data

Input	Function/Description	Data Type
Cfg_AlignmentMode	Alignment Mode; 0 = Disabled, 1 = Enabled, 2 = Enabled for 120s, 3 = Enabled for 240s	SINT
Cfg_OutputPolarityInverted	Output Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	SINT
Cmd_ResetCount	Counter Reset Command	BOOL
Cmd_ResetDurations	Duration Reset Command	BOOL
Cmd_TeachCancel	Duration Reset Command	BOOL
Cmd_TeachPrecision_ShowTarget	Teach Precision Show Target Command	BOOL
Cmd_TeachStatic_Background	Teach Static Background Command	BOOL
Cmd_TeachStatic_ShowTarget	Teach Static Show Target Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity Alarm of Sensor	BOOL

Input	Function/Description	Data Type
Inp_ChxSignalStrength	Signal Strength of Sensor	DINT
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Set_Setpoint	Enter Setpoint Value To Turn ON Sensor Output	DINT
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Val_AlignmentModeEnable	Alignment Mode Status; 0 = Disabled, 1 = Enabled, 2 = Enabled for 120s, 3 = Enabled for 240s	INT
Val_Contrast	Sensor Contrast Level	INT
Val_NotTriggeredDuration	Sensor Output OFF Duration	INT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_OperatingHrsSincePowerUp	Operating Hours Since Power Up	DINT
Val_OutputPolarityInverted	Output Polarity Status, 0 = Not Inverted, 1 = Inverted	INT
Val_PercentSP	Setpoint in Percent	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Setpoint	Setpoint Value To Turn ON Sensor Output	DINT

Output	Function/Description	Data Type
Val_TeachStep	Teach Step	INT
Val_TemperatureCurrent	Internal Temperature Of Sensor	SINT
Val_TemperatureMaxSinceInception	Maximum Temperature Since Inception	SINT
Val_TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	SINT
Val_TemperatureMinSinceInception	Minimum Temperature Since Inception	SINT
Val_TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	SINT
Val_Trigger_Counter	Sensor Counter Value	SINT
Val_TriggeredDuration	Sensor Output ON Duration	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_42EF_Type1_5032, 2, raC_Dvc_42EF_Type2_5032 , raC_Dvc_42EF_Type3_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_42EF_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_Ctrl_Inf	IO-Link Device Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	IO-Link Device Command, Status	raC_UDT_ItfAD_IOLinkDevices
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_42EF_Inp_5032
Cfg_C	Device Object Configuration	raC_UDT_IOLink_42EF_Type1_Cfg or raC_UDT_IOLink_42EF_Type2_Cfg or raC_UDT_IOLink_42EF_Type3_Cfg

Input Data

Input	Function/Description	Data Type
Cfg_AlignmentMode	Alignment Mode; 0 = Disabled, 1 = Enabled, 2 = Enabled for 120s, 3 = Enabled for 240s	SINT
Cfg_OutputPolarityInverted	Output Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	SINT
Cmd_ResetCount	Counter Reset Command	BOOL
Cmd_ResetDurations	Duration Reset Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity Alarm of Sensor	BOOL
Inp_ChxSignalStrength	Signal Strength of Sensor	DINT
Inp_ChxTriggered	Triggered Status of Sensor	BOOL

Input	Function/Description	DataType
Set_Setpoint	Enter Setpoint Value To Turn ON Sensor Output	DINT
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_AlignmentModeEnable	Alignment Mode Status; 0 = Disabled, 1 = Enabled, 2 = Enabled for 120s, 3 = Enabled for 240s	INT
Val_Contrast	Sensor Contrast Level	INT
Val_NotTriggeredDuration	Sensor Output OFF Duration	INT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_OperatingHrsSincePowerUp	Operating Hours Since Power Up	DINT
Val_OutputPolarityInverted	Output Polarity Status, 0 = Not Inverted, 1 = Inverted	INT
Val_PercentSP	Setpoint in Percent	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Setpoint	Setpoint Value To Turn ON Sensor Output	DINT
Val_TemperatureCurrent	Internal Temperature Of Sensor	SINT
Val_TemperatureMaxSinceInception	Maximum Temperature Since Inception	SINT
Val_TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	SINT
Val_TemperatureMinSinceInception	Minimum Temperature Since Inception	SINT
Val_TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	SINT
Val_Trigger_Counter	Sensor Counter Value	SINT
Val_TriggeredDuration	Sensor Output ON Duration	INT


Output	Function/Description	Data Type
Val.SignalStrengthOn	Signal Strength On Value	DINT
Val.SignalStrengthOff	Signal Strength Off Value	DINT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 42EF device object connected to channel #3 of a POINT I/O 1734-4IOL IO-Link Master module named *PointIO_4IOL_Master* in slot #8 of a POINT I/O adapter named *Rack01*.




The following example uses the 42EF device object connected to channel #0 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.




The following example uses the 42EF Sensor Type 1 device object connected to channel #6 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Masters5032_1*



The following example uses the 42EF Sensor Type 2 device object connected to channel #8 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Masters5032_1*



The following example uses the 42EF Sensor Type 3 device object connected to channel #10 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master5032_1*





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {::[PAC]Program::IOLinkProgram._InstanceName }) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_LightSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {::[PAC]Program::IOLinkProgram._InstanceName }) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_42EF_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Name	Usage	Alias For	Base Tag	Data Type	Description
▶ Sensor_42JT_Type1_Cfg_C	Local			raC_UDT_IOLink_42JT_Type1_Cfg	Sensor_42JT_Type1 Configuration Interface
▶ Sensor_42JT_Type1	Local			raC_Dvc_42JT_Type1_5032	Sensor_42JT_Type1
▶ Sensor_42EF_Type3_Inp_I	Local			raC_UDT_IOLink_42EF_Inp_5032	Sensor_42EF_Type3 Input Interface
▶ Sensor_42EF_Type3_Cfg_C	Local			raC_UDT_IOLink_42EF_Type3_Cfg	Sensor_42EF_Type3 Configuration Interface
▶ Sensor_42EF_Type3	Local			raC_Dvc_42EF_Type3_5032	Sensor_42EF_Type3
▶ Sensor_42EF_Type2_Inp_I	Local			raC_UDT_IOLink_42EF_Inp_5032	Sensor_42EF_Type2 Input Interface
▶ Sensor_42EF_Type2_Cfg_C	Local			raC_UDT_IOLink_42EF_Type2_Cfg	Sensor_42EF_Type2 Configuration Interface
▶ Sensor_42EF_Type2	Local			raC_Dvc_42EF_Type2_5032	Sensor_42EF_Type2
▶ Sensor_42EF_Type1_Inp_I	Local			raC_UDT_IOLink_42EF_Inp_5032	Sensor_42EF_Type1 Input Interface
▶ Sensor_42EF_Type1_Cfg_C	Local			raC_UDT_IOLink_42EF_Type1_Cfg	Sensor_42EF_Type1 Configuration Interface
▶ Sensor_42EF_Type1	Local			raC_Dvc_42EF_Type1_5032	Sensor_42EF_Type1
▶ Sensor_42AF_Type3_Inp_I	Local			raC_UDT_IOLink_42AF_Inp_5032	Sensor_42AF_Type3 Input Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Signal Strength (%) Sparkline Trend The spark line shows the signal strength value over last 30 seconds
6	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
7	Process Data - Triggered Duration (ms): Displays the amount of time that the sensor output has been ON. To show the trigger duration on faceplate, required to make Timer Mode Enabled setting in AOP in Logix Designer. - Not Triggered Duration (ms): Displays the amount of time that the sensor output has been OFF. To show the trigger duration on faceplate, required to make Timer Mode Enabled setting in AOP in Logix Designer. - Trigger Counter: Displays the sensor counter value when enabled. The counter value increments every time the sensor is triggered this process data element can count up to 65535 and can be reset via reset count button from config tab. Refer to Appendix B for additional information about index. To show the trigger count on faceplate, required to make Counter Mode Enabled setting in AOP in Logix Designer. - Signal Strength (%): Signal Strength provides the raw measurement value of the amount of light reflected from the target. - Contrast: Displays the difference between the light signal levels that the sensor read the last time the output was ON versus the last time the output was OFF. - Gain: Displays the excess gain above the sensor threshold to ensure reliable detection of the target.



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Internal Temperature Bar Graph Green Indicators: Min/Max since inception (lifetime) Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Internal Temperature Current Value
3	Operating Hours Since Inception (lifetime)
4	Operating Hours Since Power Up



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.


Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. One trend is displayed for Setpoint and Signal Strength.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Setpoint & Signal strength.



Configure Tab


The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Trigger Settings
- Local Settings
- Configuration Apply Settings



In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Parameter Settings

Setpoint - Allows operators to enter the signal value required for the sensor output to turn ON (threshold) upon target detection. That means that the sensor signal level must be higher than the threshold for the output to turn ON. The default value for this parameter is 1000 with acceptable values between 1000 and 65535.

Output Polarity - Polarity changes the sensor output to operate as Not Inverted (Light On) and Inverted (Dark On). Click on output polarity drop-down selector object to switch between Light On & Dark On.

Alignment Mode - This parameter changes the sensor user interface to operate in alignment mode. The alignment mode uses the green and orange LEDs of the sensor to visually indicate the strength of the light signal that is reflected back from the object. Click on alignment mode drop-down selector object to switch between Enable & Disable

Trigger Settings

Reset Count - Allows users to reset the counter function, it will reset the sensor counts to zero.

Reset Duration - Allows users to reset the timer function, it will reset Duration Triggered & Duration Not Triggered time.

Local Settings


Disable/Enable LEDs - This parameter allows operators to turn OFF or turn ON the User Interface LEDs (green and orange LEDs). This parameter is ideal for applications where turning OFF the LEDs is desired to accommodate the application.

Local Teach Parameters - This section allow user to lock / unlock device local parameterization. Touch Lock/Unlock Toggle switch to Lock Local Parameterization


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_42EF_4IOL, raC_Dvc_42EF_8IOL, raC_Dvc_42EF_Type1_5032, raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_42EF_4IOL, raC_LD_Dvc_42EF_8IOL

Implementation Objects: raC_Dvc_42EF_Type1_5032,

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

raC_Dvc_42EF_Type2_5032, raC_Dvc_42EF_Type3_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReferance		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 42EF), This name depends upon the TagName assigned to object.
SensorType	42EF-D2JBAK-xx	42EF-D2JBAK-xx	42EF-D2JBAK-xx	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.

Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.
-------------------	-----------------	--	-------------------	---



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_42EF_4IOL	raC_Dvc_42EF_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_42EF_8IOL	raC_Dvc_42EF_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_42EF_Type1_5032 Or raC_Dvc_42EF_Type2_5032 Or raC_Dvc_42EF_Type3_5032	raC_Dvc_42EF_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME) Graphic Symbols - lo-link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE) Graphic Symbols - lo-link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_42EF	Faceplate ME	(raC-3_xx-ME) raC_Dvc_42EF-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_42EF	Faceplate SE	(raC-3_xx-SE) raC_Dvc_42EF-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

42JT - VisiSight Photoelectric Sensor (raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL, raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032)

Overview

The 42JT VisiSight Photoelectric Sensor device object (raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL, raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor diagnostics
- Sensor configuration and parameters
- Device Fault log

Primary device object configuration functions include:



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:

"Operational_Overview_of_42JT_Objects_Faceplate.MP4"

- **Setpoint:** Setpoint will allow the operators to enter the signal value required for the sensor output to turn ON upon target detection.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).
- **Teach:** Offers the different teach functions.

Functional Description

The 42JT VisiSight Photoelectric Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the /Studio 5000 Logix Designer Files - L5X/ folder in the library. Each device is supplied with five versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
42JT	POINT I/O 1734-4IOL	42JT-B2LAT1-xx, 42JT-B2LAT2-xx, 42JT-C2LAT1-xx, 42JT-R9LAT1-xx, 42JT-R8LAT1-xx, 42JT-F5LET1-xx, 42JT-P8LAT1-xx, 42JT-D8LAT1-xx, 42JT-P2LAT1-xx, 42JT-D2LAT1-xx, 42JT-B8LAT1-xx	raC_Dvc_42JT_4IOL_3.02_AOI.L5X	raC_Dvc_42JT_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	42JT-B2LAT1-xx, 42JT-B2LAT2-xx, 42JT-C2LAT1-xx, 42JT-R9LAT1-xx, 42JT-R8LAT1-xx, 42JT-F5LET1-xx, 42JT-P8LAT1-xx, 42JT-D8LAT1-xx, 42JT-P2LAT1-xx, 42JT-D2LAT1-xx	raC_Dvc_42JT_8IOL_3.02_AOI.L5X	raC_Dvc_42JT_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	42JT-B2LAT1-xx, 42JT-B2LAT2-xx, 42JT-C2LAT1-xx, 42JT-R9LAT1-xx, 42JT-R8LAT1-xx	raC_Dvc_42JT_Type1_5032_3.02_AOI.L5X	raC_Dvc_42JT_Type1_5032_3.02_RUNG.L5X
		42JT-F5LET1-xx, 42JT-P8LAT1-xx, 42JT-D8LAT1-xx	raC_Dvc_42JT_Type2_5032_3.02_AOI.L5X	raC_Dvc_42JT_Type2_5032_3.02_RUNG.L5X
		42JT-P2LAT1-xx, 42JT-D2LAT1-xx	raC_Dvc_42JT_Type3_5032_3.02_AOI.L5X	raC_Dvc_42JT_Type3_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the /HMI FactoryTalk View Images - png/ folder of the library. FactoryTalk View ME files are stored in the /HMI - FactoryTalk View ME/ library folder and FactoryTalk View SE files are stored in the /HMI - FactoryTalk View SE/ library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
42JT	Display	(raC-3_02-ME) raC_Dvc_42JT-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_42JT-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
42JT	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
42JT	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_42JT_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42JT_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_42JT_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42JT_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42JT_Type1_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_42JT_5032_(3.2)
		RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42JT_Type2_5032_(3.2)	
RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_42JT_Type3_5032_(3.2)			


Device Definition (raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...



2. Specify the Application Specific Name e.g. 42JT_101




Device Definition (raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)

- Configure the parameters of sensor from configuration tab from AOP of the 42JT sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data (raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_42JT_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_Ctrl_Inf	IO-Link Device Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	IO-Link Device Command, Status Interface	raC_UDT_ItfAD_IOLinkDevices
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[20]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_42JT_Inp_4IOL Or raC_UDT_ItfAD_42JT_Inp_8IOL

Input Data

Input	Function/Description	Data Type
Cfg_Gain	Gain; 0 = Low, 1 = High	SINT
Cfg_LightSource	Light Source; 0 = OFF, 1 = ON	SINT
Cfg_OutputPolarityInverted	Polarity; 0 = Inverted, 1 = Not Inverted	SINT
Cmd_DynamicTeachStart	Dynamic Teach Start Command	BOOL
Cmd_DynamicTeachStop	Dynamic Teach Stop Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_PrecisionTeach	Precision Teach Command	BOOL
Cmd_StaticTeachShowBackground	Static Teach Background Command	BOOL
Cmd_StaticTeachShowTarget	Static Teach Mark Command	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachCancel	Teach Cancel Command	BOOL
Cmd_TeachModeStart	Teach Mode Start Command	BOOL
Set_Setpoint	Enter Setpoint Value To Turn ON Sensor Output	BOOL
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Inp_ChxMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Val_Gain	Gain Status; 0 = Low, 1 = High	INT
Val_LightSource	Light Source Status; 0 = OFF, 1 = ON	DINT
Val_OutputPolarityInverted	Polarity Status; 0 = Inverted, 1 = Not Inverted	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Setpoint	Setpoint Value To Turn ON Sensor Output	DINT
Val_TeachMode	Teach Mode Status; 0 = Static, 1 = Dynamic, 2 = Precision	INT
Val_TeachStep	Teach Step	INT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_42JT_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ltfAD_IOLinkSensor_CtrlSet

InOut	Function / Description	Data Type
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_Ctrl_Inf	IO-Link Device Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	IO-Link Device Command, Status	raC_UDT_ItfAD_IOLinkDevices
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_42JT_Inp_5032
Cfg_C	Device Object Configuration	raC_UDT_IOLink_42JT_Type1_Cfg or raC_UDT_IOLink_42JT_Type2_Cfg or raC_UDT_IOLink_42JT_Type3_Cfg

Input Data

Input	Function/Description	Data Type
Cfg_Gain	Gain; 0 = Low, 1 = High	SINT
Cfg_LightSource	Light Source; 0 = OFF, 1 = ON	SINT
Cfg_OutputPolarityInverted	Polarity; 0 = Inverted, 1 = Not Inverted	SINT
Cmd_DynamicTeachStart	Dynamic Teach Start Command	BOOL
Cmd_DynamicTeachStop	Dynamic Teach Stop Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_PrecisionTeach	Precision Teach Command	BOOL
Cmd_StaticTeachShowBackground	Static Teach Background Command	BOOL
Cmd_StaticTeachShowTarget	Static Teach Mark Command	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachCancel	Teach Cancel Command	BOOL
Cmd_TeachModeStart	Teach Mode Start Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Set_Setpoint	Enter Setpoint Value To Turn ON Sensor Output	BOOL
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Inp_ChxMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL


Output	Function/Description	Data Type
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_Gain	Gain Status; 0 = Low, 1 = High	INT
Val_LightSource	Light Source Status; 0 = OFF, 1 = ON	DINT
Val_OutputPolarityInverted	Polarity Status; 0 = Inverted, 1 = Not Inverted	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Setpoint	Setpoint Value To Turn ON Sensor Output	DINT
Val_TeachMode	Teach Mode Status; 0 = Static, 1 = Dynamic, 2 = Precision	INT
Val_TeachStep	Teach Step	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 42JT device object connected to channel #9 of a POINT I/O 1734-4IOL IO-Link Master module in slot #1 of a POINT I/O adapter named *_AdapterName*.




The following example uses the 42JT device object connected to channel #2 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.




The following example uses the 42JT Sensor Type 1 device object connected to channel #12 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_1*.



The following example uses the 42JT Sensor Type 2 device object connected to channel #14 of a ArmorBlock 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_1*.



The following example uses the 42JT Sensor Type 3 device object connected to channel #0 of a ArmorBlock 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_2*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_LightSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_42JT_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates

There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#)


The faceplate title is linked to `_InstanceName.@description`, the `.@description` extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Name	Description	Usage	Data Type
▶ Sensor_102	Sensor 102	Local	raC_Dvc_42JT_8IOL
▶ Sensor_102_Inp_I	Sensor_102 Input Interface	Local	rac_UDT_ItfAD_42JT_Inp_8IOL
▶ Sensor_102_CtrlCmd	Sensor_102 Command Interface	Public	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
▶ Sensor_102_CtrlSet	Sensor_102 Setting Interface	Public	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
▶ Sensor_102_CtrlSts	Sensor_102 Status Interface	Public	raC_UDT_ItfAD_IOLinkSensor_CtrlSts

Name	Usage	Alias For	Base Tag	Data Type	Description
▶ Sensor_42JT_Type3_Inp_I	Local			raC_UDT_IOLink_42JT_Inp_5032	Sensor_42JT_Type3 Input Interface
▶ Sensor_42JT_Type3_Cfg_C	Local			raC_UDT_IOLink_42JT_Type3_Cfg	Sensor_42JT_Type3 Configuration Interface
▶ Sensor_42JT_Type3	Local			raC_Dvc_42JT_Type3_5032	Sensor_42JT_Type3
▶ Sensor_42JT_Type2_Inp_I	Local			raC_UDT_IOLink_42JT_Inp_5032	Sensor_42JT_Type2 Input Interface
▶ Sensor_42JT_Type2_Cfg_C	Local			raC_UDT_IOLink_42JT_Type2_Cfg	Sensor_42JT_Type2 Configuration Interface
▶ Sensor_42JT_Type2	Local			raC_Dvc_42JT_Type2_5032	Sensor_42JT_Type2
▶ Sensor_42JT_Type1_Inp_I	Local			raC_UDT_IOLink_42JT_Inp_5032	Sensor_42JT_Type1 Input Interface
▶ Sensor_42JT_Type1_Cfg_C	Local			raC_UDT_IOLink_42JT_Type1_Cfg	Sensor_42JT_Type1 Configuration Interface
▶ Sensor_42JT_Type1	Local			raC_Dvc_42JT_Type1_5032	Sensor_42JT_Type1

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.



Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Configure Tab


The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Local Settings
- Teach Settings
- Configuration Apply Settings



In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Item	Description
1	Setpoint: This parameter allows you to enter the threshold of when the sensor output turns ON. Valid setpoint ranges vary by specific sensor type: 42JT-D2x: 20...1000 42JT-P2x: 60...1000 42JT-B2LAT2x: 0...25000 42JT-B2LAT1x: 0...28000 42JT-B8LAT1x: 0...31700
2	Output Polarity: Polarity changes the sensor output to operate as Light On (Non Inverted) and Dark On (Inverted).
3	Light Source: Turn the sensor Light Source ON or OFF.
4	Teach Settings: Launch the teach settings window.
5	Gain: Current gain level of the sensor to operate in high or low conditions. A high gain helps ensure that the sensor is able to detect targets with good reflectivity at longer ranges or verify that targets with low reflectivity are also detected at shorter ranges.
6	Local Teach Unlock/Lock Toggle Switch: Locks unauthorized people from changing the sensor settings using the local device push buttons. Toggle the lock/unlock button to prevent parameterization using local push buttons.

Teach Settings


Teach Settings display includes the Teach Methods, Teach Command & Teach Cancel buttons. Touch on the Teach Settings navigation button to access the Teach Settings tab.

Teach tab includes the following functions:

- Teach mode selection drop-down menu (Static/Dynamic/Precision)
- Teach procedure flow buttons
- Teach cancel button


The operator must complete each stage to teach sensor successfully. During the teach process the operator must complete the current stage prior to the next stage being made available to operator. At any stage of teaching, the

process can be canceled by pressing cancel button. When operator cancels the teach process, all completed stages are cleared and the teach process will restart from initial stage.



Item	Description
1	Teach Mode: - Static - Dynamic - Precision Teach
2	Teach procedure flow buttons
3	Teach setting window close button
4	Cancel: To cancel the procedure, you can send the "Teach Cancel" command at any point.


Teach mode - This parameter selects the desired mode.




Static Teach - The first method is Static Teach, which is intended for applications where the web can be stopped, or for more challenging applications.

1. Place the target in front of the sensor and send the command to **"Static Teach - Show Target"**.
2. Show the background where the target will be present and then send the command **"Static Teach - Show Background"**.

- To cancel the procedure, you can send the **“Teach Cancel”** command at any point.



Dynamic Teach - The second method is Dynamic Teach, which is intended for applications where the web can be Running.



Precision Teach - The Precision Teach is intended for applications where the precise setting of the distance is more critical. This teach method is also recommended for contrast applications.

- Place the target in front of the sensor and send the command to **“Precision Teach – Show Target”**.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_42JT_4IOL, raC_Dvc_42JT_8IOL, raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_42JT_4IOL, raC_LD_Dvc_42JT_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_Dvc_42JT_Type1_5032, raC_Dvc_42JT_Type2_5032, raC_Dvc_42JT_Type3_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 42JT), This name depends upon the TagName assigned to object.
SensorType	42JT-B2LAT1-xx	42JT-B2LAT1-xx	42JT-B2LAT1-xx	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_42JT_4IOL	raC_Dvc_42JT_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_42JT_8IOL	raC_Dvc_42JT_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_42JT_Type1_5032 Or raC_Dvc_42JT_Type2_5032 Or raC_Dvc_42JT_Type3_5032	raC_Dvc_42JT_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_42JT	Faceplate ME	(raC-3_xx-ME) raC_Dvc_42JT-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_42JT	Faceplate SE	(raC-3_xx-SE) raC_Dvc_42JT-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

871FM - Mini Flat Pack Sensor (raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL, raC_Dvc_871FM_Type1_5032, raC_Dvc_871FM_Type2_5032)

Overview

The 871FM Mini Flat Pack Sensor device object (raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL, raC_Dvc_871FM_Type1_5032, raC_Dvc_871FM_Type2_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor diagnostics
- Sensor configuration and parameters
- Process data trending
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_871FM_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).

Functional Description

The 871FM Mini Flat Pack Sensor Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with four versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
871FM	POINT I/O 1734-4IOL	871FM-M10BA30-xxxx, 871FM-M7BA20-xxxx, 871FM-MV10BA30-xxxx, 871FM-MV7BA20-xxxx 871FM-M1NP5-AP3, 871FM-M1NP5-E2, 871FM-M2NP5-AP3, 871FM-M2NP5-E2, 871FM-M2NP8-E2, 871FM-M2NP8-P3	raC_Dvc_871FM_4IOL_3.02_AOI.L5X	raC_Dvc_871FM_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	871FM-M10BA30-xxxx, 871FM-M7BA20-xxxx, 871FM-MV10BA30-xxxx, 871FM-MV7BA20-xxxx 871FM-M1NP5-AP3, 871FM-M1NP5-E2, 871FM-M2NP5-AP3, 871FM-M2NP5-E2, 871FM-M2NP8-E2, 871FM-M2NP8-P3	raC_Dvc_871FM_8IOL_3.02_AOI.L5X	raC_Dvc_871FM_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	871FM-M10BA30-xxxx, 871FM-M7BA20-xxxx, 871FM-MV10BA30-xxxx, 871FM-MV7BA20-xxxx 871FM-M1NP5-AP3, 871FM-M1NP5-E2, 871FM-M2NP5-AP3, 871FM-M2NP5-E2, 871FM-M2NP8-E2, 871FM-M2NP8-P3	raC_Dvc_871FM_Type1_5032_3.02_AOI.L5X raC_Dvc_871FM_Type2_5032_3.02_AOI.L5X	raC_Dvc_871FM_Type1_5032_3.02_RUNG.L5X raC_Dvc_871FM_Type2_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
871FM	Display	(raC-3_02-ME) raC_Dvc_871FM-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_871FM-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
871FM	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
871FM	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871FM_4IOL(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871FM_4IOL(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871FM_8IOL(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871FM_8IOL(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871FM_Type1_5032(3.2) (RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871FM_Type2_5032(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871FM_8IOL(3.2)


Device Definition (raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




2. Specify the Application Specific Name e.g. *MetalDetect_101*
3. Select the Process Data Input as *Triggered, Margin, Proximity, Gain, Signal*.



Device Definition (raC_Dvc_871FM_Type1_5032, 2, raC_Dvc_871FM_Type2_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link for Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 871FM, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 871FM Sensor.



3. Configure the parameters of sensor from configuration tab from AOP of the 871FM sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data

(raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_871FM_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_871FM_Inp_4IOL Or raC_UDT_ItfAD_871FM_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Inp_ChXMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity Alarm of Sensor	BOOL
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxSignalStrength	Signal Strength of Sensor	DINT
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_OutputPolarity	Set Output Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_ResetCount	Counter Reset Command	BOOL
Cmd_ResetDurations	Duration Reset Command	BOOL
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_EnableLEDs	LED Indicator; 0 = Disable, 1 = Enable	BOOL
Sts_InhibitCfg	1 = Inhibit user Configuration Parameters from HMI Faceplate; 0 = Allow	BOOL
Sts_InhibitCmd	1 = Inhibit user Configuration Parameters from HMI Faceplate; 0 = Allow	BOOL
Sts_InhibitSet	1 = Inhibit user Settings from HMI Faceplate; 0 = Allow	BOOL
Sts_Located	Locator Indicator; 1 = Located	BOOL
Val_Contrast	Sensor Contrast Level	INT
Val_NotTriggeredDuration	Sensor Output OFF Duration	DINT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_OperatingHrsSincePowerUp	Operating Hours Since Power Up	DINT
Val_OutputPolarity	Output Polarity Status, 0 = Not Inverted, 1 = Inverted	SINT
Val_PercentSP	Setpoint in Percent	DINT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Setpoint	Setpoint Value To Turn ON Sensor Output	INT
Val_TemperatureCurrent	Internal Temperature Of Sensor	INT
Val_TemperatureMaxSinceInception	Maximum Temperature Since Inception	INT
Val_TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	INT
Val_TemperatureMinSinceInception	Minimum Temperature Since Inception	SINT
Val_TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	INT
Val_Trigger_Counter	Sensor Counter Value	DINT
Val_TriggeredDuration	Sensor Output ON Duration	DINT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_871FM_Type1_5032, raC_Dvc_871FM_Type2_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_871FM_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_871FM_Type1_Inp_5032 Or raC_UDT_IOLink_871FM_Type2_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_871FM_Type1_Cfg Or raC_UDT_IOLink_871FM_Type2_Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Inp_ChXMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity Alarm of Sensor	BOOL
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxSignalStrength	Signal Strength of Sensor	DINT
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_OutputPolarity	Set Output Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_ResetCount	Counter Reset Command	BOOL
Cmd_ResetDurations	Duration Reset Command	BOOL

Input	Function/Description	Data Type
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_Contrast	Sensor Contrast Level	INT
Val_NotTriggeredDuration	Sensor Output OFF Duration	DINT
Val_TriggeredDuration	Sensor Output ON Duration	DINT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_OperatingHrsSincePowerUp	Operating Hours Since Power Up	DINT
Val_OutputPolarity	Output Polarity Status, 0 = Not Inverted, 1 = Inverted	SINT
Val_PercentSP	Setpoint in Percent	DINT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Setpoint	Setpoint Value To Turn ON Sensor Output	INT
Val_TemperatureCurrent	Internal Temperature Of Sensor	INT
Val_TemperatureMaxSinceInception	Maximum Temperature Since Inception	INT
Val_TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	INT
Val_TemperatureMinSinceInception	Minimum Temperature Since Inception	SINT
Val_TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	INT


Output	Function/Description	Data Type
Val.Trigger_Counter	Sensor Counter Value	DINT
Val.TriggeredDuration	Sensor Output ON Duration	DINT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example

Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 871FM device object connected to channel #0 of a POINT I/O 1734-4IOL IO-Link Master module in slot #7 of a POINT I/O adapter named *Rack01*.



The following example uses the 871FM device object connected to channel #1 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 871FM Type1 Sensor device object connected to channel #0 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_3*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_IndSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_871FM_Launch		<p>The supplied launch button in View Designer is used to navigate to the faceplate in a user application.</p>	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Sensor871FM_102	Sensor 102
▶ Sensor871FM_102_CtrlCmd	Sensor871FM_102 Command Interface
▶ Sensor871FM_102_CtrlSet	Sensor871FM_102 Setting Interface
▶ Sensor871FM_102_CtrlSts	Sensor871FM_102 Status Interface
▶ Sensor871FM_102_Inp_I	Sensor871FM_102 Input Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Signal Strength (%) Sparkline Trend The spark line shows the signal strength value over last 30 seconds
6	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
7	Process Data - Triggered Duration (ms): Displays the amount of time that the sensor output has been ON. To show the trigger duration on faceplate, required to make Timer Mode Enabled setting in AOP in Logix Designer. - Not Triggered Duration (ms): Displays the amount of time that the sensor output has been OFF. To show the trigger duration on faceplate, required to make Timer Mode Enabled setting in AOP in Logix Designer. - Trigger Counter: Displays the sensor counter value when enabled. The counter value increments every time the sensor is triggered this process data element can count up to 65535 and can be reset via reset count button from config tab. Refer to Appendix B for additional information about index. To show the trigger count on faceplate, required to make Counter Mode Enabled setting in AOP in Logix Designer. - Signal Strength (%): Signal Strength provides the raw measurement value of the amount of light reflected from the target. - Contrast: Displays the difference between the light signal levels that the sensor read the last time the output was ON versus the last time the output was OFF. - Gain: Displays the excess gain above the sensor threshold to ensure reliable detection of the target.



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Internal Temperature Bar Graph Green Indicators: Min/Max since inception (lifetime) Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Internal Temperature Current Value
3	Operating Hours Since Inception (lifetime)
4	Operating Hours Since Power Up



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.

Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. One trend is displayed for Setpoint and Signal Strength.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Setpoint & Signal strength.



Configure Tab

The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.


The configuration section is divided into sections:

- Parameter Settings
- Local Settings

- Configuration Apply Settings



In case of 5032 Master, “Config Apply” Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Parameter Settings

Output Polarity - Polarity changes the sensor output to operate as Not Inverted (Light On) and Inverted (Dark On). Click on output polarity drop-down selector object to switch between Light On & Dark On.

Trigger Settings

Reset Count - Allows users to reset the counter function, it will reset the sensor counts to zero.

Reset Duration - Allows users to reset the timer function, it will reset Duration Triggered & Duration Not Triggered time.


Local Settings

Disable/Enable LEDs - This parameter allows operators to turn OFF or turn ON the User Interface LEDs (green and orange LEDs). This parameter is ideal for applications where turning OFF the LEDs is desired to accommodate the application.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_871FM_4IOL, raC_Dvc_871FM_8IOL, raC_Dvc_871FM_Type1_5032, raC_Dvc_871FM_Type2_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_871FM_4IOL, raC_LD_Dvc_871FM_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
SensorType				Select the sensor type as per version of the device.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_871FM_Type1_5032, raC_LD_Dvc_871FM_Type2_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 871FM), This name depends upon the TagName assigned to object.
SensorType	871FM-M10BA30-xxxx	871FM-M10BA30-xxxx	871FM-M10BA30-xxxx	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_871FM_4IOL	raC_Dvc_871FM_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_871FM_8IOL	raC_Dvc_871FM_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_871FM_Type1_5032 Or raC_Dvc_871FM_Type2_5032	raC_Dvc_871FM_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
-------------	---------------	-------------

Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_871FM	Faceplate ME	(raC-3_xx-ME) raC_Dvc_871FM-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_871FM	Faceplate SE	(raC-3_xx-SE) raC_Dvc_871FM-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

871C - Mini Tubular Sensor (raC_Dvc_871C_4IOL, raC_Dvc_871C_8IOL, raC_Dvc_871C_5032)

Overview

The 871C Mini Tubular Sensor device object (raC_Dvc_871C_4IOL, raC_Dvc_871C_8IOL, raC_Dvc_871C_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Diagnostic Data
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_871C_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Timer Settings:** This function helps to manipulating the output of the sensor in relation to timing. It is useful for precision applications where the output of the sensor must be precisely triggered at a certain time.

Functional Description

The 871C Mini Tubular Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the /Studio 5000 Logix Designer Files - L5X/ folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
871C	POINT I/O 1734-4IOL	871C-D1NP4-AP3, 871C-DM1NP3-AP3, 871C-DM1NP4-AP3, 871C-M1NP4-AP3, 871C-MM1NP3-AP3 871C-D1NP4-E2, 871C-D1NP5-E2, 871C-DM1NP3-E2, 871C-DM1NP4-E2, 871C-M1NP4-E2, 871C-M1NP5-E2, 871C-MM1NP3-E2, 871C-MM1NP4-E2 871C-D1NP5-P3, 871C-DM1NP4-P3, 871C-M1NP5-P3, 871C-MM1NP4-P3	raC_Dvc_871C_4IOL_3.02_AOI.L5X	raC_Dvc_871C_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	871C-D1NP4-AP3, 871C-DM1NP3-AP3, 871C-DM1NP4-AP3, 871C-M1NP4-AP3, 871C-MM1NP3-AP3 871C-D1NP4-E2, 871C-D1NP5-E2, 871C-DM1NP3-E2, 871C-DM1NP4-E2, 871C-M1NP4-E2, 871C-M1NP5-E2, 871C-MM1NP3-E2, 871C-MM1NP4-E2 871C-D1NP5-P3, 871C-DM1NP4-P3, 871C-M1NP5-P3, 871C-MM1NP4-P3	raC_Dvc_871C_8IOL_3.02_AOI.L5X	raC_Dvc_871C_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	871C-D1NP4-AP3, 871C-DM1NP3-AP3, 871C-DM1NP4-AP3, 871C-M1NP4-AP3, 871C-MM1NP3-AP3 871C-D1NP4-E2, 871C-D1NP5-E2, 871C-DM1NP3-E2, 871C-DM1NP4-E2, 871C-M1NP4-E2, 871C-M1NP5-E2, 871C-MM1NP3-E2, 871C-MM1NP4-E2 871C-D1NP5-P3, 871C-DM1NP4-P3, 871C-M1NP5-P3, 871C-MM1NP4-P3	raC_Dvc_871C_5032_3.02_AOI.L5X	raC_Dvc_871C_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the /HMI FactoryTalk View Images - png/ folder of the library. FactoryTalk View

ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
871C	Display	(raC-3_02-ME) raC_Dvc_871C-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_871C-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
871C	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
871C	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871C_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871C_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871C_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871C_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871C_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871C_5032_(3.2)

Device Definition (raC_Dvc_871C_410L, raC_Dvc_871C_810L)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...



2. Apply the following Channel Configuration for 871C.

Channel	Mode	Vendor	Device	Application Specific Name	Electronic Keying	Process Data Input	Data Storage	Change Device
0	IO-Link	Allen-Bradley	871C-MM1NP3-AP3		Exact M... ▾		Enable ADC ▾	...
1	IO-Link	Allen-Bradley	871C-D1NP4-E2		Exact M... ▾		Enable ADC ▾	...
2	IO-Link							...
3	IO-Link							...
4	IO-Link							...
5	IO-Link							...
6	IO-Link							...
7	IO-Link							...

Discover Devices... Path: Unable to display. Project has not been online yet. OK Cancel

Device Definition (raC_Dvc_871C_5032)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)

The screenshot displays the Logix Designer interface for configuring a 5032-8IOLM12M12LDR/A Mod_Master5032 module. The 'Module Properties' dialog is open, showing the 'General' tab. The 'Change...' button is highlighted. The 'Module Definition' table is visible, showing channel configurations for ports 0 through 7.

Port	Channel	IO-Link Class B Enabled	Channel Mode	Channel Mode Types		
				DI	DO	IO-Link
0	0		IO-Link	✓	✓	✓
0	1		Digital Output, Short Circuit, No Load	✓	✓	✓
1	2		IO-Link	✓	✓	✓
1	3		Digital Input	✓	✓	✓
2	4	<input type="checkbox"/>	IO-Link	✓	✓	✓
2	5	<input type="checkbox"/>	Disabled	✓	✓	✓
3	6	<input type="checkbox"/>	IO-Link	✓	✓	✓
3	7	<input type="checkbox"/>	Disabled	✓	✓	✓
4	8	<input type="checkbox"/>	IO-Link	✓	✓	✓
4	9	<input type="checkbox"/>	Disabled	✓	✓	✓
5	10	<input type="checkbox"/>	IO-Link	✓	✓	✓
5	11	<input type="checkbox"/>	Disabled	✓	✓	✓
6	12	<input type="checkbox"/>	IO-Link	✓	✓	✓
6	13	<input type="checkbox"/>	Disabled	✓	✓	✓
7	14	<input type="checkbox"/>	IO-Link	✓	✓	✓
7	15	<input type="checkbox"/>	Disabled	✓	✓	✓




Note: If Sensor is Class B, Then, User should select the IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 871C, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 871C Sensor.

- ▲ I/O Configuration
 - ▲ 1756 Backplane, 1756-A7
 - ▢ [0] 1756-L85E Master_5032_Test_Cases
 - ▲ Ethernet
 - ▢ 1756-L85E Master_5032_Test_Cases
 - ▢ 5032-8IOLM12M12LDR/A Mod_Master_5032_1
 - ▢ 5032-8IOLM12M12LDR/A Mod_Master_5032_2
 - ▲ 5032-8IOLM12M12LDR/A Mod_Master_5032_3
 - ▲ IO-Link
 - ▢ 0 836P-D1xxxA36PP-D4 (182) Mod_836P_Type2
 - ▢ 2 837T-D3xxxxxxxPA-D4 (207) Mod_837T_Type1
 - ▢ 4 837T-D3xxxxxxxPP-D4 (206) Mod_837T_Type2
 - ▢ 6 856T-B24LC (297) Mod_856T
 - ▢ 8 871C-D1NP4-AP3 (80) Mod_871C
 - ▢ 10 871FM-M10BA30-xxxx (200) Mod_871FM_Type1
 - ▢ 12 871FM-M1NP5-AP3 (129) Mod_871FM_Type2
 - ▢ 14 871TM-M10NP18-A2 (101) Mod_871TM

- Configure the parameters of sensor from configuration tab from AOP of the 871C sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data (raC_Dvc_871C_410L, raC_Dvc_871C_810L)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_871C_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_871C_Inp_410L Or raC_UDT_ItfAD_871C_Inp_810L
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChXTriggered	Triggered Status of Sensor	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_BaseTime	Set Time Base for setting delay; 0= 0.1 ms, 1 = 0.4 ms, 2 = 1.6 ms, 3 = 6.4 ms	DINT
Cfg_TimerMode	Set the Timer Mode; 0 = No Timer, 1 = Off Delay, 2 = On Delay, 3 = On Delay and Off Delay	DINT
Set_Multiplier	Set Multiplier for setting delay; 0 to 63	INT
Cmd_ResetCount	Counter Reset Command	BOOL

Output Data

Output	Function/Description	Data Type
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Active	Device active status: 1 = output power structure is active	BOOL

Output	Function/Description	Data Type
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Val_BaseTime	Value for Time Base for setting delay; 0=0.1ms, 1 = 0.4 ms, 2 = 1.6 ms, 3 = 6.4 ms	INT
Val_Counter	Sensor Counter Value	INT
Val_Multiplier	Value of Multiplier for setting delay; 0 to 255	INT
Val_TimerMode	Value of the Timer Mode; 0 = No Timer, 1 = Off Delay, 2 = On Delay, 3 = On Delay and Off Delay	INT
Val_TemperatureCurrent	Actual internal Sensor Temperature	REAL
Val_TemperatureMaxSinceInception	Maximum internal sensor temperature over whole sensor lifetime	REAL
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_871C_5032) InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_871C_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_871C_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_871C_Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChXTriggered	Triggered Status of Sensor	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_BaseTime	Set Time Base for setting delay; 0= 0.1 ms, 1 = 0.4 ms, 2 = 1.6 ms, 3 = 6.4 ms	DINT
Cfg_TimerMode	Set the Timer Mode; 0 = No Timer, 1 = Off Delay, 2 = On Delay, 3 = On Delay and Off Delay	DINT
Set_Multiplier	Set Multiplier for setting delay; 0 to 63	INT
Cmd_ResetCount	Counter Reset Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL

Output Data

Output	Function/Description	Data Type
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL


Output	Function/Description	Data Type
Sts_Ready	Device is Ready	BOOL
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_BaseTime	Value for Time Base for setting delay; 0= 0.1 ms, 1 = 0.4 ms, 2 = 1.6 ms, 3 = 6.4 ms	INT
Val_Counter	Sensor Counter Value	INT
Val_Multiplier	Value of Multiplier for setting delay; 0 to 255	INT
Val_TimerMode	Value of the Timer Mode; 0 = No Timer, 1 = Off Delay, 2 = On Delay, 3 = On Delay and Off Delay	INT
Val_TemperatureCurrent	Actual internal Sensor Temperature	REAL
Val_TemperatureMaxSinceInception	Maximum internal sensor temperature over whole sensor lifetime	REAL
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 871C device object connected to channel #3 of a POINT I/O 1734-4IOL IO-Link Master module in slot #5 of a POINT I/O adapter named *Rack01*.



The following example uses the 871C device object connected to channel #0 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 871C device object connected to channel #0 of a 5032-8IOLM12.M12LDR/A IO-Link Master module in named *Mod_Master_5032_3*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_IndSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
A0G_871C_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Sensor871C_101	Sensor 101
▶ Sensor871C_101_Inp_I	Sensor871C_101 Input Interface
▶ Sensor871C_101_CtrlCmd	Sensor871C_101 Command Interface
▶ Sensor871C_101_CtrlSet	Sensor871C_101 Setting Interface
▶ Sensor871C_101_CtrlSts	Sensor871C_101 Status Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data.




Item	Description
1	Banner- Ready Status
2	Sensor Name
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Trigger Counter



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.



Item	Description
1	Provides maximum internal sensor temperature over the sensor lifetime.
2	Live internal sensor temperature when read.

Configure Tab


The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section include

- Parameter Settings
- Configuration Apply Settings



In case of 5032 Master, "[Config Apply](#)" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Base Time- While sensing the Target if user wants to add Time delay, it is added with combination of base time and multiplier. Here unit of Base time is milliseconds. Click on Base Time drop-down selector object to select different Base times like 0.1, 0.4, 1.6 and 6.4

Multiplier- While counting the object if user wants to add Time delay, it is added with combination of base time and multiplier. This parameter allows you to enter the Multiplier values.


Mode- The switching timer is a useful function for manipulating the output of the sensor in relation to timing. It is useful for precision applications where the output of the sensor must be precisely triggered at a certain time. Click on Mode drop-down selector object to select different Timer modes like No Timer, Off Delay, On Delay and On Delay and Off Delay

Reset Count - Allows users to reset the counter function, it will reset the sensor counts to zero


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_871C_410L, raC_Dvc_871C_810L

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_871C_410L, raC_LD_Dvc_871C_810L, raC_LD_Dvc_871C_5032

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_871C_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag

RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReferance		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 871C), This name depends upon the TagName assigned to object.
SensorType	871C-D1NP4-AP3	871C-D1NP4-AP3	871C-D1NP4-AP3	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_871C_410L	raC_Dvc_871C_410L	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_871C_810L	raC_Dvc_871C_810L	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_871C_5032	raC_Dvc_871C_810L	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_871C	Faceplate ME	(raC-3_xx-ME) raC_Dvc_871C-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_871C	Faceplate SE	(raC-3_xx-SE) raC_Dvc_871C-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

871TM - Tubular Stainless Steel Sensor (raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL, raC_Dvc_871TM_5032)

Overview

The 871TM Tubular Stainless Steel Sensor device object (raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL, raC_Dvc_871TM_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: "Operational_Overview_of_871TM_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Timer Settings:** This function helps to manipulating the output of the sensor in relation to timing. It is useful for precision applications where the output of the sensor must be precisely triggered at a certain time.

Functional Description

The 871TM Tubular Stainless Steel Sensor Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
871TM	POINT I/O 1734-4IOL	871TM-M10NP18-A2, 871TM-M10NP18-D4, 871TM-M2ONP30-A2, 871TM-M2ONP30-D4 871TM-M3NP8-D4, 871TM-M3NP8-D4 871TM-M3NP8-J2, 871TM-M3NP8-P3 871TM-M6NP12-A2, 871TM-M6NP12-A7, 871TM-M6NP12-D4, 871TM-M6NP8-J2 871TM-M10NP12-A2, 871TM-M10NP12-D4 871TM-M2ONP18-A2, 871TM-M2ONP18-D4 871TM-M4ONP30-A2, 871TM-M4ONP30-D4 871TM-N6NP8-D4, 871TM-N6NP8-P3	raC_Dvc_871TM_4IOL_3.02_AOI.L5X	raC_Dvc_871TM_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	871TM-M10NP18-A2, 871TM-M10NP18-D4, 871TM-M2ONP30-A2, 871TM-M2ONP30-D4 871TM-M3NP8-D4, 871TM-M3NP8-D4 871TM-M3NP8-J2, 871TM-M3NP8-P3 871TM-M6NP12-A2, 871TM-M6NP12-A7, 871TM-M6NP12-D4, 871TM-N6NP8-J2 871TM-M10NP12-A2, 871TM-M10NP12-D4 871TM-M2ONP18-A2, 871TM-M2ONP18-D4 871TM-M4ONP30-A2, 871TM-M4ONP30-D4 871TM-N6NP8-D4, 871TM-N6NP8-P3	raC_Dvc_871TM_8IOL_3.02_AOI.L5X	raC_Dvc_871TM_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	871TM-M10NP18-A2, 871TM-M10NP18-D4, 871TM-M2ONP30-A2, 871TM-M2ONP30-D4 871TM-M3NP8-D4, 871TM-M3NP8-D4 871TM-M3NP8-J2, 871TM-M3NP8-P3 871TM-M6NP12-A2, 871TM-M6NP12-A7, 871TM-M6NP12-D4, 871TM-N6NP8-J2 871TM-M10NP12-A2, 871TM-M10NP12-D4 871TM-M2ONP18-A2, 871TM-M2ONP18-D4 871TM-M4ONP30-A2, 871TM-M4ONP30-D4 871TM-N6NP8-D4, 871TM-N6NP8-P3	raC_Dvc_871TM_5032_3.02_AOI.L5X	raC_Dvc_871TM_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and

FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
871TM	Display	(raC-3_02-ME) raC_Dvc_871TM-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_871TM-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
871TM	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
871TM	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871TM_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871TM_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871TM_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871TM_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_871TM_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_871TM_5032_(3.2)

Device Definition (raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...



2. Apply the following Channel Configuration for 871TM.


Channel	Mode	Vendor	Device	Application Specific Name	Electronic Keying	Process Data Input	Data Storage	Change Device
0	IO-Link	Allen-Bradley	871TM-M3NP8-D4		Exact M...		Enable ADC	...
1	IO-Link	Allen-Bradley	871TM-N20NP18-A2		Exact M...		Enable ADC	...
2	IO-Link							...
3	IO-Link							...
4	IO-Link							...
5	IO-Link							...
6	IO-Link							...
7	IO-Link							...

Discover Devices... Path: Unable to display. Project has not been online yet. OK Cancel

Device Definition (raC_Dvc_871TM_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 871TM, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 871TM Sensor.



3. Configure the parameters of sensor from configuration tab from AOP of the 871TM sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data (raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_871TM_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inf_Lookup_HEX	List Entry for Timer and Multiplier Selection	raC_UDT_Hex_Code_LookupMember[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_871TM_Inp_4IOL Or raC_UDT_ItfAD_871TM_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChXTriggered	Triggered Status of Sensor	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_BaseTime	Set Time Base for setting delay; 0= 0.1 ms, 1 = 0.4 ms, 2 = 1.6 ms, 3 = 6.4 ms	INT
Cfg_Enable	Set for Enabling Timer Modes; 0 = ON, 1 = OFF	DINT
Cfg_TimerMode	Set the Timer Mode; 0 = No Timer, 1 = Off Delay, 2 = On Delay, 3 = On Delay and Off Delay	SINT
Set_Multiplier	Set Multiplier for setting delay; 0 to 63	INT
Cmd_ResetDurations	Duration Reset Command	BOOL

Output Data

Output	Function/Description	Data Type
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL

Output	Function/Description	Data Type
Sts_Ready	Device is Ready	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Val_BaseTime	Value for Time Base for setting delay; 0= 0.1 ms, 1= 0.4 ms, 2 = 1.6 ms, 3 = 6.4 ms	INT
Val_Enable	Value for Enabling Timer Modes; 0 = ON, 1 = OFF	DINT
Val_Counter	Sensor Counter Value	INT
Val_TimerMode	Value of the Timer Mode; 0 = No Timer, 1 = Off Delay, 2 = On Delay, 3 = On Delay and Off Delay	INT
Val_TemperatureCurrent	Actual internal Sensor Temperature	REAL
Val_TemperatureMaxSinceInception	Maximum internal sensor temperature over whole sensor lifetime	REAL
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_871TM_5032) InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_871TM_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_871TM_Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChXTriggered	Triggered Status of Sensor	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_BaseTime	Set Time Base for setting delay; 0= 0.1 ms, 1 = 0.4 ms, 2 = 1.6 ms, 3 = 6.4 ms	INT
Cfg_Enable	Set for Enabling Timer Modes; 0 = ON, 1 = OFF	DINT
Cfg_TimerMode	Set the Timer Mode; 0 = No Timer, 1 = Off Delay, 2 = On Delay, 3 = On Delay and Off Delay	SINT
Set_Multiplier	Set Multiplier for setting delay; 0 to 63	INT
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL

Output Data

Output	Function/Description	Data Type
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT


Output	Function/Description	Data Type
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_BaseTime	Value for Time Base for setting delay; 0= 0.1 ms, 1 = 0.4 ms, 2 = 1.6 ms, 3 = 6.4 ms	INT
Val_Enable	Value for Enabling Timer Modes; 0 = ON, 1 = OFF	SINT
Val_TimerMode	Value of the Timer Mode; 0 = No Timer, 1 = Off Delay, 2 = On Delay, 3 = On Delay and Off Delay	SINT
Val_Multiplier	Value of Multiplier for setting delay; 0 to 63	SINT
Val_TemperatureMaxSinceInception	Maximum internal sensor temperature over whole sensor lifetime	REAL
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 871TM device object connected to channel #3 of a POINT I/O 1734-4IOL IO-Link Master module in slot #5 of a POINT I/O adapter named *Rack01*.



The following example uses the 871TM device object connected to channel #1 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 871TM device object connected to channel #14 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_3*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {::[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_IndSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {::[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_871TM _Launch		<p>The supplied launch button in View Designer is used to navigate to the faceplate in a user application.</p>	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Sensor871TM_102	Sensor 102
▶ Sensor871TM_102_CtrlCmd	Sensor871TM_102 Command Interface
▶ Sensor871TM_102_CtrlSet	Sensor871TM_102 Setting Interface
▶ Sensor871TM_102_CtrlSts	Sensor871TM_102 Status Interface
▶ Sensor871TM_102_Inp_I	Sensor871TM_102 Input Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data.



Item	Description
1	Banner- Ready Status
2	Sensor Name
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds


Configure Tab

The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section include Timer Settings.



In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Enable- The enable parameter must be ON to enable the switching timer mode. In Off mode the timer setting parameters are disable.

Base Time- While sensing the Target if user wants to add Time delay, it is added with combination of base time and multiplier. Here unit of Base time is milliseconds. Click on Base Time dropdown selector object to select different Base times like 0.1, 0.4, 1.6 and 6.4


Multiplier- While counting the object if user wants to add Time delay, it is added with combination of base time and multiplier. This parameter allows you to enter the Multiplier values.

Mode- The switching timer is a useful function for manipulating the output of the sensor in relation to timing. It is useful for precision applications where the output of the sensor must be precisely triggered at a certain time. Click on Mode drop-down selector object to select different Timer modes like No Timer, Off Delay, On Delay and On Delay and Off Delay


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_871TM_4IOL, raC_Dvc_871TM_8IOL, raC_Dvc_871TM_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_871TM_4IOL, raC_LD_Dvc_871TM_8IOL, raC_LD_Dvc_871TM_5032

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_871TM_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 871TM), This name depends upon the TagName assigned to object.
SensorType	871TM-M10NP18-A2	871TM-M10NP18-A2	871TM-M10NP18-A2	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)

ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_871TM_4IOL	raC_Dvc_871TM_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_871TM_8IOL	raC_Dvc_871TM_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_871TM_5032	raC_Dvc_871TM_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-LinkDevice.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-LinkDevice.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_871TM	Faceplate ME	(raC-3_xx-ME) raC_Dvc_871TM-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_871TM	Faceplate SE	(raC-3_xx-SE) raC_Dvc_871TM-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

45CRM - Color Registration Mark Sensor (raC_Dvc_45CRM_4IOL, raC_Dvc_45CRM_8IOL, raC_Dvc_45CRM_5032)

Overview

The 45CRM Color Registration Mark Sensor device object (raC_Dvc_45CRM_4IOL, raC_Dvc_45CRM_8IOL, raC_Dvc_45CRM_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor diagnostics
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_45CRM_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Profile selection:** Profile setup will allow the operators to set the one of the profile from five. Each profile contains the Mark & Background Color value required for the sensor output to turn ON upon target detection.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).
- **Teach:** Offers the different teach functions.

Functional Description

The 45CRM Color Registration Mark Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplate's for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
45CRM	POINT I/O 1734-4IOL	45CRM-4LHT1-D4, 45CRM-4LHT2-D4	raC_Dvc_45CRM_4IOL_3.02_AOI.L5X	raC_Dvc_45CRM_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	45CRM-4LHT1-D4, 45CRM-4LHT2-D4	raC_Dvc_45CRM_8IOL_3.02_AOI.L5X	raC_Dvc_45CRM_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	45CRM-4LHT1-D4, 45CRM-4LHT2-D4	raC_Dvc_45CRM_5032_3.02_AOI.L5X	raC_Dvc_45CRM_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
45CRM	Display	(raC-3_02-ME) raC_Dvc_45CRM-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_45CRM-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
45CRM	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
45CRM	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45CRM_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45CRM_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45CRM_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45CRM_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45CRM_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45CRM_5032_(3.2)


Device Definition (raC_Dvc_45CRM_4IOL, raC_Dvc_45CRM_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




2. Specify the Application Specific Name e.g. *WhiteMark_100*.



**Device Definition
(raC_Dvc_45CRM_Type1_5032,
raC_Dvc_45CRM_Type2_5032)**


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 45CRM, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 45CRM Sensor.



- Configure the parameters of sensor from configuration tab from AOP of the 45CRM sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data (raC_Dvc_45CRM_4IOL, raC_Dvc_45CRM_8IOL)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_45CRM_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[20]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_45CRM_Inp_4IOL Or raC_UDT_ItfAD_45CRM_Inp_8IOL
Ref_Ctrl_Inf	Interfacing Data from Configured Sensors	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	InformationDatafromConfiguredSensors	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChXTriggered	Triggered Status of Sensor	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_OutputPolarityInverted	Output Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cfg_ProfileSelection	Set value for Profile Selection	SINT
Cmd_DynamicTeach	Dynamic Teach Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_ReadAndStoreSettings	Read and Store Settings Command	BOOL
Cmd_StaticTeachBackground	Static Teach Background Command	BOOL
Cmd_StaticTeachMark	Static Teach Mark Command	BOOL
Cmd_TeachEvaluate	Teach Evaluate Command	BOOL
Cmd_TeachModeButton	Start Teach Mode Button Command	BOOL

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Val_CurrProfile	Displays the Current Profile	SINT
Val_CurrTeachMode	Unique Parameter Name for auto - discovery	INT
Val_OutputPolarityInverted	Displays the Current Profile	INT
Val_ProfileSelection	Displays Teach Mode	INT
Val_TeachStep	Teach Step Value	INT
raC_Dvc_ADframework_DV_L D	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_45CRM_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_45CRM_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[20]

InOut	Function / Description	Data Type
Inp_I	Device Object Inputs	raC_UDT_IOLink_45CRM_Inp_5032
Ref_Ctrl_Inf	Interfacing Data from Configured Sensors	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Information Data from Configured Sensors	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_45CRM_Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChXTriggered	Triggered Status of Sensor	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_OutputPolarityInverted	Output Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cfg_ProfileSelection	Set value for Profile Selection	SINT
Cmd_DynamicTeach	Dynamic Teach Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_ReadAndStoreSettings	Read and Store Settings Command	BOOL
Cmd_StaticTeachBackground	Static Teach Background Command	BOOL
Cmd_StaticTeachMark	Static Teach Mark Command	BOOL
Cmd_TeachEvaluate	Teach Evaluate Command	BOOL
Cmd_TeachModeButton	Start Teach Mode Button Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL


Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_CurrProfile	Displays the Current Profile	SINT
Val_CurrTeachMode	Unique Parameter Name for auto - discovery	INT
Val_OutputPolarityInverted	Displays the Current Profile	INT
Val_ProfileSelection	Displays Teach Mode	INT
Val_TeachStep	Teach Step Value	INT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 45CRM device object connected to channel #3 of a POINT I/O 1734-4IOL IO-Link Master module named *Point_IO_4IOLMaster* in slot #1 of a POINT I/O adapter named *Rack01*.



The following example uses the 45CRM device object connected to channel #0 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*



The following example uses the 45CRM device object connected to channel #2 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_2*.



Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_ColorSens_45CRM		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_45CRM_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	<div style="border: 1px solid gray; padding: 5px;"> <div style="display: flex; justify-content: space-between; border-bottom: 1px solid gray;"> Properties Animations Events </div> <div style="padding: 5px;"> <p>General</p> <p>AOI_Tag ::PAC_VD \\MainProgram.Sensor_45CRM ...</p> <p>Appearance</p> <p>Position and Size</p> <p>Security</p> </div> </div>

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Name	Description	Usage	Data Type
▶ Sensor45CRM_102	Sensor 102	Local	raC_Dvc_45CRM_8IOL
▶ Sensor45CRM_102_Inp_I	Sensor45CRM_102 Input Interface	Local	raC_UDT_ItfAD_45CRM_Inp_8IOL
▶ Sensor45CRM_102_CtrlCmd	Sensor45CRM_102 Command Interface	Public	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
▶ Sensor45CRM_102_CtrlSet	Sensor45CRM_102 Setting Interface	Public	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
▶ Sensor45CRM_102_CtrlSts	Sensor45CRM_102 Status Interface	Public	raC_UDT_ItfAD_IOLinkSensor_CtrlSts

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.



Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED

Item	Description
4	Trigger Sparkling Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
6	Current Profile Current Profile displays the Current Profile Name and their Mark & Background color code values which is downloaded/read from/to Sensor



Note: In Case of, 5032 Master, changes made to the Application Specific Name or Locate Toggle Switch require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Configure Tab

The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Local Settings
- Profile Settings
- Configuration Apply Settings




In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Item	Description
1	Output Polarity: Polarity changes the sensor output to operate as Light On (Non Inverted) and Dark On (Inverted).
2	Profile Settings: Launch the Profile settings window.
3	Local Teach Unlock/Lock Toggle Switch: Locks unauthorized people from changing the sensor settings using the local device push buttons. Toggle the lock/unlock button to prevent parameterization using local push buttons.

Profile Settings

Profile Settings display includes the Select Profile dropdown menu to select up to 5 profiles, Rename Profile and Teach Settings buttons. Touch on the Rename Profile button to change the profile name e.g. Profile 1- Candy Green.



Note: Profiles are Stored in the Logix Designer and user can select and download the Profile to the sensor whenever needed.

**** All Profiles values are stored by teaching the Mark and Background color of that profile using Teach Settings.


Teach Settings

Teach Settings display includes the Teach Methods, Teach Commands & Teach Read & Store buttons. Touch on the Teach Settings navigation button to access the Teach Settings tab.

Teach tab includes the following functions:


- Teach mode selection drop-down menu (Static/Dynamic)
- Teach procedure flow buttons
- Teach values Read & Store button

The operator must complete each stage to teach sensor successfully. During the teach process the operator must complete the current stage prior to the next stage being made available to operator.



Item	Description
1	Teach Mode: - Static - Dynamic
2	Teach procedure flow buttons
3	Read & Store: Stored the Mark & background values to the Selected Profile.


Static Teach



The first method is Static Teach, which is intended for applications where the web can be stopped, or for more challenging applications.

1. Click on Start Button to Start the Procedure.
2. Place the Mark under the sensor light Spot to teach the color of the Mark.
3. Click on Teach Mark Button.
4. Place the Background under the sensor light Spot to teach the color of the Background.
5. Click on Teach Background Button.
6. Click on Evaluate Button.
7. Click on Read and Store Colors Button to store Mark and Background color values into Profile which is selected in the Profile Setup window.

Dynamic Teach




The Second method is Dynamic Teach, which is intended for applications where the web can be Running.

1. Click on Start button to Start the procedure.
2. Place the target and background in front of the sensor at the speed of the application.
3. Click on Dynamic Teach button
4. Click on Evaluate button
5. Click on Read and Store Colors Button to store Mark and Background color values into Profile which is selected in the Profile Setup window.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, "Config Apply" button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_45CRM_410L, raC_Dvc_45CRM_810L, raC_Dvc_45CRM_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_45CRM_410L, raC_LD_Dvc_45CRM_810L

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_45CRM_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 45CRM), This name depends upon the TagName assigned to object.
SensorType	45CRM-4LHT1-D4	45CRM-4LHT1-D4	45CRM-4LHT1-D4	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_45CRM_4IOL	raC_Dvc_45CRM_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_45CRM_8IOL	raC_Dvc_45CRM_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_45CRM_5032	raC_Dvc_45CRM_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button

Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_45CRM	Faceplate ME	(raC-3_xx-ME) raC_Dvc_45CRM-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_45CRM	Faceplate SE	(raC-3_xx-SE) raC_Dvc_45CRM-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

836P - Solid-State Pressure Sensor (raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL, raC_Dvc_836P_Type1_5032, raC_Dvc_836P_Type2_5032)

Overview

The 836P Solid-State Pressure Sensor device object (raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL, raC_Dvc_836P_Type1_5032, raC_Dvc_836P_Type2_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor diagnostics
- Process data trending
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_836P_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).

Functional Description

The 836P Solid-State Pressure Sensor Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with four versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/ Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
836P	POINT I/O 1734-4IOL	836P-D1xxxA14PA-D4, 836P-D1xxxA20PA-D4, 836P-D1xxxA30PA-D4, 836P-D1xxxA36PA-D4, 836P-D1xxxA60PA-D4 836P-D1xxxB10PA-D4, 836P-D1xxxB14PA-D4, 836P-D1xxxB20PA-D4, 836P-D1xxxB25PA-D4, 836P-D1xxxB30PA-D4 836P-D2xxxA14PA-D4, 836P-D2xxxA20PA-D4, 836P-D2xxxA30PA-D4, 836P-D2xxxA36PA-D4, 836P-D2xxxA60PA-D4 836P-D2xxxB10PA-D4, 836P-D2xxxB14PA-D4, 836P-D2xxxB20PA-D4, 836P-D2xxxB25PA-D4, 836P-D2xxxB30PA-D4, 836P-D2xxxB36PA-D4, 836P-D2xxxB50PA-D4 836P-D2xxxC10PA-D4, 836P-D2xxxC14PA-D4, 836P-D2xxxC20PA-D4, 836P-D2xxxC30PA-D4, 836P-D2xxxC36PA-D4, 836P-D2xxxC50PA-D4, 836P-D2xxxC58PA-D4, 836P-D2xxxC80PA-D4 836P-D1xxxA14PP-D4, 836P-D1xxxA20PP-D4, 836P-D1xxxA30PP-D4, 836P-D1xxxA36PP-D4, 836P-D1xxxA60PP-D4 836P-D1xxxB10PP-D4, 836P-D1xxxB14PP-D4, 836P-D1xxxB20PP-D4, 836P-D1xxxB25PP-D4, 836P-D1xxxB30PP-D4 836P-D2xxxA14PP-D4, 836P-D2xxxA20PP-D4, 836P-D2xxxA30PP-D4, 836P-D2xxxA36PP-D4, 836P-D2xxxA60PP-D4 836P-D2xxxB10PP-D4, 836P-D2xxxB14PP-D4, 836P-D2xxxB20PP-D4, 836P-D2xxxB25PP-D4, 836P-D2xxxB30PP-D4, 836P-D2xxxB36PP-D4, 836P-D2xxxB50PP-D4 836P-D2xxxC10PP-D4, 836P-D2xxxC14PP-D4, 836P-D2xxxC20PP-D4, 836P-D2xxxC30PP-D4, 836P-D2xxxC36PP-D4, 836P-D2xxxC50PP-D4, 836P-D2xxxC58PP-D4, 836P-D2xxxC80PP-D4	raC_Dvc_836P_4IOL_3.02_A01.L5X	raC_Dvc_836P_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	836P-D1xxxA14PA-D4, 836P-D1xxxA20PA-D4, 836P-D1xxxA30PA-D4, 836P-D1xxxA36PA-D4, 836P-D1xxxA60PA-D4, 836P-D1xxxB10PA-D4, 836P-D1xxxB14PA-D4, 836P-D1xxxB20PA-D4, 836P-D1xxxB25PA-D4, 836P-D1xxxB30PA-D4 836P-D2xxxA14PA-D4, 836P-D2xxxA20PA-D4, 836P-D2xxxA30PA-D4, 836P-D2xxxA36PA-D4, 836P-D2xxxA60PA-D4 836P-D2xxxB10PA-D4, 836P-D2xxxB14PA-D4, 836P-D2xxxB20PA-D4, 836P-D2xxxB25PA-D4, 836P-D2xxxB30PA-D4, 836P-D2xxxB36PA-D4, 836P-D2xxxB50PA-D4 836P-D2xxxC10PA-D4, 836P-D2xxxC14PA-D4, 836P-D2xxxC20PA-D4, 836P-D2xxxC30PA-D4, 836P-D2xxxC36PA-D4, 836P-D2xxxC50PA-D4, 836P-D2xxxC58PA-D4, 836P-D2xxxC80PA-D4 836P-D1xxxA14PP-D4, 836P-D1xxxA20PP-D4, 836P-D1xxxA30PP-D4, 836P-D1xxxA36PP-D4, 836P-D1xxxA60PP-D4, 836P-D1xxxB10PP-D4, 836P-D1xxxB14PP-D4, 836P-D1xxxB20PP-D4, 836P-D1xxxB25PP-D4, 836P-D1xxxB30PP-D4 836P-D2xxxA14PP-D4, 836P-D2xxxA20PP-D4, 836P-D2xxxA30PP-D4, 836P-D2xxxA36PP-D4, 836P-D2xxxA60PP-D4 836P-D2xxxB10PP-D4, 836P-D2xxxB14PP-D4, 836P-D2xxxB20PP-D4, 836P-D2xxxB25PP-D4, 836P-D2xxxB30PP-D4, 836P-D2xxxB36PP-D4, 836P-D2xxxB50PP-D4 836P-D2xxxC10PP-D4, 836P-D2xxxC14PP-D4, 836P-D2xxxC20PP-D4, 836P-D2xxxC30PP-D4, 836P-D2xxxC36PP-D4, 836P-D2xxxC50PP-D4, 836P-D2xxxC58PP-D4, 836P-D2xxxC80PP-D4	raC_Dvc_836P_8IOL_3.02_A01.L5X	raC_Dvc_836P_8IOL_3.02_RUNG.L5X

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
836P	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	836P-D1xxxA14PA-D4, 836P-D1xxxA20PA-D4, 836P-D1xxxA30PA-D4, 836P-D1xxxA36PA-D4, 836P-D1xxxA60PA-D4 836P-D1xxxB10PA-D4, 836P-D1xxxB14PA-D4, 836P-D1xxxB20PA-D4, 836P-D1xxxB25PA-D4, 836P-D1xxxB30PA-D4 836P-D2xxxA14PA-D4, 836P-D2xxxA20PA-D4, 836P-D2xxxA30PA-D4, 836P-D2xxxA36PA-D4, 836P-D2xxxA60PA-D4 836P-D2xxxB10PA-D4, 836P-D2xxxB14PA-D4, 836P-D2xxxB20PA-D4, 836P-D2xxxB25PA-D4, 836P-D2xxxB30PA-D4, 836P-D2xxxB36PA-D4, 836P-D2xxxB50PA-D4 836P-D2xxxC10PA-D4, 836P-D2xxxC14PA-D4, 836P-D2xxxC20PA-D4, 836P-D2xxxC30PA-D4, 836P-D2xxxC36PA-D4, 836P-D2xxxC50PA-D4, 836P-D2xxxC58PA-D4, 836P-D2xxxC80PA-D4	raC_Dvc_836P_Type1_5032_3.02_A01.L5X	raC_Dvc_836P_Type1_5032_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	836P-D1xxxA14PP-D4, 836P-D1xxxA20PP-D4, 836P-D1xxxA30PP-D4, 836P-D1xxxA36PP-D4, 836P-D1xxxA60PP-D4 836P-D1xxxB10PP-D4, 836P-D1xxxB14PP-D4, 836P-D1xxxB20PP-D4, 836P-D1xxxB25PP-D4, 836P-D1xxxB30PP-D4 836P-D2xxxA14PP-D4, 836P-D2xxxA20PP-D4, 836P-D2xxxA30PP-D4, 836P-D2xxxA36PP-D4, 836P-D2xxxA60PP-D4 836P-D2xxxB10PP-D4, 836P-D2xxxB14PP-D4, 836P-D2xxxB20PP-D4, 836P-D2xxxB25PP-D4, 836P-D2xxxB30PP-D4, 836P-D2xxxB36PP-D4, 836P-D2xxxB50PP-D4 836P-D2xxxC10PP-D4, 836P-D2xxxC14PP-D4, 836P-D2xxxC20PP-D4, 836P-D2xxxC30PP-D4, 836P-D2xxxC36PP-D4, 836P-D2xxxC50PP-D4, 836P-D2xxxC58PP-D4, 836P-D2xxxC80PP-D4	raC_Dvc_836P_Type2_5032_3.02_A01.L5X	raC_Dvc_836P_Type2_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
836P	Display	(raC-3_02-ME) raC_Dvc_836P-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_836P-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
836P	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the / *ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
836P	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_836P_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_836P_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_836P_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_836P_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_836P_Type1_5032_(3.2) (RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_836P_Type2_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_836P_5032_(3.2)


Device Definition (raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




- Specify the Application Specific Name e.g. *SupplyPressure_100*



Device Definition (raC_Dvc_836P_Type1_5032, 2, raC_Dvc_836P_Type2_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

- Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link for Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 836P, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 836P Sensor.



- Configure the parameters of sensor from configuration tab from AOP of the 836P sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data (raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_836P_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_836P_Inp_4IOL Or raC_UDT_ItfAD_836P_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Triggered Status When the Pressure is equal to Defined Pressure Set for Trigger1	BOOL
Inp_ChxTriggered2	Triggered Status When the Pressure is equal to Defined Pressure Set for Trigger2	BOOL
Inp_ChxPressure	Displays Pressure Value of the Sensor	INT
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_DisplayModePA	Set type of Information shown on Unit Display; 0=Current Pressure, 1=Highest Pressure, 2=Low Pressure, 3=Triggered1 Set Pressure, 4=Triggered1 Reset Pressure, 7=Display OFF	DINT
Cfg_DisplayModePP	Set type of Information shown on Unit Display; 0=Current Pressure, 1=Highest Pressure, 2=Low Pressure, 3=Triggered1 Set Pressure, 4=Triggered1 Reset Pressure, 5=Triggered2 Set Pressure, 6=Triggered2 Reset Pressure, 7=Display OFF	DINT
Cfg_DisplayRotation	Set the change of orientation of the status indicator by 180°; 0=Default, 1=Rotate 180 Degrees	DINT
Cfg_MeasuringUnit	Set Measuring Unit; 0=Bar, 1=Mpa, 2=kPa, 3=psi, 4= kg/cm ²	DINT
Cfg_OperatingModeTrig1	Set Operating Modes for Triggered1 Output; 0=Hysteresis, 1=Window	INT
Cfg_OperatingModeTrig2	Set Operating Modes for Triggered2 Output; 0=Hysteresis, 1=Window	INT
Cfg_UpdateRate	Set Sensor Display Update Rate; 0=1Hz, 1=2Hz, 2=5 Hz, 3=10Hz	SINT
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Set_TrendPressMaxValue	Trend Tab Max value for VD/ME/SE faceplate	REAL

Input	Function/Description	Data Type
Set_TrendPressMinValue	Trend Tab Min value for VD/ME/SE faceplate	REAL
Set_Trig1OffDelay	Set the Delay Value for the change of state from ON to OFF for the Triggered1	DINT
Set_Trig1OnDelay	Set the Delay Value for the change of state from OFF to ON for the Triggered1	DINT
Set_Trig1RP	Set the value of system pressure that turns the sensor output OFF for Trigger1	REAL
Set_Trig1SP	Set the value of system pressure that turns the sensor output ON for Trigger1	REAL
Set_Trig2OffDelay	Set the Delay Value for the change of state from ON to OFF for the Triggered2	DINT
Set_Trig2OnDelay	Set the Delay Value for the change of state from OFF to ON for the Triggered2	DINT
Set_Trig2RP	Set the value of system pressure that turns the sensor output OFF for Trigger2	REAL
Set_Trig2SP	Set the value of system pressure that turns the sensor output ON for Trigger2	REAL

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_CatPA	Catalog of Connected Sensor; 0=PP, 1=PA	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Val_MeasuringUnit	Displays the Pressure Measurement Unit; 0=Bar, 1=Mpa, 2=kPa, 3=psi, 4= kg/cm ²	INT
Val_Mode	As per Connected Sensor Catalog	INT
Val_OperatingHrsSinceInception	Displays the Total Sensor Operating Hours since the sensor was first powered ON	DINT
Val_OperatingModeTrig1	Displays Operating Modes for Triggered1 Output; 0=Hysteresis, 1=Window	INT
Val_OperatingModeTrig2	Displays Operating Modes for Triggered2 Output; 0=Hysteresis, 1=Window	INT
Val_Pressure	Displays Pressure Value of the Sensor	REAL
Val_PressureConverted	Displays Converted Pressure Value of the Sensor	REAL
Val_PressureMaxSinceReset	Displays Highest Recorded Pressure Value since the last pressure reset	REAL
Val_PressureMinSinceReset	Displays Lowest Recorded Pressure Value since the last pressure reset	REAL
Val_Rotation	Displays the change of orientation of the status indicator by 180°; 0=0 Deg, 1=Rotate 180 Degrees	INT
Val_RPRangeMax	Sensor ResetPoint Maximum Range in Trend	REAL
Val_RPRangeMaxUnit	Sensor ResetPoint Unitwise Maximum Range in Trend	REAL
Val_RPRangeMin	Sensor ResetPoint Minimum Range in Trend	REAL
Val_RPRangeMinUnit	Sensor ResetPoint Unitwise Minimum Range in Trend	REAL
Val_SPRangeMax	Sensor SwitchPoint Maximum Range in Trend	REAL
Val_SPRangeMaxUnit	Sensor SwitchPoint Unitwise Maximum Range in Trend	REAL
Val_SPRangeMin	Sensor SwitchPoint Minimum Range in Trend	REAL
Val_SPRangeMinUnit	Sensor SwitchPoint Unitwise Minimum Range in Trend	REAL

Output	Function/Description	Data Type
Val_Trig1OffDelay	Displays the Delay Value for the change of state from ON to OFF for the Triggered1	DINT
Val_Trig1OnDelay	Displays the Delay Value for the change of state from OFF to ON for the Triggered1	DINT
Val_Trig1RP	Displays the value of system pressure that turns the sensor output OFF for Trigger1	REAL
Val_Trig1SP	Display the value of system pressure that turns the sensor output OFF for Trigger1	REAL
Val_Trig2OffDelay	Displays the Delay Value for the change of state from ON to OFF for the Triggered2	DINT
Val_Trig2OnDelay	Displays the Delay Value for the change of state from OFF to ON for the Triggered2	DINT
Val_Trig2RP	Displays the value of system pressure that turns the sensor output OFF for Trigger2	REAL
Val_Trig2SP	Display the value of system pressure that turns the sensor output OFF for Trigger2	REAL
Val_UpdateRate	Displays Sensor Display Update Rate; 0=1Hz, 1=2Hz, 2=5 Hz, 3=10Hz	INT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_836P_Type1_5032, raC_Dvc_836P_Type2_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_836P_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_836P_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_836P_Type1.Cfg or raC_UDT_IOLink_836P_Type2.Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Triggered Status When the Pressure is equal to Defined Pressure Set for Trigger1	BOOL
Inp_ChxTriggered2	Triggered Status When the Pressure is equal to Defined Pressure Set for Trigger2	BOOL
Inp_ChxPressure	Displays Pressure Value of the Sensor	INT
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_DisplayModePA	Set type of Information shown on Unit Display; 0=Current Pressure, 1=Highest Pressure, 2=Low Pressure, 3=Triggered1 Set Pressure, 4=Triggered1 Reset Pressure, 7=Display OFF	DINT
Cfg_DisplayModePP	Set type of Information shown on Unit Display; 0=Current Pressure, 1=Highest Pressure, 2=Low Pressure, 3=Triggered1 Set Pressure, 4=Triggered1 Reset Pressure, 5=Triggered2 Set Pressure, 6=Triggered2 Reset Pressure, 7=Display OFF	DINT
Cfg_DisplayRotation	Set the change of orientation of the status indicator by 180°; 0=Default, 1=Rotate 180 Degrees	DINT
Cfg_MeasuringUnit	Set Measuring Unit; 0=Bar, 1=Mpa, 2=kPa, 3=psi, 4= kg/cm ²	DINT
Cfg_OperatingModeTrig1	Set Operating Modes for Triggered1 Output; 0=Hysteresis, 1=Window	INT
Cfg_OperatingModeTrig2	Set Operating Modes for Triggered2 Output; 0=Hysteresis, 1=Window	INT
Cfg_UpdateRate	Set Sensor Display Update Rate; 0=1Hz, 1=2Hz, 2=5 Hz, 3=10Hz	SINT
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL

Input	Function/Description	Data Type
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Set_TrendPressMaxValue	Trend Tab Max value for VD/ME/SE faceplate	REAL
Set_TrendPressMinValue	Trend Tab Min value for VD/ME/SE faceplate	REAL
Set_Trig1OffDelay	Set the Delay Value for the change of state from ON to OFF for the Triggered1	DINT
Set_Trig1OnDelay	Set the Delay Value for the change of state from OFF to ON for the Triggered1	DINT
Set_Trig1RP	Set the value of system pressure that turns the sensor output OFF for Trigger1	REAL
Set_Trig1SP	Set the value of system pressure that turns the sensor output ON for Trigger1	REAL
Set_Trig2OffDelay	Set the Delay Value for the change of state from ON to OFF for the Triggered2	DINT
Set_Trig2OnDelay	Set the Delay Value for the change of state from OFF to ON for the Triggered2	DINT
Set_Trig2RP	Set the value of system pressure that turns the sensor output OFF for Trigger2	REAL
Set_Trig2SP	Set the value of system pressure that turns the sensor output ON for Trigger2	REAL

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_CatPA	Catalog of Connected Sensor; 0=PP, 1=PA	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_MeasuringUnit	Displays the Pressure Measurement Unit; 0=Bar, 1=Mpa, 2=kPa, 3=psi, 4= kg/cm ²	INT
Val_Mode	As per Connected Sensor Catalog	INT
Val_OperatingHrsSinceInception	Displays the Total Sensor Operating Hours since the sensor was first powered ON	DINT


Output	Function/Description	Data Type
Val_OperatingModeTrig1	Displays Operating Modes for Triggered1 Output; 0=Hysteresis, 1=Window	INT
Val_OperatingModeTrig2	Displays Operating Modes for Triggered2 Output; 0=Hysteresis, 1=Window	INT
Val_Pressure	Displays Pressure Value of the Sensor	REAL
Val_PressureConverted	Displays Converted Pressure Value of the Sensor	REAL
Val_PressureMaxSinceReset	Displays Highest Recorded Pressure Value since the last pressure reset	REAL
Val_PressureMinSinceReset	Displays Lowest Recorded Pressure Value since the last pressure reset	REAL
Val_Rotation	Displays the change of orientation of the status indicator by 180°; 0=0 Deg, 1=Rotate 180 Degrees	INT
Val_RPRangeMax	Sensor ResetPoint Maximum Range in Trend	REAL
Val_RPRangeMaxUnit	Sensor ResetPoint Unitwise Maximum Range in Trend	REAL
Val_RPRangeMin	Sensor ResetPoint Minimum Range in Trend	REAL
Val_RPRangeMinUnit	Sensor ResetPoint Unitwise Minimum Range in Trend	REAL
Val_SPRangeMax	Sensor SwitchPoint Maximum Range in Trend	REAL
Val_SPRangeMaxUnit	Sensor SwitchPoint Unitwise Maximum Range in Trend	REAL
Val_SPRangeMin	Sensor SwitchPoint Minimum Range in Trend	REAL
Val_SPRangeMinUnit	Sensor SwitchPoint Unitwise Minimum Range in Trend	REAL
Val_Trig1OffDelay	Displays the Delay Value for the change of state from ON to OFF for the Triggered1	DINT
Val_Trig1OnDelay	Displays the Delay Value for the change of state from OFF to ON for the Triggered1	DINT
Val_Trig1RP	Displays the value of system pressure that turns the sensor output OFF for Trigger1	REAL
Val_Trig1SP	Display the value of system pressure that turns the sensor output OFF for Trigger1	REAL
Val_Trig2OffDelay	Displays the Delay Value for the change of state from ON to OFF for the Triggered2	DINT
Val_Trig2OnDelay	Displays the Delay Value for the change of state from OFF to ON for the Triggered2	DINT
Val_Trig2RP	Displays the value of system pressure that turns the sensor output OFF for Trigger2	REAL
Val_Trig2SP	Display the value of system pressure that turns the sensor output OFF for Trigger2	REAL
Val_UpdateRate	Displays Sensor Display Update Rate; 0=1Hz, 1=2Hz, 2=5 Hz, 3=10Hz	INT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 836P device object connected to channel #2 of a POINT I/O 1734-4IOL IO-Link Master module in slot #1 of a POINT I/O adapter named *Rack01*.




The following example uses the 836P device object connected to channel #0 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 836P Type1 Sensor device object connected to channel #14 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named Mod_Master_5032_2.





The following example uses the 836P Type2 Sensor device object connected to channel #0 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named Mod_Master_5032_3.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram_...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_PresSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram_...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_836P_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Sensor_836P_102	Sensor 102
▶ Sensor_836P_102_CtrlCmd	Sensor_836P_102 Command Interface
▶ Sensor_836P_102_CtrlSet	Sensor_836P_102 Setting Interface
▶ Sensor_836P_102_CtrlSts	Sensor_836P_102 Status Interface
▶ Sensor_836P_102_Inp_I	Sensor_836P_102 Input Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger1 Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Trigger2 Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
6	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
7	Process Data - Pressure: Displays the current pressure value along with unit.



Note: In Case of, 5032 Master, changes made to the Application Specific Name or Locate Toggle Switch require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Pressure Bar Graph Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Pressure Current Value
3	Operating Hours Since Inception



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.


Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. One trend is displayed for Pressure.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Pressure.



Configure Tab


The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Trigger Settings
- Configuration Apply Settings



In case of 5032 Master, “[Config Apply](#)” Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Parameter Settings

Update Rate- The Update rate will allow the operators to change how often the sensor display is updated. Available options are 1 Hz, 2 Hz, 5 Hz, and 10 Hz. The default rate is 5 Hz.

Display Mode- The Display Mode will allow the operators to change the type of information that should be shown on the unit display. Operators can select – Current Pressure, Highest Pressure, Lowest Pressure, Triggered 1 Set Pressure, Triggered 1 Reset Pressure, Triggered2 Set Pressure (only available in 2 PNP models), Triggered2 Reset Pressure (only available in 2 x PNP models) and Display OFF.

Display Units- This parameter allows you to change the pressure measurement that is shown in the sensor display. Acceptable units are psi, bar, MPa, kPa, and kg/cm². The default display unit for these sensors is psi.

Display Rotation- This parameter allows operators to change the orientation of the status indicator by 180°. This feature is deal for applications where the display may be in a direction that’s not visible to the operator and needs to be rotated for ease of use

Lock/Unlock- This parameter keeps unauthorized people from changing the sensor settings when using the local push buttons. Toggle the lock/unlock button to prevent parameterization using local push buttons.

Trigger Settings

	Trigger 1	Trigger 2
Switch Point	14.50 PSI	14.50 PSI
Reset Point	-1.02 PSI	13.10 PSI
Operating Mode	Window	Hysteresis
On Delay	0 ms	0 ms
Off Delay	0 ms	0 ms

The Trigger settings divided into sections:

- Trigger 1 - Visible for Single output sensor
- Trigger 2 - Visible for two output sensor

Switch Point- Triggered₁ Switch Point/Window High-Condition 1: Sets the system Pressure that turns the sensor output ON when operating in Hysteresis Mode. Or turns the sensor output OFF when the system Pressure exceeds the set value in Window Mode. The operating mode for Triggered₁ can be changed by modifying the Function parameter.

To set the desired Set-point value please refer the pressure range of the 836P pressure sensor from the user manual

Reset Point- Triggered₁ Reset Point/Window Low-Condition 2: Sets the system Pressure that turns the sensor output OFF when operating in Hysteresis Mode. Or it turns the sensor output ON when the system Pressure exceeds the set value in Window Mode. The operating mode for Triggered₁ can be changed by modifying the Function parameter. Touch within the Reset Point window to change the value. To set the desired Reset point value please refer the pressure range of the 836P pressure sensor from the user manual.

On Delay- Delays the change of state from OFF to ON for the Triggered₁ parameter (Output₁ in SIO) for up to 32 seconds when the polarity is defined as Normally Open. This parameter helps operators filter out unwanted Pressure peaks in their systems.

Off Delay- Delays the change of state from ON to OFF for the Triggered₁ parameter (Output₁ in SIO) for up to 32 seconds when the polarity is defined as Normally Open. This parameter helps operators filter out unwanted Pressure peaks in their systems.


Operating Mode- This parameter defines the operating mode for Triggered₁ sensor output. The output can be configured to operate in the following modes.

- **Hysteresis Mode:** Output₁ and the Triggered₁ process data parameter turn ON when the Pressure value is higher than the Switch Point. And turns OFF when the Pressure value is lower than the reset point.
- **Window Mode:** Output₁ and the Triggered₁ process data parameter turn ON when the Pressure value is between the Switch Point and the Reset Point. It turns OFF when the Pressure value is higher than the Switch Point or lower than the Reset Point.

Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_836P_4IOL, raC_Dvc_836P_8IOL, raC_Dvc_836P_Type1_5032, raC_Dvc_836P_Type2_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_836P_4IOL, raC_LD_Dvc_836P_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_836P_Type1_5032, raC_LD_Dvc_836P_Type2_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 836P), This name depends upon the TagName assigned to object.

SensorType	836P-D1xxxA14PA-D4	836P-D1xxxA14PA-D4	836P-D1xxxA14PA-D4	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_836P_4IOL	raC_Dvc_836P_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_836P_8IOL	raC_Dvc_836P_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_836P_Type1_5032 Or raC_Dvc_836P_Type2_5032	raC_Dvc_836P_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_836P	Faceplate ME	(raC-3_xx-ME) raC_Dvc_836P-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_836P	Faceplate SE	(raC-3_xx-SE) raC_Dvc_836P-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd

V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

837T - Solid-State Temperature Sensor (raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL, raC_Dvc_837T_Type1_5032, raC_Dvc_837T_Type2_5032)

Overview

The 837T Solid-State Temperature Sensor device object (raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL, raC_Dvc_837T_Type1_5032, raC_Dvc_837T_Type2_5032) includes HMI faceplate's which displays device information including:

- Sensor data
- Sensor diagnostics
- Process data trending
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_837T_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).

Functional Description

The 837T Solid-State Temperature Sensor Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with four versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
837T	POINT I/O 1734-4IOL	837T-D3xxxxxxxPA-D4, 837T-D3xxxxxxxPP-D4	raC_Dvc_837T_4IOL_3.02_AOI.L5X	raC_Dvc_837T_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	837T-D3xxxxxxxPA-D4, 837T-D3xxxxxxxPP-D4	raC_Dvc_837T_8IOL_3.02_AOI.L5X	raC_Dvc_837T_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	837T-D3xxxxxxxPA-D4	raC_Dvc_837T_Type1_5032_3.02_AOI.L5X	raC_Dvc_837T_Type1_5032_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	837T-D3xxxxxxxPP-D4	raC_Dvc_837T_Type2_5032_3.02_AOI.L5X	raC_Dvc_837T_Type2_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
837T	Display	(raC-3_02-ME) raC_Dvc_837T-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_837T-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
837T	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
837T	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_837T_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_837T_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_837T_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_837T_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_837T_Type1_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_837T_5032_(3.2)
		(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_837T_Type2_5032_(3.2)	


Device Definition (raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




2. Specify the Application Specific Name e.g. *VesselTemp_100*



**Device Definition
(raC_Dvc_837T_Type1_5032,
raC_Dvc_837T_Type2_5032)**

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link for Class B and Tick on “IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 837T, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 837T Sensor.

- └─ I/O Configuration
 - └─ 1756 Backplane, 1756-A7
 - └─ [0] 1756-L85E Master_5032_Test_Cases
 - └─ Ethernet
 - └─ 1756-L85E Master_5032_Test_Cases
 - └─ 5032-8IOLM12M12LDR/A Mod_Master_5032_1
 - └─ 5032-8IOLM12M12LDR/A Mod_Master_5032_2
 - └─ 5032-8IOLM12M12LDR/A Mod_Master_5032_3
 - └─ IO-Link
 - └─ 0 836P-D1xxxA36PP-D4 (182) Mod_836P_Type2
 - └─ 2 837T-D3xxxxxxxPA-D4 (207) Mod_837T_Type1
 - └─ 4 837T-D3xxxxxxxPP-D4 (206) Mod_837T_Type2
 - └─ 6 856T-B24LC (297) Mod_856T
 - └─ 8 871C-D1NP4-AP3 (80) Mod_871C
 - └─ 10 871FM-M10BA30-xxxx (200) Mod_871FM_Type1
 - └─ 12 871FM-M1NP5-AP3 (129) Mod_871FM_Type2
 - └─ 14 871TM-M10NP18-A2 (101) Mod_871TM

- Configure the parameters of sensor from configuration tab from AOP of the 837T sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data (raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_837T_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_837T_Inp_4IOL Or raC_UDT_ItfAD_837T_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger1	BOOL
Inp_ChxTriggered2	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger2	BOOL
Inp_ChxTemperature	Displays Temperature Value of the Sensor	INT
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_DisplayModePA	Set type of Information shown on Unit Display; 0=Current Temperature, 1=Highest Temperature, 2=Low Temperature, 3=Triggered1 Set Temperature, 4=Triggered1 Reset Temperature, 5=Display OFF	DINT
Cfg_DisplayModePP	Set type of Information shown on Unit Display; 0=Current Temperature, 1=High Temperature, 2=Low Temperature, 3=Triggered1 Set Temperature, 4=Triggered1 Reset Temperature, 5=Triggered2 Set Temperature, 6=Triggered2 Reset Temperature, 7=Display OFF	DINT
Cfg_DisplayRotation	Set the change of orientation of the status indicator by 180°; 0=Default, 1=Rotate 180 Degrees	DINT
Cfg_MeasuringUnit	Set Measuring Unit; 0=Celsius, 1=Fahrenheit	DINT
Cfg_OperatingModeTrig1	Set Operating Modes for Triggered1 Output; 0=Hysteresis, 1=Window	INT
Cfg_OperatingModeTrig2	Set Operating Modes for Triggered2 Output; 0=Hysteresis, 1=Window	INT
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_ResetTemp	Reset Command for Temperature	BBOL
Set_TrendTempMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT

Input	Function/Description	Data Type
Set_TrendTempMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT
Set_Trig1OffDelay	Set the Delay Value for the change of state from ON to OFF for the Triggered1	DINT
Set_Trig1OnDelay	Set the Delay Value for the change of state from OFF to ON for the Triggered1	DINT
Set_Trig1RP	Set the value of system Temperature that turns the sensor output OFF for Trigger1	REAL
Set_Trig1SP	Set the value of system Temperature that turns the sensor output ON for Trigger1	REAL
Set_Trig2OffDelay	Set the Delay Value for the change of state from ON to OFF for the Triggered2	DINT
Set_Trig2OnDelay	Set the Delay Value for the change of state from OFF to ON for the Triggered2	DINT
Set_Trig2RP	Set the value of system Temperature that turns the sensor output OFF for Trigger2	REAL
Set_Trig2SP	Set the value of system Temperature that turns the sensor output ON for Trigger2	REAL

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_CatPA	Catalog of Connected Sensor; 0=PP, 1=PA	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Val_MeasuringUnit	Displays the Temperature Measurement Unit; 0=Celsius, 1=Fahrenheit	INT
Val_Mode	As per Connected Sensor Catalog	INT
Val_OperatingHrsSinceInception	Displays the Total Sensor Operating Hours since the sensor was first powered ON	DINT
Val_OperatingModeTrig1	Displays Operating Modes for Triggered1 Output; 0=Hysteresis, 1=Window	INT
Val_OperatingModeTrig2	Displays Operating Modes for Triggered2 Output; 0=Hysteresis, 1=Window	INT
Val_Temperature	Displays Temperature Value of the Sensor	REAL
Val_ChTemperature	Displays Converted Temperature Value of the Sensor	REAL
Val_TemperatureMaxSinceReset	Displays Highest Recorded Temperature Value since the last Temperature reset	REAL
Val_TemperatureMinSinceReset	Displays Lowest Recorded Temperature Value since the last Temperature reset	REAL
Val_Rotation	Displays the change of orientation of the status indicator by 180°; 0=0 Deg, 1=Rotate 180 Degrees	INT
Val_RPRangeMax	Sensor ResetPoint Maximum Range in Trend	REAL
Val_RPRangeMaxUnit	Sensor ResetPoint Unitwise Maximum Range in Trend	REAL
Val_RPRangeMin	Sensor ResetPoint Minimum Range in Trend	REAL
Val_RPRangeMinUnit	Sensor ResetPoint Unitwise Minimum Range in Trend	REAL
Val_SPRangeMax	Sensor SwitchPoint Maximum Range in Trend	REAL
Val_SPRangeMaxUnit	Sensor SwitchPoint Unitwise Maximum Range in Trend	REAL
Val_SPRangeMin	Sensor SwitchPoint Minimum Range in Trend	REAL
Val_SPRangeMinUnit	Sensor SwitchPoint Unitwise Minimum Range in Trend	REAL

Output	Function/Description	Data Type
Val_Trig1OffDelay	Displays the Delay Value for the change of state from ON to OFF for the Triggered1	DINT
Val_Trig1OnDelay	Displays the Delay Value for the change of state from OFF to ON for the Triggered1	DINT
Val_Trig1RP	Displays the value of system Temperature that turns the sensor output OFF for Trigger1	REAL
Val_Trig1SP	Display the value of system Temperature that turns the sensor output OFF for Trigger1	REAL
Val_Trig2OffDelay	Displays the Delay Value for the change of state from ON to OFF for the Triggered2	DINT
Val_Trig2OnDelay	Displays the Delay Value for the change of state from OFF to ON for the Triggered2	DINT
Val_Trig2RP	Displays the value of system Temperature that turns the sensor output OFF for Trigger2	REAL
Val_Trig2SP	Display the value of system Temperature that turns the sensor output OFF for Trigger2	REAL
Val_UpdateRate	Displays Sensor Display Update Rate; 0=1Hz, 1=2Hz, 2=5 Hz, 3=10Hz	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_837T_Type1_5032, raC_Dvc_837T_Type2_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_837T_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_837T_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_837T_Type1.Cfg or raC_UDT_IOLink_837T_Type2.Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger1	BOOL
Inp_ChxTriggered2	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger2	BOOL
Inp_ChxTemperature	Displays Temperature Value of the Sensor	INT
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_DisplayModePA	Set type of Information shown on Unit Display; 0=Current Temperature, 1=Highest Temperature, 2=Low Temperature, 3=Triggered1 Set Temperature, 4=Triggered1 Reset Temperature, 5=Display OFF	DINT
Cfg_DisplayModePP	Set type of Information shown on Unit Display; 0=Current Temperature, 1=High Temperature, 2=Low Temperature, 3=Triggered1 Set Temperature, 4=Triggered1 Reset Temperature, 5=Triggered2 Set Temperature, 6=Triggered2 Reset Temperature, 7=Display OFF	DINT
Cfg_DisplayRotation	Set the change of orientation of the status indicator by 180°; 0=Default, 1=Rotate 180 Degrees	DINT
Cfg_MeasuringUnit	Set Measuring Unit; 0=Celsius, 1=Fahrenheit	DINT
Cfg_OperatingModeTrig1	Set Operating Modes for Triggered1 Output; 0=Hysteresis, 1=Window	INT
Cfg_OperatingModeTrig2	Set Operating Modes for Triggered2 Output; 0=Hysteresis, 1=Window	INT
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_ResetTemp	Reset Command for Temperature	BBOL

Input	Function/Description	Data Type
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Set_TrendTempMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendTempMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT
Set_Trig1OffDelay	Set the Delay Value for the change of state from ON to OFF for the Triggered1	DINT
Set_Trig1OnDelay	Set the Delay Value for the change of state from OFF to ON for the Triggered1	DINT
Set_Trig1RP	Set the value of system Temperature that turns the sensor output OFF for Trigger1	REAL
Set_Trig1SP	Set the value of system Temperature that turns the sensor output ON for Trigger1	REAL
Set_Trig2OffDelay	Set the Delay Value for the change of state from ON to OFF for the Triggered2	DINT
Set_Trig2OnDelay	Set the Delay Value for the change of state from OFF to ON for the Triggered2	DINT
Set_Trig2RP	Set the value of system Temperature that turns the sensor output OFF for Trigger2	REAL
Set_Trig2SP	Set the value of system Temperature that turns the sensor output ON for Trigger2	REAL

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_CatPA	Catalog of Connected Sensor; 0=PP, 1=PA	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_MeasuringUnit	Displays the Temperature Measurement Unit; 0=Celsius, 1=Fahrenheit	INT
Val_Mode	As per Connected Sensor Catalog	INT
Val_OperatingHrsSinceInception	Displays the Total Sensor Operating Hours since the sensor was first powered ON	DINT


Output	Function/Description	Data Type
Val_OperatingModeTrig1	Displays Operating Modes for Triggered1 Output; 0=Hysteresis, 1=Window	INT
Val_OperatingModeTrig2	Displays Operating Modes for Triggered2 Output; 0=Hysteresis, 1=Window	INT
Val_Temperature	Displays Temperature Value of the Sensor	REAL
Val_ChTemperature	Displays Converted Temperature Value of the Sensor	REAL
Val_TemperatureMaxSinceReset	Displays Highest Recorded Temperature Value since the last Temperature reset	REAL
Val_TemperatureMinSinceReset	Displays Lowest Recorded Temperature Value since the last Temperature reset	REAL
Val_Rotation	Displays the change of orientation of the status indicator by 180°; 0=0 Deg, 1=Rotate 180 Degrees	INT
Val_RPRangeMax	Sensor ResetPoint Maximum Range in Trend	REAL
Val_RPRangeMaxUnit	Sensor ResetPoint Unitwise Maximum Range in Trend	REAL
Val_RPRangeMin	Sensor ResetPoint Minimum Range in Trend	REAL
Val_RPRangeMinUnit	Sensor ResetPoint Unitwise Minimum Range in Trend	REAL
Val_SPRangeMax	Sensor SwitchPoint Maximum Range in Trend	REAL
Val_SPRangeMaxUnit	Sensor SwitchPoint Unitwise Maximum Range in Trend	REAL
Val_SPRangeMin	Sensor SwitchPoint Minimum Range in Trend	REAL
Val_SPRangeMinUnit	Sensor SwitchPoint Unitwise Minimum Range in Trend	REAL
Val_Trig1OffDelay	Displays the Delay Value for the change of state from ON to OFF for the Triggered1	DINT
Val_Trig1OnDelay	Displays the Delay Value for the change of state from OFF to ON for the Triggered1	DINT
Val_Trig1RP	Displays the value of system Temperature that turns the sensor output OFF for Trigger1	REAL
Val_Trig1SP	Display the value of system Temperature that turns the sensor output OFF for Trigger1	REAL
Val_Trig2OffDelay	Displays the Delay Value for the change of state from ON to OFF for the Triggered2	DINT
Val_Trig2OnDelay	Displays the Delay Value for the change of state from OFF to ON for the Triggered2	DINT
Val_Trig2RP	Displays the value of system Temperature that turns the sensor output OFF for Trigger2	REAL
Val_Trig2SP	Display the value of system Temperature that turns the sensor output OFF for Trigger2	REAL
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 837T device object connected to channel #0 of a POINT I/O 1734-4IOL IO-Link Master module in slot #1 of a POINT I/O adapter named *Rack01*.




The following example uses the 837T device object connected to channel #1 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 837T Type1 Sensor device object connected to channel #2 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named Mod_Master_5032_3.





The following example uses the 837T Type2 Sensor device object connected to channel #4 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named Mod_Master_5032_3.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_TempSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_837T_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▸ Sensor837T_102	Sensor 102
▸ Sensor837T_102_CtrlCmd	Sensor837T_102 Command Interface
▸ Sensor837T_102_CtrlSet	Sensor837T_102 Setting Interface
▸ Sensor837T_102_CtrlSts	Sensor837T_102 Status Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger1 Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
6	Process Data - Temperature: Displays the current Temperature value along with unit.



Note: In Case of, 5032 Master, changes made to the Application Specific Name or Locate Toggle Switch require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Temperature Bar Graph Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Temperature Current Value
3	Operating Hours Since Inception



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.


Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. One trend is displayed for Temperature.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Temperature.



Configure Tab


The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Trigger Settings
- Configuration Apply Settings



In case of 5032 Master, “[Config Apply](#)” Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Parameter Settings

Display Mode- The Display Mode will allow the operators to change the type of information that should be shown on the unit display. Operators can select – Current Temperature, Highest Temperature, Lowest Temperature, Triggered 1 Set Temperature, Triggered 1 Reset Temperature, Triggered2 Set Temperature (only available in 2 PNP models), Triggered2 Reset Temperature (only available in 2 x PNP models) and Display OFF.


Display Units- This parameter allows you to change the Temperature measurement that is shown in the sensor display. Acceptable units are psi, bar, MPa, kPa, and kg/cm². The default display unit for these sensors is psi.

Display Rotation- This parameter allows operators to change the orientation of the status indicator by 180°. This feature is deal for applications where the display may be in a direction that’s not visible to the operator and needs to be rotated for ease of use

Lock/Unlock- This parameter keeps unauthorized people from changing the sensor settings when using the local push buttons. Toggle the lock/unlock button to prevent parameterization using local push buttons.

Reset High-Low Temperature- This parameter resets the high and low temperature values stored in the sensor since the last device Reset

Trigger Settings



The Trigger settings divided into sections:

- Trigger 1 - Visible for Single output sensor
- Trigger 2 - Visible for two output sensor

Switch Point- Triggered1 Switch Point/Window High-Condition 1: Sets the system Temperature that turns the sensor output ON when operating in Hysteresis Mode. Or turns the sensor output OFF when the system Temperature exceeds the set value in Window Mode. The operating mode for Triggered1 can be changed by modifying the Function parameter.

To set the desired Set-point value please refer the Temperature range of the 837T Temperature sensor from the user manual

Reset Point- Triggered1 Reset Point/Window Low-Condition 2: Sets the system Temperature that turns the sensor output OFF when operating in Hysteresis Mode. Or it turns the sensor output ON when the system Temperature exceeds the set value in Window Mode. The operating mode for Triggered1 can be changed by modifying the Function parameter. Touch within the Reset Point window to change the value. To set the desired Reset point value please refer the Temperature range of the 837T Temperature sensor from the user manual.

On Delay- Delays the change of state from OFF to ON for the Triggered1 parameter (Output1 in SIO) for up to 32 seconds when the polarity is defined as Normally Open. This parameter helps operators filter out unwanted Temperature peaks in their systems.

Off Delay- Delays the change of state from ON to OFF for the Triggered1 parameter (Output1 in SIO) for up to 32 seconds when the polarity is defined as Normally Open. This parameter helps operators filter out unwanted Temperature peaks in their systems.


Operating Mode- This parameter defines the operating mode for Triggered1 sensor output. The output can be configured to operate in the following modes.

- **Hysteresis Mode:** Output1 and the Triggered1 process data parameter turn ON when the Temperature value is higher than the Switch Point. And turns OFF when the Temperature value is lower than the reset point.
- **Window Mode:** Output1 and the Triggered1 process data parameter turn ON when the Temperature value is between the Switch Point and the Reset Point. It turns OFF when the Temperature value is higher than the Switch Point or lower than the Reset Point.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_837T_4IOL, raC_Dvc_837T_8IOL, raC_Dvc_837T_Type1_5032, raC_Dvc_837T_Type2_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_837T_4IOL, raC_LD_Dvc_837T_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_837T_Type1_5032, raC_LD_Dvc_837T_Type2_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 837T), This name depends upon the TagName assigned to object.

SensorType	837T-D3xxxxxxPA-D4	837T-D3xxxxxxPA-D4	837T-D3xxxxxxPA-D4	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_837T_4IOL	raC_Dvc_837T_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_837T_8IOL	raC_Dvc_837T_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_837T_Type1_5032 Or raC_Dvc_837T_Type2_5032	raC_Dvc_837T_8IOL	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - gfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - gfx
V3_raC_Dvc_837T	Faceplate ME	(raC-3_xx-ME) raC_Dvc_837T-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_837T	Faceplate SE	(raC-3_xx-SE) raC_Dvc_837T-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx

V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

856T - 856T Control Tower Stack Light (raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL, raC_Dvc_856T_5032)

Overview

The 856T Control Tower Stack Light device object (raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL, raC_Dvc_856T_5032) includes HMI faceplate's which displays device information including:

- Sensor data
- Sensor diagnostics
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_856T_Objects_Faceplate.MP4"

Primary device object configuration functions include:

Functional Description

The 856T Control Tower Stack Light Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplate's for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is

defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
856T	POINT I/O 1734-4IOL	856T-B24LC	raC_Dvc_856T_4IOL_3.02_AOI.L5X	raC_Dvc_856T_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	856T-B24LC	raC_Dvc_856T_8IOL_3.02_AOI.L5X	raC_Dvc_856T_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	856T-B24LC	raC_Dvc_856T_5032_3.02_AOI.L5X	raC_Dvc_856T_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
856T	Display	(raC-3_02-ME) raC_Dvc_856T-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_856T-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
856T	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the / *ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
856T	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-ControlIO-Link_raC_Dvc_856T_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_856T_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-ControlIO-Link_raC_Dvc_856T_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_856T_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-ControlIO-Link_raC_Dvc_856T_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_856T_5032_(3.2)


Device Definition (raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




2. Specify the Application Specific Name e.g. *TowerLight_M100*



Device Definition (raC_Dvc_856T_5032)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)





Note: If Sensor is Class B, Then, User should select the IODD for Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 856T, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 856T Sensor.

```

I/O Configuration
├── 1756 Backplane, 1756-A7
│   └── [0] 1756-L85E Master_5032_Test_Cases
├── Ethernet
│   └── 1756-L85E Master_5032_Test_Cases
│       ├── 5032-8IOLM12M12LDR/A Mod_Master_5032_1
│       ├── 5032-8IOLM12M12LDR/A Mod_Master_5032_2
│       └── 5032-8IOLM12M12LDR/A Mod_Master_5032_3
│           └── IO-Link
│               ├── 0 836P-D1xxxA36PP-D4 (182) Mod_836P_Type2
│               ├── 2 837T-D3xxxxxxxPA-D4 (207) Mod_837T_Type1
│               ├── 4 837T-D3xxxxxxxPP-D4 (206) Mod_837T_Type2
│               └── 6 856T-B24LC (297) Mod_856T
│                   ├── 8 871C-D1NP4-AP3 (80) Mod_871C
│                   ├── 10 871FM-M10BA30-xxxx (200) Mod_871FM_Type1
│                   └── 12 871FM-M1NP5-AP3 (129) Mod_871FM_Type2
│                       └── 14 871TM-M10NP18-A2 (101) Mod_871TM
    
```

3. Configure the parameters of sensor from configuration tab from AOP of the 856T sensor.

Name	R/W	Value	Units	Style	Description
Identification					
User Specific Information					
Application-specific Tag	rw	xxx	**		
Parameter					
Module Configuration					
Module 1 Type	rw	No Module			
Module 2 Type	rw	No Module			
Module 3 Type	rw	No Module			
Module 4 Type	rw	No Module			
Module 5 Type	rw	No Module			
Module 6 Type	rw	No Module			
Module 7 Type	rw	No Module			
Circuit Configuration					
Circuit 1					
Cycle Counter	rw	OFF			
Circuit 2					
Cycle Counter	rw	OFF			
Circuit 3					
Cycle Counter	rw	OFF			
Circuit 4					
Cycle Counter	rw	OFF			

Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data

(raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_856T_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_856T_Inp_4IOL Or raC_UDT_ItfAD_856T_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Out_ChxControlModule1	Control Module1; Bit 0 = Behaviour, Bit 1 = Behaviour, Bit 2 = Behaviour, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule2	Control Module2; Bit 0 = Behaviour, Bit 1 = Behaviour, Bit 2 = Behaviour, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule3	Control Module3; Bit 0 = Behaviour, Bit 1 = Behaviour, Bit 2 = Behaviour, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule4	Control Module4; Bit 0 = Behaviour, Bit 1 = Behaviour, Bit 2 = Behaviour, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule5	Control Module5; Bit 0 = Behaviour, Bit 1 = Behaviour, Bit 2 = Behaviour, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule6	Control Module6; Bit 0 = Behaviour, Bit 1 = Behaviour, Bit 2 = Behaviour, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule7	Control Module7; Bit 0 = Behaviour, Bit 1 = Behaviour, Bit 2 = Behaviour, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT

Input Data

Input	Function/Description	Data Type
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxAlarmStatus	Configure Device Object Input Alarm Status	INT
Set_VibCalibPeriod	Vibration Calibration Period Set Value	REAL

Input	Function/Description	Data Type
Set_VibWarningLimitX	Vibration X-axis Warning Limit Set Value	REAL
Set_VibWarningLimitY	Vibration Y-axis Warning Limit Set Value	REAL
Set_VibWarningLimitZ	Vibration Z-axis Warning Limit Set Value	REAL
Cfg_DD1ControlOutput1	Control Output1 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput2	Control Output2 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput3	Control Output3 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput4	Control Output4 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput5	Control Output5 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput6	Control Output6 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput7	Control Output7 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD2ControlOutput1	Control Output1 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput2	Control Output2 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput3	Control Output3 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput4	Control Output4 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput5	Control Output5 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput6	Control Output6 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput7	Control Output7 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_ModuleType1	Module Type1; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType2	Module Type2; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType3	Module Type3; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType4	Module Type4; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT

Input	Function/Description	Data Type
Cfg_ModuleType5	Module Type5; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType6	Module Type6; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType7	Module Type7; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_VibCalibStartStop	Vibration calibration Start/Stop Command	INT
Cmd_LocalTeachLock	Local Parameterization; 0 = Unlock, 1 = Locked	BOOL

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_InhibitCfg	Disable Configuration inputs from external sources	BOOL
Sts_InhibitCmd	Disable Command inputs from external sources	BOOL
Sts_InhibitSet	Disable Setting inputs from external sources	BOOL
Val_ClassAVoltage	Class A power supply voltage	REAL
Val_ClassBVoltage	Class B (auxiliary) power supply voltage	REAL
Val_CurrentModuleType1	Module Type1; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType2	Module Type2; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType3	Module Type3; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType4	Module Type4; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType5	Module Type5; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType6	Module Type6; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType7	Module Type7; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_OperatingHrsSinceInception	Indicates the time the IO-link module has been functional since first powered	DINT
Val_OperatingHrsSincePowerUp	Indicates the amount of time the IO-link module has been functional since last power cycle	DINT
Val_TemperatureCurrent	Current internal temperature of the IO-Link module since powerup or last power cycle	INT

Output	Function/Description	Data Type
Val_TemperatureMaxSincePowerUp	Maximum internal temperature of the IO-Link module since powerup or last power cycle	INT
Val_TemperatureMinSincePowerUp	Minimum internal temperature of the IO-Link module since powerup or last power cycle	INT
Val_VibAvgXAxis	The average vibration value for X-axis	REAL
Val_VibAvgYAxis	The average vibration value for Y-axis	REAL
Val_VibAvgZAxis	The average vibration value for Z-axis	REAL
Val_VibCalibPeriod	Vibration Calibration Period	REAL
Val_VibCalibStatusData	The functional state of the calibration process once activated	SINT
Val_VibMaxLifetimeXAxis	The average vibration value for X-axis	REAL
Val_VibMaxLifetimeYAxis	The average vibration value for Y-axis	REAL
Val_VibMaxLifetimeZAxis	The average vibration value for Z-axis	REAL
Val_VibMaxSPUXAxis	The maximum vibration value for X-axis since powerup	REAL
Val_VibMaxSPUYAxis	The maximum vibration value for Y-axis since powerup	REAL
Val_VibMaxSPUZAxis	The maximum vibration value for Z-axis since powerup	REAL
Val_VibWarningLimitX	Vibration threshold limit value of X-axis	REAL
Val_VibWarningLimitY	Vibration threshold limit value of Y-axis	REAL
Val_VibWarningLimitZ	Vibration threshold limit value of Z-axis	REAL
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data InOut Data (raC_Dvc_856T_5032)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_856T_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_856T_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Out_O	Device Object Output	raC_UDT_IOLink_856T_PdataOut_5032
Cfg_C	Device Object Configuration	raC_UDT_IOLink_856T_Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxAlarmStatus	Configure Device Object Input Alarm Status	INT
Set_VibCalibPeriod	Vibration Calibration Period Set Value	REAL
Set_VibWarningLimitX	Vibration X-axis Warning Limit Set Value	REAL
Set_VibWarningLimitY	Vibration Y-axis Warning Limit Set Value	REAL
Set_VibWarningLimitZ	Vibration Z-axis Warning Limit Set Value	REAL
Cfg_DD1ControlOutput1	Control Output1 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput2	Control Output2 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput3	Control Output3 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput4	Control Output4 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput5	Control Output5 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput6	Control Output6 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD1ControlOutput7	Control Output7 Module Behaviors; 0 = OFF, 1 = ON Steady, 2 = Slow Flash, 3 = Fast Flash	INT
Cfg_DD2ControlOutput1	Control Output1 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT

Input	Function/Description	Data Type
Cfg_DD2ControlOutput2	Control Output2 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput3	Control Output3 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput4	Control Output4 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput5	Control Output5 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput6	Control Output6 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_DD2ControlOutput7	Control Output7 Color or Sound; 0 = Red, 1 = Reserved, 2 = Yellow, 3 = Green, 4 = Blue, 5 = Cyan (Turquoise), 6 = Magenta, 7 = White, 8 = Sound1, 9 = Sound2, 10 = Sound3, 11 = Sound4, 12 = Sound5, 13 = Sound6, 14 = Sound7, 15 = Reserved	INT
Cfg_ModuleType1	Module Type1; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType2	Module Type2; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType3	Module Type3; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType4	Module Type4; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType5	Module Type5; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType6	Module Type6; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_ModuleType7	Module Type7; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Cfg_VibCalibStartStop	Vibration calibration Start/Stop Command	INT
Cmd_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_InhibitCfg	Disable Configuration inputs from external sources	BOOL
Sts_InhibitCmd	Disable Command inputs from external sources	BOOL
Sts_InhibitSet	Disable Setting inputs from external sources	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_ClassAVoltage	Class A power supply voltage	REAL
Val_ClassBVoltage	Class B (auxiliary) power supply voltage	REAL
Val_CurrentModuleType1	Module Type1; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType2	Module Type2; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType3	Module Type3; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType4	Module Type4; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType5	Module Type5; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType6	Module Type6; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_CurrentModuleType7	Module Type7; 0 = No Module, 1 = Steady Light, 2 = Multi-function Light, 3 = Rotating Light, 4 = Multi-color Light, 5 = Steady/Flash beacon, 6 = Strobe beacon, 7 = Rotating beacon, 8 = Multi-color beacon, 9 = Piezo Electric Sound, 10 = Transducer Sound, 11 = Recordable Sound	INT
Val_OperatingHrsSinceInception	Indicates the time the IO-link module has been functional since first powered	DINT

Output	Function/Description	Data Type
Val_OperatingHrsSincePowerUp	Indicates the amount of time the IO-link module has been functional since last power cycle	DINT
Val_TemperatureCurrent	Current internal temperature of the IO-Link module since powerup or last power cycle	INT
Val_TemperatureMaxSincePowerUp	Maximum internal temperature of the IO-Link module since powerup or last power cycle	INT
Val_TemperatureMinSincePowerUp	Minimum internal temperature of the IO-Link module since powerup or last power cycle	INT
Val_VibAvgXAxis	The average vibration value for X-axis	REAL
Val_VibAvgYAxis	The average vibration value for Y-axis	REAL
Val_VibAvgZAxis	The average vibration value for Z-axis	REAL
Val_VibCalibPeriod	Vibration Calibration Period	REAL
Val_VibCalibStatusData	The functional state of the calibration process once activated	SINT
Val_VibMaxLifetimeXAxis	The average vibration value for X-axis	REAL
Val_VibMaxLifetimeYAxis	The average vibration value for Y-axis	REAL
Val_VibMaxLifetimeZAxis	The average vibration value for Z-axis	REAL
Val_VibMaxSPUXAxis	The maximum vibration value for X-axis since powerup	REAL
Val_VibMaxSPUYAxis	The maximum vibration value for Y-axis since powerup	REAL
Val_VibMaxSPUZAxis	The maximum vibration value for Z-axis since powerup	REAL
Val_VibWarningLimitX	Vibration threshold limit value of X-axis	REAL
Val_VibWarningLimitY	Vibration threshold limit value of Y-axis	REAL
Val_VibWarningLimitZ	Vibration threshold limit value of Z-axis	REAL
Out_ChxControlModule1	Control Module1; Bit 0 = Behavior, Bit 1 = Behavior, Bit 2 = Behavior, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule2	Control Module2; Bit 0 = Behavior, Bit 1 = Behavior, Bit 2 = Behavior, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule3	Control Module3; Bit 0 = Behavior, Bit 1 = Behavior, Bit 2 = Behavior, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule4	Control Module4; Bit 0 = Behavior, Bit 1 = Behavior, Bit 2 = Behavior, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT


Output	Function/Description	Data Type
Out_ChxControlModule5	Control Module5; Bit 0 = Behavior, Bit 1 = Behavior, Bit 2 = Behavior, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule6	Control Module6; Bit 0 = Behavior, Bit 1 = Behavior, Bit 2 = Behavior, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
Out_ChxControlModule7	Control Module7; Bit 0 = Behavior, Bit 1 = Behavior, Bit 2 = Behavior, Bit 3 = Color/Sound, Bit 4 = Color/Sound, Bit 5 = Color/Sound	SINT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 856T device object connected to channel #2 of a POINT I/O 1734-4IOL IO-Link Master module in slot #3 of a POINT I/O adapter named *Rack01*.



The following example uses the 856T device object connected to channel #4 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 856T device object connected to channel #12 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master5032*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram_...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_TempSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram_...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_856T_Launch		<p>The supplied launch button in View Designer is used to navigate to the faceplate in a user application.</p>	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Sensor856T_102	Sensor 102
▶ Sensor856T_102_CtrlCmd	Sensor856T_102 Command Interface
▶ Sensor856T_102_CtrlSet	Sensor856T_102 Setting Interface
▶ Sensor856T_102_CtrlSts	Sensor856T_102 Status Interface
▶ Sensor856T_102_Inp_I	Sensor856T_102 Input Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data.




Item	Description
1	Banner- Ready Status
2	Configured module type on Tower Light
3	Non Configured module type on Tower Light
4	Application Specific Name - Read from device




Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Temperature Bar Graph Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Temperature Current Value
3	Operating Hours Since Inception
4	Operating Hours Since PowerUp
5	Class A Voltage
6	Class B Voltage

 Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.

Configure Tab

The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

 In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.




Parameter Settings

Module Type- Based on installed module on Tower light user can configure the module using module type selection. The following options list is available.

1. Steady Light
2. Multi-function Light
3. Rotating Light
4. Multi-color Light
5. Steady/Flashing beacon
6. Strobe beacon
7. Rotating beacon
8. Multi-color beacon
9. Piezo Electric Sounder
10. Transducer Sounder
11. Recordable Sound

Control Output Display Lock/Unlock- The Toggle button is used to Lock and Unlock the Control Output Display settings. If it is Unlock, then it will allow the user to choose the Control Output function from the HMI.


Control Output Settings- Based on the light or Sound module connected in each circuit, the output color and sound can also be configured.



Vibration Setting- To set Vibration indication which used to alert about unusual mechanical behavior when the IO-Link module detects vibration above certain threshold values.

Vibration settings divided into sections:


- Calibration
- Warning Limit



Calibration Period- The Calibration Period allows you to enter the time in which the IO-Link module gathers vibration samples to compute and obtain the vibration thresholds per axis.

Calibration Status- Calibration Status shows the functional state of the calibration process once activated.

Start, Stop Calibration - To start & Stop the calibration click the button



Warning Limit- The Warning Limit for X-axis, Y-axis, Z-axis allows you to enter a desired vibration threshold.

Average- Provides the average vibration value for each X, Y and Z axis.


Maximum Since Power Up- Provides the maximum vibration value for each X, Y and Z axis, since power up.

Maximum Lifetime- Provides the maximum vibration value for each X, Y and Z axis, since inception.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_856T_4IOL, raC_Dvc_856T_8IOL, raC_Dvc_856T_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_856T_4IOL, raC_LD_Dvc_856T_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_856T_5032

Parameter Name	Default Value	Instance Name	Definition	Description
----------------	---------------	---------------	------------	-------------

TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 856T), This name depends upon the TagName assigned to object.
SensorType	856T-B24LC	856T-B24LC	856T-B24LC	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_856T_4IOL	raC_Dvc_856T_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_856T_8IOL	raC_Dvc_856T_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_856T_5032	raC_Dvc_856T_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button

Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
------------------	-------------------------------	---

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_856T	Faceplate ME	(raC-3_xx-ME) raC_Dvc_856T-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_856T	Faceplate SE	(raC-3_xx-SE) raC_Dvc_856T-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

873P - Analog Output Ultrasonic Sensor (raC_Dvc_873P_4IOL, raC_Dvc_873P_8IOL, raC_Dvc_873P_Type1_5032, raC_Dvc_873P_Type2_5032)

Overview

The 873P Analog Output Ultrasonic Sensor device object (raC_Dvc_873P_4IOL, raC_Dvc_873P_8IOL, raC_Dvc_873P_Type1_5032, raC_Dvc_873P_Type2_5032) includes HMI faceplate's which displays device information including:

- Sensor data
- Sensor diagnostics
- Process data trending
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_873P_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).

Functional Description

The 873P Analog Output Ultrasonic Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplate's for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplate's. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with four versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
873P	POINT I/O 1734-4IOL	873P-D18AI-2200-D5, 873P-D18AI-400-D5, 873P-D18AI-900-D5, 873P-D18AIP2-900-D5, 873P-D18AV-2200-D5, 873P-D18AV-400-D5, 873P-D18AV-900-D5, 873P-D30AI-2500-D5, 873P-D30AI-3500-D5, 873P-D30AI-6000-D5, 873P-D30AIP2-2500-D5, 873P-D30AIP2-3500-D5, 873P-D30AIP2-6000-D5, 873P-D30AV-2500-D5, 873P-D30AV-3500-D5, 873P-D30AV-6000-D5, 873P-D30AVP2-2500-D5, 873P-D30AVP2-3500-D5, 873P-D30AVP2-6000-D5 873P-D18P1-2200-D4, 873P-D18P1-400-D4, 873P-D18P1-900-D4, 873P-D18P2-2200-D5, 873P-D18P2-400-D5, 873P-D18P2-900-D5, 873P-D30P1-2500-D4, 873P-D30P1-3500-D4, 873P-D30P1-6000-D4, 873P-D30P2-2500-D5, 873P-D30P2-3500-D5, 873P-D30P2-6000-D5	raC_Dvc_873P_4IOL_3.02_AOI.L5X	raC_Dvc_873P_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	873P-D18AI-2200-D5, 873P-D18AI-400-D5, 873P-D18AI-900-D5, 873P-D18AIP2-900-D5, 873P-D18AV-2200-D5, 873P-D18AV-400-D5, 873P-D18AV-900-D5, 873P-D30AI-2500-D5, 873P-D30AI-3500-D5, 873P-D30AI-6000-D5, 873P-D30AIP2-2500-D5, 873P-D30AIP2-3500-D5, 873P-D30AIP2-6000-D5, 873P-D30AV-2500-D5, 873P-D30AV-3500-D5, 873P-D30AV-6000-D5, 873P-D30AVP2-2500-D5, 873P-D30AVP2-3500-D5, 873P-D30AVP2-6000-D5 873P-D18P1-2200-D4, 873P-D18P1-400-D4, 873P-D18P1-900-D4, 873P-D18P2-2200-D5, 873P-D18P2-400-D5, 873P-D18P2-900-D5, 873P-D30P1-2500-D4, 873P-D30P1-3500-D4, 873P-D30P1-6000-D4, 873P-D30P2-2500-D5, 873P-D30P2-3500-D5, 873P-D30P2-6000-D5	raC_Dvc_873P_8IOL_3.02_AOI.L5X	raC_Dvc_873P_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	873P-D18AI-2200-D5, 873P-D18AI-400-D5, 873P-D18AI-900-D5, 873P-D18AIP2-900-D5, 873P-D18AV-2200-D5, 873P-D18AV-400-D5, 873P-D18AV-900-D5, 873P-D30AI-2500-D5, 873P-D30AI-3500-D5, 873P-D30AI-6000-D5, 873P-D30AIP2-2500-D5, 873P-D30AIP2-3500-D5, 873P-D30AIP2-6000-D5, 873P-D30AV-2500-D5, 873P-D30AV-3500-D5, 873P-D30AV-6000-D5, 873P-D30AVP2-2500-D5, 873P-D30AVP2-3500-D5, 873P-D30AVP2-6000-D5 873P-D18P1-2200-D4, 873P-D18P1-400-D4, 873P-D18P1-900-D4, 873P-D18P2-2200-D5, 873P-D18P2-400-D5, 873P-D18P2-900-D5, 873P-D30P1-2500-D4, 873P-D30P1-3500-D4, 873P-D30P1-6000-D4, 873P-D30P2-2500-D5, 873P-D30P2-3500-D5, 873P-D30P2-6000-D5	raC_Dvc_873P_Type1_5032_3.02_AOI.L5X	raC_Dvc_873P_Type1_5032_3.02_RUNG.L5X
		873P-D18P1-2200-D4, 873P-D18P1-400-D4, 873P-D18P1-900-D4, 873P-D18P2-2200-D5, 873P-D18P2-400-D5, 873P-D18P2-900-D5, 873P-D30P1-2500-D4, 873P-D30P1-3500-D4, 873P-D30P1-6000-D4, 873P-D30P2-2500-D5, 873P-D30P2-3500-D5, 873P-D30P2-6000-D5	raC_Dvc_873P_Type2_5032_3.02_AOI.L5X	raC_Dvc_873P_Type2_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
873P	Display	(raC-3_02-ME) raC_Dvc_873P-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_873P-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
873P	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
873P	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_873P_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_873P_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_873P_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_873P_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_873P_Type1_5032_(3.2) (RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_873P_Type2_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_873P_5032_(3.2)


Device Definition (raC_Dvc_873P_4IOL, raC_Dvc_873P_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




- Specify the Application Specific Name e.g. *DistanceSensor_100*



Device Definition (raC_Dvc_873P_Type1_5032, 2, raC_Dvc_873P_Type2_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

- Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)



Note: If Sensor is Class B, Then, User should select the IO-Link for Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 873P, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 873P Sensor.



3. Configure the parameters of sensor from configuration tab from AOP of the 873P sensor.

Name	R/W	Value	Units	Style	Description
Identification					
User Specific Information					
Application-specific Tag	rw	...			
User Tag 1	rw	...			
User Tag 2	rw	...			
Parameter					
Output configuration					
Analog Output Slope	rw	Analog signal rising			Output configuration [OUT 2]
Analog Output 2					
Analog Start Point 2 (ASP2)	rw	100	mm	Deciml	Analogue start point 2. [ASP2] must be smaller t...
Analog End Point 2 (AEP2)	rw	900	mm	Deciml	Analogue end point 2. [AEP2] must be greater th...
Signal					
Filter	rw	MEdl			Filter or response time of the measured signal, L...
Suppression Mode	rw	Background Reflection			Background Suppression
Sound Cone Width	rw	normal sound cone			
Teach					
Select Trigger	rw	SSC1			Teach selection
Suppression Distance	rw	900	mm	Deciml	Distance to background. Value must be greater t...
Triggered1					
SP1	rw	100	mm	Deciml	
SP2	rw	100	mm	Deciml	

Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data (raC_Dvc_873P_4IOL, raC_Dvc_873P_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_873P_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_873P_Inp_4IOL Or raC_UDT_ItfAD_873P_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger1	BOOL
Inp_ChxTriggered2	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger2	BOOL
Inp_ChxDistance	Displays Distance in mm - non-adjustable	DINT
Inp_ChNumber	Configured Channel Number for Master	SINT
Inp_ChxTemperature	Current Internal Temperature	DINT
Cfg_Filter	Filter; 0= Off, 1= Low, 2= Medium, 3= High	INT
Cfg_T1Mode	Trigger1 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	INT
Cfg_T2Mode	Trigger2 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	INT
Cfg_TeachSp	Teach Setpoint; 0= Set Point1, 1= Set Point2	INT
Cfg_TeachTrigCh	Teach Triggered Channel; 0= Triggered1, 1= Triggered2	SINT
Cmd_AnalogSlope	Analog Output Slope Rising/Falling Cmd	BOOL
Cmd_BGMode	Suppression Mode Reflect/Suppress Cmd	BOOL
Cmd_EnableCounter	Counter Disabled/Enabled Cmd	BOOL
Cmd_EnableLEDs	Indicator Disabled/Enabled Cmd	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL

Input	Function/Description	Data Type
Cmd_Locate	Locator Disable/Enable Cmd	BOOL
Cmd_ResetCount	Counter Reset Cmd	BOOL
Cmd_SoundCone	Sound Cone Width Narrow/Normal Cmd	BOOL
Cmd_T1ActiveLow	Trigger1 Logic High/Low Active Cmd	BOOL
Cmd_T2ActiveLow	Trigger2 Logic High/Low Active Cmd	BOOL
Cmd_TeachApply	Teach Apply Cmd	BOOL
Set_AnalogEnd	Analog End Point Set Value	INT
Set_AnalogStart	Analog Start Point Set Value	INT
Set_Suppression	Suppression Mode Set Value	INT
Set_T1Hysteresis	Trigger1 Hysteresis Set Value	INT
Set_T1OffDelay	Trigger1 Switch-Off delay Set Value	INT
Set_T1OnDelay	Trigger1 Switch-On delay Set Value	INT
Set_T1Sp1	Trigger1 SetPoint1 Set Value	INT
Set_T1Sp2	Trigger1 SetPoint2 Set Value	INT
Set_T2Hysteresis	Trigger2 Hysteresis Set Value	INT
Set_T2OffDelay	Trigger2 Switch-Off delay Set Value	INT
Set_T2OnDelay	Trigger2 Switch-On delay Set Value	INT
Set_T2Sp1	Trigger2 SetPoint1 Set Value	INT
Set_T2Sp2	Trigger2 SetPoint2 Set Value	INT
Set_TrendDistMaxValue	Trend Tab Distance Max for VD/ME/SE Faceplate (Below Val_RangeMax)	DINT
Set_TrendDistMinValue	Trend Tab Distance Min for VD/ME/SE Faceplate (Above Val_RangeMin)	DINT
Set_TrendTempMaxValue	Trend Tab Temperature Max for VD/ME/SE Faceplate (-20 To 70)	DINT
Set_TrendTempMinValue	Trend Tab Temperature Min for VD/ME/SE Faceplate (-20 To 70)	DINT

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_AnalogSlope	Analog Output Slope; 0= Rising, 1= Falling	BOOL
Sts_BGMode	Suppression Mode; 0= Reflection, 1= Suppression	BOOL
Sts_EnableCounter	Counter Enable; 0= Disable, 1= Enable	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_SoundCone	Sound Cone; 0= Normal, 1= Narrow	BOOL
Sts_T1ActiveLow	Trigger1 Logic Active; 0= Low, 1=High	BOOL
Sts_T2ActiveLow	Trigger2 Logic Active; 0= Low, 1=High	BOOL
Val_AnalogEnd	Analog End Point	INT
Val_AnalogStart	Analog Start Point	INT
Val_Filter	Filter Selected	INT
Val_HysteresisMax	Hysteresis Maximum Selected	DINT
Val_OperatingHours	Operating Hours	INT
Val_PowerCycles	Number of Power Cycle	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Suppression	Suppression Distance	INT
Val_T1Hysteresis	Trigger1 Hysteresis	INT
Val_T1Mode	Trigger1 Operating Mode Selected	INT
Val_T1OffDelay	Trigger1 Switch-Off Delay	INT
Val_T1OnDelay	Trigger1 Switch-On Delay	INT

Output	Function/Description	Data Type
Val.T1Sp1	Trigger1 Setpoint1	INT
Val.T1Sp2	Trigger1 Setpoint2	INT
Val.T2Hysteresis	Trigger2 Hysteresis	INT
Val.T2Mode	Trigger2 Operating Mode Selected	INT
Val.T2OffDelay	Trigger2 Switch-Off Delay	INT
Val.T2OnDelay	Trigger2 Switch-On Delay	INT
Val.T2Sp1	Trigger2 Setpoint1	INT
Val.T2Sp2	Trigger2 Setpoint2	INT
Val.TeachTrig	Teach Trigger Channel Selected	INT
Val.TemperatureMaxSinceInception	Maximum Temperature Since Inception	DINT
Val.TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	DINT
Val.TemperatureMinSinceInception	Minimum Temperature Since Inception	DINT
Val.TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	DINT
Val.TriggerCount	Trigger Counter	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_873P_Type1_5032, raC_Dvc_873P_Type2_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_873P_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_873P_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_873P_Type1_Cfg Or raC_UDT_IOLink_873P_Type2_Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger1	BOOL
Inp_ChxTriggered2	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger2	BOOL
Inp_ChxDistance	Displays Distance in mm - non-adjustable	DINT
Inp_ChNumber	Configured Channel Number for Master	SINT
Inp_ChxTemperature	Current Internal Temperature	DINT
Cfg_Filter	Filter; 0= Off, 1= Low, 2= Medium, 3= High	INT
Cfg_T1Mode	Trigger1 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	INT
Cfg_T2Mode	Trigger2 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	INT
Cfg_TeachSp	Teach Setpoint; 0= Set Point1, 1= Set Point2	INT
Cfg_TeachTrigCh	Teach Triggered Channel; 0= Triggered1, 1= Triggered2	SINT
Cmd_AnalogSlope	Analog Output Slope Rising/Falling Cmd	BOOL
Cmd_BGMode	Suppression Mode Reflect/Suppress Cmd	BOOL
Cmd_EnableCounter	Counter Disabled/Enabled Cmd	BOOL

Input	Function/Description	Data Type
Cmd_EnableLEDs	Indicator Disabled/Enabled Cmd	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Cmd	BOOL
Cmd_ResetCount	Counter Reset Cmd	BOOL
Cmd_SoundCone	Sound Cone Width Narrow/Normal Cmd	BOOL
Cmd_T1ActiveLow	Trigger1 Logic High/Low Active Cmd	BOOL
Cmd_T2ActiveLow	Trigger2 Logic High/Low Active Cmd	BOOL
Cmd_TeachApply	Teach Apply Cmd	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Set_AnalogEnd	Analog End Point Set Value	INT
Set_AnalogStart	Analog Start Point Set Value	INT
Set_Suppression	Suppression Mode Set Value	INT
Set_T1Hysteresis	Trigger1 Hysteresis Set Value	INT
Set_T1OffDelay	Trigger1 Switch-Off delay Set Value	INT
Set_T1OnDelay	Trigger1 Switch-On delay Set Value	INT
Set_T1Sp1	Trigger1 SetPoint1 Set Value	INT
Set_T1Sp2	Trigger1 SetPoint2 Set Value	INT
Set_T2Hysteresis	Trigger2 Hysteresis Set Value	INT
Set_T2OffDelay	Trigger2 Switch-Off delay Set Value	INT
Set_T2OnDelay	Trigger2 Switch-On delay Set Value	INT
Set_T2Sp1	Trigger2 SetPoint1 Set Value	INT
Set_T2Sp2	Trigger2 SetPoint2 Set Value	INT
Set_TrendDistMaxValue	Trend Tab Distance Max for VD/ME/SE Faceplate (Below Val_RangeMax)	DINT
Set_TrendDistMinValue	Trend Tab Distance Min for VD/ME/SE Faceplate (Above Val_RangeMin)	DINT
Set_TrendTempMaxValue	Trend Tab Temperature Max for VD/ME/SE Faceplate (-20 To 70)	DINT
Set_TrendTempMinValue	Trend Tab Temperature Min for VD/ME/SE Faceplate (-20 To 70)	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL

Output	Function/Description	Data Type
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_AnalogSlope	Analog Output Slope; 0= Rising, 1= Falling	BOOL
Sts_BGMMode	Suppression Mode; 0= Reflection, 1= Suppression	BOOL
Sts_EnableCounter	Counter Enable; 0= Disable, 1= Enable	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_SoundCone	Sound Cone; 0= Normal, 1= Narrow	BOOL
Sts_T1ActiveLow	Trigger1 Logic Active; 0= Low, 1=High	BOOL
Sts_T2ActiveLow	Trigger2 Logic Active; 0= Low, 1=High	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_AnalogEnd	Analog End Point	INT
Val_AnalogStart	Analog Start Point	INT
Val_Filter	Filter Selected	INT
Val_HysteresisMax	Hysteresis Maximum Selected	DINT
Val_OperatingHours	Operating Hours	INT
Val_PowerCycles	Number of Power Cycle	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Suppression	Suppression Distance	INT
Val_T1Hysteresis	Trigger1 Hysteresis	INT
Val_T1Mode	Trigger1 Operating Mode Selected	INT
Val_T1OffDelay	Trigger1 Switch-Off Delay	INT
Val_T1OnDelay	Trigger1 Switch-On Delay	INT
Val_T1Sp1	Trigger1 Setpoint1	INT
Val_T1Sp2	Trigger1 Setpoint2	INT
Val_T2Hysteresis	Trigger2 Hysteresis	INT
Val_T2Mode	Trigger2 Operating Mode Selected	INT
Val_T2OffDelay	Trigger2 Switch-Off Delay	INT


Output	Function/Description	Data Type
Val.T2OnDelay	Trigger2 Switch-On Delay	INT
Val.T2Sp1	Trigger2 Setpoint1	INT
Val.T2Sp2	Trigger2 Setpoint2	INT
Val.TeachTrig	Teach Trigger Channel Selected	INT
Val.TemperatureMaxSinceInception	Maximum Temperature Since Inception	DINT
Val.TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	DINT
Val.TemperatureMinSinceInception	Minimum Temperature Since Inception	DINT
Val.TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	DINT
Val.TriggerCount	Trigger Counter	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference. The first rung is required and the others are optional.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 873P device object connected to channel #2 of a POINT I/O 1734-4IOL IO-Link Master module in slot #1 of a POINT I/O adapter named *Rack01*.




The following example uses the 873P device object connected to channel #2 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_Master*.



The following example uses the 873P Type 1 Sensor device object connected to channel #0 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_4*.





The following example uses the 873P Type 2 Sensor device object connected to channel #2 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_4*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram_...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_UltraSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram_...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_873P_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates

There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Sensor873P_102	Sensor 102
▶ Sensor873P_102_CtrlCmd	Sensor873P_102 Com...
▶ Sensor873P_102_CtrlSet	Sensor873P_102 Setti...
▶ Sensor873P_102_CtrlSts	Sensor873P_102 Stat...
▶ Sensor873P_102_Inp_I	Sensor873P_102 Inpu...

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status 1 & 2 OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger1 & 2 Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
6	Process Data: Displays the Distance value along with unit.
7	Process Data: Displays the Temperature value along with unit.
8	Process Data: Displays the Trigger Count value.



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab


Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.



Item	Description
1	Device Temperature Bar Graph Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Device Temperature Current Value
3	Number of Power Cycle


Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. Two trends are displayed. One for Distance and the other for temperature.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Scaling.



Configure Tab


The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Trigger Settings
- Teach Settings
- Reset Counts
- Configuration Apply Settings



In case of 5032 Master, "[Config Apply](#)" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Parameter Settings

Analog Output Slope- Applied to configure an analog output when the sensor is operated in the Standard I/O (SIO) mode.

Item	Description
Signal Slope	Use toggle button to select Rising / Falling of Analog signal slope. •Rising- Analog value increases with increasing distance. •Falling- Analog value decreases with increasing distance.
Start Point	Set the Analog Starting Point (ASP) value to define an analog range.
End Point	Set the Analog Ending Point (AEP) value to define an analog range.


Signal Setting-

Item	Description
Filter	Click the Filter Dropdown object & choose one of the filter. The filter feature is applied for non-static objects such as liquid with a turbulent surface.
Suppression Mode	Use toggle button to select the Background reflection / Background Suppression
Sound Cone Width	Allows for the adjustment of the acoustic beam width. A narrow sound cone has around 10% beam width reduction compared to the normal sound cone.

Local Setting-

Item	Description
LED's	Allows you to turn off or disable indicators at operation. Default is 'enabled.'
Parameter Lock	Applied to Lock or Unlock the teach button. • Lock: Teach button which is mounted on device is disabled/locked. • Unlock: Teach button which is mounted on device is enabled.
Trigger Counter	Use toggle button to Enable or disable this function. Default is 'disabled'

Trigger Settings



Operating Mode- There are four operation modes for each trigger/output

- Single Point
- Window
- Two Point
- Deactivated

SP1 (Far)- To set Switching point 1 click on input field and enter the value.

SP2 (Near)- To set Switching point 2 click on input field and enter the value.

Hysteresis- To set Hysteresis click on input field and enter the value.


On Delay- The On Delay defines the desired delay for the output to turn ON once a target has been detected.

Off Delay- The Off Delay defines the desired delay for the output to turn OFF once a target has left the detection area.

Logic Active- Use the toggle button to select the High Active (Normally Open) / Low Active (Normally Closed).

Teach Settings-


1. Choose Trigger 1 or 2
2. Select Set Point 1 or 2
3. Set Background Suppression Distance Value
4. Press Teach Apply Button




Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_873P_4I0L, raC_Dvc_873P_8I0L, raC_Dvc_873P_Type1_5032, raC_Dvc_873P_Type2_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_873P_4IOL, raC_LD_Dvc_873P_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_873P_Type1_5032, raC_LD_Dvc_873P_Type2_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReferance		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 873P), This name depends upon the TagName assigned to object.
SensorType	873P-D18AI-2200-D5	873P-D18AI-2200-D5	873P-D18AI-2200-D5	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)

ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_873P_4IOL	raC_Dvc_873P_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_873P_8IOL	raC_Dvc_873P_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_873P_Type1_5032 Or raC_Dvc_873P_Type2_5032	raC_Dvc_873P_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_873P	Faceplate ME	(raC-3_xx-ME) raC_Dvc_873P-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_873P	Faceplate SE	(raC-3_xx-SE) raC_Dvc_873P-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

1694 - 1694 Modular Electronic Circuit Protector (raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL, raC_Dvc_1694_5032)

Overview

The 1694 Modular Electronic Circuit Protector device object (raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL, raC_Dvc_1694_5032) includes HMI faceplate's which displays device information including:

- Sensor data
- Sensor I/O
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_1694_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- Provides overall status and device monitoring parameters for power feed 1694-PMD and each channel controlled by Electronic Circuit Protection device.
- Allows you to change the device parameters offered by 1694 Electronic Circuit Protection system.
- Provides diagnostics parameter information, those parameters facilitate troubleshooting if device does not work correctly.

Functional Description

The 1694 Modular Electronic Circuit Protector Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplate's for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
1694	POINT I/O 1734-4IOL	1694-PFD1244	raC_Dvc_1694_4IOL_3.02_AOI.L5X	raC_Dvc_1694_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	1694-PFD1244	raC_Dvc_1694_8IOL_3.02_AOI.L5X	raC_Dvc_1694_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	1694-PFD1244	raC_Dvc_1694_5032_3.02_AOI.L5X	raC_Dvc_1694_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL or 8IOL versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
1694	Display	(raC-3_02-ME) raC_Dvc_1694-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_1694-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
1694	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
1694	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_1694_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_1694_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_1694_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_1694_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_1694_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_1694_5032_(3.2)


Device Definition (raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




2. Specify the Application Specific Name e.g. *SensorProtection_100*



Device Definition (raC_Dvc_1694_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IODD for Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 1694 you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 1694 Sensor.



3. Configure the parameters of sensor from configuration tab from AOP of the 1694 sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data (raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Ref_Msg_Read_Index_Sync	Message Configuration Read	MESSAGE
Ref_Msg_Data	Message Configuration Data	raC_UDT_1694_Msg_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	aC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STRO082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_1694_Inp_4IOL Or raC_UDT_ItfAD_1694_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Out_O	1694_4IOL Out Data	raC_UDT_ItfAD_1694_Out_4IOL

Input Data

Input	Function/Description	Data Type
Cfg_ChannelSelection	Select Channel Number	DINT
Cfg_ResetTrip	Trip Reset Alarm	INT
Cmd_PLCControlTrigger	Allows user to define if a particular channel can be controlled by PLC	BOOL
Cmd_Refresh	Allows user to update values	BOOL
Cmd_ResetAvgMemory	Average Memory Reset Command	BOOL
Cmd_ResetFault	Update Channel Values	BOOL
Cmd_ResetMaxMemory	Maximum Memory Reset Command	BOOL
Cmd_ResetMinMemory	Minimum Memory Reset Command	BOOL
Cmd_ResetTripCounter	Trip Counter Reset Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Set_Triplimit	Allows user to define Current Trip Limit value for adjustable Electronic Over-current Protection module	SINT
Set_WarningLimit	Allows user to define current value (warning limit) for the channel	SINT

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_InhibitCfg	Disable Configuration inputs from external sources	BOOL
Sts_InhibitCmd	Disable Command inputs from external sources	BOOL
Sts_InhibitSet	Disable Setting inputs from external sources	BOOL
Sts_PLCControlTrigger	Displays if a particular channel is controlled by PLC	BOOL
Val_AvgCurrent	Provides value of average measured current for particular channel since first power ON or last device reset	REAL
Val_DeviceType	Provides type of each type of Electronic Overcurrent Protection Module attached to Power Feed	DINT
Val_LastTripType	Provides reason of last trip for particular channel	SINT
Val_MaxCurrent	Provides value of highest measured current for particular channel since first power ON or last device reset	REAL
Val_MaxVoltage	Provides value of highest measured voltage for particular channel since first power ON or last device reset	REAL
Val_MinCurrent	Provides value of lowest measured current for particular channel since first power ON or last device reset	REAL
Val_MinVoltage	Provides value of lowest measured voltage for particular channel since first power ON or last device reset	REAL
Val_PLCControl	PLC Control Status for particular channel	INT
Val_ReqStep	Step Update	INT
Val_TripCounter	Counter Value	DINT
Val_Triplimit	Displays Current Trip Limit value for adjustable Electronic Overcurrent Protection module	SINT
Val_WarningLimit	Displays current value (warning limit) for particular channel when the LED starts blinking	SINT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data(raC_Dvc_1694_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE

InOut	Function / Description	Data Type
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgCustGetSubIdx_Sync	Message Configuration Read	MESSAGE
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Ref_Msg_Data	Message Configuration Data	raC_UDT_1694_Msg_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_1694_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Out_O	1694_4IOL Out Data	raC_UDT_ItfAD_1694_Out_4IOL
Cfg_C	Device Object Configuration	raC_UDT_IOLink_1694_Cfg

Input Data

Input	Function/Description	Data Type
Cfg_ChannelSelection	Select Channel Number	DINT
Cfg_ResetTrip	Trip Reset Alarm	INT
Cmd_PLCControlTrigger	Allows user to define if a particular channel can be controlled by PLC	BOOL
Cmd_Refresh	Allows user to update values	BOOL
Cmd_ResetAvgMemory	Average Memory Reset Command	BOOL
Cmd_ResetFault	Update Channel Values	BOOL
Cmd_ResetMaxMemory	Maximum Memory Reset Command	BOOL
Cmd_ResetMinMemory	Minimum Memory Reset Command	BOOL
Cmd_ResetTripCounter	Trip Counter Reset Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Set_Triplimit	Allows user to define Current Trip Limit value for adjustable Electronic Over-current Protection module	SINT
Set_WarningLimit	Allows user to define current value (warning limit) for the channel	SINT

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_InhibitCfg	Disable Configuration inputs from external sources	BOOL
Sts_InhibitCmd	Disable Command inputs from external sources	BOOL
Sts_InhibitSet	Disable Setting inputs from external sources	BOOL
Sts_PLCControlTrigger	Displays if a particular channel is controlled by PLC	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_AvgCurrent	Provides value of average measured current for particular channel since first power ON or last device reset	REAL
Val_DeviceType	Provides type of each type of Electronic Overcurrent Protection Module attached to Power Feed	DINT
Val_LastTripType	Provides reason of last trip for particular channel	SINT


Output	Function/Description	Data Type
Val_MaxCurrent	Provides value of highest measured current for particular channel since first power ON or last device reset	REAL
Val_MaxVoltage	Provides value of highest measured voltage for particular channel since first power ON or last device reset	REAL
Val_MinCurrent	Provides value of lowest measured current for particular channel since first power ON or last device reset	REAL
Val_MinVoltage	Provides value of lowest measured voltage for particular channel since first power ON or last device reset	REAL
Val_PLCControl	PLC Control Status for particular channel	INT
Val_ReqStep	Step Update	INT
Val_TripCounter	Counter Value	DINT
Val_Triplimit	Displays Current Trip Limit value for adjustable Electronic Overcurrent Protection module	SINT
Val_WarningLimit	Displays current value (warning limit) for particular channel when the LED starts blinking	SINT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference. The first rung is required and the others are optional.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 1694 device object connected to channel #2 of a POINT I/O 1734-4IOL IO-Link Master module in slot #5 of a POINT I/O adapter named *Rack01*.



The following example uses the 1694 device object connected to channel #0 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 1694 device object connected to channel #0 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_4*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_MECP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_1694_Launch		<p>The supplied launch button in View Designer is used to navigate to the faceplate in a user application.</p>	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Device1694_102	CB 102
▶ Device1694_102_CtrlCmd	Device1694_102 Command Interface
▶ Device1694_102_CtrlSet	Device1694_102 Setting Interface
▶ Device1694_102_CtrlSts	Device1694_102 Status Interface
▶ Device1694_102_Inp_I	Device1694_102 Input Interface
▶ Device1694_102_Out_O	Device1694_102 Output Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the basic control functions.




Item	Description
1	Banner- Ready Status
2	ChannelStatus- Based on the status of channel, the status indicator changes its color. If the Channel 01 is ON, the indicator turns from gray to blue.
3	Current- The Current field provides the channel XX current value. Unit 'A'
4	Voltage- The Voltage field provides the channel XX voltage value. Unit 'V'
5	PLC Control- The Off-On toggle button is used to switch the respective channel On or Off, depending on the PLC Control mode.
6	Channel Description- Description field provides feasibility for operator to enter (input field) the channel descriptions, based on the device connected to respective channel
7	Channel is not configured (Device is not connected)
8	Page 1 to 4- The page buttons allow to toggle back and forth between 1 to 16 channel status information
9	Application Specific Name - Read from device
10	Channel Faulted- Channel Faulted Description with yellow rectangle highlighted & Reset button



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

I/O Tab

I/O tab provides the Current and Average voltage value of the each channel. which helps ensure that sensors are operating correctly. It displays the Trip counter & Last trip type.




Item	Description
1	Channel number- Dropdown selector object to select different channels
2	Minimum Current- Provides value of lowest measured current for channel since first power ON or last device/statistics reset.
3	Maximum Current- Provides value of highest measured current for channel since first power ON or last device reset.
4	Average Current- Provides value of average measured current for channel since first power ON or last device reset.
5	Minimum Voltage- Provides value of lowest measured voltage for channel since first power ON or last device reset.
6	Maximum Voltage- Provides value of highest measured voltage for channel since first power ON or last device reset
7	Last Trip Type- Last Trip Type provides reason of device trip for each channel, below are the different reasons: <ul style="list-style-type: none"> • Not Triggered • Channel Short Circuit • Channel Overload • Device Internal Fault
8	Trip Counter- Provides number of trips for channel counted since first device use or last reset
9	Refresh- Refresh Button to update the values.

Configure Tab

The configuration tab displays the Device parameter settings, Reset buttons as well as enabling the user to read data from the Device.



In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Parameter Settings

Channel Selection- Used to select different Channel.

Device Type- The Device Type provides information about Electronic Overcurrent Protection Module type attached to the Power Feed module:

- 1694 IO-Link With 1 Channel, Fixed Current Threshold
- 1694 IO-Link With 2 Channel, Fixed Current Threshold
- 1694 IO-Link With 4 Channel, Fixed Current Threshold
- 1694 IO-Link With 2 Channels, Adjustable Current Threshold

Trip Limit- Trip Limit allows user to define Current Trip Limit value for adjustable Electronic Overcurrent Protection module. When this value exceeds in the circuit of each channel, then device will go into trip state.

- For fixed protection modules, this value is read only.
- For Adjustable Protection Modules, the trip limit value can be set from the faceplate.

Warning Limit- Warning Limit allows user to define current value (warning limit) for the channel.

PLC Control- PLC Control mode allows user to define if a particular channel can be controlled by PLC.


Reset Button- The Reset Buttons are used to reset the Minimum, Maximum, Average Value Memory and Trip Counter.

Button	Description
Reset Maximum Value Memory	Allows user to reset maximum value memory of voltage and current statistics for channel. If channel is controlled by 2-channels module then both channels will be reset
Reset Minimum Value Memory	Allows user to reset minimum value memory of voltage and current statistics for channel. If channel is controlled by 2-channels module then both channels will be reset
Reset Average Value Memory	Allows user to reset average value memory of voltage and current statistics for channel. If channel is controlled by 2-channels module then both channels will be reset.
Reset Trip Counter	Allows user to reset trip counter for channel. If channel is controlled by 2-channels module then both channels will be reset


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_1694_4IOL, raC_Dvc_1694_8IOL, raC_Dvc_1694_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_1694_4IOL, raC_LD_Dvc_1694_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tagName for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag

Parameter Name	Default Value	Instance Name	Definition	Description
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_1694_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReferance		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 1694), This name depends upon the TagName assigned to object.
SensorType	1694-PFD1244	1694-PFD1244	1694-PFD1244	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_1694_4IOL	raC_Dvc_1694_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_1694_8IOL	raC_Dvc_1694_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_1694_5032	raC_Dvc_1694_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_1694	Faceplate ME	(raC-3_xx-ME) raC_Dvc_1694-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_1694	Faceplate SE	(raC-3_xx-SE) raC_Dvc_1694-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IOLink	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

45DMS - Distance Measurement Sensor (raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL, raC_Dvc_45DMS_Type1_5032, raC_Dvc_45DMS_Type2_5032)

Overview

The 45DMS Distance Measurement Sensor device object (raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL, raC_Dvc_45DMS_Type1_5032, raC_Dvc_45DMS_Type2_5032) includes HMI faceplate's which displays device information including:

- Sensor data
- Sensor diagnostics
- Process data trending
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_45DMS_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).

Functional Description

The 45DMS Distance Measurement Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the /Studio 5000 Logix Designer Files - L5X/ folder in the library. Each device is supplied with four versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
45DMS	POINT I/O 1734-4IOL	45DMS_B8LAT1.D4, 45DMS_B8LGT1.D5	raC_Dvc_45DMS_4IOL_3.02_AOI.L5X	raC_Dvc_45DMS_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	45DMS_B8LAT1.D4, 45DMS_B8LGT1.D5	raC_Dvc_45DMS_8IOL_3.02_AOI.L5X	raC_Dvc_45DMS_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	45DMS_B8LAT1.D4	raC_Dvc_45DMS_Type1_5032_3.02_AOI.L5X	raC_Dvc_45DMS_Type1_5032_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	45DMS_B8LGT1.D5	raC_Dvc_45DMS_Type2_5032_3.02_AOI.L5X	raC_Dvc_45DMS_Type2_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the /HMI FactoryTalk View Images - png/ folder of the library. FactoryTalk View ME files are stored in the /HMI - FactoryTalk View ME/ library folder and FactoryTalk View SE files are stored in the /HMI - FactoryTalk View SE/ library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
45DMS	Display	(raC-3_02-ME) raC_Dvc_45DMS-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_45DMS-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
45DMS	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
45DMS	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45DMS_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45DMS_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45DMS_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45DMS_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45DMS_Type1_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45DMS_5032_(3.2)
		(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45DMS_Type2_5032_(3.2)	


Device Definition (raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...



2. Specify the Application Specific Name e.g. *Distance_100*
3. Select the Process Data Input as *Triggered1, Triggered2, SignalScore, Distance, SignalQuality*.




Device Definition (raC_Dvc_45PLA_Type1_5032, raC_Dvc_45PLA_Type2_5032)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)

- Configure the parameters of sensor from configuration tab from AOP of the 45DMS sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data

(raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_45DMS_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_45DMS_Inp_4IOL Or raC_UDT_ItfAD_45DMS_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger1	BOOL
Inp_ChxTriggered2	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger2	BOOL
Inp_ChxDistance	Displays Distance in mm - non-adjustable	INT
Inp_ChxSignalQuality	Signal Quality 0...100%	SINT
Inp_ChxSignalQualityScore	adjustable via index 196(0xC4)	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_AveragingFilter	Averaging Filter; 0 = Disabled, 1...10 = 10...100 Measurements	SINT
Cfg_MeasurementMode	Measurement Mode; 0 = Negative Slope, 1 = Positive Slope	SINT
Cfg_Pin2Input	Pin 2 Input; 0 = Disabled, 1 = Enabled	SINT
Cfg_TeachChannel	Teach Channel; 0 or 1 = Triggered 1, 2 = Triggered2	SINT
Cfg_Trig1_OperMode	Trigger1 Operation Mode; 0 = Off, 1 = Hysteresis, 2 = Window, 3 = Adjustable Hysteresis	SINT
Cfg_Trig1_Polarity	Trigger 1 Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cfg_Trig2_OperMode	Trigger2 Operation Mode Status; 0 = Off, 1 = Hysteresis, 2 = Window, 3 = Adjustable Hysteresis	SINT
Cfg_Trig2_Polarity	Trigger 2 Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL

Input	Function/Description	Data Type
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachCancel	Teach Cancel Command	BOOL
Cmd_TeachDynamic_Start	Teach Dynamic Start Command	BOOL
Cmd_TeachDynamic_Stop	Teach Dynamic Stop Command	BOOL
Cmd_TeachPrecision_ShowTarget	Teach Precision Show Target Command	BOOL
Cmd_TeachStatic_Background	Teach Static Background Command	BOOL
Cmd_TeachStatic_ShowTarget	Teach Static Show Target Command	BOOL
Set_Offset	Enter Offset to define an offset from the current measured value	INT
Set_SignalQualityLev	Enter Signal Quality to define level of reflectivity	INT
Set_TrendDistMaxValue	Trend Tab Distance Max for VD/ME/SE Faceplate	INT
Set_TrendDistMinValue	Trend Tab Distance Min for VD/ME/SE Faceplate	INT
Set_Trig1_OFFDelay	Enter Trigger1 OFF delay for the Output to turn OFF after target left Detection Area	DINT
Set_Trig1_ONDelay	Enter Trigger1 ON delay for the Output to turn ON, once target has been detected	DINT
Set_Trig1_SP1	Enter First SetPoint For Triggered1	INT
Set_Trig1_SP2	Enter Second SetPoint For Triggered1	INT
Set_Trig2_OFFDelay	Enter Trigger2 OFF delay for the Output to turn OFF after target left Detection Area	DINT
Set_Trig2_ONDelay	Enter Trigger2 ON delay for the Output to turn ON, once target has been detected	DINT
Set_Trig2_SP1	Enter First SetPoint For Triggered2	INT
Set_Trig2_SP2	Enter Second SetPoint For Triggered2	INT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Val_AveragingFilter	Averaging Filter Status; 0 = Disabled, 1...10 = 10...100 Measurements	INT
Val_MeasurementMode	Measurement Mode Status; 0 = Negative Slope, 1 = Positive Slope	INT
Val_Offset	Offset Value to define an offset from the current measured value	INT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_Pin2Input	Pin 2 Input Status; 0 = Disabled, 1 = Enabled	INT
Val_RangeMax	Sensor Maximum Range in Trend	INT
Val_RangeMin	Sensor Minimum Range in Trend	INT
Val_SignalQualityLev	Signal Quality Level Value defines level of Reflectivity	INT
Val_TeachChannel	Teach Channel Value; 0 or 1 = Triggered 1, 2 = Triggered2	INT
Val_TeachStep	Teach Step	INT
Val_TemperatureCurrent	Internal Temperature Of Sensor	INT
Val_TemperatureMaxSinceInception	Maximum Temperature Since Inception	INT
Val_TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	INT
Val_TemperatureMinSinceInception	Minimum Temperature Since Inception	INT
Val_TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	INT
Val_Trig1_Mode	Trigger1 Operation Mode Status; 0 = Off, 1 = Hysteresis, 2 = Window, 3 = Adjustable Hysteresis	INT
Val_Trig1_OFFDelay	Trigger1 OFF delay Value for the Output to turn OFF after target left Detection Area	DINT
Val_Trig1_ONDelay	Trigger1 ON delay Value for the Output to turn ON, once target has been detected	DINT
Val_Trig1_Polarity	Trigger 1 Polarity; 0 = Not Inverted, 1 = Inverted	INT

Output	Function/Description	Data Type
Val.Trig1.SP1	First SetPoint Value For Triggered1	INT
Val.Trig1.SP2	Second SetPoint Value for Triggered1	INT
Val.Trig2_Mode	Trigger2 Operation Mode Status; 0 = Off, 1 = Hysteresis, 2 = Window, 3 = Adjustable Hysteresis	INT
Val.Trig2_OFFDelay	Trigger2 OFF delay Value for the Output to turn OFF after target left Detection Area	DINT
Val.Trig2_ONDelay	Trigger2 ON delay Value for the Output to turn ON, once target has been detected	DINT
Val.Trig2_Polarity	Trigger 2 Polarity; 0 = Not Inverted, 1 = Inverted	INT
Val.Trig2_SP1	First SetPoint Value For Triggered2	INT
Val.Trig2_SP2	Second SetPoint Value for Triggered2	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data (raC_Dvc_45DMS_Type1_5032, raC_Dvc_45DMS_Type2_5032)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_45DMS_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_45DMS_Type1_Cfg or raC_UDT_IOLink_45DMS_Type2_Cfg
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_45DMS_Type1_Cfg or raC_UDT_IOLink_45DMS_Type2_Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger1	BOOL
Inp_ChxTriggered2	Triggered Status When the Temperature is equal to Defined Temperature Set for Trigger2	BOOL
Inp_ChxDistance	Displays Distance in mm - non-adjustable	INT
Inp_ChxSignalQuality	Signal Quality 0...100%	SINT
Inp_ChxSignalQualityScore	adjustable via index 196(0xC4)	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Cfg_AveragingFilter	Averaging Filter; 0 = Disabled, 1...10 = 10...100 Measurements	SINT
Cfg_MeasurementMode	Measurement Mode; 0 = Negative Slope, 1 = Positive Slope	SINT
Cfg_Pin2Input	Pin 2 Input; 0 = Disabled, 1 = Enabled	SINT
Cfg_TeachChannel	Teach Channel; 0 or 1 = Triggered 1, 2 = Triggered2	SINT
Cfg_Trig1_OperMode	Trigger1 Operation Mode; 0 = Off, 1 = Hysteresis, 2 = Window, 3 = Adjustable Hysteresis	SINT
Cfg_Trig1_Polarity	Trigger 1 Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cfg_Trig2_OperMode	Trigger2 Operation Mode Status; 0 = Off, 1 = Hysteresis, 2 = Window, 3 = Adjustable Hysteresis	SINT
Cfg_Trig2_Polarity	Trigger 2 Polarity; 0 = Not Inverted, 1 = Inverted	SINT
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL

Input	Function/Description	Data Type
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachCancel	Teach Cancel Command	BOOL
Cmd_TeachDynamic_Start	Teach Dynamic Start Command	BOOL
Cmd_TeachDynamic_Stop	Teach Dynamic Stop Command	BOOL
Cmd_TeachPrecision_ShowTarget	Teach Precision Show Target Command	BOOL
Cmd_TeachStatic_Background	Teach Static Background Command	BOOL
Cmd_TeachStatic_ShowTarget	Teach Static Show Target Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Set_Offset	Enter Offset to define an offset from the current measured value	INT
Set_SignalQualityLev	Enter Signal Quality to define level of reflectivity	INT
Set_TrendDistMaxValue	Trend Tab Distance Max for VD/ME/SE Faceplate	INT
Set_TrendDistMinValue	Trend Tab Distance Min for VD/ME/SE Faceplate	INT
Set_Trig1_OFFDelay	Enter Trigger1 OFF delay for the Output to turn OFF after target left Detection Area	DINT
Set_Trig1_ONDelay	Enter Trigger1 ON delay for the Output to turn ON, once target has been detected	DINT
Set_Trig1_SP1	Enter First SetPoint For Triggered1	INT
Set_Trig1_SP2	Enter Second SetPoint For Triggered1	INT
Set_Trig2_OFFDelay	Enter Trigger2 OFF delay for the Output to turn OFF after target left Detection Area	DINT
Set_Trig2_ONDelay	Enter Trigger2 ON delay for the Output to turn ON, once target has been detected	DINT
Set_Trig2_SP1	Enter First SetPoint For Triggered2	INT
Set_Trig2_SP2	Enter Second SetPoint For Triggered2	INT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL


Output	Function/Description	Data Type
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_AveragingFilter	Averaging Filter Status; 0 = Disabled, 1...10 = 10...100 Measurements	INT
Val_MeasurementMode	Measurement Mode Status; 0 = Negative Slope, 1 = Positive Slope	INT
Val_Offset	Offset Value to define an offset from the current measured value	INT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_Pin2Input	Pin 2 Input Status; 0 = Disabled, 1 = Enabled	INT
Val_RangeMax	Sensor Maximum Range in Trend	INT
Val_RangeMin	Sensor Minimum Range in Trend	INT
Val_SignalQualityLev	Signal Quality Level Value defines level of Reflectivity	INT
Val_TeachChannel	Teach Channel Value; 0 or 1 = Triggered 1, 2 = Triggered2	INT
Val_TeachStep	Teach Step	INT
Val_TemperatureCurrent	Internal Temperature Of Sensor	INT
Val_TemperatureMaxSinceInception	Maximum Temperature Since Inception	INT
Val_TemperatureMaxSincePowerUp	Maximum Temperature Since Power Up	INT
Val_TemperatureMinSinceInception	Minimum Temperature Since Inception	INT
Val_TemperatureMinSincePowerUp	Minimum Temperature Since Power Up	INT
Val_Trig1_Mode	Trigger1 Operation Mode Status; 0 = Off, 1 = Hysteresis, 2 = Window, 3 = Adjustable Hysteresis	INT
Val_Trig1_OFFDelay	Trigger1 OFF delay Value for the Output to turn OFF after target left Detection Area	DINT
Val_Trig1_ONDelay	Trigger1 ON delay Value for the Output to turn ON, once target has been detected	DINT
Val_Trig1_Polarity	Trigger 1 Polarity; 0 = Not Inverted, 1 = Inverted	INT
Val_Trig1_SP1	First SetPoint Value For Triggered1	INT
Val_Trig1_SP2	Second SetPoint Value for Triggered1	INT
Val_Trig2_Mode	Trigger2 Operation Mode Status; 0 = Off, 1 = Hysteresis, 2 = Window, 3 = Adjustable Hysteresis	INT
Val_Trig2_OFFDelay	Trigger2 OFF delay Value for the Output to turn OFF after target left Detection Area	DINT
Val_Trig2_ONDelay	Trigger2 ON delay Value for the Output to turn ON, once target has been detected	DINT
Val_Trig2_Polarity	Trigger 2 Polarity; 0 = Not Inverted, 1 = Inverted	INT
Val_Trig2_SP1	First SetPoint Value For Triggered2	INT
Val_Trig2_SP2	Second SetPoint Value for Triggered2	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.

The following example uses the 45DMS device object connected to channel #2 of a POINT I/O 1734-4IOL IO-Link Master module in slot #1 of a POINT I/O adapter named *Rack01*.




The following example uses the 45DMS device object connected to channel #6 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.







Note: If tags for Triggered1, Triggered2, Signal Quality Score, Distance, and Signal Quality are missing after importing the AOI into Master 4IOL or 8IOL models, modify the 'Process Input Data' parameter within the AOP.



The following example uses the 45DMS Typ1 Sensor device object connected to channel #4 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_2*.



The following example uses the 45DMS Type2 Sensor device object connected to channel #6 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_2*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_LightSens WithData		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #105: Live Data Engineering Unit #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_45PLA _Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Sensor45DMS_102	Sensor 102
▶ Sensor45DMS_102_CtrlCmd	Sensor45DMS_102 Command Interface
▶ Sensor45DMS_102_CtrlSet	Sensor45DMS_102 Setting Interface
▶ Sensor45DMS_102_CtrlSts	Sensor45DMS_102 Status Interface
▶ Sensor45DMS_102_Inp_I	Sensor45DMS_102 Input Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status 1 & 2 OFF (0) = Gray LED ON (1) = Blue LED
4	Trigger1 Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
6	Process Data: Displays the current Temperature value along with unit.



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Device Temperature Bar Graph Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Device Temperature Current Value
3	Operating Hours Since Inception



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.


Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. One trend is displayed for Distance.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Distance.




Configure Tab

The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Trigger Settings
- Teach Settings
- Configuration Apply Settings



In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.

Parameter Settings

Measurement Mode- The Measurement Mode parameter enables operators to invert the measurement from Positive slope to Negative Slope.

Averaging Filter- The Averaging Filter parameter allows operators to average multiple measurements, inside of the sensor with the goal of providing a more stable measurement.

Pin 2 Input- The pin two Input parameter allows operators to enable or disable the pin two Input available on catalog number, 45DMS-B8LAT1-D4.

Signal Quality Level- Signal Quality Level accepts values from 10 to 90% and can help operators understand the level of reflectivity, which may be acceptable or could affect your application.

Offset- - The Offset parameter allows operators to define an offset from the current measured value. Operators can choose between -5000 to +5000 as an offset.

Local Teach- The Local Teach toggle button is used to Enable or disable the local push button to prevent undesired teach on the sensors.

Trigger Settings

	Trigger 1	Trigger 2
Operating Mode	Hysteresis	Disabled
Switch Point 1	1200 mm	2000 mm
Switch Point 2	1400 mm	2500 mm
Polarity	Not Inverted	Not Inverted
On Delay	1000 ms	2000 ms
Off Delay	1500 ms	2500 ms

The Trigger settings divided into sections:

- Trigger 1
- Trigger 2

Operating Mode- The operating mode parameter enables operators to define the desired output mode for Trigger 1 & Trigger 2. These modes can be Hysteresis, Window & Adjustable Hysteresis.

Switch Point 1- Switch point 1 defines the first set point value for Trigger 1 & Trigger 2. The Hysteresis mode uses the value of switch point 1 to determine when the output will be ON or OFF depending on the Polarity setting. For this setting, the sensor will only detect objects between the minimum distance and the set point distance. Any higher reflectivity objects will be ignored beyond this point.

Switch Point 2- Switch point 2 defines the second set point value for Trigger 1 & Trigger 2. Switch Point1 & Switch Point2 parameter can accept values between 60 and 5000 and is expressed in mm. The Window mode uses the values of switch point 1 and switch point 2 to determine when the output will be ON or OFF depending on the polarity settings. Only objects between switch point 1 and switch point 2 will be detected while objects outside of these distances will be ignored.

Polarity value- The Polarity value can either be Not-Inverted or Inverted. Not-Inverted means that the output will turn ON when the target is within the expected set points. Inverted means that the output will turn OFF when the target is within the expected set points.


On Delay- The On Delay defines the desired delay for the output to turn ON once a target has been detected.

Off Delay- The Off Delay defines the desired delay for the output to turn OFF once a target has left the detection area.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_45DMS_4IOL, raC_Dvc_45DMS_8IOL, raC_Dvc_45DMS_Type1_5032, raC_Dvc_45DMS_Type2_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_45DMS_4IOL, raC_LD_Dvc_45DMS_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
Sensor Type				Select sensor type of 45DMS as per device catalog no.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_45DMS_Type1_5032, raC_LD_Dvc_45DMS_Type2_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.

TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 45DMS), This name depends upon the TagName assigned to object.
SensorType	45DMS_B8LAT1_D4	45DMS_B8LAT1_D4	45DMS_B8LAT1_D4	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_45DMS_4IOL	raC_Dvc_45DMS_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_45DMS_8IOL	raC_Dvc_45DMS_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_45DMS_Type1_5032 Or raC_Dvc_45DMS_Type2_5032	raC_Dvc_45DMS_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_45DMS	Faceplate ME	(raC-3_xx-ME) raC_Dvc_45DMS-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_45DMS	Faceplate SE	(raC-3_xx-SE) raC_Dvc_45DMS-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

46CLR - ColorSight True Color Sensor (raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL, raC_Dvc_46CLR_5032)

Overview

The 46CLR ColorSight True Color Sensor device object (raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL, raC_Dvc_46CLR_5032) includes HMI faceplate's which displays device information including:

- Sensor data
- Snapshots of Sensor Parameter
- Sensor diagnostics
- Process data trending
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: "Operational_Overview_of_46CLR_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).

Functional Description

The 46CLR ColorSight True Color Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplate's for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplate's. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
46CLR	POINT I/O 1734-4IOL	46CLR-D5LAC1-D5, 46CLR-D5LAC2-D5, 46CLR-D5LAC3-D5	raC_Dvc_46CLR_4IOL_3.02_AOI.L5X	raC_Dvc_46CLR_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	46CLR-D5LAC1-D5, 46CLR-D5LAC2-D5, 46CLR-D5LAC3-D5	raC_Dvc_46CLR_8IOL_3.02_AOI.L5X	raC_Dvc_46CLR_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	46CLR-D5LAC1-D5, 46CLR-D5LAC2-D5, 46CLR-D5LAC3-D5	raC_Dvc_46CLR_5032_3.02_AOI.L5X	raC_Dvc_46CLR_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
46CLR	Display	(raC-3_02-ME) raC_Dvc_46CLR-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_46CLR-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
46CLR	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
46CLR	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_46CLR_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_46CLR_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_46CLR_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_46CLR_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_46CLR_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_46CLR_5032_(3.2)


Device Definition (raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




2. Specify the Application Specific Name e.g.
3. Select the Process Data Input as *Triggered, QualityScore, SignalQuality*.



Device Definition (raC_Dvc_46CLR_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 46CLR, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 46CLR Sensor.



- Configure the parameters of sensor from configuration tab from AOP of the 46CLR sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data (raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL)

InOut Data

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Write_Index	Message Configuration Write	MESSAGE
Read_Index	Message Configuration Read	MESSAGE
Write_SubIndex	Message Configuration Write	MESSAGE
Read_SubIndex	Message Configuration Read	MESSAGE
Msg_Sensor_Data	Messaging Data	raC_UDT_46CLR_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_46CLR_Inp_4IOL Or raC_UDT_ItfAD_46CLR_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Cfg_DetectionMode	Set the detection mode; 0=Colour Mode, 1=Best Fit Mode	SINT
Cfg_Snapshot	Snapshot Command Storing for Signal Values	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_IntensityEvaluationCh1	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel1; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh2	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel2; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh3	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel3; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh4	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel4; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh5	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel5; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh6	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel6; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh7	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel7; 0=Off, 1=On	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_OperationCh1	Enables or disables the operation of Channel1; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh2	Enables or disables the operation of Channel2; 0=Disabled, 1=Enabled	BOOL

Input	Function/Description	Data Type
Cmd_OperationCh3	Enables or disables the operation of Channel 3; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh4	Enables or disables the operation of Channel 4; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh5	Enables or disables the operation of Channel 5; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh6	Enables or disables the operation of Channel 6; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh7	Enables or disables the operation of Channel 7; 0=Disabled, 1=Enabled	BOOL
Cmd_PolarityCh1	Set the Polarity of Channel 1; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh2	Set the Polarity of Channel 2; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh3	Set the Polarity of Channel 3; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh4	Set the Polarity of Channel 4; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh5	Set the Polarity of Channel 5; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh6	Set the Polarity of Channel 6; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh7	Set the Polarity of Channel 7; 0=Not Inverted, 1=Inverted	BOOL
Cmd_ResetCountCh1	Counter Reset Command for Channel1	BOOL
Cmd_ResetCountCh2	Counter Reset Command for Channel2	BOOL
Cmd_ResetCountCh3	Counter Reset Command for Channel3	BOOL
Cmd_ResetDurationsCh1	Duration Reset Command for Channel1	BOOL
Cmd_ResetDurationsCh2	Duration Reset Command for Channel2	BOOL
Cmd_ResetDurationsCh3	Duration Reset Command for Channel3	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachCancel	Teach Cancel Command	BOOL
Cmd_TeachColorScanStart	Teach Color Scan Start Command	BOOL
Cmd_TeachColorScanStop	Teach Color Scan Stop Command	BOOL
Cmd_TeachStandard	Teach Standard Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxSignalQuality	Reflects the strength of the return signal reflected from the target	INT
Inp_ChxSignalQualityScore	Indicate if the signal strength is higher or lower than a defined threshold	BOOL
Inp_ChxTriggered1	Triggered Status of channel 1 of Sensor	BOOL
Inp_ChxTriggered2	Triggered Status of channel 2 of Sensor	BOOL
Inp_ChxTriggered3	Triggered Status of channel 3 of Sensor	BOOL
Inp_ChxTriggered4	Triggered Status of channel 4 of Sensor	BOOL
Inp_ChxTriggered5	Triggered Status of channel 5 of Sensor	BOOL
Inp_ChxTriggered6	Triggered Status of channel 6 of Sensor	BOOL
Inp_ChxTriggered7	Triggered Status of channel 7 of Sensor	BOOL
Set_CounterCh1	Defines the desired number of counts for the discrete output to turn ON for Ch 01	DINT
Set_CounterCh2	Defines the desired number of counts for the discrete output to turn ON for Ch 02	DINT

Input	Function/Description	Data Type
Set_CounterCh3	Defines the desired number of counts for the discrete output to turn ON for Ch 03	DINT
Set_GreenToleranceCh1	Sets the color threshold tolerance for the green color for channel 1	REAL
Set_GreenToleranceCh2	Sets the color threshold tolerance for the green color for channel 2	REAL
Set_GreenToleranceCh3	Sets the color threshold tolerance for the green color for channel 3	REAL
Set_GreenToleranceCh4	Sets the color threshold tolerance for the green color for channel 4	REAL
Set_GreenToleranceCh5	Sets the color threshold tolerance for the green color for channel 5	REAL
Set_GreenToleranceCh6	Sets the color threshold tolerance for the green color for channel 6	REAL
Set_GreenToleranceCh7	Sets the color threshold tolerance for the green color for channel 7	REAL
Set_IntensityToleranceCh1	Sets the color threshold tolerance for the intensity for channel 1	REAL
Set_IntensityToleranceCh2	Sets the color threshold tolerance for the intensity for channel 2	REAL
Set_IntensityToleranceCh3	Sets the color threshold tolerance for the intensity for channel 3	REAL
Set_IntensityToleranceCh4	Sets the color threshold tolerance for the intensity for channel 4	REAL
Set_IntensityToleranceCh5	Sets the color threshold tolerance for the intensity for channel 5	REAL
Set_IntensityToleranceCh6	Sets the color threshold tolerance for the intensity for channel 6	REAL
Set_IntensityToleranceCh7	Sets the color threshold tolerance for the intensity for channel 7	REAL
Set_RedToleranceCh1	Sets the color threshold tolerance for the red color for channel 1	REAL
Set_RedToleranceCh2	Sets the color threshold tolerance for the red color for channel 2	REAL
Set_RedToleranceCh3	Sets the color threshold tolerance for the red color for channel 3	REAL
Set_RedToleranceCh4	Sets the color threshold tolerance for the red color for channel 4	REAL
Set_RedToleranceCh5	Sets the color threshold tolerance for the red color for channel 5	REAL
Set_RedToleranceCh6	Sets the color threshold tolerance for the red color for channel 6	REAL
Set_RedToleranceCh7	Sets the color threshold tolerance for the red color for channel 7	REAL
Set_TeachChannel	Select Teach Channel	INT
Set_ToleranceCh1	Sets the color tolerance levels for Channel 1	INT
Set_ToleranceCh2	Sets the color tolerance levels for Channel 2	INT
Set_ToleranceCh3	Sets the color tolerance levels for Channel 3	INT
Set_ToleranceCh4	Sets the color tolerance levels for Channel 4	INT
Set_ToleranceCh5	Sets the color tolerance levels for Channel 5	INT
Set_ToleranceCh6	Sets the color tolerance levels for Channel 6	INT
Set_ToleranceCh7	Sets the color tolerance levels for Channel 7	INT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Val_Blue	Displays the blue component of the color under detection	REAL
Val_BlueSnapshot1	Used for Storing Blue parameter value for snapshot 1	REAL
Val_BlueSnapshot2	Used for Storing Blue parameter value for snapshot 2	REAL
Val_BlueSnapshot3	Used for Storing Blue parameter value for snapshot 3	REAL
Val_Counter	Counter Value	DINT
Val_DetectionCounterSinceInception	Displays the number of targets that have been detected since the sensor has been in operation	DINT
Val_DetectionMode	Displays the detection mode; 0=Colour Mode, 1=Best Fit Mode	SINT
Val_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	SINT
Val_Green	Displays the green component of the color under detection	REAL
Val_GreenSnapshot1	Used for Storing Green parameter value for snapshot 1	REAL
Val_GreenSnapshot2	Used for Storing Green parameter value for snapshot 2	REAL
Val_GreenSnapshot3	Used for Storing Green parameter value for snapshot 3	REAL
Val_GreenTolerance	Display the color threshold tolerance for the green color	REAL
Val_Intensity	Displays the intensity of the color under detection	REAL
Val_IntensityEvaluation	Display value of the sensor to consider evaluating the intensity of the color as part of the color detection ; 0=Off, 1=On	INT
Val_IntensitySnapshot1	Used for Storing intensity parameter value for snapshot 1	REAL
Val_IntensitySnapshot2	Used for Storing intensity parameter value for snapshot 2	REAL
Val_IntensitySnapshot3	Used for Storing intensity parameter value for snapshot 3	REAL
Val_IntensityTolerance	Display the value of color threshold tolerance for the intensity	REAL

Output	Function/Description	Data Type
Val_OperatingHrsSinceInception	Displays the number of hours that the sensor has been continuously in operation	DINT
Val_Operation	Display the operation state of channel; 0=Disabled, 1=Enabled	INT
Val_Polarity	Displays the polarity of channel; 0 = Not Inverted, 1=Inverted	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Red	Displays the red component of the color under detection	REAL
Val_RedSnapshot1	Used for Storing Red parameter value for snapshot 1	REAL
Val_RedSnapshot2	Used for Storing Red parameter value for snapshot 2	REAL
Val_RedSnapshot3	Used for Storing Red parameter value for snapshot 3	REAL
Val_RedTolerance	Display the value of color threshold tolerance for the respective color	REAL
Val_TeachChannel	Displays the number of channel selected	INT
Val_TeachStatus	Displays the status of Teach mode	INT
Val_TeachStep	Teach Step	INT
Val_TemperatureCurrent	Displays the internal temperature information available in the sensor	SINT
Val_TemperatureMaxSinceInception	Reflects the maximum temperature inside of the microprocessor die of the Sensor since inception	SINT
Val_TemperatureMaxSincePowerUp	Reflects the maximum temperature inside of the microprocessor die of the sensor since the last power up	SINT
Val_TemperatureMinSinceInception	Reflects the minimum temperature inside of the microprocessor die of the sensor since inception	SINT
Val_TemperatureMinSincePowerUp	Reflects the minimum temperature inside of the microprocessor die of the sensor since the last power up	SINT
Val_Tolerance	Displays the color tolerance levels for Channel	INT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data InOut Data (raC_Dvc_46CLR_5032)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_46CLR_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_46CLR_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_46CLR_Cfg

Input Data

Input	Function/Description	Data Type
Cfg_DetectionMode	Set the detection mode; 0=Colour Mode, 1=Best Fit Mode	SINT
Cfg_Snapshot	Snapshot Command Storing for Signal Values	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_IntensityEvaluationCh 1	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel1; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh 2	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel2; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh 3	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel3; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh 4	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel4; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh 5	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel5; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh 6	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel6; 0=Off, 1=On	BOOL
Cmd_IntensityEvaluationCh 7	Allows the sensor to consider evaluating the intensity of the color as part of the color detection for Channel7; 0=Off, 1=On	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL

Input	Function/Description	Data Type
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_OperationCh1	Enables or disables the operation of Channel 1; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh2	Enables or disables the operation of Channel 2; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh3	Enables or disables the operation of Channel 3; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh4	Enables or disables the operation of Channel 4; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh5	Enables or disables the operation of Channel 5; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh6	Enables or disables the operation of Channel 6; 0=Disabled, 1=Enabled	BOOL
Cmd_OperationCh7	Enables or disables the operation of Channel 7; 0=Disabled, 1=Enabled	BOOL
Cmd_PolarityCh1	Set the Polarity of Channel 1; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh2	Set the Polarity of Channel 2; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh3	Set the Polarity of Channel 3; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh4	Set the Polarity of Channel 4; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh5	Set the Polarity of Channel 5; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh6	Set the Polarity of Channel 6; 0=Not Inverted, 1=Inverted	BOOL
Cmd_PolarityCh7	Set the Polarity of Channel 7; 0=Not Inverted, 1=Inverted	BOOL
Cmd_ResetCountCh1	Counter Reset Command for Channel1	BOOL
Cmd_ResetCountCh2	Counter Reset Command for Channel2	BOOL
Cmd_ResetCountCh3	Counter Reset Command for Channel3	BOOL
Cmd_ResetDurationsCh1	Duration Reset Command for Channel1	BOOL
Cmd_ResetDurationsCh2	Duration Reset Command for Channel2	BOOL
Cmd_ResetDurationsCh3	Duration Reset Command for Channel3	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachCancel	Teach Cancel Command	BOOL
Cmd_TeachColorScanStart	Teach Color Scan Start Command	BOOL
Cmd_TeachColorScanStop	Teach Color Scan Stop Command	BOOL
Cmd_TeachStandard	Teach Standard Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxSignalQuality	Reflects the strength of the return signal reflected from the target	INT
Inp_ChxSignalQualityScore	Indicate if the signal strength is higher or lower than a defined threshold	BOOL
Inp_ChxTriggered1	Triggered Status of channel 1 of Sensor	BOOL
Inp_ChxTriggered2	Triggered Status of channel 2 of Sensor	BOOL
Inp_ChxTriggered3	Triggered Status of channel 3 of Sensor	BOOL
Inp_ChxTriggered4	Triggered Status of channel 4 of Sensor	BOOL

Input	Function/Description	Data Type
Inp_ChxTriggered5	Triggered Status of channel 5 of Sensor	BOOL
Inp_ChxTriggered6	Triggered Status of channel 6 of Sensor	BOOL
Inp_ChxTriggered7	Triggered Status of channel 7 of Sensor	BOOL
Set_CounterCh1	Defines the desired number of counts for the discrete output to turn ON for Ch 01	DINT
Set_CounterCh2	Defines the desired number of counts for the discrete output to turn ON for Ch 02	DINT
Set_CounterCh3	Defines the desired number of counts for the discrete output to turn ON for Ch 03	DINT
Set_GreenToleranceCh1	Sets the color threshold tolerance for the green color for channel 1	REAL
Set_GreenToleranceCh2	Sets the color threshold tolerance for the green color for channel 2	REAL
Set_GreenToleranceCh3	Sets the color threshold tolerance for the green color for channel 3	REAL
Set_GreenToleranceCh4	Sets the color threshold tolerance for the green color for channel 4	REAL
Set_GreenToleranceCh5	Sets the color threshold tolerance for the green color for channel 5	REAL
Set_GreenToleranceCh6	Sets the color threshold tolerance for the green color for channel 6	REAL
Set_GreenToleranceCh7	Sets the color threshold tolerance for the green color for channel 7	REAL
Set_IntensityToleranceCh1	Sets the color threshold tolerance for the intensity for channel 1	REAL
Set_IntensityToleranceCh2	Sets the color threshold tolerance for the intensity for channel 2	REAL
Set_IntensityToleranceCh3	Sets the color threshold tolerance for the intensity for channel 3	REAL
Set_IntensityToleranceCh4	Sets the color threshold tolerance for the intensity for channel 4	REAL
Set_IntensityToleranceCh5	Sets the color threshold tolerance for the intensity for channel 5	REAL
Set_IntensityToleranceCh6	Sets the color threshold tolerance for the intensity for channel 6	REAL
Set_IntensityToleranceCh7	Sets the color threshold tolerance for the intensity for channel 7	REAL
Set_RedToleranceCh1	Sets the color threshold tolerance for the red color for channel 1	REAL
Set_RedToleranceCh2	Sets the color threshold tolerance for the red color for channel 2	REAL
Set_RedToleranceCh3	Sets the color threshold tolerance for the red color for channel 3	REAL
Set_RedToleranceCh4	Sets the color threshold tolerance for the red color for channel 4	REAL
Set_RedToleranceCh5	Sets the color threshold tolerance for the red color for channel 5	REAL
Set_RedToleranceCh6	Sets the color threshold tolerance for the red color for channel 6	REAL
Set_RedToleranceCh7	Sets the color threshold tolerance for the red color for channel 7	REAL
Set_TeachChannel	Select Teach Channel	INT
Set_ToleranceCh1	Sets the color tolerance levels for Channel 1	INT
Set_ToleranceCh2	Sets the color tolerance levels for Channel 2	INT
Set_ToleranceCh3	Sets the color tolerance levels for Channel 3	INT
Set_ToleranceCh4	Sets the color tolerance levels for Channel 4	INT
Set_ToleranceCh5	Sets the color tolerance levels for Channel 5	INT
Set_ToleranceCh6	Sets the color tolerance levels for Channel 6	INT
Set_ToleranceCh7	Sets the color tolerance levels for Channel 7	INT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_Blue	Displays the blue component of the color under detection	REAL
Val_BlueSnapshot1	Used for Storing Blue parameter value for snapshot 1	REAL
Val_BlueSnapshot2	Used for Storing Blue parameter value for snapshot 2	REAL
Val_BlueSnapshot3	Used for Storing Blue parameter value for snapshot 3	REAL
Val_Counter	Counter Value	DINT
Val_DetectionCounterSinceInception	Displays the number of targets that have been detected since the sensor has been in operation	DINT
Val_DetectionMode	Displays the detection mode; 0=Colour Mode, 1=Best Fit Mode	SINT
Val_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	SINT
Val_Green	Displays the green component of the color under detection	REAL
Val_GreenSnapshot1	Used for Storing Green parameter value for snapshot 1	REAL
Val_GreenSnapshot2	Used for Storing Green parameter value for snapshot 2	REAL
Val_GreenSnapshot3	Used for Storing Green parameter value for snapshot 3	REAL
Val_GreenTolerance	Display the color threshold tolerance for the green color	REAL
Val_Intensity	Displays the intensity of the color under detection	REAL
Val_IntensityEvaluation	Display value of the sensor to consider evaluating the intensity of the color as part of the color detection ; 0=Off, 1=On	INT
Val_IntensitySnapshot1	Used for Storing intensity parameter value for snapshot 1	REAL
Val_IntensitySnapshot2	Used for Storing intensity parameter value for snapshot 2	REAL
Val_IntensitySnapshot3	Used for Storing intensity parameter value for snapshot 3	REAL


Output	Function/Description	Data Type
Val.IntensityTolerance	Display the value of color threshold tolerance for the intensity	REAL
Val.OperatingHrsSinceInception	Displays the number of hours that the sensor has been continuously in operation	DINT
Val.Operation	Display the operation state of channel; 0=Disabled, 1=Enabled	INT
Val.Polarity	Displays the polarity of channel; 0 = Not Inverted, 1=Inverted	INT
Val.RangeMax	Sensor Maximum Range in Trend	DINT
Val.RangeMin	Sensor Minimum Range in Trend	DINT
Val.Red	Displays the red component of the color under detection	REAL
Val.RedSnapshot1	Used for Storing Red parameter value for snapshot 1	REAL
Val.RedSnapshot2	Used for Storing Red parameter value for snapshot 2	REAL
Val.RedSnapshot3	Used for Storing Red parameter value for snapshot 3	REAL
Val.RedTolerance	Display the value of color threshold tolerance for the respective color	REAL
Val.TeachChannel	Displays the number of channel selected	INT
Val.TeachStatus	Displays the status of Teach mode	INT
Val.TeachStep	Teach Step	INT
Val.TemperatureCurrent	Displays the internal temperature information available in the sensor	SINT
Val.TemperatureMaxSinceInception	Reflects the maximum temperature inside of the microprocessor die of the Sensor since inception	SINT
Val.TemperatureMaxSincePowerUp	Reflects the maximum temperature inside of the microprocessor die of the sensor since the last power up	SINT
Val.TemperatureMinSinceInception	Reflects the minimum temperature inside of the microprocessor die of the sensor since inception	SINT
Val.TemperatureMinSincePowerUp	Reflects the minimum temperature inside of the microprocessor die of the sensor since the last power up	SINT
Val.Tolerance	Displays the color tolerance levels for Channel	INT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference. The first rung is required and the others are optional.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 46CLR device object connected to channel #2 of a POINT I/O 1734-4IOL IO-Link Master module in slot #8 of a POINT I/O adapter named *Rack01*.



The following example uses the 46CLR device object connected to channel #4 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 46CLR device object connected to channel #10 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_2*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_ColorSens_46CLR		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_46CLR _Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Sensor46CLR_102	Sensor 102
▶ Sensor46CLR_102_CtrlCmd	Sensor46CLR_102 Command Interface
▶ Sensor46CLR_102_CtrlSet	Sensor46CLR_102 Setting Interface
▶ Sensor46CLR_102_CtrlSts	Sensor46CLR_102 Status Interface
▶ Sensor46CLR_102_Inp_I	Sensor46CLR_102 Input Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status Channel 1 to 7
4	Trigger1 to 7 Sparkline Trend The spark line shows trigger ON/OFF status over last 30 seconds
5	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
6	Process Data: Displays the Bar graph of Red, Green, Blue and Intensity.
7	Process Data: Displays the value of Red, Green, Blue and Intensity.
8	Process Data: Displays the threshold value of Red, Green, Blue and Intensity.
9	Channel selection 1 to 7



Note: In Case of, 5032 Master, changes made to the Application Specific Name or Locate Toggle Switch require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Snapshot

The Snapshot tab is used to save up to three independent snapshots of the color profile. This can be used during commissioning, configuration, or troubleshooting as a method of saving a color reference of a particular object. Each snapshot can be assigned a short name using a string entry.




Snapshot 1- Once you click on button under Snapshot1, the value is captured and stored in the Snapshot1 displays.

Snapshot 2- Once you click on button under Snapshot1, the value is captured and stored in the Snapshot2 displays.

Snapshot 3- Once you click on button under Snapshot1, the value is captured and stored in the Snapshot1 displays.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Internal Temperature Bar Graph Green Indicators: Min/Max since inception (lifetime) Purple Indicators: Min/Max since power up Light Blue Triangle Indicator: Current value
2	Internal Temperature Current Value
3	Operating Hours Since Inception (lifetime)
4	Detection Counter Since Inception



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.

Trend Tab

This tab shows trend of Red, Green, Blue and Intensity Values. Also it contains numeric displays for of Red, Green, Blue and Intensity Values.



Configure Tab


The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Parameter Settings
- Trigger Settings
- Local Settings
- Teach settings
- Configuration Apply Settings



In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Parameter Settings

We can set the Parameter Settings for each channel separately. Each page corresponds to each channel 1 through 7. For accessing individual channel, user need to use the page navigation button.

Analog Output Slope- Applied to configure an analog output when the sensor is operated in the Standard I/O (SIO) mode. Trigger Settings

Red Threshold- Sets the color threshold tolerance for the respective color. The default value for this parameter is 1.59 with acceptable values between 0 and 100.

Green Threshold- Sets the color threshold tolerance for the respective color. The default value for this parameter is 1.59 with acceptable values between 0 and 100.

Intensity Threshold- Sets the color threshold for the intensity. The default value for this parameter is 1.83 with acceptable values between 0 and 100.

Channel Enable- Enables or disables the operation of the selected channel.

Invert Polarity- Sets the polarity of the of the selected channel. The polarity could be either not inverted or inverted.

Intensity Evaluation- Enables or disables the sensor to consider evaluating the intensity of the color as part of the color detection.

Tolerance- Sets the color tolerance levels of the selected channel. The operator can set zero as the finest tolerance while level nine is the widest tolerance.

Trigger Settings

We can set the Trigger Settings for each channel separately. For accessing individual channel, user need to use the page navigation button.

Disable/Enable LEDs- This parameter allows operators to turn OFF or turn ON the User Interface LEDs (green and orange LEDs). This parameter is ideal for applications where turning OFF the LEDs is desired to accommodate the application.


Local Teach Parameters - This section allow user to lock / unlock device local parameterization. Touch Lock/Unlock Toggle switch to Lock Local Parameterization.

Teach Settings.

Teach Settings display includes the Teach Methods, Teach Command & Teach Cancel buttons. Touch on the Teach Settings navigation button to access the Teach Settings tab. We can teach each channel separately. For accessing individual channel, user need to use the page navigation button.

Teach Tab include the following functions:

- Teach mode selection and Teach Detection mode Dropdown menu
- Teach procedure flow buttons
- Teach Apply and Cancel Button.



Teach mode- This parameter selects the desired mode.

Color Scan Teach - The first method is Color Scan Teach, enables you to teach and detect objects with various colors and individual colors to each channel.

4. Place the target in front of the field of view of the sensor and send the command “**Color Scan - Start**”. Move the color targets that you want to teach as needed until all desired colors are presented in the field of view of the sensor.
5. Send the command “**Color Scan - Stop**” to stop the color scan process.
6. Send the command “**Teach - Apply**” to finalize the teach process.
7. To cancel the procedure, you can send the “**Teach Cancel**” command at any point.


Standard Teach - The second method is Standard Teach.

8. Place the target in front of the sensor. Send the command “**Standard Teach - Show Color**” to start the teach process.
9. Send the command “**Teach - Apply**” to finalize the teach process
10. To cancel the procedure, you can send the “**Teach Cancel**” command at any point.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_46CLR_4IOL, raC_Dvc_46CLR_8IOL, raC_Dvc_46CLR_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_46CLR_4IOL, raC_LD_Dvc_46CLR_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_46CLR_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag

RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReference		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 46CLR), This name depends upon the TagName assigned to object.
SensorType	46CLR-D5LAC1-D5	46CLR-D5LAC1-D5	46CLR-D5LAC1-D5	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_46CLR_4IOL	raC_Dvc_46CLR_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_46CLR_8IOL	raC_Dvc_46CLR_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_46CLR_5032	raC_Dvc_46CLR_8IOL	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button

Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
------------------	-------------------------------	---

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	{raC-3-ME}GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols ME	{raC-3-SE}GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_46CLR	Faceplate ME	{raC-3_xx-ME} raC_Dvc_46CLR-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_46CLR	Faceplate SE	{raC-3_xx-SE} raC_Dvc_46CLR-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	{raC-3_xx-VD} raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

875L - Capacitive Sensors (raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL, raC_Dvc_875L_5032)

Overview

The 875L Capacitive Sensor device object (raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL, raC_Dvc_875L_5032) includes HMI faceplate's which displays device information including:

- Sensor data
- Sensor diagnostics
- Process data trending
- Sensor configuration and parameters
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_875L_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.

Functional Description

The 875L Capacitive Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
875L	POINT I/O 1734-4IOL	875L_M16xx30-xx, 875L_M8xx18-xx, 875L_N12xx18-xx, 875L_N25xx30-xx	raC_Dvc_875L_4IOL_3.02_AOI.L5X	raC_Dvc_875L_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	875L_M16xx30-xx, 875L_M8xx18-xx, 875L_N12xx18-xx, 875L_N25xx30-xx	raC_Dvc_875L_8IOL_3.02_AOI.L5X	raC_Dvc_875L_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	875L_M16xx30-xx, 875L_M8xx18-xx, 875L_N12xx18-xx, 875L_N25xx30-xx	raC_Dvc_875L_5032_3.02_AOI.L5X	raC_Dvc_875L_5032_3.02_RUNG.L5X

FactoryTalk® View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk® View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk® View ME Faceplate	FactoryTalk® View SE Faceplate
875L	Display	(raC-3_02-ME) raC_Dvc_875L-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_875L-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
875L	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the / *ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
875L	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_875L_4IOL(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_875L_4IOL(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_875L_8IOL(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_875L_8IOL(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_875L_5032(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_875L_5032(3.2)

Device Definition (raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




- Specify the Application Specific Name e.g. Tank Level 1001

Device Definition (raC_Dvc_875L_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

- Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link for Class B and Tick on "IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

- Whichever channels are selected for 875L you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 875L Sensor.



- Configure the parameters of sensor from configuration tab from AOP of the 875L sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data (raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_875L_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_875L_Inp_4IOL Or raC_UDT_ItfAD_875L_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Status Triggered 1 Sensor	BOOL
Inp_ChxTriggered2	Status Triggered 2 Sensor	BOOL
Inp_ChxAnalogValue	Analog Value Dielectric Data	INT
Inp_ChxSwitchingSignalChannel1	Status Switching Signal Channel 1	BOOL
Inp_ChxSwitchingSignalChannel2	Status Switching Signal Channel 2	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxTemperatureAlarm	Status Temperature Alarm	BOOL
Inp_ChxMarginAlarm1	Status Margin Alarm 1	BOOL
Inp_ChxMarginAlarm2	Status Margin Alarm 2	BOOL
Inp_ChxShortCircuit	Status Short Circuit	BOOL
Cfg_AdjustmentMode	Adjustment Method Drop-Down; 0= Disabled, 1= Trimmer Input, 2= Teach By Wire	INT
Cfg_SensorApplication	Sensor Application Drop-Down: 0= Full Scale Range 1= Liquid Level 2= Plastic Pellets	INT
Cfg_SSC1_Mode	SSC1 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	INT
Cfg_SSC1_SwitchingLogic	SSC1 Switching Logic; 0= High Active 1= Low Active	INT
Cfg_SSC2_SwitchingLogic	SSC1 Switching Logic; 0= High Active 1= Low Active	INT

Input	Function/Description	Data Type
Cfg_T1_InputSelector	Trigger1 InputSelector; 0= Deactivated, 1= SSC1, 2= SSC2, 3= Margin Alarm 1 4= Margin Alarm 2 5= Temp Alarm 6= Ext Logic Input	INT
Cfg_T1_LogicalFunction	0= Direct 1= AND 2= OR 3= XOR	INT
Cfg_T1_PhysicalMode	Trigger1 Mode; 0= Disabled Output, 1= PNP, 2= NPN, 3= Push-Pull	INT
Cfg_T1_Polarity	Trigger1 Polarity Mode; 0= Not Inverted (N.O.) 1= Inverted (N.C.)	INT
Cfg_T1_TimerMode	Trigger1 Timer Mode; 0= Disabled, 1= T-On Delay, 2= T-Off Delay, 3= T-On/T-Off Delay 4= One-Shot Leading 5= One-Shot Trailing	INT
Cfg_T1_TimerScale	Trigger 1 Timer Scale: 0= Milliseconds 1= Seconds 2= Minutes	INT
Cfg_T2_InputSelector	Trigger2 InputSelector; 0= Deactivated, 1= SSC1, 2= SSC2, 3= Margin Alarm 1 4= Margin Alarm 2 5= Temp Alarm 6= Ext Logic Input	INT
Cfg_T2_LogicalFunction	0= Direct 1= AND 2= OR 3= XOR	INT
Cfg_T2_PhysicalMode	Trigger2 Mode; 0= Disabled Output, 1= PNP, 2= NPN, 3= Push-Pull	INT
Cfg_T2_Polarity	Trigger2 Polarity Mode; 0= Not Inverted (N.O.) 1= Inverted (N.C.)	SINT
Cfg_T2_TimerMode	Trigger2 Timer Mode; 0= Disabled, 1= T-On Delay, 2= T-Off Delay, 3= T-On/T-Off Delay 4= One-Shot Leading 5= One-Shot Trailing	INT
Cfg_T2_TimerScale	Trigger 2 Timer Scale: 0= Milliseconds 1= Seconds 2= Minutes	INT
Cfg_Teach_SSC	Teach SSC Mode; 1= SSC 1 2= SSC 2	INT
Cmd_EnableLED	LED Disable/Enable Command	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_SP1_DTStart	SP1 - Dynamic Teach Start Command	BOOL
Cmd_SP1_DTStop	SP1 - Dynamic Teach Stop Command	BOOL
Cmd_SP1_SingleVal	SP1 - Single Value Teach Command	BOOL
Cmd_SP1_TwoVal_TP1	SP1 - Two Value Trigger Point 1 Teach Command	BOOL
Cmd_SP1_TwoVal_TP2	SP1 - Two Value Trigger Point 2 Teach Command	BOOL
Cmd_SP2_DTStart	SP2 - Dynamic Teach Start Command	BOOL
Cmd_SP2_DTStop	SP2 - Dynamic Teach Stop Command	BOOL
Cmd_SP2_SingleVal	SP2 - Single Value Teach Command	BOOL
Cmd_SP2_TwoVal_TP1	SP2 - Two Value Trigger Point 1 Teach Command	BOOL
Cmd_SP2_TwoVal_TP2	SP2 - Two Value Trigger Point 2 Teach Command	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachCancel	Teach Cancel Command	BOOL
Set_FilterScaler_SP	Filter Scaler Setpoint 1...255	INT
Set_PDC_Data	Process Data Enable Disable Settings	DINT
Set_PDC_EnableDisable_SP	Process data configuration disable enable settings	DINT
Set_SafeLimitSSC1	Safe Limit SSC1 Setpoint 0...100	INT
Set_SafeLimitSSC2	Safe Limit SSC2 Set point 0...100	INT
Set_SparkMaxValueT1	Spark T1 Max value for VD/ME/SE Faceplate	INT
Set_SparkMaxValueT2	Spark T2 Max value for VD/ME/SE Faceplate	INT

Input	Function/Description	Data Type
Set_SparkMinValueT1	Spark T1 Min value for VD/ME/SE Faceplate	INT
Set_SparkMinValueT2	Spark T2 Min value for VD/ME/SE Faceplate	INT
Set_SSC_CH1_Hyst_SP	SSC Channel 1 Hysteresis Setpoint 1...100	INT
Set_SSC_CH1_SP1	SSC Channel 1 Setpoint 1 0...10000	INT
Set_SSC_CH1_SP2	SSC Channel 1 Setpoint 2 0...10000	INT
Set_SSC_CH2_Hyst_SP	SSC Channel 2 Hysteresis Set point 1...100	INT
Set_SSC_CH2_SP1	SSC Channel 2 Setpoint 1 0...10000	INT
Set_SSC_CH2_SP2	SSC Channel 2 Setpoint 2 0...10000	INT
Set_TempHighThreshold	Temperature Threshold High -50...150	INT
Set_TempLowThreshold	Temperature Threshold Low -50...150	INT
Set_TrendMaxValue	Trend max value for VD/ME/SE Faceplate	INT
Set_TrendMinValue	Trend min value for VD/ME/SE Faceplate	INT
Set_Trig1_SP1	SP1 value for trigger 1 Spark trend VD/ME/SE Faceplate	INT
Set_Trig1_SP2	SP2 value for trigger 1 Spark trend VD/ME/SE Faceplate	INT
Set_Trig1_TimerValue	Timer value 1 setpoint0...32,767	INT
Set_Trig2_SP1	SP1 value for trigger 2 Spark trend VD/ME/SE Faceplate	INT
Set_Trig2_SP2	SP1 value for trigger 2 Spark trend VD/ME/SE Faceplate	INT
Set_Trig2_TimerValue	Timer value 2 setpoint0...32,767	INT

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_EnableLED	LED Status, 0=Disable, 1=Enable	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Val_AdjustmentModeEnable	Adjustment Method; 0= Disabled, 1= Trimmer Input, 2= Teach By Wire	SINT
Val_AnalogValueT1	Spark Trigger 1 Analog Value	INT
Val_AnalogValueT2	Spark Trigger 2 Analog Value	INT
Val_FilterScaler_SP	Filter Scaler value	INT
Val_MinutesAbvMaxTemp	Minutes above Maximum Temperature	DINT
Val_MinutesBelMinTemp	Minutes below Minimum Temperature	DINT
Val_NumberPowerCycles	Number of Power Cycles	DINT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_RangeMax	Sensor Maximum Range in Trend	INT
Val_RangeMin	Sensor Minimum Range in Trend	INT
Val_SafeLimitSSC1_SP	Safe limit SSC1	SINT
Val_SafeLimitSSC2_SP	Safe limit SSC2	SINT
Val_SensorApplicationEnable	Sensor Application; 0= Full Scale Range 1= Liquid Level 2= Plastic Pellets	SINT
Val_SSC_CH1_Hyst	SSC Channel 1 Hysteresis	INT
Val_SSC_CH1_SP1	SSC Channel 1 SP1	INT
Val_SSC_CH1_SP2	SSC Channel 1 SP2	INT
Val_SSC_CH2_Hyst	SSC Channel 2 Hysteresis	INT
Val_SSC_CH2_SP1	SSC Channel 2 SP1	INT
Val_SSC_CH2_SP2	SSC Channel 2 SP2	INT
Val_SSC1_Mode	SSC1 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	SINT

Output	Function/Description	Data Type
Val_SSC1_SwitchingLogic	SSC1 Switching Logic; 0= High Active 1= Low Active	SINT
Val_SSC2_Mode	SSC2 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	SINT
Val_SSC2_SwitchingLogic	SSC2 Switching Logic; 0= High Active 1= Low Active	SINT
Val_T1_InputSelector	Trigger1 InputSelector; 0= Deactivated, 1= SSC1, 2= SSC2, 3= Margin Alarm 1 4= Margin Alarm 2 5= Temp Alarm 6= Ext Logic Input	SINT
Val_T1_LogicalFunction	Logical Function T1; 0= Direct 1= AND 2= OR 3= XOR	SINT
Val_T1_PhysicalMode	Trigger1 Physical Mode; 0= Disabled Output, 1= PNP, 2= NPN, 3= Push-Pull	SINT
Val_T1_Polarity	Trigger1 Polarity Mode Selected	SINT
Val_T1_Timer	Trigger 1 Timer value	INT
Val_T1_TimerMode	Trigger1 Timer Mode; 0= Disabled, 1= T-On Delay, 2= T-Off Delay, 3= T-On/T-Off Delay 4= One-Shot Leading 5= One-Shot Trailing	SINT
Val_T1_TimerScale	Trigger1 Timer Scale Mode Selected	SINT
Val_T2_InputSelector	Trigger2 InputSelector; 0= Deactivated, 1= SSC1, 2= SSC2, 3= Margin Alarm 1 4= Margin Alarm 2 5= Temp Alarm 6= Ext Logic Input	SINT
Val_T2_LogicalFunction	Logical Function T2; 0= Direct 1= AND 2= OR 3= XOR	SINT
Val_T2_PhysicalMode	Trigger2 Physical Mode; 0= Disabled Output, 1= PNP, 2= NPN, 3= Push-Pull	SINT
Val_T2_Polarity	Trigger2 Polarity Mode Selected	SINT
Val_T2_Timer	Trigger 2 Timer value	INT
Val_T2_TimerMode	Trigger 2 Timer Mode; 0= Disabled, 1= T-On Delay, 2= T-Off Delay, 3= T-On/T-Off Delay 4= One-Shot Leading 5= One-Shot Trailing	SINT
Val_T2_TimerScale	Trigger2 Timer Scale Mode Selected	SINT
Val_Teach_SSC	Teach SSC Mode Selected	INT
Val_TeachStep	Teach Step Value	INT
Val_TemperatureCurrent	Current temperature	INT
Val_TemperatureMaxSinceInception	Maximum temperature - All time high	INT
Val_TemperatureMaxSincePowerUp	Maximum temperature since power up	INT
Val_TemperatureMinSinceInception	Minimum temperature - All time low	INT
Val_TemperatureMinSincePowerUp	Minimum temperature since power up	INT
Val_TempHighThreshold	Temperature high threshold	INT
Val_TempLowThreshold	Temperature low threshold	INT
Val_Trig1_SP1	First SetPoint Value For Triggered1	INT
Val_Trig1_SP2	Second SetPoint Value for Triggered1	INT
Val_Trig2_SP1	First SetPoint Value For Triggered2	INT
Val_Trig2_SP2	Second SetPoint Value for Triggered2	INT
raC_Dvc_ADframework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data InOut Data (raC_Dvc_875L_5032)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_875L_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Set
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensorDiscrete_Cmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[2]
Inp_I	Device Object Inputs	raC_UDT_IOLink_875L_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_875L_Cfg

Input Data

Input	Function/Description	Data Type
Inp_ChxTriggered1	Status Triggered 1 Sensor	BOOL
Inp_ChxTriggered2	Status Triggered 2 Sensor	BOOL
Inp_ChxAnalogValue	Analog Value Dielectric Data	INT
Inp_ChxSwitchingSignalChannel1	Status Switching Signal Channel 1 Status Switching Signal Channel 1	BOOL
Inp_ChxSwitchingSignalChannel2	Status Switching Signal Channel 2	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxTemperatureAlarm	Status Temperature Alarm	BOOL
Inp_ChxMarginAlarm1	Status Margin Alarm 1	BOOL
Inp_ChxMarginAlarm2	Status Margin Alarm 2	BOOL
Inp_ChxShortCircuit	Status Short Circuit	BOOL
Cfg_AdjustmentMode	Adjustment Method Drop-Down; 0= Disabled, 1= Trimmer Input, 2= Teach By Wire	INT
Cfg_SensorApplication	Sensor Application Drop-Down: 0= Full Scale Range 1= Liquid Level 2= Plastic Pellets	INT
Cfg_SSC1_Mode	SSC1Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	INT

Input	Function/Description	Data Type
Cfg_SSC1_SwitchingLogic	SSC1 Switching Logic; 0= High Active 1= Low Active	INT
Cfg_SSC2_SwitchingLogic	SSC2 Switching Logic; 0= High Active 1= Low Active	INT
Cfg_T1_InputSelector	Trigger1 InputSelector; 0= Deactivated, 1= SSC1, 2= SSC2, 3= Margin Alarm 1 4= Margin Alarm 2 5= Temp Alarm 6= Ext Logic Input	INT
Cfg_T1_LogicalFunction	0= Direct 1= AND 2= OR 3= XOR	INT
Cfg_T1_PhysicalMode	Trigger1 Mode; 0= Disabled Output, 1= PNP, 2= NPN, 3= Push-Pull	INT
Cfg_T1_Polarity	Trigger1 Polarity Mode; 0= Not Inverted (N.O.) 1= Inverted (N.C.)	INT
Cfg_T1_TimerMode	Trigger1 Timer Mode; 0= Disabled, 1= T-On Delay, 2= T-Off Delay, 3= T-On/T-Off Delay 4= One-Shot Leading 5= One-Shot Trailing	INT
Cfg_T1_TimerScale	Trigger 1 Timer Scale: 0= Milliseconds 1= Seconds 2= Minutes	INT
Cfg_T2_InputSelector	Trigger2 InputSelector; 0= Deactivated, 1= SSC1, 2= SSC2, 3= Margin Alarm 1 4= Margin Alarm 2 5= Temp Alarm 6= Ext Logic Input	INT
Cfg_T2_LogicalFunction	0= Direct 1= AND 2= OR 3= XOR	INT
Cfg_T2_PhysicalMode	Trigger2 Mode; 0= Disabled Output, 1= PNP, 2= NPN, 3= Push-Pull	INT
Cfg_T2_Polarity	Trigger2 Polarity Mode; 0= Not Inverted (N.O.) 1= Inverted (N.C.)	SINT
Cfg_T2_TimerMode	Trigger2 Timer Mode; 0= Disabled, 1= T-On Delay, 2= T-Off Delay, 3= T-On/T-Off Delay 4= One-Shot Leading 5= One-Shot Trailing	INT
Cfg_T2_TimerScale	Trigger 2 Timer Scale: 0= Milliseconds 1= Seconds 2= Minutes	INT
Cfg_Teach_SSC	Teach SSC Mode; 1= SSC 1 2= SSC 2	INT
Cmd_EnableLED	LED Disable/Enable Command	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_SP1_DTStart	SP1 - Dynamic Teach Start Command	BOOL
Cmd_SP1_DTStop	SP1 - Dynamic Teach Stop Command	BOOL
Cmd_SP1_SingleVal	SP1 - Single Value Teach Command	BOOL
Cmd_SP1_TwoVal_TP1	SP1 - Two Value Trigger Point 1 Teach Command	BOOL
Cmd_SP1_TwoVal_TP2	SP1 - Two Value Trigger Point 2 Teach Command	BOOL
Cmd_SP2_DTStart	SP2 - Dynamic Teach Start Command	BOOL
Cmd_SP2_DTStop	SP2 - Dynamic Teach Stop Command	BOOL
Cmd_SP2_SingleVal	SP2 - Single Value Teach Command	BOOL
Cmd_SP2_TwoVal_TP1	SP2 - Two Value Trigger Point 1 Teach Command	BOOL
Cmd_SP2_TwoVal_TP2	SP2 - Two Value Trigger Point 2 Teach Command	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachCancel	Teach Cancel Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Set_FilterScaler_SP	Filter Scaler Setpoint 1...255	INT
Set_PDC_Data	Process Data Enable Disable Settings	DINT
Set_PDC_EnableDisable_SP	Process data configuration disable enable settings	DINT

Input	Function/Description	Data Type
Set_SafeLimitSSC1	Safe Limit SSC1 Setpoint 0...100	INT
Set_SafeLimitSSC2	Safe Limit SSC2 Set point 0...100	INT
Set_SparkMaxValueT1	Spark T1 Max value for VD/ME/SE Faceplate	INT
Set_SparkMaxValueT2	Spark T2 Max value for VD/ME/SE Faceplate	INT
Set_SparkMinValueT1	Spark T1 Min value for VD/ME/SE Faceplate	INT
Set_SparkMinValueT2	Spark T2 Min value for VD/ME/SE Faceplate	INT
Set_SSC_CH1_Hyst_SP	SSC Channel 1 Hysteresis Setpoint 1...100	INT
Set_SSC_CH1_SP1	SSC Channel 1 Setpoint 1 0...10000	INT
Set_SSC_CH1_SP2	SSC Channel 1 Setpoint 2 0...10000	INT
Set_SSC_CH2_Hyst_SP	SSC Channel 2 Hysteresis Set point 1...100	INT
Set_SSC_CH2_SP1	SSC Channel 2 Setpoint 1 0...10000	INT
Set_SSC_CH2_SP2	SSC Channel 2 Setpoint 2 0...10000	INT
Set_TempHighThreshold	Temperature Threshold High -50...150	INT
Set_TempLowThreshold	Temperature Threshold Low -50...150	INT
Set_TrendMaxValue	Trend max value for VD/ME/SE Faceplate	INT
Set_TrendMinValue	Trend min value for VD/ME/SE Faceplate	INT
Set_Trig1_SP1	SP1 value for trigger 1 Spark trend VD/ME/SE Faceplate	INT
Set_Trig1_SP2	SP2 value for trigger 1 Spark trend VD/ME/SE Faceplate	INT
Set_Trig1_TimerValue	Timer value 1 setpoint0...32,767	INT
Set_Trig2_SP1	SP1 value for trigger 2 Spark trend VD/ME/SE Faceplate	INT
Set_Trig2_SP2	SP1 value for trigger 2 Spark trend VD/ME/SE Faceplate	INT
Set_Trig2_TimerValue	Timer value 2 setpoint0...32,767	INT

Output Data

Output	Function/Description	Data Type
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_Ready	Device is Ready	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Connected	Device is connected to the Programmable Controller	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Available	Device is available for interaction with user code	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL

Output	Function/Description	Data Type
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_EnableLED	LED Status, 0=Disable, 1=Enable	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_AdjustmentModeEnable	Adjustment Method; 0= Disabled, 1= Trimmer Input, 2= Teach By Wire	SINT
Val_AnalogValueT1	Spark Trigger 1 Analog Value	INT
Val_AnalogValueT2	Spark Trigger 2 Analog Value	INT
Val_FilterScaler_SP	Filter Scaler value	INT
Val_MinutesAbvMaxTemp	Minutes above Maximum Temperature	DINT
Val_MinutesBelMinTemp	Minutes below Minimum Temperature	DINT
Val_NumberPowerCycles	Number of Power Cycles	DINT
Val_OperatingHrsSinceInception	Operating Hours Since Inception	DINT
Val_RangeMax	Sensor Maximum Range in Trend	INT
Val_RangeMin	Sensor Minimum Range in Trend	INT
Val_SafeLimitSSC1.SP	Safe limit SSC1	SINT
Val_SafeLimitSSC2.SP	Safe limit SSC2	SINT
Val_SensorApplicationEnable	Sensor Application; 0= Full Scale Range 1= Liquid Level 2= Plastic Pellets	SINT
Val_SSC_CH1_Hyst	SSC Channel 1 Hysteresis	INT
Val_SSC_CH1.SP1	SSC Channel 1 SP1	INT
Val_SSC_CH1.SP2	SSC Channel 1 SP2	INT
Val_SSC_CH2_Hyst	SSC Channel 2 Hysteresis	INT
Val_SSC_CH2.SP1	SSC Channel 2 SP1	INT
Val_SSC_CH2.SP2	SSC Channel 2 SP2	INT
Val_SSC1_Mode	SSC1 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	SINT
Val_SSC1_SwitchingLogic	SSC1 Switching Logic; 0= High Active 1= Low Active	SINT
Val_SSC2_Mode	SSC2 Mode; 0= Deactivated, 1= Single Point, 2= Window, 3= Two Point	SINT
Val_SSC2_SwitchingLogic	SSC2 Switching Logic; 0= High Active 1= Low Active	SINT
Val_T1_InputSelector	Trigger1 InputSelector; 0= Deactivated, 1= SSC1, 2= SSC2, 3= Margin Alarm 1 4= Margin Alarm 2 5= Temp Alarm 6= Ext Logic Input	SINT
Val_T1_LogicalFunction	Logical Function T1; 0= Direct 1= AND 2= OR 3= XOR	SINT
Val_T1_PhysicalMode	Trigger1 Physical Mode; 0= Disabled Output, 1= PNP, 2= NPN, 3= Push-Pull	SINT
Val_T1_Polarity	Trigger1 Polarity Mode Selected	SINT
Val_T1_Timer	Trigger 1 Timer value	INT
Val_T1_TimerMode	Trigger1 Timer Mode; 0= Disabled, 1= T-On Delay, 2= T-Off Delay, 3= T-On/T-Off Delay 4= One-Shot Leading 5= One-Shot Trailing	SINT


Output	Function/Description	Data Type
Val.T1.TimerScale	Trigger1 Timer Scale Mode Selected	SINT
Val.T2.InputSelector	Trigger2 InputSelector; 0= Deactivated, 1= SSC1, 2= SSC2, 3= Margin Alarm 1 4= Margin Alarm 2 5= Temp Alarm 6= Ext Logic Input	SINT
Val.T2.LogicalFunction	Logical Function T2; 0= Direct 1= AND 2= OR 3= XOR	SINT
Val.T2.PhysicalMode	Trigger2 Physical Mode; 0= Disabled Output, 1= PNP, 2= NPN, 3= Push-Pull	SINT
Val.T2.Polarity	Trigger2 Polarity Mode Selected	SINT
Val.T2.Timer	Trigger 2 Timer value	INT
Val.T2.TimerMode	Trigger 2 Timer Mode; 0= Disabled, 1= T-On Delay, 2= T-Off Delay, 3= T-On/T-Off Delay 4= One-Shot Leading 5= One-Shot Trailing	SINT
Val.T2.TimerScale	Trigger2 Timer Scale Mode Selected	SINT
Val.Teach_SSC	Teach SSC Mode Selected	INT
Val.TeachStep	Teach Step Value	INT
Val.TemperatureCurrent	Current temperature	INT
Val.TemperatureMaxSinceInception	Maximum temperature - All time high	INT
Val.TemperatureMaxSincePowerUp	Maximum temperature since power up	INT
Val.TemperatureMinSinceInception	Minimum temperature - All time low	INT
Val.TemperatureMinSincePowerUp	Minimum temperature since power up	INT
Val.TempHighThreshold	Temperature high threshold	INT
Val.TempLowThreshold	Temperature low threshold	INT
Val.Trig1_SP1	First SetPoint Value For Triggered1	INT
Val.Trig1_SP2	Second SetPoint Value for Triggered1	INT
Val.Trig2_SP1	First SetPoint Value For Triggered2	INT
Val.Trig2_SP2	Second SetPoint Value for Triggered2	INT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example

Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 875L device object connected to channel #2 of a POINT I/O 1734-4IOL IO-Link Master module in slot #13 of a POINT I/O adapter named *Rack01*.



The following example uses the 875L device object connected to channel #6 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the 875L device object connected to channel #4 of a 5032-8IOLM12.M12LDR/A IO-Link Master module in named *Mod_Master_5032_4*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_CapSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)


Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_875L_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Name	Description	Usage 
[-] Sensor875L_1001	Sensor 875L 1001	Local
[-] Sensor875L_1001_CtrlCmd	Sensor875L_1001 Command Interface	Public
[-] Sensor875L_1001_CtrlSet	Sensor875L_1001 Setting Interface	Public
[-] Sensor875L_1001_CtrlSts	Sensor875L_1001 Status Interface	Public

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.



Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status 1 & 2 OFF (0) = Gray LED ON (1) = Blue LED Input Depending on Input Selector 1 & 2 for Trigger 1 & 2 settings it will displays the Deactivated, SSC1, SSC2, Margin Alarm 1, Margin Alarm 2, Temperature Alarm, External Logic Input.
4	Trigger1 & 2 Sparkline Trend The spark line shows dielectric values (blue) and set-points (gray) over last 30 seconds.
5	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
6	Process Data: Displays the current Dielectric value.
7	Switching Signal CH 1 & 2 OFF (0) = Gray LED ON (1) = Blue LED
8	Margin Alarm 1 & 2 OFF (0) = Gray LED ON (1) = Blue LED




Trend Spark 1 & 2 changed its Spark line (blue) parameter depending on input selector of trigger1 & 2. Input selector is selected as a Temperature then Spark Line (blue) incorporate with current temperature value and Set-points (gray) incorporate with High & Low threshold value.



Note: In Case of, 5032 Master, changes made to the Application Specific Name require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Device Temperature Bar Graph Purple Indicators: Min/Max since power up Green Indicators: Min/Max since inception Light Blue Triangle Indicator: Current value
2	Device Temperature Current Value
3	Operating Hours Since Inception
4	Minutes above maximum temperature
5	Short Circuit OFF (0) = Gray LED ON (1) = Blue LED
6	Number of Power Cycle
7	Minutes below minimum temperature
8	Temperature Alarm OFF (0) = Gray LED ON (1) = Blue LED



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.

Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. One trend is displayed for Distance.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Distance.

The screenshot shows the 'Sensor 875L 1001' interface with the 'Trend and Spark Limits' configuration window open. The window title is 'Trend and Spark Limits'. Under the heading 'Dielectric Value Scale', there are two input fields: 'Minimum' with a value of 0 and 'Maximum' with a value of 700. The background shows the same 'Ready' status and navigation icons as the previous screenshot.

Configure Tab

The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.


The configuration section is divided into five pages with Teach Settings:

- Parameter Settings
- Process Data Enable Settings
- Switching Signal Channel Settings
- Trigger Settings 1
- Trigger Settings 2
- Teach Settings
- Configuration Apply Settings



In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.

Parameter Settings



Adjustment Method- The Adjustment Method parameter enables operators to select local/remote adjustment of Teach sensor. To enable teach from IO-Link choose it to Disabled.

Sensor Application- Depending on the application operator may select one of the three presets.

Temperature Alarm- This setting means that the sensor gives an alarm in the maximum or minimum temperature is exceeded.


Safe ON/OFF Limit- The sensor has a built-in safety margin that helps adjust the sensing up to the set-points with an additional safe margin. The factory settings are set to two times the standard hysteresis of the sensor.

Local Settings LEDs- The Local Settings LEDs toggle button is used to Enable or disable the LED of the device.


Teach Settings- To navigate the Teach Settings operation.

Process Data Enable Settings

Toggle buttons used to enable or access the cyclic process data variable



Switching Signal Channel Settings



Mode- Operator selects the switching behavior used to create more advanced output.


Switching Logic- High Active or Low active output switching logic.

Set Point 1- Set point 1 defines the first set point value for SSC.

Set Point 2- Set point 2 defines the second set point value for SSC. Its disabled when Mode is selected as Single Point.

Hysteresis- In SSC1 and SSC2 - single point mode and in windows mode the hysteresis can be set 1...100% of the actual switching value.

Trigger 1 settings



Physical Mode- Physical mode has various settings like Deactivated, PNP, NPN, Push-Pull. It decides the switching outputs operate.

Input Selector- This function block allows you to select any of the signals from the sensor front to the Channel A or B. Channel A and B: Can select between SSC1, SSC2, margin alarm 1, margin alarm 2, temperature alarm, and external input.

Polarity- The Polarity value can either be Not-Inverted or Inverted. Not-Inverted means that the output will turn ON when the target is within the expected set points. Inverted means that the output will turn OFF when the target is within the expected set points.


Logic Function- In the logic function block, the selected signals from the input selector can be added a logic function directly without using a PLC - which makes decentralize decisions possible. The logic functions available are AND, OR, XOR, and gated SR-FF.

Timer Mode- Selects which type of timer function is introduced on the Switching Output. Any one of the following is possible: T-On Delay, T-Off Delay, T-On/T-Off Delay, One-Shot Leading, One-Shot Trailing.

Timer Scale- Parameter defines if the delay specified in the Timer delay should be in milliseconds, seconds, or minutes.

Timer Value- Parameter defines the actual duration of the delay. The delay can be set to any integer value from 1... 32,767.

Trigger 2 settings



Physical Mode- Physical mode has various settings like Deactivated, PNP, NPN, Push-Pull, External input (Active high/Pull-down), External input (Active low/pull up), or External Teach input. It decides the switching outputs operate.

Input Selector- This function block allows you to select any of the signals from the sensor front to the Channel A or B. Channel A and B: Can select between SSC1, SSC2, margin alarm 1, margin alarm 2, temperature alarm, and external input.

Polarity- The Polarity value can either be Not-Inverted or Inverted. Not-Inverted means that the output will turn ON when the target is within the expected set points. Inverted means that the output will turn OFF when the target is within the expected set points.


Logic Function- In the logic function block, the selected signals from the input selector can be added a logic function directly without using a PLC - which makes decentralize decisions possible. The logic functions available are AND, OR, XOR, and gated SR-FF.

Timer Mode- Selects which type of timer function is introduced on the Switching Output. Any one of the following is possible: T-On Delay, T-Off Delay, T-On/T-Off Delay, One-Shot Leading, One-Shot Trailing.

Timer Scale- Parameter defines if the delay specified in the Timer delay should be in milliseconds, seconds, or minutes.

Timer Value- Parameter defines the actual duration of the delay. The delay can be set to any integer value from 1... 32,767.

Teach settings




In order to configure the window for teaching operations effectively, there are several options available. The window encompasses three drop-down menus that provide users with the flexibility to select the desired configuration for their specific teaching requirements. Based on the chosen configuration settings, relevant Teach command buttons are dynamically displayed, empowering users to initiate the teaching process. It's important to note that only one button or command remains active at any given time during the teach operation. Additionally, users have the option to interrupt the teach operation and cancel the settings by utilizing the dedicated cancel button/command.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_875L_4IOL, raC_Dvc_875L_8IOL, raC_Dvc_875L_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_875L_4IOL, raC_LD_Dvc_875L_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tagname for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag

Parameter Name	Default Value	Instance Name	Definition	Description
ChannelNumber				Select the Channel Number where the sensor is connected.
Sensor Type				Select sensor type of 875L as per device catalog no.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_875L_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReferance		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 875L), This name depends upon the TagName assigned to object.
SensorType	875L-M8xx18-xx	875L-M8xx18-xx	875L-M8xx18-xx	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
-----------	----------------	----------	----------	----------

raC_Dvc_875L_4IOL	raC_Dvc_875L_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_875L_8IOL	raC_Dvc_875L_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_875L_5032	raC_Dvc_875L_8IOL	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)GraphicSymbols-IO-LinkDevice.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)GraphicSymbols-IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_875L	Faceplate ME	(raC-3_xx-ME) raC_Dvc_875L-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_875L	Faceplate SE	(raC-3_xx-SE) raC_Dvc_875L-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

46DFA - Small Aperture Fiber-optic Amplifier (raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL, raC_Dvc_46DFA_5032)

Overview

The 46DFA small aperture fiber-optic amplifier sensor device object (raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL, raC_Dvc_46DFA_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor diagnostics
- Sensor configuration and parameters
- Process data trending
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: "Operational_Overview_of_46DFA_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Setpoint:** Setpoint will allow the operators to enter the signal value required for the sensor output to turn ON upon target detection.
- **Polarity:** This function changes the sensor output to operate as Not-Inverted (Light Operate) and Inverted (Dark Operate).

Functional Description

The 46DFA small aperture fiber-optic amplifier sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
46DFA	POINT I/O 1734-4IOL	46DFA-L2LBT1-xx	raC_Dvc_46DFA_4IOL_3.02_AOI.L5X	raC_Dvc_46DFA_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	46DFA-L2LBT1-xx	raC_Dvc_46DFA_8IOL_3.02_AOI.L5X	raC_Dvc_46DFA_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	46DFA-L2LBT1-xx	raC_Dvc_46DFA_5032_3.02_AOI.L5X	raC_Dvc_46DFA_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk® View SE files are stored in the */HMI - FactoryTalk View SE* library folder.

Note that a single faceplate is used for either the 4IOL or 8IOL versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
46DFA	Display	(raC-3_02-ME) raC_Dvc_46DFA-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_46DFA-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
46DFA	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the / *ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
46DFA	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_46DFA_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_46DFA_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_46DFA_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_46DFA_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_46DFA_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_46DFA_5032_(3.2)


Device Definition (raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




2. Specify the Application Specific Name e.g. *Light 1001*
3. Select the Process Data Input as *Triggered, Margin, Proximity, Gain, Signal*.



Device Definition (raC_Dvc_46DFA_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 46DFA, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 46DFA Sensor.



- Configure the parameters of sensor from configuration tab from AOP of the 46DFA sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data (raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_46DFA_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[20]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_46DFA_Inp_4IOL Or raC_UDT_ItfAD_46DFA_Inp_8IOL
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices

Input Data

Input	Function/Description	Data Type
Cfg_DisplayIndication	Display Indication; 0 - Standard Indication (Default), 1 - Percentage Indication, 2 - Zero Offset Indication, 3 - Counter Mode Indication	SINT
Cfg_DisplayRotation	Display Rotation; 0 - Normal 1 - Rotate 180°	SINT
Cfg_Function	Function; 1 - Hysteresis, 2 - Window Mode	SINT
Cfg_LightSource	Light Source; 0 - Light Source ON (Default) 1 - Light Source OFF	SINT
Cfg_LightSourceAdj	Light Source Adjustment; 1 - 12...50 µs Settings 1 - 5...500 µs - 32 ms Settings	SINT
Cfg_LightSourceMode	Light Source Mode; 0 - Auto (Default) 1 - Manual	SINT
Cfg_MarginLevelHM	Margin Level - High Multiplier; 0 - 1.2 X (Default), 1 - 1.5 X, 2 - 2.0 X, 3 - 3.0 X, 4 - 4.0 X, 5 - 5.0 X	SINT
Cfg_MarginLevelLM	Margin Level - Low Multiplier; 0 - 0.5 X (Default), 1 - 0.6 X, 2 - 0.7 X, 3 - 0.8 X	SINT
Cfg_OutputPolarityInverted	Output Polarity; 0 - Not Inverted (Default) 1 - Inverted	SINT
Cfg_Pin2Type	Pin 2 type; 0 - Disabled, 1 - PNP, 2 - NPN	SINT
Cfg_ResponseTime	Response Time; 0 - 50 µs, 1 - 500 µs (Default), 2 - 4 ms, 3 - 32 ms	SINT

Input	Function/Description	Data Type
Cmd_Cancel	Teach Cancel - Cancels the Teach Process Command	BOOL
Cmd_CountReset	Count Reset	BOOL
Cmd_DynamicTeachStart	Dynamic Teach Start Command	BOOL
Cmd_DynamicTeachStop	Dynamic Teach Stop Command	BOOL
Cmd_LocalInterfaceLock	Device Access Locks. Local User Interface Lock; 1 = Locked	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_MaxSensitivityTeach	Teach the maximum sensitivity of the sensor Command	BOOL
Cmd_PBLock	Local Push Button Lock Command	BOOL
Cmd_PrecisionTeachStart	Teach the desired set point to ensure detection Command	BOOL
Cmd_StaticTeachBackground	Learn signal level while target is not present Command	BOOL
Cmd_StaticTeachTarget	Learn threshold while target is present Command	BOOL
Cmd_TeachStartButton	Start Teach command	BOOL
Cmd_WindowStartTeach	Teach SP1 when operating in Window Mode Command	BOOL
Cmd_WindowStopTeach	Teach SP2 when operating in Window Mode Command	BOOL
EnableIn	Enable Input - System Defined Parameter	BOOL
Inp_ChNumber	Configured Channel Number for Master	SINT
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxMarginLowAlarm	Margin Low alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity alarm of Sensor	BOOL
Inp_ChxSignalStrength	Signal Strength of Sensor	INT
Inp_ChxTriggered	Triggered status of Sensor	BOOL
Set_Threshold1SP	Set Point - Threshold 1	INT
Set_Threshold2SP	Set Point - Threshold 2	INT
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_PBLock	Local Push Button Lock; 1= Locked	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Val_Count	Sensor Count Value	INT
Val_CounterEN	Counter Enable; 0= Disabled, 1= Enabled	SINT
Val_Display_Ind	Display Indication; 0 - Standard Indication (Default) 1 - Percentage Indication	SINT
Val_Display_Rot	Display Rotation; 0 - Normal 1 - Rotate 180°	SINT
Val_Function	Function; 1 - Hysteresis 2 - Window Mode	SINT
Val_LightSource	Light Source; 0 - Light Source ON (Default) 1 - Light Source OFF	SINT
Val_LightSourceAdj	Light Source Adjustment; 1 - 12...50 μ s Settings 1 - 5...500 μ s - 32 ms Settings	SINT
Val_LightSourceMode	Light Source Mode; 0 - Auto (Default) 1 - Manual	SINT
Val_MarginLevelHigh	Margin Level - High Multiplier; 0 - 1.2 X (Default), 1 - 1.5 X, 2 - 2.0 X, 3 - 3.0 X, 4 - 4.0 X, 5 - 5.0 X	SINT
Val_MarginLevelLow	Margin Level - Low Multiplier; 0 - 0.5 X (Default), 1 - 0.6 X, 2 - 0.7 X, 3 - 0.8 X	SINT
Val_OperatingHours_Inception	Operation Hours - Since Inception	DINT
Val_OperatingHours_PowerUp	Operation Hours - Since Power-Up	DINT
Val_OutputPolarityInverted	Polarity; 0 - Not Inverted (Default) 1 - Inverted	SINT
Val_Pin2Type	Pin 2 type; 0 - Disabled, 1 - PNP, 2 - NPN	SINT

Output	Function/Description	Data Type
Val_ResponseTime	Response Time; 0 - 50 μ S, 1 - 500 μ S (Default), 2 - 4 ms, 3 - 32 ms	SINT
Val_SpeedActual	Speed Actual - Since Power Up	DINT
Val_SpeedMax	Speed Maximum - Since Power Up	DINT
Val_Teach_Status	Teach-in Status	SINT
Val_TeachSelection	Teach type selection	SINT
Val_TeachStep	Teach Step Value	DINT
Val_TempActual	Actual Temperature - Since Power Up	SINT
Val_TempMax_SinceInception	Maximum Temperature Since Inception	SINT
Val_TempMax_SincePowerUp	Maximum Temperature Since Power Up	SINT
Val_TempMin_SinceInception	Minimum Temperature Since Inception	SINT
Val_TempMin_SincePowerUp	Minimum Temperature Since Power Up	SINT
Val_Threshold1	Set Point - Threshold 1	INT
Val_Threshold2	Set Point - Threshold 2	INT
Val_Trigger_Counter	Trigger count	DINT
Val_Voltage_MaxPowerUp	Voltage Maximum - Since Power Up	REAL
Val_Voltage_MinPowerUp	Voltage Minimum - Since Power Up	REAL
Val_VoltageActual	Voltage Actual	REAL
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data InOut Data (raC_Dvc_46DFA_5032)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_46DFA_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_MsgModReconfigure	Message Module Reconfigure	MESSAGE
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[20]
Inp_I	Device Object Inputs	raC_UDT_IOLink_46DFA_Inp_5032
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf_5032
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Cfg_C	Device Object Configuration	raC_UDT_IOLink_46DFA_Cfg

Input Data

Input	Function/Description	Data Type
Cfg_DisplayIndication	Display Indication; 0 - Standard Indication (Default), 1 - Percentage Indication, 2 - Zero Offset Indication, 3 - Counter Mode Indication	SINT
Cfg_DisplayRotation	Display Rotation; 0 - Normal 1 - Rotate 180°	SINT
Cfg_Function	Function; 1 - Hysteresis, 2 - Window Mode	SINT
Cfg_LightSource	Light Source; 0 - Light Source ON (Default) 1 - Light Source OFF	SINT
Cfg_LightSourceAdj	Light Source Adjustment; 1 - 12...50 µs Settings 1 - 5...500 µs - 32 ms Settings	SINT
Cfg_LightSourceMode	Light Source Mode; 0 - Auto (Default) 1 - Manual	SINT
Cfg_MarginLevelHM	Margin Level - High Multiplier; 0 - 1.2 X (Default), 1 - 1.5 X, 2 - 2.0 X, 3 - 3.0 X, 4 - 4.0 X, 5 - 5.0 X	SINT
Cfg_MarginLevelLM	Margin Level - Low Multiplier; 0 - 0.5 X (Default), 1 - 0.6 X, 2 - 0.7 X, 3 - 0.8 X	SINT
Cfg_OutputPolarityInverted	Output Polarity; 0 - Not Inverted (Default) 1 - Inverted	SINT

Input	Function/Description	Data Type
Cfg_Pin2Type	Pin 2 type; 0 - Disabled, 1 - PNP, 2 - NPN	SINT
Cfg_ResponseTime	Response Time; 0 - 50 μ S, 1 - 500 μ S (Default), 2 - 4 mS, 3 - 32 ms	SINT
Cmd_Cancel	Teach Cancel - Cancels the Teach Process Command	BOOL
Cmd_CountReset	Count Reset	BOOL
Cmd_DynamicTeachStart	Dynamic Teach Start Command	BOOL
Cmd_DynamicTeachStop	Dynamic Teach Stop Command	BOOL
Cmd_LocalInterfaceLock	Device Access Locks. Local User Interface Lock; 1 = Locked	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Command	BOOL
Cmd_MaxSensitivityTeach	Teach the maximum sensitivity of the sensor Command	BOOL
Cmd_PBLock	Local Push Button Lock Command	BOOL
Cmd_PrecisionTeachStart	Teach the desired set point to ensure detection Command	BOOL
Cmd_StaticTeachBackground	Learn signal level while target is not present Command	BOOL
Cmd_StaticTeachTarget	Learn threshold while target is present Command	BOOL
Cmd_TeachStartButton	Start Teach command	BOOL
Cmd_WindowStartTeach	Teach SP1 when operating in Window Mode Command	BOOL
Cmd_WindowStopTeach	Teach SP2 when operating in Window Mode Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
EnableIn	Enable Input - System Defined Parameter	BOOL
Inp_ChNumber	Configured Channel Number for Master	SINT
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxMarginLowAlarm	Margin Low alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity alarm of Sensor	BOOL
Inp_ChxSignalStrength	Signal Strength of Sensor	INT
Inp_ChxTriggered	Triggered status of Sensor	BOOL
Set_Setpoint	Setpoint	INT
Set_Threshold1SP	Set Point - Threshold 1	INT
Set_Threshold2SP	Set Point - Threshold 2	INT
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_PBLock	Local Push Button Lock; 1= Locked	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_Count	Sensor Count Value	INT
Val_CounterEN	Counter Enable; 0= Disabled, 1= Enabled	SINT
Val_Display_Ind	Display Indication; 0 - Standard Indication (Default) 1 - Percentage Indication	SINT
Val_Display_Rot	Display Rotation; 0 - Normal 1 - Rotate 180°	SINT
Val_Function	Function; 1 - Hysteresis 2 - Window Mode	SINT
Val_LightSource	Light Source; 0 - Light Source ON (Default) 1 - Light Source OFF	SINT
Val_LightSourceAdj	Light Source Adjustment; 1 - 12...50 μ s Settings 1 - 5...500 μ s - 32 ms Settings	SINT
Val_LightSourceMode	Light Source Mode; 0 - Auto (Default) 1 - Manual	SINT
Val_MarginLevelHigh	Margin Level - High Multiplier; 0 - 1.2 X (Default), 1 - 1.5 X, 2 - 2.0 X, 3 - 3.0 X, 4 - 4.0 X, 5 - 5.0 X	SINT
Val_MarginLevelLow	Margin Level - Low Multiplier; 0 - 0.5 X (Default), 1 - 0.6 X, 2 - 0.7 X, 3 - 0.8 X	SINT
Val_OperatingHours_Inception	Operation Hours - Since Inception	DINT
Val_OperatingHours_PowerUp	Operation Hours - Since Power-Up	DINT
Val_OutputPolarityInverted	Polarity; 0 - Not Inverted (Default) 1 - Inverted	SINT
Val_Pin2Type	Pin 2 type; 0 - Disabled, 1 - PNP, 2 - NPN	SINT


Output	Function/Description	Data Type
Val_ResponseTime	Response Time; 0 - 50 μ S, 1 - 500 μ s (Default), 2 - 4 ms, 3 - 32 ms	SINT
Val_SpeedActual	Speed Actual - Since Power Up	DINT
Val_SpeedMax	Speed Maximum - Since Power Up	DINT
Val_Teach_Status	Teach-in Status	SINT
Val_TeachSelection	Teach type selection	SINT
Val_TeachStep	Teach Step Value	DINT
Val_TempActual	Actual Temperature - Since Power Up	SINT
Val_TempMax_SinceInception	Maximum Temperature Since Inception	SINT
Val_TempMax_SincePowerUp	Maximum Temperature Since Power Up	SINT
Val_TempMin_SinceInception	Minimum Temperature Since Inception	SINT
Val_TempMin_SincePowerUp	Minimum Temperature Since Power Up	SINT
Val_Threshold1	Set Point - Threshold 1	INT
Val_Threshold2	Set Point - Threshold 2	INT
Val_VoltageNoise	Voltage Noise Value Vpp	SINT
Val_Voltage_MaxPowerUp	Voltage Maximum - Since Power Up	REAL
Val_Voltage_MinPowerUp	Voltage Minimum - Since Power Up	REAL
Val_VoltageActual	Voltage Actual	REAL
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung.L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 46DFA device object connected to channel #0 of a POINT I/O1734-4IOLM IO-Link Master module in slot #13 of a POINT I/O adapter.



The following example uses the 46DFA device object connected to channel #0 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module.



The following example uses the 46DFA device object connected to channel #12 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_2*.





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: A0I Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram_...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_LRIndSensor		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: A0I Backing Tag Instance (e.g. {[PAC]Program::IOLinkProgram_...InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_46DFA _Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Name	Usage	Description
▸ _InstanceName	Local	46DFA 1001
▸ _InstanceName_CtrlCmd	Public	46DFA Command Interface
▸ _InstanceName_CtrlSet	Public	46DFA Setting Interface
▸ _InstanceName_CtrlSts	Public	46DFA Status Interface

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Threshold Sparkline Trend The spark line shows Signal Strength, threshold 1 and threshold 2 values over last 30 seconds
5	Margin low alarm status OFF (0) = Gray LED ON (1) = Blue LED
6	Proximity alarm status OFF (0) = Gray LED ON (1) = Blue LED
7	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
8	- Function: Displays the operation mode of the sensor output and the available options are "Hysteresis" or "Window".
9	Process Data - Signal Strength (%): Signal Strength provides the raw measurement value of the amount of light reflected from the target. - Gain: Displays the excess gain above the sensor threshold to ensure reliable detection of the target. - When the Counter Value is enabled, the parameter reflects the sensor count amount. If the counter functionality is disabled, then "Disabled" text is seen.



Note: In Case of, 5032 Master, changes made to the Application Specific Name or Locate Toggle Switch require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.



Item	Description
1	Internal Temperature Bar Graph
2	Internal Temperature Current Value
3	Voltage Bar Graph
4	Voltage Current Value
5	Speed Bar Graph
6	Speed Current Value
7	Operating Hours Since Power Up
8	Operating Hours Since Inception (lifetime)




Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.

Trend Tab


Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action

decisions. One trend is displayed for Signal Strength, Threshold 1 and Threshold 2.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Threshold Setpoints & Signal strength.



Configure Tab

The configuration tab displays the sensor parameter settings, as well as enabling the user to read data from the sensor.


The configuration section is divided into :

- Operating Configuration

- Local device access Locks
- Reset Count
- Teach Settings
- Sensor Configuration (Page 2)
- Configuration Apply Settings



In case of 5032 Master, “[Config Apply](#)” Button on Configure tab should be pressed compulsory after updating parameters on faceplate.



Operating Configuration

Setpoint Threshold 1 - Allows operators to enter the signal value required for the sensor output to turn ON (threshold) upon target detection. That means that the sensor signal level must be higher than the threshold for the output to turn ON.

Setpoint Threshold 2 - This parameter is updated when the window teach procedures are executed. The default value for this parameter is 300.

Pin 2 Type- Changes the output type on pin 2. The sensor default when connected using the AOP is disabled and the output can be changed to operate as PNP only or NPN only.

Function - Allows operator to change the operation mode of the sensor output to ‘Hysteresis’ or ‘Window’. Hysteresis mode turns the sensor output ON after the received signal level is higher than the Threshold 1 parameter, while Window mode turns the output ON while the received signal level is between Threshold 1 and Threshold 2.

Polarity - This parameter allows the user to change the sensor output to operate as non-inverted or inverted.

Local Device access Locks

Push Button Lock- This parameter allows operators to Lock the local push button on the sensor. The push button can be unlocked locally following the unlock procedure.

User Interface Lock- This parameter locks the local user interface and implements an IO-Link controlled lock. This means that the operator cannot unlock the sensor locally even if the unlock procedure is implemented using the push button.

Reset Count

This button allows user to reset the count value already stored in sensor.

Teach Settings

This button navigates to teach settings screen. The available teach methods are:

Static Teach- Press the 'Teach Start' button to initiate the Teach Process.

Place the target in front of the sensor and between the reflectors. Send the 'Teach Target' Command, then remove the target blocking the reflector.

The Teach in status will update to 'wait for command'.

Show the reflector where the target is present and then send 'Teach Background' Command.

The 'Static teach' process is complete and 'Teach in status' will be displayed as 'Idle'.

Dynamic Teach- Press the 'Teach Start' button to begin the Teach Process.

While the object is moving in front of the field of view of the sensor, send 'Dynamic Start' command.

The Teach in status will be displayed as 'Wait for Command' for few seconds.

Send the 'Dynamic Stop' command.

The dynamic teach process is completed.

Precision Teach- Place the target in front of the field of view of the sensor and then send 'Precision Start' command.

The 'Teach in status' will be displayed as 'Teach SP1 success' for few seconds.

The 'Precision teach' process is complete.


Max Sensitivity- Place the target in front of the field of view of the sensor and then send 'Max Sensitivity' command.

The 'Teach in status' will be displayed as 'Busy' for few seconds. The 'Maximum sensitivity' teach process is now complete.

Window Teach- Place the target in front of the field of view of the sensor and send 'Window Start' command. The 'Teach in status' will be displayed as 'Wait for Command' for few seconds.

Keep the target from the field of view of the sensor and send 'Window Stop' command. The 'Window Teach' teach process is now complete.

Sensor Configuration



Margin Level Low Multiplier- Allows you to define when the green LED should start flashing to reflect a signal level that is below the threshold. The default value for this parameter is 0.8 with multiple selection options from 0.5...0.8 in increments of 0.1X.

Margin Level High Multiplier- Allows you to define when the green LED can stop flashing to reflect a signal level that is higher than the threshold. The default value for this parameter is 1.5 with multiple selections that could reach a maximum of 5X.

Display Rotation- Changes the orientation of the LED display. The default setting is standard orientation.

Display Indication- Changes how the received light information is displayed in the sensor LED and received signal strength process data parameter.

Response Time- Changes the sensor response time to increase or decrease the amount of light received by the sensor. The default response time is 500 μ s.

Light Source Adjustment- Changes the LED intensity. When operating in 50 μ s Response Time, the maximum intensity that can be set is 12. Operation on response times higher than 50 μ s, can be set up to 15.


Light Source Mode-Enables automatic or manual operation of the sensor LED intensity. The default parameter is Auto.

Light Source- Enables or disables the light source of the sensor. The default value is ON.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_46DFA_4IOL, raC_Dvc_46DFA_8IOL, raC_Dvc_46DFA_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_46DFA_4IOL, raC_LD_Dvc_46DFA_8IOL

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
Sensor Type				Select sensor type of 46DFA as per device catalog no.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_46DFA_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReferance		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 46DFA), This name depends upon the TagName assigned to object.

SensorType	46DFA-L2LBT1-xx	46DFA-L2LBT1-xx	46DFA-L2LBT1-xx	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)
ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_46DFA_4IOL	raC_Dvc_46DFA_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_46DFA_8IOL	raC_Dvc_46DFA_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_46DFA_5032	raC_Dvc_46DFA_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME)Graphic Symbols - lo-link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE)Graphic Symbols - lo-link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_46DFA	Faceplate ME	(raC-3_xx-ME) raC_Dvc_46DFA-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_46DFA	Faceplate SE	(raC-3_xx-SE) raC_Dvc_46DFA-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation

V3_I0_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png
-------------------	---------------	---------------------------------------	--

45PLA - Polarized Light Array Photoelectric Sensor (raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL, raC_Dvc_45PLA_5032)

Overview

The 45PLA Polarized Light Array Photoelectric Sensor device object (raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL, raC_Dvc_45PLA_5032) includes HMI faceplates which displays device information including:

- Sensor data
- Sensor diagnostics
- Sensor configuration and parameters
- Process data trending
- Device Fault log



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: "Operational_Overview_of_45PLA_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Health:** View device health such as run-hours and temperature.
- **Sensor Configuration:** Configure general sensor parameters including local LED and lock settings, process data enable/disable, and adjustment method & sensor application.
- **Teach:** Offers the different teach functions.

Functional Description

The 45PLA Polarized Light Array Photoelectric Sensor pre-configured Device Objects:

- Collect, Process and Deliver Data between Smart Devices and Application Logic
- Provide Device Status & Diagnostics Faceplates for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplates. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. Each device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with each IO-Link Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Compatible IO-Link Sensor	Add-On Instruction	Rung Import
45PLA	POINT I/O 1734-4IOL	45PLA-P2LPT1-F4	raC_Dvc_45PLA_4IOL_3.02_AOI.L5X	raC_Dvc_45PLA_4IOL_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	45PLA-P2LPT1-F4	raC_Dvc_45PLA_8IOL_3.02_AOI.L5X	raC_Dvc_45PLA_8IOL_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	45PLA-P2LPT1-F4	raC_Dvc_45PLA_5032_3.02_AOI.L5X	raC_Dvc_45PLA_5032_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder

Note that a single faceplate is used for either the 4IOL, 8IOL & 5032 versions of the Add-On Instruction.

Device/Item	Type	FactoryTalk® View ME Faceplate	FactoryTalk® View SE Faceplate
45PLA	Display	(raC-3-02-ME) raC_Dvc_45PLA-Faceplate.gfx	(raC-3-02-SE) raC_Dvc_45PLA-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx

Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx
---------	---------------	--	--

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
45PLA	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
45PLA	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45PLA_4IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45PLA_4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_45PLA_8IOL_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45PLA_8IOL_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IOLink_raC_Dvc_45PLA_5032_(3.2)	(RA-LIB)_Device_Device_IO-Link_raC_LD_Dvc_45PLA_5032_(3.2)


Device Definition (raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL)

The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Click on Change...




2. Specify the Application Specific Name e.g. *Sensor_1001*
3. Select the Process Data Input as *Triggered, Margin, Proximity, Gain, Signal*.



Device Definition (raC_Dvc_45PLA_5032)


The device must be configured with the correct device definition. Proper device configuration enables the required cyclic device data to pass information from the device into the add-on instruction.

1. Go to Properties of 5032-8IOLM12M12LDR/A Master Module >> General >> Click on Change... and Configure the required channels as a IO-Link configuration. (Only even nos. of channel can be configured as a IO-Link)




Note: If Sensor is Class B, Then, User should select the IO-Link Class B Enabled Check box, Shown in above image (Applicable for Channel No. 2,3,6 & 7).

2. Whichever channels are selected for 45PLA, you can find them, in IO-Link of 5032 Master. Expand the IO-Link tree and select the 45PLA Sensor.



- Configure the parameters of sensor from configuration tab from AOP of the 45PLA sensor.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data (raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgCustSetSubIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetSubIdx	Message Configuration Read	MESSAGE
Ref_MsgData	Messaging Data	raC_UDT_45PLA_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_Ctrl_Inf	IO-Link Device Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	IO-Link Device Command, Status Interface	raC_UDT_ItfAD_IOLinkDevices
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STR0082[20]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_45PLA_Inp_4IOL Or raC_UDT_ItfAD_45PLA_Inp_8IOL

Input Data

Input	Function/Description	Data Type
Cfg_BeamMode	Beam Mode; 0 - Object Detection - Six Beams, 1 - Object Detection - Five Beams, 2 - Object Detection - Four Beams, 3 - Object Detection - Three Beams, 4 - Object Detection - Two Beams, 5 - Object Detection - One Beam, 8 - Gap Detection - Six Beams, 9 - Gap Detection - Five Beams, 10 - Gap Detection - Four Beams, 11 - Gap Detection - Three Beams, 12 - Gap Detection - Two Beams, 13 - Gap Detection - One Beam	DINT
Cfg_MarginLevelHighMultiplier	Margin Level-High Multiplier; 10 - 1.0, 11 - 1.1, 12 - 1.2, 15 - 1.5, 20 - 2.0, 50 - 5.0, 100 - 10.0, 150 - 15.0	DINT
Cfg_MarginLevelLowMultiplier	Margin Level-Low Multiplier; 0 - 0.8, 1 - 0.7, 2 - 0.6, 3 - 0.5	SINT
Cfg_Mode	Mode; 0 - PNP, 1 - NPN	SINT
Cfg_OperatingFrequency	Operating Frequency; 0 - 1 (800 uS), 1 - 2 (860 uS)	SINT
Cfg_Pin2Mode	Pin 2 Mode; 0 - Disable, 1 - PNP-Not Inverted, 2 - PNP-Inverted, 3 - NPN-Not Inverted, 4 - NPN-Inverted, 5 - Remote Teach Input, 6 - Independent Control PNP, 7 - Independent Control NPN	DINT
Cfg_Polarity	Polarity; 0 - Not Inverted, 1 - Inverted	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_ResetCount	Counter Reset Command	BOOL
Cmd_TeachApply	Teach Apply Command	BOOL

Input	Function/Description	Data Type
Cmd_TeachPrecisionShowReflector	Teach Precision Show Reflector Command	BOOL
Cmd_TeachStandardShowReflector	Teach Standard Show Reflector Command	BOOL
Cmd_TeachStart	Teach Start Command	BOOL
Cmd_TeachStaticShowReflector	Teach Static Show Reflector Command	BOOL
Cmd_TeachStaticShowTarget	Teach Static Show Target Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity Alarm of Sensor	BOOL
Inp_ChxSignalStrength	Indicates the reflectivity level of the reflector	DINT
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Set_Beam1Emitter1LEDIntensity	Set the LED Intensity for Beam One for Emitter1	DINT
Set_Beam1Receiver1ThresholdEmitter1	Set the Threshold for Beam One Receiver1 for Emitter1	DINT
Set_Beam2Emitter2LEDIntensity	Set the LED Intensity for Beam Two and Three for Emitter2	DINT
Set_Beam2Receiver1ThresholdEmitter2	Set the Threshold for Beam Two Receiver1 for Emitter2	DINT
Set_Beam3Receiver2ThresholdEmitter2	Set the Threshold for Beam Three Receiver2 for Emitter2	DINT
Set_Beam4Emitter3LEDIntensity	Set the LED Intensity for Beam Four and Five for Emitter3	DINT
Set_Beam4Receiver2ThresholdEmitter3	Set the Threshold for Beam Four Receiver2 for Emitter3	DINT
Set_Beam5Receiver3ThresholdEmitter3	Set the Threshold for Beam Five Receiver3 for Emitter3	DINT
Set_Beam6Emitter4LEDIntensity	Set the LED Intensity for Beam Six for Emitter4	DINT
Set_Beam6Receiver3ThresholdEmitter4	Set the Threshold for Beam Six Receiver3 for Emitter4	DINT
Set_MarginBooster	Set the multiplier factor that applies to the LEDs current value	DINT
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_CounterEnabled	Counter Enabled Indication; 0= Disable, 1= Enable	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Val_Beam1Emitter1LEDIntensity	Displays the LED intensity for Emitter1 for Beam One	DINT
Val_Beam1Receiver1ThresholdEmitter1	Display the Threshold for Beam One Receiver1 for Emitter1	DINT
Val_Beam2Emitter2LEDIntensity	Display the LED Intensity for Beam Two and Three for Emitter2	DINT
Val_Beam2Receiver1ThresholdEmitter2	Display the Threshold for Beam Two Receiver1 for Emitter2	DINT
Val_Beam3Receiver2ThresholdEmitter2	Display the Threshold for Beam Three Receiver2 for Emitter2	DINT
Val_Beam4Emitter3LEDIntensity	Display the LED Intensity for Beam Four and Five for Emitter3	DINT
Val_Beam4Receiver2ThresholdEmitter3	Display the Threshold for Beam Four Receiver2 for Emitter3	DINT
Val_Beam5Receiver3ThresholdEmitter3	Display the Threshold for Beam Five Receiver3 for Emitter3	DINT
Val_Beam6Emitter4LEDIntensity	Display the LED Intensity for Beam Six for Emitter4	DINT
Val_Beam6Receiver3ThresholdEmitter4	Display the Threshold for Beam Six Receiver3 for Emitter4	DINT
Val_BeamMode	Beam Mode Status; 0 - Object Detection - Six Beams, 1 - Object Detection - Five Beams, 2 - Object Detection - Four Beams, 3 - Object Detection - Three Beams, 4 - Object Detection - Two Beams, 5 - Object Detection - One Beam, 8 - Gap Detection - Six Beams, 9 - Gap Detection - Five Beams, 10 - Gap Detection - Four Beams, 11 - Gap Detection - Three Beams, 12 - Gap Detection - Two Beams, 13 - Gap Detection - One Beam	DINT
Val_Counter	Display Counter Value	DINT
Val_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	SINT
Val_MarginBooster	Display the multiplier factor that applies to the LEDs current value	DINT
Val_MarginLevelHighMultiplier	Margin Level-High Multiplier Status; 10 - 1.0, 11 - 1.1, 12 - 1.2, 15 - 1.5, 20 - 2.0, 50 - 5.0, 100 - 10.0, 150 - 15.0	INT

Output	Function/Description	Data Type
Val.MarginLevelLowMultiplier	Margin Level-Low Multiplier Status; 0 - 0.8, 1 - 0.7, 2 - 0.6, 3 - 0.5	INT
Val.Mode	Mode Status; 0 - PNP, 1 - NPN	INT
Val.OperatingFrequency	Operating Frequency Status; 0 - 1 (800 uS), 1 - 2 (860 uS)	INT
Val.OperatingHrsSinceInception	Displays the number of hours that the sensor has been continuously in operation	DINT
Val.OperatingHrsSincePowerUp	Displays the number of targets that have been detected since the sensor has been in operation	DINT
Val.Pin2Mode	Pin 2 Mode Status; 0 - Disable, 1 - PNP-Not Inverted, 2 - PNP-Inverted, 3 - NPN-Not Inverted, 4 - NPN-Inverted, 5 - Remote Teach Input, 6 - Independent Control PNP, 7 - Independent Control	DINT
Val.Polarity	Displays the polarity of channel; 0 = Not Inverted, 1=Inverted	INT
Val.RangeMax	Sensor Maximum Range in Trend	DINT
Val.RangeMin	Sensor Minimum Range in Trend	DINT
Val.Speed	Display the the actual frequency of detection in Hertz	DINT
Val.TeachStep	Teach Step	INT
Val.Temperature	Displays the internal temperature information available in the sensor	SINT
Val.TemperatureMaxSinceInception	Reflects the maximum temperature inside of the microprocessor die of the sensor since inception	SINT
Val.TemperatureMaxSincePowerUp	Reflects the maximum temperature inside of the microprocessor die of the sensor since the last power up	SINT
Val.TemperatureMinSinceInception	Reflects the minimum temperature inside of the microprocessor die of the sensor since inception	SINT
Val.TemperatureMinSincePowerUp	Reflects the minimum temperature inside of the microprocessor die of the sensor since the last power up	SINT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Add-On Instruction I/O Data InOut Data (raC_Dvc_45PLA_5032)

InOut	Function / Description	Data Type
Ref_Module	Reference to module in I/O tree	MODULE
Ref_MsgCustSetIdx	Message Configuration Write	MESSAGE
Ref_MsgCustGetIdx	Message Configuration Read	MESSAGE
Ref_MsgModReconfigure	Message Module Reconfigure	MESSEAG
Ref_MsgData	Messaging Data	raC_UDT_45PLA_Sensor_Data
Ref_Ctrl_Set	IO-Link Device Setting Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSet
Ref_Ctrl_Cmd	IO-Link Device Command Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd
Ref_Ctrl_Sts	IO-Link Device Status Interface	raC_UDT_ItfAD_IOLinkSensor_CtrlSts
Ref_Ctrl_Inf	IO-Link Device Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	IO-Link Device Command, Status	raC_UDT_ItfAD_IOLinkDevices
Inf_Lookup	Code / Description List Entry	raC_UDT_LookupMember_STRO082[20]
Inp_I	Device Object Inputs	raC_UDT_ItfAD_45PLA_Inp_5032
Cfg_C	Device Object Configuration	raC_UDT_IOLink_45PLA_Cfg

Input Data

Input	Function/Description	Data Type
Cfg_BeamMode	Beam Mode; 0 - Object Detection - Six Beams, 1 - Object Detection - Five Beams, 2 - Object Detection - Four Beams, 3 - Object Detection - Three Beams, 4 - Object Detection - Two Beams, 5 - Object Detection - One Beam, 8 - Gap Detection - Six Beams, 9 - Gap Detection - Five Beams, 10 - Gap Detection - Four Beams, 11 - Gap Detection - Three Beams, 12 - Gap Detection - Two Beams, 13 - Gap Detection - One Beam	DINT
Cfg_MarginLevelHighMultiplier	Margin Level-High Multiplier; 10 - 1.0, 11 - 1.1, 12 - 1.2, 15 - 1.5, 20 - 2.0, 50 - 5.0, 100 - 10.0, 150 - 15.0	DINT
Cfg_MarginLevelLowMultiplier	Margin Level-Low Multiplier; 0 - 0.8, 1 - 0.7, 2 - 0.6, 3 - 0.5	SINT
Cfg_Mode	Mode; 0 - PNP, 1 - NPN	SINT
Cfg_OperatingFrequency	Operating Frequency; 0 - 1 (800 uS), 1 - 2 (860 uS)	SINT
Cfg_Pin2Mode	Pin 2 Mode; 0 - Disable, 1 - PNP-Not Inverted, 2 - PNP-Inverted, 3 - NPN-Not Inverted, 4 - NPN-Inverted, 5 - Remote Teach Input, 6 - Independent Control PNP, 7 - Independent Control NPN	DINT
Cfg_Polarity	Polarity; 0 - Not Inverted, 1 - Inverted	SINT
Cmd_DisableLEDs	Indicator Disabled Command	BOOL
Cmd_EnableLEDs	Indicator Enabled Command	BOOL
Cmd_LocalTeachLock	Parameters Unlock/Lock Cmd	BOOL
Cmd_Locate	Locator Disable/Enable Command	BOOL
Cmd_ResetCount	Counter Reset Command	BOOL

Input	Function/Description	Data Type
Cmd_TeachApply	Teach Apply Command	BOOL
Cmd_TeachPrecisionShowReflector	Teach Precision Show Reflector Command	BOOL
Cmd_TeachStandardShowReflector	Teach Standard Show Reflector Command	BOOL
Cmd_TeachStart	Teach Start Command	BOOL
Cmd_TeachStaticShowReflector	Teach Static Show Reflector Command	BOOL
Cmd_TeachStaticShowTarget	Teach Static Show Target Command	BOOL
Cmd_ApplyConfiguration	Module reconfigure Command	BOOL
Inp_ChNumber	Configured Channel number for Master	SINT
Inp_ChxGain	Gain of Sensor	INT
Inp_ChxMarginLowAlarm	Margin Low Alarm of Sensor	BOOL
Inp_ChxProximityAlarm	Proximity Alarm of Sensor	BOOL
Inp_ChxSignalStrength	Indicates the reflectivity level of the reflector	DINT
Inp_ChxTriggered	Triggered Status of Sensor	BOOL
Set_Beam1Emitter1LEDIntensity	Set the LED Intensity for Beam One for Emitter1	DINT
Set_Beam1Receiver1ThresholdEmitter1	Set the Threshold for Beam One Receiver1 for Emitter1	DINT
Set_Beam2Emitter2LEDIntensity	Set the LED Intensity for Beam Two and Three for Emitter2	DINT
Set_Beam2Receiver1ThresholdEmitter2	Set the Threshold for Beam Two Receiver1 for Emitter2	DINT
Set_Beam3Receiver2ThresholdEmitter2	Set the Threshold for Beam Three Receiver2 for Emitter2	DINT
Set_Beam4Emitter3LEDIntensity	Set the LED Intensity for Beam Four and Five for Emitter3	DINT
Set_Beam4Receiver2ThresholdEmitter3	Set the Threshold for Beam Four Receiver2 for Emitter3	DINT
Set_Beam5Receiver3ThresholdEmitter3	Set the Threshold for Beam Five Receiver3 for Emitter3	DINT
Set_Beam6Emitter4LEDIntensity	Set the LED Intensity for Beam Six for Emitter4	DINT
Set_Beam6Receiver3ThresholdEmitter4	Set the Threshold for Beam Six Receiver3 for Emitter4	DINT
Set_MarginBooster	Set the multiplier factor that applies to the LEDs current value	DINT
Set_TrendMaxValue	Trend Tab Max value for VD/ME/SE faceplate	DINT
Set_TrendMinValue	Trend Tab Min value for VD/ME/SE faceplate	DINT

Output Data

Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_bNotReady	Enumerated state value: 0 = Reserved 1 = Device not connected 2 = Device not available 3 = Device is faulted 4 - 31 = Reserved	DINT
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_CounterEnabled	Counter Enabled Indication; 0= Disable, 1= Enable	BOOL
Sts_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_InhibitCfg	1=Inhibit user Configuration Parameters from HMI Faceplate; 0=Allow	BOOL
Sts_InhibitCmd	1=Inhibit user Commands from HMI Faceplate; 0=Allow Control	BOOL
Sts_InhibitSet	1=Inhibit user Settings from HMI Faceplate; 0=Allow	BOOL
Sts_LocalTeachLock	Local Parameterization; 0= Unlock, 1= Locked	BOOL
Sts_Located	Locator Indicator; 1= Located	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_ApplyConfiguration	Module Reconfigure Request On Status	BOOL
Val_Beam1Emitter1LEDIntensity	Displays the LED intensity for Emitter1 for Beam One	DINT
Val_Beam1Receiver1ThresholdEmitter1	Display the Threshold for Beam One Receiver1 for Emitter1	DINT
Val_Beam2Emitter2LEDIntensity	Display the LED Intensity for Beam Two and Three for Emitter2	DINT
Val_Beam2Receiver1ThresholdEmitter2	Display the Threshold for Beam Two Receiver1 for Emitter2	DINT
Val_Beam3Receiver2ThresholdEmitter2	Display the Threshold for Beam Three Receiver2 for Emitter2	DINT
Val_Beam4Emitter3LEDIntensity	Display the LED Intensity for Beam Four and Five for Emitter3	DINT
Val_Beam4Receiver2ThresholdEmitter3	Display the Threshold for Beam Four Receiver2 for Emitter3	DINT
Val_Beam5Receiver3ThresholdEmitter3	Display the Threshold for Beam Five Receiver3 for Emitter3	DINT
Val_Beam6Emitter4LEDIntensity	Display the LED Intensity for Beam Six for Emitter4	DINT
Val_Beam6Receiver3ThresholdEmitter4	Display the Threshold for Beam Six Receiver3 for Emitter4	DINT
Val_BeamMode	Beam Mode Status; 0 - Object Detection - Six Beams, 1 - Object Detection - Five Beams, 2 - Object Detection - Four Beams, 3 - Object Detection - Three Beams, 4 - Object Detection - Two Beams, 5 - Object Detection - One Beam, 8 - Gap Detection - Six Beams, 9 - Gap Detection - Five Beams, 10 - Gap Detection - Four Beams, 11 - Gap Detection - Three Beams, 12 - Gap Detection - Two Beams, 13 - Gap Detection - One Beam	DINT
Val_Counter	Display Counter Value	DINT
Val_EnableLEDs	LED Indicator; 0= Disable, 1= Enable	SINT


Output	Function/Description	Data Type
Val_MarginBooster	Display the multiplier factor that applies to the LEDs current value	DINT
Val_MarginLevelHighMultiplier	Margin Level-High Multiplier Status; 10 - 1.0, 11 - 1.1, 12 - 1.2, 15 - 1.5, 20 - 2.0, 50 - 5.0, 100 - 10.0, 150 - 15.0	INT
Val_MarginLevelLowMultiplier	Margin Level-Low Multiplier Status; 0 - 0.8, 1 - 0.7, 2 - 0.6, 3 - 0.5	INT
Val_Mode	Mode Status; 0 - PNP, 1 - NPN	INT
Val_OperatingFrequency	Operating Frequency Status; 0 - 1 (800 uS), 1 - 2 (860 uS)	INT
Val_OperatingHrsSinceInception	Displays the number of hours that the sensor has been continuously in operation	DINT
Val_OperatingHrsSincePowerUp	Displays the number of targets that have been detected since the sensor has been in operation	DINT
Val_Pin2Mode	Pin 2 Mode Status; 0 - Disable, 1 - PNP-Not Inverted, 2 - PNP-Inverted, 3 - NPN-Not Inverted, 4 - NPN-Inverted, 5 - Remote Teach Input, 6 - Independent Control PNP, 7 - Independent	DINT
Val_Polarity	Displays the polarity of channel; 0 = Not Inverted, 1=Inverted	INT
Val_RangeMax	Sensor Maximum Range in Trend	DINT
Val_RangeMin	Sensor Minimum Range in Trend	DINT
Val_Speed	Display the the actual frequency of detection in Hertz	DINT
Val_TeachStep	Teach Step	INT
Val_Temperature	Displays the internal temperature information available in the sensor	SINT
Val_TemperatureMaxSinceInception	Reflects the maximum temperature inside of the microprocessor die of the sensor since inception	SINT
Val_TemperatureMaxSincePowerUp	Reflects the maximum temperature inside of the microprocessor die of the sensor since the last power up	SINT
Val_TemperatureMinSinceInception	Reflects the minimum temperature inside of the microprocessor die of the sensor since inception	SINT
Val_TemperatureMinSincePowerUp	Reflects the minimum temperature inside of the microprocessor die of the sensor since the last power up	SINT
raC_Dvc_ADFramework_DV_LD	Unique Parameter Name for auto - discovery	BOOL

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung .L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 45PLA device object connected to channel #2 of a POINT I/O 1734-4IOL IO-Link Master module named *Point_IO_4IOLMaster* in slot #14 of a POINT I/O adapter named *Rack01*.



The following example uses the 45PLA device object connected to channel #3 of a ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*



The following example uses the 45PLA device object connected to channel #8 of a 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_2*





Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_LightSens		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g. {:[PAC]Program::IOLinkProgram._InstanceName}) #104: Custom button label. Leave blank to use Tag.@Description #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_45PLA _Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates

There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).


The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Name	Usage	Data Type	Description
▶ Sensor_1002	Local	raC_Dvc_45PLA_8IOL	Sensor 45PLA
▶ Sensor_1002_CtrlCmd	Public	raC_UDT_ItfAD_IOLinkSensor_CtrlCmd	_InstanceName Command Interface

Name	Usage	Alias For	Base Tag	Data Type	Description
▶ Sensor_45PLA	Local			raC_Dvc_45PLA_5032	Sensor_45PLA

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data and the Locate button.




Item	Description
1	Banner- Ready Status
2	Application Specific Name - Read from device
3	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED
4	Signal Strength Sparkline Trend The spark line shows the signal strength value.
5	Margin Low Alarm indicates, when the target Signal is marginal and about to fail. Proximity Alarm indicates, if there is a target in the background that may be in close proximity to the threshold.
6	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
7	The Beam Mode defines the number of active beams and operation logic that is applied to the state of the beams.
8	Process Data - Signal strength indicates the reflectivity level of the reflector, which makes this feature ideal for continuous monitoring. - Gain displays the excess gain above the sensor threshold to confirm reliable detection of the target. - When the Counter Value is enabled, the parameter reflects the sensor count amount. If the counter functionality is disabled, then "Disabled" text is seen.



Note: In Case of, 5032 Master, changes made to the Application Specific Name or Locate Toggle Switch require pressing the 'Config Apply' button in the Config tab to update the sensor parameters.

Health Tab

Health tab provides different diagnostic information of sensor which helps ensure that sensors are operating correctly.




Item	Description
1	Speed Bar Graph Blue Triangle Indicator: Current value
2	Speed Current Value
3	Internal Temperature Bar Graph Green Indicators: Min/Max since inception (lifetime) Purple Indicators: Min/Max since power up Blue Triangle Indicator: Current value
4	Internal Temperature Current Value
5	Operating Hours Since Power Up
6	Operating Hours Since Inception (lifetime)



Inception/Lifetime values are recorded since the first time the sensor was ever powered ON. These value are retained and not reset during default factory reset. Power Up values are reset to zero and recorded new each time the sensor is power cycled.

Trend Tab

Trends display values over time, often used to compare similar or related values and to allow operators to predict future states to make control action decisions. Trend is displayed for Signal Strength.



Trend Settings Screen

We can set trend limits using configuration tab by clicking on the *Settings* button present on trend screen. This sub screen display contains two numeric input elements that allow the user to enter the minimum and maximum values to be used on the Trend screen for Signal strength.

The screenshot shows the 'Sensor 45PLA' interface with the 'Trend and Spark Limits' configuration window open. The window title is 'Trend and Spark Limits'. Under the heading 'Signal Strength Scale', there are two input fields: 'Minimum' with the value '0' and 'Maximum' with the value '65535'. The background shows the same navigation menu and status indicator as the previous screenshot.

Configure Tab


The configuration tab displays the various parameter settings and options, as well as enabling the user to read data from the sensor.

The configuration section is divided into sections:

- Operation Configuration
- Sensor Configuration
- Teach Settings
- Configuration Apply Settings



In case of 5032 Master, "Config Apply" Button on Configure tab should be pressed compulsory after updating parameters on faceplate.




Operation Configuration

Intensity and Threshold - Allows the user to set the LED intensity and Threshold for Beam-1 to Beam-6.

Local Teach Parameters - This section allow user to lock / unlock device local parameterization. Touch Lock/Unlock Toggle switch to Lock Local Parameterization

Disable/Enable LEDs - This parameter allows operators to turn OFF or turn ON the User Interface LEDs (green and orange LEDs). This parameter is ideal for applications where turning OFF the LEDs is desired to accommodate the application.

Reset Count - Allows users to reset the counter function, it will reset the sensor counts to zero.



Sensor Configuration

Margin Level- Low Multiplier - Allows the user to defines the signal level at which the green LED starts flashing, indicating it is below the threshold.

Margin Level- High Multiplier - Allows the user to determines when the green LED can stop flashing, indicating a signal level higher than the threshold.

Operating Frequency - In certain applications, where it's necessary to place two 45PLA sensors in close proximity, their emission may interfere with each other. Adjusting the operating frequency helps mitigate such interference.

Polarity - Allows the user to change the sensor output to operate as Non-Inverted or Inverted.

Beam Mode - Allows the user to define the number of active beams and operation logic that is applied to the state of the beams.

Pin2 Mode - Allows the user to enables the operation of the output on pin 2 in IO-Link Mode.

Mode - Allows the user to change the output mode to operate as PNP or NPN.

Margin Booster - Allows the user to indicate the multiplier factor that applies to the current value of the LEDs.



Teach Settings

Teach Settings display includes the Teach Mode, Teach procedure flow buttons, and Teach Apply button. Touch on the Teach Settings navigation button to access the Teach Settings tab.

Teach tab includes the following functions.

- Teach mode selection dropdown menu

- Teach procedure flow buttons



Teach mode - This parameter selects the desired mode.

Static Teach - The first method is Static Teach.

1. Press the **“Teach Start”** button to initiate the Teach Process
2. Place the target in front of the sensor while ensuring it is placed in between the reflector. Press the **“Show Target”** command button. Once the target has been displayed, remove it from obstructing the reflector.
3. Show the reflector where the target is present and then press the **“Show Reflector”** button.
4. Send the **“Teach Apply”** command to finalize the teach process.

Standard Teach - The second method is Standard Teach.

1. Press the **“Teach Start”** button to begin the Teach Process.

2. Place the reflector in front of the sensor's field of view and send **“Show Reflector”** command.
3. Press the **“Teach Apply”** button to finalize the teach process.


Precision Teach - The third method is Precision Teach.

1. Press the **“Teach Start”** button to begin the Teach Process.
2. Place the reflector in front of the sensor's field of view and send the **“Show Reflector”** command.
3. Send the **“Teach Apply”** command to finalize the teach process.


Configuration Apply Settings

Config Apply - This Button allows user to Update the configuration parameters after modifying the parameters on faceplate.

Ideally, “Config Apply” button on Configuration tab is disabled, as shown in below image.



If User Changes any Parameter from Configuration Tab, then, “Config apply” Button is Enabled. For updating the desired change in Sensor, user needs to Click on “Config Apply” Button, as shown in below image.




After updating the Parameters, “Config Apply” Button gets disabled still there is any parameter change by the User.

Fault Warning Tab


The Fault Warning tab displays information for up to four faults for the device. The fault table displays the Severity level (Fault, Warning or Active Fault), time (and date) and a description of the fault.

Note, only row 1 will display the “Active Fault” in the severity column if there is a current active fault, else it will display the last fault. Rows 2-4 only display past faults and warnings, not an active fault.



Item	Description
1	Banner
2	Last fault is in first row and show in bold if active
3	Yellow border visible when a fault is active
4	Fault severity
5	Fault event time
6	4 most recent fault/warning event messages

Click on any row in the fault table to view fault details. The details window provides a more detailed description and possible action steps to remedy condition.



Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_45PLA_4IOL, raC_Dvc_45PLA_8IOL, raC_Dvc_45PLA_5032

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_45PLA_410L, raC_LD_Dvc_45PLA_810L

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
ChannelNumber				Select the Channel Number where the sensor is connected.
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_45PLA_5032

Parameter Name	Default Value	Instance Name	Definition	Description
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
MasterReferance		[Master5032]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
ModuleName	Mod_{ObjectName}	Mod_{ObjectName}	Module	Select the sensor series (i.e. 45PLA), This name depends upon the TagName assigned to object.
SensorType	45PLA-P2LPT1-F4	45PLA-P2LPT1-F4	45PLA-P2LPT1-F4	Select the sensor from drop down list. with this selection, AOI type of the sensor is generated in ACD. (i.e. Type1, Type2 or Type3)

ChannelNumber				Select the Channel Number where the sensor is connected.
Navigation Button	GraphicalButton		HMI Configuration	Select the Launch Button Type for Generate the HMI through ACM.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_45PLA_4IOL	raC_Dvc_45PLA_4IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_45PLA_8IOL	raC_Dvc_45PLA_8IOL	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_45PLA_5032	raC_Dvc_45PLA_5032	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_45PLA	Faceplate ME	(raC-3_xx-ME) raC_Dvc_45PLA-Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_45PLA	Faceplate SE	(raC-3_xx-SE) raC_Dvc_45PLA-Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

IO-Link HUB

Overview

The IO-Link HUB device object (raC_Dvc_1732IL_10X6M12, raC_Dvc_1732IL_16CFGM12M12L, raC_Dvc_1732IL_IB16M12_8IOL) includes HMI faceplate's which displays device information including:

- Module description, status, and faults
- Channel description, status



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section: "Operational_Overview_of_IO-Link_HUB_Objects_Faceplate.MP4"

Required Files

IO Device Objects include HMI faceplates. There is no controller programming required other than the creation of the I/O module in the project. If using FactoryTalk® View ME/SE you must also import the tag import file *FTViewStudio_IOLinkLibrary_Tags_3_00.CSV* to support navigation on faceplates.

FactoryTalk View HMI Files

FactoryTalk View ME/SE applications require importing the desired device faceplates in addition to all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
1732IL_10X6M12	Display	(raC-3_01-ME) raC_Dvc_1732IL_10X6M12-Faceplate.gfx	(raC-3_01-SE) raC_Dvc_1732IL_10X6M12-Faceplate.gfx
1732IL_16CFGM12M12L	Display	(raC-3_01-ME) raC_Dvc_1732IL_16CFGM12M12-Faceplate.gfx	(raC-3_01-SE) raC_Dvc_1732IL_16CFGM12M12-Faceplate.gfx
1732IL_IB16M12	Display	(raC-3_01-ME) raC_Dvc_1732IL_IB16M12-Faceplate.gfx	(raC-3_01-SE) raC_Dvc_1732IL_IB16M12-Faceplate.gfx

Studio 5000 View Designer HMI Files




All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
IO-Link HUB	raC_Dvc_17321L_Hubs.vpd




Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays.



FactoryTalk View ME/SE Graphic Symbols



Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFP10X6HUB		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #106.	#102: Faceplate Display Name e.g. (raC-3_00-ME)raC_Dvc_XXXX_XXXX-Faceplate or (raC-3_00-SE) raC_Dvc_XXXX_XXXX-Faceplate #103: IO Module Input Tag e.g. {::[Topic Name]Local:1:} #104: IO Module Output Tag e.g. {::[Topic Name]Local:1:} #105: Channel No e.g. (0...7) #106: Custom button label e.g.g (HUB_100) #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchFP16CFGHUB		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #106.	#102: Faceplate Display Name e.g. (raC-3_00-ME)raC_Dvc_XXXX_XXXX-Faceplate or (raC-3_00-SE) raC_Dvc_XXXX_XXXX-Faceplate #103: IO Module Input Tag e.g. {::[Topic Name]Local:1:} #104: IO Module Output Tag e.g. {::[Topic Name]Local:1:} #105: Channel No e.g. (0...7) #106: Custom button label e.g.g (HUB_101) #130: Channel0 Configuration (Input =I, Output =O) #131: Channel1 Configuration (Input =I, Output =O) #132: Channel2 Configuration (Input =I, Output =O) #133: Channel3 Configuration (Input =I, Output =O) #134: Channel4 Configuration (Input =I, Output =O) #135: Channel5 Configuration (Input =I, Output =O) #136: Channel6 Configuration (Input =I, Output =O) #137: Channel7 Configuration (Input =I, Output =O) #138: Channel8 Configuration (Input =I, Output =O) #139: Channel9 Configuration (Input =I, Output =O) #140: Channel10 Configuration (Input =I, Output =O) #141: Channel11 Configuration (Input =I, Output =O) #142: Channel12 Configuration (Input =I, Output =O) #143: Channel13 Configuration (Input =I, Output =O) #144: Channel14 Configuration (Input =I, Output =O) #145: Channel15 Configuration (Input =I, Output =O) #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchFP16HUB		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: Faceplate Display Name e.g. (raC-3_00-ME)raC_Dvc_XXXX_XXXX-Faceplate or raC-3_00-SE) raC_Dvc_XXXX_XXXX-Faceplate #103: IO Module Input Tag e.g. {::[Topic Name]Local:1:} #104: Channel No e.g. (0...7) #105: Custom button label e.g.g (HUB_102) #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)

Configuring FactoryTalk View Objects

Graphic Symbol Name	Graphic Symbol	Configured Parameter																																																																																																																								
GO_LaunchFP10X6HUB		<p>This IO-Link Hub is connected to the Channel 0 of 1732E-8IOL Master module named "MASTER1"</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p>Global Object Parameter Values</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th>Name</th> <th>Value</th> <th>Tag</th> <th></th> </tr> </thead> <tbody> <tr><td>1</td><td>#102</td><td>(raC-3_00-ME) raC_Dvc_1732IL_10X6M12-Faceplate</td><td>...</td><td>Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_</td></tr> <tr><td>2</td><td>#103</td><td>{::[PAC]MASTER1:I}</td><td>...</td><td>IO Module Input Tag e.g. {::[Topic Name]Local:1:I}</td></tr> <tr><td>3</td><td>#104</td><td>{::[PAC]MASTER1:O}</td><td>...</td><td>IO Module Output Tag e.g. {::[Topic Name]Local:1:O}</td></tr> <tr><td>4</td><td>#105</td><td>0</td><td>...</td><td>Channel No</td></tr> <tr><td>5</td><td>#106</td><td>HUB_100</td><td>...</td><td>Custom button label.</td></tr> <tr><td>6</td><td>#120</td><td></td><td>...</td><td>Display's left position (e.g. 100) (optional)</td></tr> <tr><td>7</td><td>#121</td><td></td><td>...</td><td>Display's top position (e.g. 100) (optional)</td></tr> </tbody> </table> </div>		Name	Value	Tag		1	#102	(raC-3_00-ME) raC_Dvc_1732IL_10X6M12-Faceplate	...	Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_	2	#103	{::[PAC]MASTER1:I}	...	IO Module Input Tag e.g. {::[Topic Name]Local:1:I}	3	#104	{::[PAC]MASTER1:O}	...	IO Module Output Tag e.g. {::[Topic Name]Local:1:O}	4	#105	0	...	Channel No	5	#106	HUB_100	...	Custom button label.	6	#120		...	Display's left position (e.g. 100) (optional)	7	#121		...	Display's top position (e.g. 100) (optional)																																																																																
	Name	Value	Tag																																																																																																																							
1	#102	(raC-3_00-ME) raC_Dvc_1732IL_10X6M12-Faceplate	...	Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_																																																																																																																						
2	#103	{::[PAC]MASTER1:I}	...	IO Module Input Tag e.g. {::[Topic Name]Local:1:I}																																																																																																																						
3	#104	{::[PAC]MASTER1:O}	...	IO Module Output Tag e.g. {::[Topic Name]Local:1:O}																																																																																																																						
4	#105	0	...	Channel No																																																																																																																						
5	#106	HUB_100	...	Custom button label.																																																																																																																						
6	#120		...	Display's left position (e.g. 100) (optional)																																																																																																																						
7	#121		...	Display's top position (e.g. 100) (optional)																																																																																																																						
GO_LaunchFP16CFGHUB		<p>This IO-Link Hub is connected to the Channel 1 of 1734-4IOL Master module installed in the "Slot 13" of the communication adapter module named "AENTR1"</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p>Global Object Parameter Values</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th>Name</th> <th>Value</th> <th>Tag</th> <th></th> </tr> </thead> <tbody> <tr><td>1</td><td>#102</td><td>(raC-3_00-ME) raC_Dvc_1732IL_16CFGM12M12L-Fa</td><td>...</td><td>Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_</td></tr> <tr><td>2</td><td>#103</td><td>{::[PAC]AENTR1:13:I}</td><td>...</td><td>IO Module Input Tag e.g. {::[Topic Name]Local:1:I}</td></tr> <tr><td>3</td><td>#104</td><td>{::[PAC]AENTR1:13:O}</td><td>...</td><td>IO Module Output Tag e.g. {::[Topic Name]Local:1:O}</td></tr> <tr><td>4</td><td>#105</td><td>1</td><td>...</td><td>Channel No</td></tr> <tr><td>5</td><td>#106</td><td>HUB_101</td><td>...</td><td>Custom button label.</td></tr> <tr><td>6</td><td>#130</td><td>I</td><td>...</td><td>Channel0 Configuration (Input =I, Output =O)</td></tr> <tr><td>7</td><td>#131</td><td>I</td><td>...</td><td>Channel1 Configuration (Input =I, Output =O)</td></tr> <tr><td>8</td><td>#132</td><td>O</td><td>...</td><td>Channel2 Configuration (Input =I, Output =O)</td></tr> <tr><td>9</td><td>#133</td><td>O</td><td>...</td><td>Channel3 Configuration (Input =I, Output =O)</td></tr> <tr><td>10</td><td>#134</td><td>I</td><td>...</td><td>Channel4 Configuration (Input =I, Output =O)</td></tr> <tr><td>11</td><td>#135</td><td>I</td><td>...</td><td>Channel5 Configuration (Input =I, Output =O)</td></tr> <tr><td>12</td><td>#136</td><td>O</td><td>...</td><td>Channel6 Configuration (Input =I, Output =O)</td></tr> <tr><td>13</td><td>#137</td><td>O</td><td>...</td><td>Channel7 Configuration (Input =I, Output =O)</td></tr> <tr><td>14</td><td>#138</td><td>I</td><td>...</td><td>Channel8 Configuration (Input =I, Output =O)</td></tr> <tr><td>15</td><td>#139</td><td>I</td><td>...</td><td>Channel9 Configuration (Input =I, Output =O)</td></tr> <tr><td>16</td><td>#140</td><td>O</td><td>...</td><td>Channel10 Configuration (Input =I, Output =O)</td></tr> <tr><td>17</td><td>#141</td><td>O</td><td>...</td><td>Channel11 Configuration (Input =I, Output =O)</td></tr> <tr><td>18</td><td>#142</td><td>I</td><td>...</td><td>Channel12 Configuration (Input =I, Output =O)</td></tr> <tr><td>19</td><td>#143</td><td>I</td><td>...</td><td>Channel13 Configuration (Input =I, Output =O)</td></tr> <tr><td>20</td><td>#144</td><td>O</td><td>...</td><td>Channel14 Configuration (Input =I, Output =O)</td></tr> <tr><td>21</td><td>#145</td><td>O</td><td>...</td><td>Channel15 Configuration (Input =I, Output =O)</td></tr> <tr><td>22</td><td>#120</td><td></td><td>...</td><td>Display's left position (e.g. 100) (optional)</td></tr> <tr><td>23</td><td>#121</td><td></td><td>...</td><td>Display's top position (e.g. 100) (optional)</td></tr> </tbody> </table> </div>		Name	Value	Tag		1	#102	(raC-3_00-ME) raC_Dvc_1732IL_16CFGM12M12L-Fa	...	Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_	2	#103	{::[PAC]AENTR1:13:I}	...	IO Module Input Tag e.g. {::[Topic Name]Local:1:I}	3	#104	{::[PAC]AENTR1:13:O}	...	IO Module Output Tag e.g. {::[Topic Name]Local:1:O}	4	#105	1	...	Channel No	5	#106	HUB_101	...	Custom button label.	6	#130	I	...	Channel0 Configuration (Input =I, Output =O)	7	#131	I	...	Channel1 Configuration (Input =I, Output =O)	8	#132	O	...	Channel2 Configuration (Input =I, Output =O)	9	#133	O	...	Channel3 Configuration (Input =I, Output =O)	10	#134	I	...	Channel4 Configuration (Input =I, Output =O)	11	#135	I	...	Channel5 Configuration (Input =I, Output =O)	12	#136	O	...	Channel6 Configuration (Input =I, Output =O)	13	#137	O	...	Channel7 Configuration (Input =I, Output =O)	14	#138	I	...	Channel8 Configuration (Input =I, Output =O)	15	#139	I	...	Channel9 Configuration (Input =I, Output =O)	16	#140	O	...	Channel10 Configuration (Input =I, Output =O)	17	#141	O	...	Channel11 Configuration (Input =I, Output =O)	18	#142	I	...	Channel12 Configuration (Input =I, Output =O)	19	#143	I	...	Channel13 Configuration (Input =I, Output =O)	20	#144	O	...	Channel14 Configuration (Input =I, Output =O)	21	#145	O	...	Channel15 Configuration (Input =I, Output =O)	22	#120		...	Display's left position (e.g. 100) (optional)	23	#121		...	Display's top position (e.g. 100) (optional)
	Name	Value	Tag																																																																																																																							
1	#102	(raC-3_00-ME) raC_Dvc_1732IL_16CFGM12M12L-Fa	...	Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_																																																																																																																						
2	#103	{::[PAC]AENTR1:13:I}	...	IO Module Input Tag e.g. {::[Topic Name]Local:1:I}																																																																																																																						
3	#104	{::[PAC]AENTR1:13:O}	...	IO Module Output Tag e.g. {::[Topic Name]Local:1:O}																																																																																																																						
4	#105	1	...	Channel No																																																																																																																						
5	#106	HUB_101	...	Custom button label.																																																																																																																						
6	#130	I	...	Channel0 Configuration (Input =I, Output =O)																																																																																																																						
7	#131	I	...	Channel1 Configuration (Input =I, Output =O)																																																																																																																						
8	#132	O	...	Channel2 Configuration (Input =I, Output =O)																																																																																																																						
9	#133	O	...	Channel3 Configuration (Input =I, Output =O)																																																																																																																						
10	#134	I	...	Channel4 Configuration (Input =I, Output =O)																																																																																																																						
11	#135	I	...	Channel5 Configuration (Input =I, Output =O)																																																																																																																						
12	#136	O	...	Channel6 Configuration (Input =I, Output =O)																																																																																																																						
13	#137	O	...	Channel7 Configuration (Input =I, Output =O)																																																																																																																						
14	#138	I	...	Channel8 Configuration (Input =I, Output =O)																																																																																																																						
15	#139	I	...	Channel9 Configuration (Input =I, Output =O)																																																																																																																						
16	#140	O	...	Channel10 Configuration (Input =I, Output =O)																																																																																																																						
17	#141	O	...	Channel11 Configuration (Input =I, Output =O)																																																																																																																						
18	#142	I	...	Channel12 Configuration (Input =I, Output =O)																																																																																																																						
19	#143	I	...	Channel13 Configuration (Input =I, Output =O)																																																																																																																						
20	#144	O	...	Channel14 Configuration (Input =I, Output =O)																																																																																																																						
21	#145	O	...	Channel15 Configuration (Input =I, Output =O)																																																																																																																						
22	#120		...	Display's left position (e.g. 100) (optional)																																																																																																																						
23	#121		...	Display's top position (e.g. 100) (optional)																																																																																																																						
GO_LaunchFP16B16HUB		<p>This IO-Link Hub is connected to the Channel 2 of 1732E-8IOL Master module named "MASTER1"</p> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 10px;"> <p>Global Object Parameter Values</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th>Name</th> <th>Value</th> <th>Tag</th> <th></th> </tr> </thead> <tbody> <tr><td>1</td><td>#102</td><td>(raC-3_00-ME) raC_Dvc_1732IL_IB16M12-Faceplate</td><td>...</td><td>Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_</td></tr> <tr><td>2</td><td>#103</td><td>{::[PAC]MASTER1:I}</td><td>...</td><td>IO Module Input Tag e.g. {::[Topic Name]Local:1:I}</td></tr> <tr><td>3</td><td>#104</td><td>2</td><td>...</td><td>Channel No</td></tr> <tr><td>4</td><td>#105</td><td>HUB_102</td><td>...</td><td>Custom button label.</td></tr> <tr><td>5</td><td>#120</td><td></td><td>...</td><td>Display's left position (e.g. 100) (optional)</td></tr> <tr><td>6</td><td>#121</td><td></td><td>...</td><td>Display's top position (e.g. 100) (optional)</td></tr> </tbody> </table> </div>		Name	Value	Tag		1	#102	(raC-3_00-ME) raC_Dvc_1732IL_IB16M12-Faceplate	...	Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_	2	#103	{::[PAC]MASTER1:I}	...	IO Module Input Tag e.g. {::[Topic Name]Local:1:I}	3	#104	2	...	Channel No	4	#105	HUB_102	...	Custom button label.	5	#120		...	Display's left position (e.g. 100) (optional)	6	#121		...	Display's top position (e.g. 100) (optional)																																																																																					
	Name	Value	Tag																																																																																																																							
1	#102	(raC-3_00-ME) raC_Dvc_1732IL_IB16M12-Faceplate	...	Faceplate Display Name e.g. (raC-5_00-ME) raC_Dvc_																																																																																																																						
2	#103	{::[PAC]MASTER1:I}	...	IO Module Input Tag e.g. {::[Topic Name]Local:1:I}																																																																																																																						
3	#104	2	...	Channel No																																																																																																																						
4	#105	HUB_102	...	Custom button label.																																																																																																																						
5	#120		...	Display's left position (e.g. 100) (optional)																																																																																																																						
6	#121		...	Display's top position (e.g. 100) (optional)																																																																																																																						

Studio 5000 View Designer Graphic Symbols


Graphic Symbol Name	Graphic Symbol	Description	Property Configuration																																																																																								
10X6M12		<p>The supplied launch button in View Designer is used to navigate to the faceplate in a user application.</p>	<p>This IO-Link Hub is connected to the Channel 0 of 1732E-8IOL Master module named "MASTER1"</p> <div style="border: 1px solid gray; padding: 5px;"> <p>Name: grp_LB_10X6M12_4IOL Type: PanelDeviceGroup</p> <p>Properties Animations Events</p> <p>Touch Press</p> <p>Open Popup: User-Defined Screens\raC_Dvc_1732IL_10X6M12_FP</p> <p>Property Configuration:</p> <table border="1"> <tr><td>ChXCh0</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch0</td><td>...</td></tr> <tr><td>ChXCh1</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch1</td><td>...</td></tr> <tr><td>ChXCh10</td><td>☞</td><td>::PAC.MASTER1:O.Ch0Ch0</td><td>...</td></tr> <tr><td>ChXCh11</td><td>☞</td><td>::PAC.MASTER1:O.Ch0Ch1</td><td>...</td></tr> <tr><td>ChXCh12</td><td>☞</td><td>::PAC.MASTER1:O.Ch0Ch2</td><td>...</td></tr> <tr><td>ChXCh13</td><td>☞</td><td>::PAC.MASTER1:O.Ch0Ch3</td><td>...</td></tr> <tr><td>ChXCh14</td><td>☞</td><td>::PAC.MASTER1:O.Ch0Ch4</td><td>...</td></tr> <tr><td>ChXCh15</td><td>☞</td><td>::PAC.MASTER1:O.Ch0Ch5</td><td>...</td></tr> <tr><td>ChXCh2</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch2</td><td>...</td></tr> <tr><td>ChXCh3</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch3</td><td>...</td></tr> <tr><td>ChXCh4</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch4</td><td>...</td></tr> <tr><td>ChXCh5</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch5</td><td>...</td></tr> <tr><td>ChXCh6</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch6</td><td>...</td></tr> <tr><td>ChXCh7</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch7</td><td>...</td></tr> <tr><td>ChXCh8</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch8</td><td>...</td></tr> <tr><td>ChXCh9</td><td>☞</td><td>::PAC.MASTER1:I.Ch0Ch9</td><td>...</td></tr> <tr><td>ChXModuleActuatorPwrLow</td><td>☞</td><td>::PAC.MASTER1:I.Ch0ModuleActuatorPwrLow</td><td>...</td></tr> <tr><td>ChXModuleInputError</td><td>☞</td><td>::PAC.MASTER1:I.Ch0ModuleInputError</td><td>...</td></tr> <tr><td>ChXModuleOutputError</td><td>☞</td><td>::PAC.MASTER1:I.Ch0ModuleOutputError</td><td>...</td></tr> <tr><td>ChXModuleSensorPwrLow</td><td>☞</td><td>::PAC.MASTER1:I.Ch0ModuleSensorPwrLow</td><td>...</td></tr> <tr><td>Module_Tag_I</td><td>☞</td><td>::PAC.MASTER1:I</td><td>...</td></tr> <tr><td>Status_ChxFault</td><td>☞</td><td>::PAC.MASTER1:I.Status.Ch0Fault</td><td>...</td></tr> </table> </div>	ChXCh0	☞	::PAC.MASTER1:I.Ch0Ch0	...	ChXCh1	☞	::PAC.MASTER1:I.Ch0Ch1	...	ChXCh10	☞	::PAC.MASTER1:O.Ch0Ch0	...	ChXCh11	☞	::PAC.MASTER1:O.Ch0Ch1	...	ChXCh12	☞	::PAC.MASTER1:O.Ch0Ch2	...	ChXCh13	☞	::PAC.MASTER1:O.Ch0Ch3	...	ChXCh14	☞	::PAC.MASTER1:O.Ch0Ch4	...	ChXCh15	☞	::PAC.MASTER1:O.Ch0Ch5	...	ChXCh2	☞	::PAC.MASTER1:I.Ch0Ch2	...	ChXCh3	☞	::PAC.MASTER1:I.Ch0Ch3	...	ChXCh4	☞	::PAC.MASTER1:I.Ch0Ch4	...	ChXCh5	☞	::PAC.MASTER1:I.Ch0Ch5	...	ChXCh6	☞	::PAC.MASTER1:I.Ch0Ch6	...	ChXCh7	☞	::PAC.MASTER1:I.Ch0Ch7	...	ChXCh8	☞	::PAC.MASTER1:I.Ch0Ch8	...	ChXCh9	☞	::PAC.MASTER1:I.Ch0Ch9	...	ChXModuleActuatorPwrLow	☞	::PAC.MASTER1:I.Ch0ModuleActuatorPwrLow	...	ChXModuleInputError	☞	::PAC.MASTER1:I.Ch0ModuleInputError	...	ChXModuleOutputError	☞	::PAC.MASTER1:I.Ch0ModuleOutputError	...	ChXModuleSensorPwrLow	☞	::PAC.MASTER1:I.Ch0ModuleSensorPwrLow	...	Module_Tag_I	☞	::PAC.MASTER1:I	...	Status_ChxFault	☞	::PAC.MASTER1:I.Status.Ch0Fault	...
ChXCh0	☞	::PAC.MASTER1:I.Ch0Ch0	...																																																																																								
ChXCh1	☞	::PAC.MASTER1:I.Ch0Ch1	...																																																																																								
ChXCh10	☞	::PAC.MASTER1:O.Ch0Ch0	...																																																																																								
ChXCh11	☞	::PAC.MASTER1:O.Ch0Ch1	...																																																																																								
ChXCh12	☞	::PAC.MASTER1:O.Ch0Ch2	...																																																																																								
ChXCh13	☞	::PAC.MASTER1:O.Ch0Ch3	...																																																																																								
ChXCh14	☞	::PAC.MASTER1:O.Ch0Ch4	...																																																																																								
ChXCh15	☞	::PAC.MASTER1:O.Ch0Ch5	...																																																																																								
ChXCh2	☞	::PAC.MASTER1:I.Ch0Ch2	...																																																																																								
ChXCh3	☞	::PAC.MASTER1:I.Ch0Ch3	...																																																																																								
ChXCh4	☞	::PAC.MASTER1:I.Ch0Ch4	...																																																																																								
ChXCh5	☞	::PAC.MASTER1:I.Ch0Ch5	...																																																																																								
ChXCh6	☞	::PAC.MASTER1:I.Ch0Ch6	...																																																																																								
ChXCh7	☞	::PAC.MASTER1:I.Ch0Ch7	...																																																																																								
ChXCh8	☞	::PAC.MASTER1:I.Ch0Ch8	...																																																																																								
ChXCh9	☞	::PAC.MASTER1:I.Ch0Ch9	...																																																																																								
ChXModuleActuatorPwrLow	☞	::PAC.MASTER1:I.Ch0ModuleActuatorPwrLow	...																																																																																								
ChXModuleInputError	☞	::PAC.MASTER1:I.Ch0ModuleInputError	...																																																																																								
ChXModuleOutputError	☞	::PAC.MASTER1:I.Ch0ModuleOutputError	...																																																																																								
ChXModuleSensorPwrLow	☞	::PAC.MASTER1:I.Ch0ModuleSensorPwrLow	...																																																																																								
Module_Tag_I	☞	::PAC.MASTER1:I	...																																																																																								
Status_ChxFault	☞	::PAC.MASTER1:I.Status.Ch0Fault	...																																																																																								
IB16M12		<p>The supplied launch button in View Designer is used to navigate to the faceplate in a user application.</p>	<p>This IO-Link Hub is connected to the Channel 0 of 1732E-8IOL Master module named "Master8IOL_48"</p> <div style="border: 1px solid gray; padding: 5px;"> <p>Name: grp_LB_IB16M12_4IOL Type: PanelDeviceGroup</p> <p>Properties Animations Events</p> <p>Touch Press</p> <p>Open Popup: User-Defined Screens\raC_Dvc_1732IL_IB16M12_FP</p> <p>Property Configuration:</p> <table border="1"> <tr><td>ChxCh0_Ch7</td><td>☞</td><td>::PAC.Master8IOL_48:I.Ch0Ch0_Ch7</td><td>...</td></tr> <tr><td>ChxCh8_Ch15</td><td>☞</td><td>::PAC.Master8IOL_48:I.Ch0Ch8_Ch15</td><td>...</td></tr> <tr><td>ChxModuleActuatorPwrLow</td><td>☞</td><td>::PAC.Master8IOL_48:I.Ch0ModuleActuatorPwrLow</td><td>...</td></tr> <tr><td>ChxModuleInputError</td><td>☞</td><td>::PAC.Master8IOL_48:I.Ch0ModuleInputError</td><td>...</td></tr> <tr><td>ChxModuleOutputError</td><td>☞</td><td>::PAC.Master8IOL_48:I.Ch0ModuleOutputError</td><td>...</td></tr> <tr><td>ChxModuleSensorPwrLow</td><td>☞</td><td>::PAC.Master8IOL_48:I.Ch0ModuleSensorPwrLow</td><td>...</td></tr> <tr><td>Module_Tag_I</td><td>☞</td><td>::PAC.Master8IOL_48:I</td><td>...</td></tr> <tr><td>Status_ChxFault</td><td>☞</td><td>::PAC.Master8IOL_48:I.Status.Ch0Fault</td><td>...</td></tr> </table> </div>	ChxCh0_Ch7	☞	::PAC.Master8IOL_48:I.Ch0Ch0_Ch7	...	ChxCh8_Ch15	☞	::PAC.Master8IOL_48:I.Ch0Ch8_Ch15	...	ChxModuleActuatorPwrLow	☞	::PAC.Master8IOL_48:I.Ch0ModuleActuatorPwrLow	...	ChxModuleInputError	☞	::PAC.Master8IOL_48:I.Ch0ModuleInputError	...	ChxModuleOutputError	☞	::PAC.Master8IOL_48:I.Ch0ModuleOutputError	...	ChxModuleSensorPwrLow	☞	::PAC.Master8IOL_48:I.Ch0ModuleSensorPwrLow	...	Module_Tag_I	☞	::PAC.Master8IOL_48:I	...	Status_ChxFault	☞	::PAC.Master8IOL_48:I.Status.Ch0Fault	...																																																								
ChxCh0_Ch7	☞	::PAC.Master8IOL_48:I.Ch0Ch0_Ch7	...																																																																																								
ChxCh8_Ch15	☞	::PAC.Master8IOL_48:I.Ch0Ch8_Ch15	...																																																																																								
ChxModuleActuatorPwrLow	☞	::PAC.Master8IOL_48:I.Ch0ModuleActuatorPwrLow	...																																																																																								
ChxModuleInputError	☞	::PAC.Master8IOL_48:I.Ch0ModuleInputError	...																																																																																								
ChxModuleOutputError	☞	::PAC.Master8IOL_48:I.Ch0ModuleOutputError	...																																																																																								
ChxModuleSensorPwrLow	☞	::PAC.Master8IOL_48:I.Ch0ModuleSensorPwrLow	...																																																																																								
Module_Tag_I	☞	::PAC.Master8IOL_48:I	...																																																																																								
Status_ChxFault	☞	::PAC.Master8IOL_48:I.Status.Ch0Fault	...																																																																																								

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration																																																																																																																																																								
16CFGM12M12L		<p>The supplied launch button in View Designer is used to navigate to the faceplate in a user application.</p>	<p>This IO-Link Hub is connected to the Channel 1 of 1732E-8IOL Master module named "MASTER"</p>  <p>Properties</p> <p>Name: grp_LB_16CFGM12M12L Type: PanelDeviceGroup</p> <p>Events</p> <p>Touch Press</p> <p>Open Popup: User-Defined Screens\raC_Dvc_1732IL_16CFGM12M12L_FP</p> <p>Property Configuration:</p> <table border="1"> <tbody> <tr><td>ChXCh0</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch0</td><td>...</td></tr> <tr><td>ChXCh1</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch1</td><td>...</td></tr> <tr><td>ChXCh10</td><td>☺</td><td>::PAC.MASTER:O.Ch1Ch10</td><td>...</td></tr> <tr><td>ChXCh11</td><td>☺</td><td>::PAC.MASTER:O.Ch1Ch11</td><td>...</td></tr> <tr><td>ChXCh12</td><td>☺</td><td>::PAC.MASTER:O.Ch1Ch12</td><td>...</td></tr> <tr><td>ChXCh13</td><td>☺</td><td>::PAC.MASTER:O.Ch1Ch13</td><td>...</td></tr> <tr><td>ChXCh14</td><td>☺</td><td>::PAC.MASTER:O.Ch1Ch14</td><td>...</td></tr> <tr><td>ChXCh15</td><td>☺</td><td>::PAC.MASTER:O.Ch1Ch15</td><td>...</td></tr> <tr><td>ChXCh2</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch2</td><td>...</td></tr> <tr><td>ChXCh3</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch3</td><td>...</td></tr> <tr><td>ChXCh4</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch4</td><td>...</td></tr> <tr><td>ChXCh5</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch5</td><td>...</td></tr> <tr><td>ChXCh6</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch6</td><td>...</td></tr> <tr><td>ChXCh7</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch7</td><td>...</td></tr> <tr><td>ChXCh8</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch8</td><td>...</td></tr> <tr><td>ChXCh9</td><td>☺</td><td>::PAC.MASTER:I.Ch1Ch9</td><td>...</td></tr> <tr><td>ChXModuleActuatorPwrLow</td><td>☺</td><td>::PAC.MASTER:I.Ch1ModuleActuatorPwrLow</td><td>...</td></tr> <tr><td>ChXModuleInputError</td><td>☺</td><td>::PAC.MASTER:I.Ch1ModuleInputError</td><td>...</td></tr> <tr><td>ChXModuleOutputError</td><td>☺</td><td>::PAC.MASTER:I.Ch1ModuleOutputError</td><td>...</td></tr> <tr><td>ChXModuleSensorPwrLow</td><td>☺</td><td>::PAC.MASTER:I.Ch1ModuleSensorPwrLow</td><td>...</td></tr> <tr><td>IOCfg_Ch0</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch1</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch10</td><td>☺</td><td>O</td><td></td></tr> <tr><td>IOCfg_Ch11</td><td>☺</td><td>O</td><td></td></tr> <tr><td>IOCfg_Ch12</td><td>☺</td><td>O</td><td></td></tr> <tr><td>IOCfg_Ch13</td><td>☺</td><td>O</td><td></td></tr> <tr><td>IOCfg_Ch14</td><td>☺</td><td>O</td><td></td></tr> <tr><td>IOCfg_Ch15</td><td>☺</td><td>O</td><td></td></tr> <tr><td>IOCfg_Ch2</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch3</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch4</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch5</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch6</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch7</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch8</td><td></td><td>I</td><td></td></tr> <tr><td>IOCfg_Ch9</td><td></td><td>I</td><td></td></tr> <tr><td>Module_Tag_I</td><td>☺</td><td>::PAC.MASTER:I</td><td>...</td></tr> <tr><td>Status_ChXFault</td><td>☺</td><td>::PAC.MASTER:I.Status.Ch1Fault</td><td>...</td></tr> </tbody> </table>	ChXCh0	☺	::PAC.MASTER:I.Ch1Ch0	...	ChXCh1	☺	::PAC.MASTER:I.Ch1Ch1	...	ChXCh10	☺	::PAC.MASTER:O.Ch1Ch10	...	ChXCh11	☺	::PAC.MASTER:O.Ch1Ch11	...	ChXCh12	☺	::PAC.MASTER:O.Ch1Ch12	...	ChXCh13	☺	::PAC.MASTER:O.Ch1Ch13	...	ChXCh14	☺	::PAC.MASTER:O.Ch1Ch14	...	ChXCh15	☺	::PAC.MASTER:O.Ch1Ch15	...	ChXCh2	☺	::PAC.MASTER:I.Ch1Ch2	...	ChXCh3	☺	::PAC.MASTER:I.Ch1Ch3	...	ChXCh4	☺	::PAC.MASTER:I.Ch1Ch4	...	ChXCh5	☺	::PAC.MASTER:I.Ch1Ch5	...	ChXCh6	☺	::PAC.MASTER:I.Ch1Ch6	...	ChXCh7	☺	::PAC.MASTER:I.Ch1Ch7	...	ChXCh8	☺	::PAC.MASTER:I.Ch1Ch8	...	ChXCh9	☺	::PAC.MASTER:I.Ch1Ch9	...	ChXModuleActuatorPwrLow	☺	::PAC.MASTER:I.Ch1ModuleActuatorPwrLow	...	ChXModuleInputError	☺	::PAC.MASTER:I.Ch1ModuleInputError	...	ChXModuleOutputError	☺	::PAC.MASTER:I.Ch1ModuleOutputError	...	ChXModuleSensorPwrLow	☺	::PAC.MASTER:I.Ch1ModuleSensorPwrLow	...	IOCfg_Ch0		I		IOCfg_Ch1		I		IOCfg_Ch10	☺	O		IOCfg_Ch11	☺	O		IOCfg_Ch12	☺	O		IOCfg_Ch13	☺	O		IOCfg_Ch14	☺	O		IOCfg_Ch15	☺	O		IOCfg_Ch2		I		IOCfg_Ch3		I		IOCfg_Ch4		I		IOCfg_Ch5		I		IOCfg_Ch6		I		IOCfg_Ch7		I		IOCfg_Ch8		I		IOCfg_Ch9		I		Module_Tag_I	☺	::PAC.MASTER:I	...	Status_ChXFault	☺	::PAC.MASTER:I.Status.Ch1Fault	...
ChXCh0	☺	::PAC.MASTER:I.Ch1Ch0	...																																																																																																																																																								
ChXCh1	☺	::PAC.MASTER:I.Ch1Ch1	...																																																																																																																																																								
ChXCh10	☺	::PAC.MASTER:O.Ch1Ch10	...																																																																																																																																																								
ChXCh11	☺	::PAC.MASTER:O.Ch1Ch11	...																																																																																																																																																								
ChXCh12	☺	::PAC.MASTER:O.Ch1Ch12	...																																																																																																																																																								
ChXCh13	☺	::PAC.MASTER:O.Ch1Ch13	...																																																																																																																																																								
ChXCh14	☺	::PAC.MASTER:O.Ch1Ch14	...																																																																																																																																																								
ChXCh15	☺	::PAC.MASTER:O.Ch1Ch15	...																																																																																																																																																								
ChXCh2	☺	::PAC.MASTER:I.Ch1Ch2	...																																																																																																																																																								
ChXCh3	☺	::PAC.MASTER:I.Ch1Ch3	...																																																																																																																																																								
ChXCh4	☺	::PAC.MASTER:I.Ch1Ch4	...																																																																																																																																																								
ChXCh5	☺	::PAC.MASTER:I.Ch1Ch5	...																																																																																																																																																								
ChXCh6	☺	::PAC.MASTER:I.Ch1Ch6	...																																																																																																																																																								
ChXCh7	☺	::PAC.MASTER:I.Ch1Ch7	...																																																																																																																																																								
ChXCh8	☺	::PAC.MASTER:I.Ch1Ch8	...																																																																																																																																																								
ChXCh9	☺	::PAC.MASTER:I.Ch1Ch9	...																																																																																																																																																								
ChXModuleActuatorPwrLow	☺	::PAC.MASTER:I.Ch1ModuleActuatorPwrLow	...																																																																																																																																																								
ChXModuleInputError	☺	::PAC.MASTER:I.Ch1ModuleInputError	...																																																																																																																																																								
ChXModuleOutputError	☺	::PAC.MASTER:I.Ch1ModuleOutputError	...																																																																																																																																																								
ChXModuleSensorPwrLow	☺	::PAC.MASTER:I.Ch1ModuleSensorPwrLow	...																																																																																																																																																								
IOCfg_Ch0		I																																																																																																																																																									
IOCfg_Ch1		I																																																																																																																																																									
IOCfg_Ch10	☺	O																																																																																																																																																									
IOCfg_Ch11	☺	O																																																																																																																																																									
IOCfg_Ch12	☺	O																																																																																																																																																									
IOCfg_Ch13	☺	O																																																																																																																																																									
IOCfg_Ch14	☺	O																																																																																																																																																									
IOCfg_Ch15	☺	O																																																																																																																																																									
IOCfg_Ch2		I																																																																																																																																																									
IOCfg_Ch3		I																																																																																																																																																									
IOCfg_Ch4		I																																																																																																																																																									
IOCfg_Ch5		I																																																																																																																																																									
IOCfg_Ch6		I																																																																																																																																																									
IOCfg_Ch7		I																																																																																																																																																									
IOCfg_Ch8		I																																																																																																																																																									
IOCfg_Ch9		I																																																																																																																																																									
Module_Tag_I	☺	::PAC.MASTER:I	...																																																																																																																																																								
Status_ChXFault	☺	::PAC.MASTER:I.Status.Ch1Fault	...																																																																																																																																																								

Faceplates

1732IL_IB16M12


The 1732IL_IB16 is the 16 Channel Digital Input IO-Link Hub. The main tab of the faceplate is the Home tab, which displays information regarding the Input channels. The banner at the top of the faceplate displays module status and fault information.








Item	Description	
1	Faceplate title bar	#106: Custom button label e.g. (HUB_100)
2	Module ready status.	
	GREEN = Ready	
	YELLOW = Module Fault/Not Ready	
3	Channel Status	
	BLUE = Active/High	
	GREY = Inactive/Low	
	Faulted Condition	
4	I: Digital Input Channel	
6	ChannelDescription:Ch.@Description	

1732IL_10X6M12


The 1732IL_10X6M12 is the 10 Channel Digital Input, 6 Channel Digital Output IO-Link Hub. The main tab of the faceplate is the Home tab, which displays information regarding the I/O channels. The banner at the top of the faceplate displays module status and fault information.



Item	Description	
1	Faceplate title bar	
2	Module ready status.	
	GREEN = Ready	 Ready
	YELLOW = Module Fault/Not Ready	 Not Ready
3	Channel Status	
	BLUE = Active/High	
	GREY = Inactive/Low	
	Faulted Condition	
4	I: Digital Input Channel	
5	O: Digital Output Channel	
6	ChannelDescription:Ch.@Description	

1732IL-16CFGM12M12L

The 1732IL-16CFGM12M12L is the 16 Channel Configurable Digital Input / Output IO-Link Hub. The main tab of the faceplate is the Home tab, which displays information regarding the I/O channels. The banner at the top of the faceplate displays module status and fault information.



Item	Description	
1	Faceplate title bar	
2	Module ready status.	
	GREEN = Ready	
	YELLOW = Module Fault/Not Ready	
3	Channel Status	
	BLUE = Active/High	
	GREY = Inactive/Low	
	Faulted Condition	
4	I: Digital Input Channel	
5	O: Digital Output Channel	
6	ChannelDescription:Ch.@Description	

IO-Link Master (raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster, raC_Dvc_5032_8IOLMaster)

Overview

The IO-Link Master device object (raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster, raC_Dvc_5032_8IOLMaster) includes HMI faceplate's which displays device information including:

- Sensor Trigger data
- Sensor Locate & Navigation
- Event & Time
- Channel Status (Non-IO Link Channels)



In the Library there is a folder named *Videos* which contains many How-To and Operational Overview Videos which walk step-by-step through each process. You can refer to the following videos for this section:
"Operational_Overview_of_IO-Link_Master_Objects_Faceplate.MP4"

Primary device object configuration functions include:

- **Locate:** This function helps to locate the sensors using the device's LED in large machines where there are several sensors close to each other.
- **Navigation:** This is used to Navigate the sensor object with respective to that channel.(Applicable for FTView ME/SE Faceplate & Not for View Designer Faceplate)

Functional Description

The IO-Link Master Device Objects:

- Collect, Process and Deliver Data between Smart Devices as well as Non-IO Link Devices and Application Logic
- Provide Device Status & Diagnostics Faceplate's for Machine Startup, Commissioning, Operations, and Maintenance
- Include Common HMI Faceplate Components, Device States, and Control Interfaces providing Application Development and Operation Efficiency

All these features provide quick feedback, shorten recovery time, and simplify implementation.

Required Files

Device Objects include Add-On Instructions (AOIs) and HMI faceplate's. The revision number (e.g. 1.01) used in filenames can change as new revisions are created.

Controller Files

Add-On Instructions are reusable code objects that contain encapsulated logic that can streamline implementing your system. This lets you create your own instruction set for programming logic as a supplement to the instruction set provided natively in the ControlLogix® firmware. An Add-On Instruction is defined once in each controller project, and can be instantiated multiple times in your application code as needed.

The Add-On Instruction must be imported into the controller project to be used in the controller configuration. These can be imported as Add-On Instruction files, or as part of the Rung Import or Import Library Objects wizard.

All Add-On Instruction and Rung Import files can be found in the */Studio 5000 Logix Designer Files - L5X/* folder in the library. IO-Link Master device is supplied with three versions of Add-On Instructions (AOI) and Rung import files - one for compatibility with 1734-4IOL Master Module second for compatibility with 1732E-8IOL Master Module and third for compatibility with 5032-8IOL Master Module. You must select the appropriate AOI for the master module being used.

Device/Item	Compatible IO-Link Master	Add-On Instruction	Rung Import
IO-Link Master	POINT I/O 1734-4IOL	raC_Dvc_1734_4IOLMaster_3.02_AOI.L5X	raC_Dvc_1734_4IOLMaster_3.02_RUNG.L5X
	ArmorBlock 1732E-8IOLM12R	raC_Dvc_1732E_8IOLMaster_3.02_AOI.L5X	raC_Dvc_1732E_8IOLMaster_3.02_RUNG.L5X
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	raC_Dvc_5032_8IOLMaster_3.02_AOI.L5X	raC_Dvc_5032_8IOLMaster_3.02_RUNG.L5X

FactoryTalk View HMI Files

FactoryTalk View ME or SE applications require importing the desired device faceplates in addition to all Global Object (ggfx) files and all images located in the */HMI FactoryTalk View Images - png/* folder of the library. FactoryTalk View ME files are stored in the */HMI - FactoryTalk View ME/* library folder and FactoryTalk View SE files are stored in the */HMI - FactoryTalk View SE/* library folder.

Device/Item	Type	FactoryTalk View ME Faceplate	FactoryTalk View SE Faceplate
1734-4IOL	Display	(raC-3_02-ME) raC_Dvc_1734_4IOL-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_1734_4IOL-Faceplate.gfx
1732E-8IOL	Display	(raC-3_02-ME) raC_Dvc_1732E_8IOL-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_1732E_8IOL-Faceplate.gfx
5032-8IOL	Display	(raC-3_02-ME) raC_Dvc_5032_8IOL-Faceplate.gfx	(raC-3_02-SE) raC_Dvc_5032_8IOL-Faceplate.gfx
Graphic Symbols	Global Object	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx
Toolbox	Global Object	(raC-3-ME) Toolbox - IO-Link Device.ggfx	(raC-3-SE) Toolbox - IO-Link Device.ggfx

Studio 5000 View Designer HMI Files

All Studio 5000 View Designer Files can be found in the */HMI - ViewDesigner - vpd/* folder of the library.

Device/Item	Studio 5000 View Designer Faceplate
IO-Link Master	(raC-3_02-VD) raC_Dvc_IOLink.vpd

Studio 5000 Application Code Manager Files

Studio 5000 Application Code Manager (ACM) can be optionally used if it is installed. All devices can be easily registered in the ACM repositories by running the *setup.cmd* file located in the root folder of the library.

Individual HSL4 files are provided as an alternative to running the *setup.cmd* to allow users to manually register specific implementation objects. Each object has two files - an Asset Control file and a Device file. The Asset Control files include attachments of all required files for that object. The Device files are used to actually add that device into a Studio 5000 project and these reference the Asset Control files.


All Studio 5000 Application Code Manager files can be found in the */ApplicationCodeManagerLibraries/* folder of the library. The files included are as follows:

Implementation Object	Compatible IO-Link Master	Asset Control File (.HSL4)	Device File (.HSL4)
IO-Link Master	POINT I/O 1734-4IOL	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_1734_4IOL_Master_(3.2)	(RA-LIB)_Device_Module_IO-Link_1734-4IOL_(3.2)
	ArmorBlock 1732E-8IOLM12R	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_1732E_8IOL_Master_(3.2)	(RA-LIB)_Device_Module_IO-Link_1732E-8IOLM12R_(3.2)
	5032-8IOLM12DR 5032-8IOLM12M12LDR/A 5032-8IOLM12P5DR	(RA-LIB)_Device_Asset-Control_IO-Link_raC_Dvc_5032_8IOL_Master_(3.2)	(RA-LIB)_Device_Module_IO-Link_5032-8IOLMaster_(3.2)


Device Definition (raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster)

The device must be configured with the correct device definition. Proper device configuration enables the required device data to pass information from the device into the add-on instruction.

- When using 1732E-8IOLM12R/B 8 Channel IO-Link Master, its required to change Data Connection in the Module Definition.
 - Click on Change...




2. Click on *Connection* and select the *Timestamp Data*



Device Definition (raC_Dvc_5032_8IOLMaster)

The device must be configured with the correct device definition. Proper device configuration enables the required device data to pass information from the device into the add-on instruction.

- When using 5032-8IOLM12M12LDR 8 Channel IO-Link Master, its required to change Data Connection in the Module Definition.
 1. Click on Change...




2. User need to assign Channel modes as per their desired hardware connection to 5032 Master. Below table shows the available Channel modes in 5032 Master Module



Channel Nos. 0,2,4,6,8,10,12 & 14 can only be assigned as a IO-Link.

Channel Mode	Description
Disabled	Channel is Disabled.
Digital Output, Short Circuit, No Load	Channel is Configured as a Digital Output.
Digital Input	Channel is Configured as a Digital Input.
IO-Link	Channel is Configured as a IO-Link
Digital Output	Channel is Configured as a Digital Output.
Digital Input, Counter	Channel is Configured as a Digital Input.
Digital Input, Fallback	Channel is Configured as a Digital Input.
Digital Output, Short Circuit	Channel is Configured as a Digital Output.
Digital Input, Timestamp	Channel is Configured as a Digital Input.
Digital Input, Timestamp, Fallback	Channel is Configured as a Digital Input.



Operations

The IO-Link Device objects provide only physical operation mode. There is no virtual device mode offered.

Execution

The following table explains the handling of instruction execution conditions.

Condition	Description
EnableIn False (false rung)	Processing for EnableIn False (false rung) is handled the same as if the device were taken out of service by Command. The device outputs are de-energized and the device is shown as Program Out of Service on the HMI. All alarms are cleared.
Powerup (prescan, first scan)	On prescan, any commands that are received before first scan are discarded. The device is de-energized. On first scan, the device is treated as if it were returning from Hand command source: the instruction state is set based on the position feedback that is received from the device. If the feedback is valid for one position, the device is set to that position. If the device does not have position feedback or the position feedback is invalid, the device is set to the 'unknown/powerup' state. The command source is set to its default, either Operator or Program (unlocked).
Postscan	No SFC Postscan logic is provided.

Add-On Instruction I/O Data InOut Data

(raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster)

InOut	Function / Description	Data Type
Ref_MsgCustGetIdx	Channel Assemblies Read	MESSAGE
Ref_MsgData	Channel Status Modes information	raC_UDT_IOLinkMaster_5032_Diag_Assembly
Ref_Ctrl_Inf	Sensor Type Information Interface	raC_UDT_ItfAD_IOLinkSensor_Inf
Ref_Ctrl_Itf	Device Command, Status Information Interface	raC_UDT_ItfAD_IOLinkDevices
Ref_Module	Reference to module in I/O tree	MODULE
Inp_I	Device Object Inputs	raC_UDT_ItfAD_4IOL_Master_Inp / raC_UDT_ItfAD_4IOL_Master_Inp

Output Data


Output	Function/Description	Data Type
Sts_Active	Device active status: 1 = output power structure is active	BOOL
Sts_Available	Device is available for interaction with user code	BOOL
Sts_Connected	Device is connected to the Programmable Automation Controller	BOOL
Sts_Faulted	Device faulted status: 1 = an active fault exists	BOOL
Sts_Ready	Device is ready to perform primary function	BOOL
Sts_Warning	Device warning status: 1 = an active alarm or warning exists	BOOL
Sts_InhibitCmd	Disable Command inputs from external sources	BOOL
Sts_InhibitSet	Disable Setting inputs from external sources	BOOL
Sts_eNotReady	Device Not Ready Status	DINT
Sts_bNotReady	Bitwise device 'not ready' reason 0: Reserved 1: Master Communication Loss 2: Master Not Available 3: Faulted 4 - 31: Reserved	DINT
Sts_bFaultCh	Bitwise Channel faulted status 1 = an active fault exists	INT

Programming Example


Fully configured device on a rung is provided below for reference.

Note that this programming example is the same code that is imported when either importing the supplied rung.L5X files or when using Application Code Manager or the Studio 5000 Import Library Objects wizard plug-in.


The following example uses the 4IOL IO-Link Master device object connected with the module POINT I/O 1734-4IOL IO-Link Master module named *PointIO_4IOL_Master* in slot #3 of a POINT I/O adapter named *Rack01*.



The following example uses the IO-Link Master device object connected to ArmorBlock 1732E-8IOLM12R IO-Link Master module in named *Armor_8IOL_MasterB*.



The following example uses the IO-Link Master device object connected to 5032-8IOLM12M12LDR/A IO-Link Master module in named *Mod_Master_5032_1*.



Graphic Symbols

Graphic Symbols are used as launch buttons within HMI applications to open up faceplate displays. See [Basic Launch Button Attributes](#) section for details on configuration and indicators.

FactoryTalk View ME/SE Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Global Object Parameter Values
GO_LaunchFPMaster		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g.:[PAC]Program::IOLinkProgram._InstanceName)) #104: Custom button label. Leave blank to use Tag.@Description #110: CH0 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #111: CH1 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #112: CH2 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #113: CH3 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #114: CH4 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #115: CH5 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #116: CH6 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #117: CH7 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_4IOL_8IOLMaster		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g.:[PAC]Program::IOLinkProgram._InstanceName)) #104: Custom button label. Leave blank to use Tag.@Description #110: CH0 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #111: CH1 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #112: CH2 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #113: CH3 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #114: CH4 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #115: CH5 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #116: CH6 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #117: CH7 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)
GO_LaunchGfx_5032Master		Faceplate navigation button with string tag label. This launch button graphic object allows the user to navigate to the device object faceplate. Graphic button can be used in schematic style displays where a system/network diagram is shown. When available, basic module diagnostics and a live value is displayed. The text on the button face is set to the parameter #104.	#102: AOI Backing Tag Instance (e.g.:[PAC]Program::IOLinkProgram._InstanceName)) #104: Custom button label. Leave blank to use Tag.@Description #110: CH0 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #111: CH2 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #112: CH4 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #113: CH6 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #114: CH8 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #115: CH10 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #116: CH12 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #117: CH14 AOI Backing Tag (Enter 0, If there is no sensor connected to the channel) #120: Display's left position (e.g. 100) (optional) #121: Display's top position (e.g. 100) (optional)



Note that for unused channels enter 0 value.

Studio 5000 View Designer Graphic Symbols

Graphic Symbol Name	Graphic Symbol	Description	Property Configuration
AOG_4IOL_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	
AOG_8IOL_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	
AOG_5032_Launch		The supplied launch button in View Designer is used to navigate to the faceplate in a user application.	

Faceplates (raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster)


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to `_InstanceName.@description`, the `.@description` extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

▶ Master4IOL_101	Master 4IOL 101
▶ Master4IOL_101_Cfg_C	Master4IOL_101 Configuration Interface
▶ Master4IOL_101_Inp_I	Master4IOL_101 Input Interface

Home


The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data.



Item	Description
1	Banner- Ready Status
2	Channel Fault - There is a fault one or more channel
3	Channel Faulted
4	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED Depending on type of sensor connected to channel the no. of trigger signal are appear. Total 16 Trigger available on display.
5	Process Data: Displays the process value and its units.
6	Channel is not configured for IO-Link or Disabled
7	Navigation Page 1- Ch0 to Ch3. Page 2- Ch4 to Ch7 Page 3- Ch8 to Ch11 Page 4- Ch12 to Ch15

Located

The Locate tab is the second tab of the faceplate. It provides the each channels App Sensor Name, Counter, Signal Strength, Location and Navigation to the respective IO-Link device object.




Item	Description
1	Application Specific Name - Read from device
2	Counter- Displays the sensor counter value
3	Signal Strength- Displays the Signal Strength Value
4	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
5	Object: Navigate to the Sensor Object for more detailed information



The View Designer faceplate object lacks the capability of Object Navigation.

Fault Warning Tab

The Fault Warning tab displays information of first fault with time stamp captured for each IO-Link Channel device.



Item	Description
1	Last fault description
2	Last fault Time captured

Faceplates (raC_Dvc_5032_8IOLMaster)


There are basic faceplate attributes that are common across all instructions. See [Basic Faceplate Attributes on page 37](#).

The faceplate title is linked to *_InstanceName.@description*, the *.@description* extended tag property of the Add-On Instruction instance. This is user-configurable from controller/program tags in Studio 5000 Logix Designer.

Name	Data Type	Description	Constant
Master1	raC_Dvc_5032_8IOLMaster	Master_5032	<input type="checkbox"/>
Master1_Inp_I	rac_UDT_ItfAD_5032_Master_Inp	Master1 Input Interface	<input type="checkbox"/>

Home

The Home tab is the main tab of the faceplate. It provides the status of the IO-Link device along with sensor process data.




Item	Description
1	Banner- Ready Status
2	Channel Fault - There is a fault for one or more channels (In this Case, CH0 is Faulted)
3	Channel Faulted (In this Case, CH0 is Faulted)
4	Trigger Status OFF (0) = Gray LED ON (1) = Blue LED Depending on type of sensor connected to channel the no. of trigger signal are appear. Total 16 Trigger available on display.
5	Process Data: Displays the process value and its units.
6	Channel is not configured for IO-Link, But Configured for Other Modes. Below is the List of Other Modes : -Disabled -Digital Output, Short Circuit, No Load -Digital Input -Digital Output -Digital Input, Counter -Digital Input, Fallback -Digital Output, Short Circuit -Digital Input, Timestamp -Digital Input, Timestamp, Fallback
7	Navigation Page 1- Ch0 to Ch3. Page 2- Ch4 to Ch7 Page 3- Ch8 to Ch11 Page 4- Ch12 to Ch15


In Addition to above status, There are few more conditions explained below:



Shown Status and description messages are explained by Assuming that, User already configured the Master and Sensor hardware in their Project. as shown in below image:




5032 Master is in Fault/Disconnected State



Item	Description
1	Banner- Not Ready Status
2	Message- Master Communication Loss
3	Channel Description: No Data Available


Sensor AOI is not Configuring in PLC Logic.



In the above image, we can find the CH8 description. This description appears when Sensor and Master hardware is configured and AOI is not configured in PLC logic.

Locate

The Locate tab is the second tab of the faceplate. It provides the each channels App Sensor Name, Counter, Signal Strength, Location and Navigation to the respective IO-Link device object.



Item	Description
1	Application Specific Name - Read from device
2	Counter- Displays the sensor counter value
3	Signal Strength- Displays the Signal Strength Value
4	Locate toggle switch Locate the sensor in large machines where there are several sensors close to each other. When Located, the sensor user interface (green and orange LEDs) start flashing synchronously until the operator disables this function
5	Object: Navigate to the Sensor Object for more detailed information
6	Channel is not configured for IO-Link, But Configured for Other Modes. Below is the List of Other Modes : -Disabled -Digital Output, Short Circuit, No Load -Digital Input -Digital Output -Digital Input, Counter -Digital Input, Fallback -Digital Output, Short Circuit -Digital Input, Timestamp -Digital Input, Timestamp, Fallback




The View Designer faceplate object lacks the capability of Object Navigation.


In Addition to above status, There are few more conditions explained below:



Shown Status and description messages are explained by Assuming that, User already configured the Master and Sensor hardware in their Project. as shown in below image:




5032 Master is in Fault/Disconnected State



Item	Description
1	Banner- Not Ready Status
2	Message- Master Communication Loss
3	Channel Description: No Data Available


Sensor AOI is not Configuring in PLC Logic.



In the above image, we can find the CH8 description. This description appears when Sensor and Master hardware is configured and AOI is not configured in PLC logic.

Fault Warning Tab

The Fault Warning tab displays information of first fault with time stamp captured for each IO-Link Channel device.




Item	Description
1	Last fault description (In this Case, CH2 is Faulted)
2	Last fault Time captured (In this Case, CH2 is Faulted)


In Addition to above status, There are few more conditions explained below:



Shown Status and description messages are explained by Assuming that, User already configured the Master and Sensor hardware in their Project. as shown in below image:




5032 Master is in Fault/Disconnected State



Item	Description
1	Banner- Not Ready Status
2	Message- Master Communication Loss
3	Channel Description: Connection Faulted (AOI for Sensor Connected on CH0 is running in PLC Logic).
4	Channel Description: No Data Available (AOI for Sensor Connected on CH2 is not running in PLC Logic).

Sensor AOI is not Configuring in PLC Logic.



In the above image, we can find the CH8 description. This description appears when Sensor and Master hardware is configured and AOI is not configured in PLC logic.

Application Code Manager

IO-Link Device Library objects can be set-up and configured using Studio 5000 Application Code Manager.

Refer to the section [Using Application Code Manager](#) for complete details.

Definition Objects: raC_Dvc_1734_4IOLMaster, raC_Dvc_1732E_8IOLMaster

This object contains the AOI definition and used as linked library to implement object. There is one definition and per add-on instruction to support each IO-Link Master Module. This gives flexibility to choose to instantiate only definition and create custom implement code. User may also create their own implement library and link with this definition library object.

Implementation Objects: raC_LD_Dvc_1734_4IOLMaster, raC_LD_Dvc_1732E_8IOLMaster

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
Ch0_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 0.
Ch1_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 1.
Ch2_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 2.
Ch3_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 3.
Ch4_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 4.
Ch5_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 5.
Ch6_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 6.
Ch7_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 7.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Implementation Objects: raC_LD_Dvc_5032_8IOLMaster

Parameter Name	Default Value	Instance Name	Definition	Description
RoutineName	{ObjectName}	{RoutineName}	Routine	Enter Routine name. Routine will be created and Object implement rung(s) inserted. A JSR will be inserted in MainRoutine. If routine name already exists, then object will be inserted into existing routine. By default, parameter is set to Object Name.
TagName	{ObjectName}	{TagName}	Backing Tag	Enter the backing tag of the main AOI. This will serve as the base tag name for other tags in this object that are derived from the base.
TagDescription	{ObjectDescription}	{TagDescription}		Tag Description of the main AOI backing tag
MasterName	MasterName	[MasterName]	Module	Select the IO-Link master module. If connecting to a non-library object module, enter the name of the master only. Note: entering non-library object modules will result in the parameter displaying a red X. This will still generate properly as long as the entered name exists in the project.
Ch0_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 0.
Ch2_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 2.
Ch4_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 4.
Ch6_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 6.
Ch8_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 8.
Ch10_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 10.
Ch12_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 12.
Ch14_AOI_BackingTagReference			Module	Select the AOI Tag for the Sensor Connected on Channel No. 14.



Note that if the tag names are manually entered or not linked to input channel tags a red 'X' will be shown beside the parameter. This is acceptable and the program can still be generated.

Linked Libraries

Link Name	Catalog Number	Revision	Solution	Category
raC_Dvc_1734_4IOLMater	raC_Dvc_1734_4IOLMaster	3.2	(RA-LIB) Device	IO-Link

raC_Dvc_1732E_8IOLMaster	raC_Dvc_1732E_8IOLMaster	3.2	(RA-LIB) Device	IO-Link
raC_Dvc_5032_8IOLMaster	raC_Dvc_5032_8IOLMaster	3.2	(RA-LIB) Device	IO-Link

Configured HMI Content

HMI Content	Instance Name	Description
Launch Button ME	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button ME	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button
Launch Button SE	{ObjectName}_GO_LaunchTextFP	Global Object configured callout instance Text Button
Launch Button SE	{ObjectName}_GO_LaunchGraphFP	Global Object configured callout instance Graphical Button

Attachments

Name	Description	File Name	Extraction Path
V3_raC_Dvc_Global	Graphic Symbols ME	(raC-3-ME) Graphic Symbols - IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewME\Global Object - ggfx
V3_raC_Dvc_Global	Graphic Symbols SE	(raC-3-SE) Graphic Symbols - IO-Link Device.ggfx	{ProjectName}\Visualization\FTViewSE\Global Object - ggfx
V3_raC_Dvc_1734_4IOLMaster	Faceplate ME	(raC-3_xx-ME) raC_Dvc_1734-4IOLMaster_Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_1734_4IOLMaster	Faceplate SE	(raC-3_xx-SE) raC_Dvc_1734-4IOLMaster_Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_1732E_8IOLMaster	Faceplate ME	(raC-3_xx-ME) raC_Dvc_1732E-8IOLMaster_Faceplate.gfx	{ProjectName}\Visualization\FTViewME\Displays - gfx
V3_raC_Dvc_1732E_8IOLMaster	Faceplate SE	(raC-3_xx-SE) raC_Dvc_1732E-8IOLMaster_Faceplate.gfx	{ProjectName}\Visualization\FTViewSE\Displays - gfx
V3_raC_Dvc_IOLink	View Designer	(raC-3_xx-VD) raC_Dvc_IOLink.vpd	{ProjectName}\Visualization\ViewDesigner - vpd
V3_RM_raC_Dvc_IO_Link	Reference Manual	DEVICE-RM300C-EN-P.pdf	{ProjectName}\Documentation
V3_IO_Link_Images	HMI Image Set	HMI FactoryTalk View Images - png.zip	{ProjectName}\Visualization\Images - png

Rockwell Automation Support

Use these resources to access support information.

Technical Support Center	Find help with how-to videos, FAQs, chat, user forums, Knowledgebase, and product notification updates.	rok.auto/support
Local Technical Support Phone Numbers	Locate the telephone number for your country.	rok.auto/phonesupport
Technical Documentation Center	Quickly access and download technical specifications, installation instructions, and user manuals.	rok.auto/techdocs
Literature Library	Find installation instructions, manuals, brochures, and technical data publications.	rok.auto/literature
Product Compatibility and Download Center (PCDC)	Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes.	rok.auto/pcdc

Documentation Feedback

Your comments help us serve your documentation needs better. If you have any suggestions on how to improve our content, complete the form at rok.auto/docfeedback.

Waste Electrical and Electronic Equipment (WEEE)



At the end of life, this equipment should be collected separately from any unsorted municipal waste.





Rockwell Automation maintains current product environmental compliance information on its website at rok.auto/pec.

Allen-Bradley, expanding human possibility, and Rockwell Automation are trademarks of Rockwell Automation, Inc.

EtherNet/IP is a trademark of ODVA, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş. Kar Plaza İş Merkezi E Blok Kat:6 34752, İçerenköy, İstanbul, Tel: +90 (216) 5698400 EEE Yönetmeliğine Uygundur

Connect with us.    

rockwellautomation.com — expanding **human possibility**[®]

AMERICAS: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000

EUROPE/MIDDLE EAST/AFRICA: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2663 0600

ASIA PACIFIC: Rockwell Automation SEA Pte Ltd, 2 Corporation Road, #04-05, Main Lobby, Corporation Place, Singapore 618494, Tel: (65) 6510 6608

UNITED KINGDOM: Rockwell Automation Ltd., Pitfield, Kiln Farm, Milton Keynes, MK11 3DR, United Kingdom, Tel: (44)(1908) 838-800

Publication DEVICE-RM300C-EN-P - July 2024

RAC-RM300B-EN-P - August 2023

Copyright © 2024 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.