



S-PM GEARED MOTOR DRIVE UNIT FR-D700-G INSTRUCTION MANUAL (BASIC) FR-D720-0.2K to 3.7K-G FR-D740-0.4K to 3.7K-G

Thank you for choosing this Mitsubishi Electric S-PM geared motor drive unit.
This Instruction Manual (Basic) provides handling information and precautions for use of the equipment.
Please forward this Instruction Manual (Basic) to the end user.

CONTENTS

[1] OUTLINE	1
[2] INSTALLATION AND WIRING	5
[3] PRECAUTIONS FOR USE OF THE DRIVE UNIT	18
[4] FAILSAFE OF THE SYSTEM WHICH USES THE DRIVE UNIT	20
[5] DRIVE THE MOTOR	21
[6] PARAMETERS	29
[7] TROUBLESHOOTING	34
[8] PRECAUTIONS FOR MAINTENANCE AND INSPECTION	39
[9] SPECIFICATIONS	41



To obtain the Instruction Manual (Applied)

Contact where you purchased the drive unit, your Mitsubishi Electric sales representative, or the nearest Mitsubishi Electric FA Center for the following manual:

- *Instruction Manual (Applied) [IB(NA)-0600478ENG]*

This manual is required if you are going to utilize functions and performance.

The PDF version of this manual is also available for download at "Mitsubishi Electric FA site", the Mitsubishi Electric FA network service on the world wide web (URL: www.MitsubishiElectric.co.jp/fa)

1

2

3

4

5

6

7

8

9

This Instruction Manual (Basic) provides handling information and precautions for use of the equipment. Please forward this Instruction Manual (Basic) to the end user.

This section is specifically about safety matters

Do not attempt to install, operate, maintain or inspect the drive unit until you have read through the Instruction Manual (Basic) and appended documents carefully and can use the equipment correctly. Do not use this product until you have a full knowledge of the equipment, safety information and instructions.

In this Instruction Manual (Basic), the safety instruction levels are classified into "WARNING" and "CAUTION".

⚠ WARNING

Incorrect handling may cause hazardous conditions, resulting in death or severe injury.

⚠ CAUTION

Incorrect handling may cause hazardous conditions, resulting in medium or slight injury, or may cause only material damage.

The **⚠ CAUTION** level may even lead to a serious consequence according to conditions. Both instruction levels must be followed because these are important to personal safety.

1. Electric Shock Prevention

⚠ WARNING

- While the drive unit power is ON, do not remove the front cover or the wiring cover. Do not run the drive unit with the front cover or the wiring cover removed. Otherwise you may access the exposed high voltage terminals or the charging part of the circuitry and get an electric shock.
- Even if power is OFF, do not remove the front cover except for wiring or periodic inspection. You may accidentally touch the charged drive unit circuits and get an electric shock.
- Before wiring or inspection, power must be switched OFF. To confirm that, LED indication of the operation panel must be checked. (It must be OFF.) Any person who is involved in wiring or inspection shall wait for at least 10 minutes after the power supply has been switched OFF and check that there are no residual voltage using a tester or the like. The capacitor is charged with high voltage for some time after power OFF, and it is dangerous.
- This drive unit must be earthed (grounded). Earthing (grounding) must conform to the requirements of national and local safety regulations and electrical code (NEC section 250, IEC 61140 class 1 and other applicable standards). A neutral-point earthed (grounded) power supply for 400V class drive unit in compliance with EN standard must be used.
- Any person who is involved in wiring or inspection of this equipment shall be fully competent to do the work.
- The drive unit must be installed before wiring. Otherwise you may get an electric shock or be injured.
- Setting dial and key operations must be performed with dry hands to prevent an electric shock. Otherwise you may get an electric shock.
- Do not subject the cables to scratches, excessive stress, heavy loads or pinching. Otherwise you may get an electric shock.
- Do not change the cooling fan while power is ON. It is dangerous to change the cooling fan while power is ON.
- Do not touch the printed circuit board or handle the cables with wet hands. Otherwise you may get an electric shock.
- When measuring the main circuit capacitor capacity, the DC voltage is applied to the motor for 1s at powering OFF. Never touch the motor terminal, etc. right after powering OFF to prevent an electric shock.
- A PM motor is a synchronous motor with embedded magnets. High-voltage is generated at motor terminals while the motor is running even after the drive unit power is turned OFF. Before wiring or inspection, the motor must be confirmed to be stopped. For applications where the motor is driven by the load, the low-voltage manual contactor, which is installed at the drive unit's output side, must be opened before wiring or inspection. Otherwise you may get an electric shock.

2. Fire Prevention

⚠ CAUTION

- The drive unit must be installed on a nonflammable wall without holes (so that nobody touches the drive unit heatsink on the rear side, etc.). Mounting it to or near flammable material can cause a fire.
- If the drive unit has become faulty, the drive unit power must be switched OFF. A continuous flow of large current could cause a fire.
- When using a brake resistor, a sequence that will turn OFF power when a fault signal is output must be configured. Otherwise the brake resistor may overheat due to damage of the brake transistor and possibly cause a fire.
- Do not connect a resistor directly to the DC terminals P/+ and N/-. Doing so could cause a fire.
- Be sure to perform daily and periodic inspections as specified in the Instruction Manual. If a product is used without any inspection, a burst, breakage, or a fire may occur.

3. Injury Prevention

⚠ CAUTION

- The voltage applied to each terminal must be the ones specified in the Instruction Manual. Otherwise burst, damage, etc. may occur.
- The cables must be connected to the correct terminals. Otherwise burst, damage, etc. may occur.
- Polarity must be correct. Otherwise burst, damage, etc. may occur.
- While power is ON or for some time after power-OFF, do not touch the drive unit since the drive unit will be extremely hot. Doing so can cause burns.

4. Additional Instructions

Also the following points must be noted to prevent an accidental failure, injury, electric shock, etc.

(1) Transportation and Mounting

⚠ CAUTION

- The product must be transported in correct method that corresponds to the weight. Failure to do so may lead to injuries.
- Do not stack the boxes containing drive units higher than the number recommended.
- The product must be installed to the position where withstands the weight of the product according to the information in the Instruction Manual.
- Do not install or operate the drive unit if it is damaged or has parts missing.
- When carrying the drive unit, do not hold it by the front cover or setting dial; it may fall off or fail.
- Do not stand or rest heavy objects on the product.
- The drive unit mounting orientation must be correct.
- Foreign conductive objects must be prevented from entering the drive unit. That includes screws and metal fragments or other flammable substance such as oil.
- As the drive unit is a precision instrument, do not drop or subject it to impact.
- The drive unit must be used under the following environment: Otherwise the drive unit may be damaged.

Environment	Surrounding air temperature	-10°C to +50°C (non-freezing)
	Ambient humidity	90%RH or less (non-condensing)
	Storage temperature	-20°C to +65°C ±1
	Atmosphere	Indoors (free from corrosive gas, flammable gas, oil mist, dust and dirt)
	Altitude/vibration	Maximum 1000 m. 5.9m/s ² or less at 10 to 55Hz (directions of X, Y, Z axes)

- *1 Temperature applicable for a short time, e.g. in transit.
- If halogen-based materials (fluorine, chlorine, bromine, iodine, etc.) infiltrate into a Mitsubishi Electric product, the product will be damaged. Halogen-based materials are often included in fumigant, which is used to sterilize or disinfect wooden packages. When packaging, prevent residual fumigant components from being infiltrated into Mitsubishi Electric products, or use an alternative sterilization or disinfection method (heat disinfection, etc.) for packaging. Sterilization of disinfection of wooden package should also be performed before packaging the product.

(2) Wiring

⚠ CAUTION

- Do not install a power factor correction capacitor or surge suppressor/capacitor type filter on the drive unit output side. These devices on the drive unit output side may be overheated or burn out.
- The connection orientation of the output cables U, V, W to the motor affects the rotation direction of the motor.
- PM motor terminals (U, V, W) hold high-voltage while the PM motor is running even after the power is turned OFF. Before wiring, the PM motor must be confirmed to be stopped. Otherwise you may get an electric shock.
- Never connect a PM motor to the commercial power supply. Applying the commercial power supply to input terminals (U, V, W) of a PM motor will burn the PM motor. The PM motor must be connected with the output terminals (U, V, W) of the drive unit.

(3) Trial run

⚠ CAUTION

- Before starting operation, each parameter must be confirmed and adjusted. A failure to do so may cause some machines to make unexpected motions.

(4) Usage


⚠ WARNING

- A PM motor and the drive unit must be used in the specified capacity combination.
- Do not use multiple PM motors with one drive unit.
- Any person must stay away from the equipment when the retry function is set as it will restart suddenly after trip.
- Since pressing the STOP/RESET key may not stop output depending on the function setting status, separate circuit and switch that make an emergency stop (power OFF, mechanical brake operation for emergency stop, etc.) must be provided.
- OFF status of the start signal must be confirmed before resetting the drive unit fault. Resetting drive unit alarm with the start signal ON restarts the motor suddenly.
- Do not use a PM motor in an application where a motor is driven by its load and runs at a speed higher than the maximum motor speed.
- According to the motor to be connected, perform PM parameter initialization. Incorrect initial setting of parameters may damage the motor.
The parameters for motor operation are initially set for an S-PM geared motor.
When other PM motors are used, set parameters according to the motor.
- Do not use the drive unit for a load other than the PM motor. Connection of any other electrical equipment to the drive unit output may damage the equipment.
- Do not modify the equipment.
- Do not perform parts removal which is not instructed in this manual. Doing so may lead to fault or damage of the product.


⚠ CAUTION

- The electronic thermal relay function does not guarantee protection of the motor from overheating. It is recommended to install an external thermal for overheat protection.
- Do not use a magnetic contactor on the drive unit input for frequent starting/stopping of the drive unit. Otherwise, the life of the drive unit decreases.
- The effect of electromagnetic interference must be reduced by using an EMC filter or by other means. Otherwise nearby electronic equipment may be affected.
- Appropriate measures must be taken to suppress harmonics. Otherwise power supply harmonics from the drive unit may heat/damage the power factor correction capacitor and generator.
- When parameter clear or all parameter clear is performed, the required parameters must be set again before starting operations because all parameters return to the initial value.
- The drive unit can be easily set for high-speed operation. Before changing its setting, the performances of the motor and machine must be fully examined.
- Stop status cannot be hold by the drive unit's brake function. In addition to the drive unit's brake function, a holding device must be installed to ensure safety.
- Before running a drive unit which had been stored for a long period, inspection and test operation must be performed.
- Static electricity in your body must be discharged before you touch the product. Otherwise the product may be damaged.
- In the system with a PM motor, the drive unit power must be turned ON before closing the contacts of the contactor at the output side.
- If you are installing the drive unit to drive a three-phase device while you are contracted for lighting and power service, consult your electric power supplier.

(5) Emergency stop

 CAUTION
<ul style="list-style-type: none"> ● A safety backup such as an emergency brake must be provided for devices or equipment in a system to prevent hazardous conditions in case of failure of the drive unit or an external device controlling the drive unit. ● When the breaker on the drive unit input side trips, the wiring must be checked for fault (short circuit), and internal parts of the drive unit for a damage, etc. The cause of the trip must be identified and removed before turning ON the power of the breaker. ● When any protective function is activated, appropriate corrective action must be taken, and the drive unit must be reset before resuming operation.

(6) Maintenance, inspection and parts replacement

 CAUTION
<ul style="list-style-type: none"> ● Do not carry out a megger (insulation resistance) test on the control circuit of the drive unit. It will cause a failure.

(7) Disposal

 CAUTION
<ul style="list-style-type: none"> ● The drive unit must be treated as industrial waste.

General instruction
<p>Many of the diagrams and drawings in this Instruction Manual (Basic) show the drive unit without a cover or partially open for explanation. Never operate the drive unit in this manner. The cover must be always reinstalled and the instruction in this Instruction Manual (Basic) must be followed when operating the drive unit.</p> <p>For more details on a PM motor, refer to the Instruction Manual of the PM motor.</p>

<Abbreviation>

PU.....	Operation panel and parameter unit (FR-PU07)
Drive unit.....	The FR-D700-G series drive unit for Mitsubishi Electric S-PM geared motor
FR-D700-G.....	The FR-D700-G series drive unit for Mitsubishi Electric S-PM geared motor
Pr.	Parameter number (Number assigned to function)
PU operation.....	Operation using the PU (operation panel/FR-PU07)
External operation.....	Operation using the control circuit signals
Combined operation	Operation using both the PU (operation panel/FR-PU07) and External operation
PM motor	Permanent magnet motor: an IPM motor, an SPM motor, or the Mitsubishi Electric GV series S-PM geared motor

<Trademark>

- Company and product names herein are the trademarks and registered trademarks of their respective owners.

<Mark>



REMARKS :Additional helpful contents and relations with other functions are stated.



NOTE :Contents requiring caution or cases when set functions are not activated are stated.




POINT :Useful contents and points are stated.

<Notes on descriptions in this Instruction Manual>


- Connection diagrams in this Instruction Manual appear with the control logic of the input terminals as sink logic, unless otherwise specified. (For the control logic, refer to *page 1.*)

<Related document>

 Refer to the Instruction Manual (Applied) for further information on the following points.

- Removal and reinstallation of the cover
- Connection of stand-alone option unit
- EMC and leakage currents
- Detailed explanation on parameters
- Troubleshooting
- Check first when you have a trouble
- Inspection items (life diagnosis, cooling fan replacement)
- Measurement of main circuit voltages, currents and powers

Harmonic suppression guideline (when drive units are used in Japan)

All models of drive units used by specific consumers are covered by "The Harmonic Suppression Guideline for Consumers Who Receive High Voltage or Special High Voltage". (For further details,  refer to Chapter 3 of the Instruction Manual (Applied).)

1 OUTLINE

1.1 Product checking and parts identification

Unpack the drive unit and check the capacity plate on the front cover and the rating plate on the drive unit side face to ensure that the product agrees with your order and the drive unit is intact.

●Drive unit model

FR - D720 - 1.5 K - G

Symbol	Voltage class
D720	Three-phase 200V class
D740	Three-phase 400V class

Represents the drive unit capacity [kW]

Cooling fan

The cooling fan is removable.
(Refer to the Instruction Manual (Applied).)

Operation panel

(Refer to page 2.)

Voltage/current input switch

(Refer to page 9.)

PU connector

(Refer to page 9.)

Front cover

Refer to the Instruction Manual (Applied) for installation/removal.

Control logic switchover jumper connector

The jumper connector is in the sink logic (SINK) when shipped from the factory. Move the jumper connector to change to the source logic (SOURCE). Always fit the jumper connector to the either position.
(Refer to the Instruction Manual (Applied).)

Control circuit terminal block

(Refer to page 10.)

Main circuit terminal block

(Refer to page 10.)

Combed shaped wiring cover

Refer to the Instruction Manual (Applied) for installation/removal.

Capacity plate

FR-D720-1.5K-G SERIAL: XXXXXX

Drive unit model Serial number

Rating plate

Drive unit model

Input rating

Output rating

Serial number

Country of origin

MITSUBISHI ELECTRIC		PASSED	DRIVE UNIT
MODEL	FR-D720-1.5K-G		
INPUT	:XXXXX		
OUTPUT	:XXXXX		
SERIAL	:		
MITSUBISHI ELECTRIC CORPORATION			SAMPLE
MADE IN JAPAN			

●Accessory

- Fan cover fixing screws (M3 × 35mm)

Capacity	Quantity
D720-0.2K to 0.75K-G	none
D740-0.4K-G, 0.75K-G	
D720-1.5K to 3.7K-G	1
D740-1.5K to 3.7K-G	

These screws are necessary for compliance with the EU Directive. (Refer to page 46.)


REMARKS


















- For how to find the SERIAL number, refer to page 50.
- Caution stickers are enclosed with this instruction manual. These caution stickers include stickers that are used for the automatic restart after instantaneous power failure function, which are not required for FR-D700-G.

1.2 Operation panel


1.2.1 Names and functions of the operation panel

The operation panel cannot be removed from the drive unit.









No.	Component	Name	Description
(a)		Unit indicator	Hz: Lit to indicate frequency. (Blinks when the set frequency monitor is displayed.) A: Lit to indicate current. (Both "Hz" and "A" are lit to indicate a value other than frequency or current.)
(b)		Monitor (4-digit LED)	Shows the speed, parameter number, etc. (To monitor the output power, the set speed and other items, set Pr: 52.)
(c)		Setting dial	The dial of the Mitsubishi Electric drive unit. The setting dial is used to change the speed and parameter settings. Press to display the following. <ul style="list-style-type: none"> The control method (PM motor control) during the monitor mode is displayed. The set speed is displayed by pressing the setting dial for 1 second or longer when the drive unit is in the PU operation mode or External/PU combined operation mode (Pr: 79 = "3"). Present set value is displayed during calibration Displays the order in the fault history mode
(d)		Start command	Select the rotation direction in Pr: 40.
(e)		MODE key	Used to switch among different setting modes. Pressing  simultaneously changes the operation mode. Holding this key for 2 seconds locks the operation. The key lock is invalid when Pr: 161 = "0 (initial setting)."  Refer to the Instruction Manual (Applied).
(f)		SET key	Used to enter a setting. If pressed during the operation, monitored item changes as the following: <div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; padding: 2px;">Rotation speed</div> <div>→</div> <div style="border: 1px solid black; padding: 2px;">Output current</div> <div>→</div> <div style="border: 1px solid black; padding: 2px;">Output voltage</div> </div>
(g)		Operation status indicator	Lit or blinks during drive unit operation:- <ul style="list-style-type: none"> * Lit: When the forward rotation operation is being performed. Slow blinking (1.4s cycle): When the reverse rotation operation is being performed. Fast blinking (0.2s cycle): When  has been pressed or the start command has been given, but the operation cannot be made. <ul style="list-style-type: none"> When the speed command is less than the starting speed. When the MRS signal is being input.
(h)		Parameter setting mode indicator	Lit to indicate the parameter setting mode.
(i)		Monitor indicator	Lit to indicate the monitor mode.
(j)		Operation mode indicator	PU: Lit to indicate the PU operation mode. EXT: Lit to indicate the External operation mode.(EXT is lit at power-ON in the initial setting.) NET: Lit to indicate the Network operation mode. PU and EXT: Lit to indicate EXT/PU combined operation mode 1 and 2 All of these indicators are OFF when the command source is not at the operation panel.
(k)		STOP/RESET key	Used to stop operation commands. Used to reset a fault when the protective function (fault) is activated.
(l)		PU/EXT key	Used to switch between the PU and External operation modes. To use the External operation mode (operation using a separately connected speed setting potentiometer and start signal), press this key to light up the EXT indicator. (Press  simultaneously (0.5s), or change the Pr: 79 setting to change to the combined operation mode.  Refer to the Instruction Manual (Applied).) PU: PU operation mode EXT: External operation mode Used to cancel the PU stop also.

1.2.2 Basic operation (factory setting)




1.2.3 Changing the parameter setting value

Changing example Change the Pr. 1 Maximum setting.

Operation	
1.	Screen at power-ON The monitor display appears.
2.	Changing the operation mode Press  to choose the PU operation mode. [PU] indicator is lit.
3.	Parameter setting mode Press  to choose the parameter setting mode.
4.	Selecting the parameter number Turn  until <i>P. 1</i> (Pr. 1) appears.
5.	Reading the set value Press  to read the present set value. "3000"(3000r/min (initial value)) appears.
6.	Changing the setting value Turn  to change the set value to "1800"(1800r/min)
7.	Setting the parameter Press  to set. The parameter number and the setting value are displayed alternately.

REMARKS


? *E r 1* to *E r 4* is displayed...Why?

 *E r 1* appears Write disable error

E r 2 appears Write error during operation

E r 3 appears Calibration error

E r 4 appears Mode designation error

(For details,  refer to the Instruction Manual (Applied).)

- The number of digits displayed on the operation panel is four. Only the upper four digits of values can be displayed and set. If the values to be displayed have five digits or more including decimal places, the fifth or later numerals cannot be displayed nor set.

(Example) For Pr. 505


When 60Hz is set, 60.00 is displayed.







When 120Hz is set, 120.0 is displayed and second decimal place is not displayed nor set.

1.2.4 Parameter clear/all parameter clear




POINT


- Set "1" in Pr.CL Parameter clear, ALLC all parameter clear to initialize all parameters. (Parameters are not cleared when "1" is set in Pr. 77 Parameter write selection.)
- Refer to the extended parameter list of  the Instruction Manual (Applied) for parameters cleared with this operation.


Operation	
1.	Screen at power-ON The monitor display appears.
2.	Changing the operation mode Press  to choose the PU operation mode. [PU] indicator is lit.
3.	Parameter setting mode Press  to choose the parameter setting mode.
4.	Selecting Parameter Clear (All Parameter Clear) Turn  until <i>P r. C L (A L L C)</i> appears.
5.	Selecting the setting value Press  to read the present set value. "0"(initial value) appears. Turn  to change it to the set value "1".
6.	Executing Parameter Clear Press  to set. "1" and Pr. CL (ALLC) indications are displayed alternately.

REMARKS

? *E r 1* and *E r 4* are displayed alternately ... Why?

 The drive unit is not in the PU operation mode.

 The PU connector is used. (The parameter unit (FR-PU07) is in use.)

Setting	Description
0	Clear is not executed.
1	Sets parameters back to the initial values. (Parameter clear sets back all parameters except calibration parameters, terminal function selection parameters to the initial values.) Refer to the parameter list of  the Instruction Manual (Applied) for availability of parameter clear and all parameter clear.

1

2 INSTALLATION AND WIRING



AC power supply

Use within the permissible power supply specifications of the drive unit. To ensure safety, use a molded case circuit breaker, earth leakage circuit breaker or magnetic contactor to switch power ON/OFF. (Refer to page 41.)

Molded case circuit breaker (MCCB) or earth leakage circuit breaker (ELB), fuse

The breaker must be selected carefully since an in-rush current flows in the drive unit at power on. (Refer to page 6.)

Magnetic contactor (MC)

Install the magnetic contactor to ensure safety. Do not use this magnetic contactor to start and stop the drive unit. Doing so will cause the drive unit life to be shorten. (Refer to page 6.)

Reactor (FR-HAL, FR-HEL option)

Reactors (option) must be used when power harmonics measures are taken, the power factor is to be improved or the drive unit is installed near a large power supply system (500kVA or more). The drive unit may be damaged if you do not use reactors. Select the reactor according to the model. Remove the jumpers across terminals P/+ and P1 to connect the DC reactor.

AC reactor (FR-HAL)



DC reactor (FR-HEL) *



Noise filter (ferrite core) * (FR-BSF01, FR-BLF)

Install a noise filter (ferrite core) to reduce the electromagnetic noise generated from the drive unit. Effective in the range from about 1MHz to 10MHz. When more wires are passed through, a more effective result can be obtained. A wire should be wound four turns or more.



Parameter unit (FR-PU07)

Enclosure surface operation panel (FR-PA07)


By connecting the connection cable (FR-CB2) to the PU connector, operation can be performed from FR-PU07, FR-PA07.



RS-232C - RS-485 converter is required when connecting to PC with RS-232C interface.

Refer to the Instruction Manual (Applied.)

RS-485 ↔ RS-232C Converter



Drive unit (FR-D700-G)

Earth (Ground)




Brake resistor (FR-ABR, MRS type, MYS type)

Braking capability can be improved. (0.4K or higher) (Refer to page 17.)



Noise filter (ferrite core) (FR-BSF01, FR-BLF)


Install a noise filter (ferrite core) to reduce the electromagnetic noise generated from the drive unit. Effective in the range from about 1MHz to 10MHz. A wire should be wound four turns at a maximum.



Contactor

Example: No-fuse switch (DSN type)

Install a contactor in an application where the PM motor is driven by the load even at power-OFF of the drive unit. Do not open or close the contactor while the drive unit is running (outputting).



Motor

Earth (Ground)

* Filterpack (FR-BFP2), which contains DC reactor and noise filter in one package, is also available.



High power factor converter (FR-HC2)

Power supply harmonics can be greatly suppressed.



Power regeneration common converter (FR-CV)

Great braking capability is obtained.



Resistor unit (FR-BR) Discharging resistor (GZG, GRZC)

The regenerative braking capability of the drive unit can be exhibited fully.



Brake unit (FR-BU2)



Devices connected to the output

Do not install a power factor correction capacitor, surge suppressor or noise filter (capacitor) on the output side of the drive unit. When installing a molded case circuit breaker on the output side of the drive unit, contact each manufacturer for selection of the molded case circuit breaker.

Earth (Ground)

To prevent an electric shock, always earth (ground) the motor and drive unit. For reduction of induction noise from the power line of the drive unit, it is recommended to wire the earth (ground) cable by returning it to the earth (ground) terminal of the drive unit.

■ : Install this as required.

**NOTE**

- The life of the drive unit is influenced by surrounding air temperature. Pay attention to the surrounding air temperature. This must be noted especially when the drive unit is installed in an enclosure. (Refer to Chapter 1 of the Instruction Manual (Applied).)
- Wrong wiring might lead to damage of the drive unit. The control signal lines must be kept fully away from the main circuit to protect them from noise. (Refer to page 9.)
- Do not install a power factor correction capacitor, surge suppressor or noise filter (capacitor) on the drive unit output side. This will cause the drive unit to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.
- Electromagnetic wave interference
The input/output (main circuit) of the drive unit includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the drive unit. In this case, install the FR-BIF optional noise filter (capacitor) (for use in the input side only) or FR-BSF01 or FR-BLF noise filter (ferrite core) to minimize interference. (Refer to Chapter 3 of the Instruction Manual (Applied).)
- Refer to the Instruction Manual of each option and peripheral devices for details of peripheral devices.
- A PM motor cannot be driven by the commercial power supply.
- A PM motor is a magnet motor. High-voltage is generated at motor terminals while the motor is running even after the drive unit power is turned OFF. Before closing the contactor on the output side, make sure that the drive unit power is ON and the motor is stopped.

2.1 Peripheral devices


Check the drive unit model of the drive unit you purchased. Appropriate peripheral devices must be selected according to the capacity.

Refer to the following list and prepare appropriate peripheral devices.

- (1) S-PM geared motor

Voltage	Applicable Drive Unit Model	Motor Output (kW)	Molded Case Circuit Breaker (MCCB)*1 or Earth Leakage Circuit Breaker (ELB)*2 (NF or NV type)		Input Side Magnetic Contactor*3		Reactor	
			Power factor improving (AC or DC) reactor connection		Power factor improving (AC or DC) reactor connection		FR-HAL	FR-HEL
			Without	With	Without	With		
200V class	FR-D720-0.2K-G	0.1	5A	5A	S-T10	S-T10	0.4K *4	0.4K *4
	FR-D720-0.4K-G	0.2	5A	5A	S-T10	S-T10	0.4K *4	0.4K *4
	FR-D720-0.75K-G	0.4	10A	5A	S-T10	S-T10	0.4K	0.4K
	FR-D720-1.5K-G	0.75	15A	10A	S-T10	S-T10	0.75K	0.75K
	FR-D720-2.2K-G	1.5	20A	15A	S-T10	S-T10	1.5K	1.5K
	FR-D720-3.7K-G	2.2	30A	30A	S-T21	S-T10	2.2K	2.2K
400V class	FR-D740-0.4K-G	0.2	5A	5A	S-T10	S-T10	H0.4K *4	H0.4K *4
	FR-D740-0.75K-G	0.4	5A	5A	S-T10	S-T10	H0.4K	H0.4K
	FR-D740-1.5K-G	0.75	10A	10A	S-T10	S-T10	H0.75K	H0.75K
	FR-D740-2.2K-G	1.5	15A	10A	S-T10	S-T10	H1.5K	H1.5K
	FR-D740-3.7K-G	2.2	20A	15A	S-T10	S-T10	H2.2K	H2.2K

- *1 • Select an MCCB according to the power supply capacity.
• Install one MCCB per drive unit.




- *2 For the use in the United States or Canada, refer to page 49, and select an appropriate fuse or molded case circuit breaker (MCCB).
- *3 Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.
If using an MC for emergency stop during motor driving, select an MC regarding the drive unit input side current as JEM1038-AC-3 class rated current.
- *4 The power factor may be slightly lower.

(2) Other PM motor (IPM or SPM)

Voltage	Applicable Drive Unit Model	Motor Output (kW)	Molded Case Circuit Breaker (MCCB)*1 or Earth Leakage Circuit Breaker (ELB)*2 (NF or NV type)		Input Side Magnetic Contactor*3		Reactor	
			Power factor improving (AC or DC) reactor connection		Power factor improving (AC or DC) reactor connection		FR-HAL	FR-HEL
			Without	With	Without	With		
200V class	FR-D720-0.2K-G	0.2	5A	5A	S-T10	S-T10	0.4K*4	0.4K*4
	FR-D720-0.4K-G	0.4	5A	5A	S-T10	S-T10	0.4K	0.4K
	FR-D720-0.75K-G	0.75	10A	5A	S-T10	S-T10	0.75K	0.75K
	FR-D720-1.5K-G	1.5	15A	10A	S-T10	S-T10	1.5K	1.5K
	FR-D720-2.2K-G	2.2	20A	15A	S-T10	S-T10	2.2K	2.2K
	FR-D720-3.7K-G	3.7	30A	30A	S-T21	S-T10	3.7K	3.7K
400V class	FR-D740-0.4K-G	0.4	5A	5A	S-T10	S-T10	H0.4K	H0.4K
	FR-D740-0.75K-G	0.75	5A	5A	S-T10	S-T10	H0.75K	H0.75K
	FR-D740-1.5K-G	1.5	10A	10A	S-T10	S-T10	H1.5K	H1.5K
	FR-D740-2.2K-G	2.2	15A	10A	S-T10	S-T10	H2.2K	H2.2K
	FR-D740-3.7K-G	3.7	20A	15A	S-T10	S-T10	H3.7K	H3.7K

*1 •Select an MCCB according to the power supply capacity.
•Install one MCCB per drive unit.



*2 For the use in the United States or Canada, refer to page 49, and select an appropriate fuse or molded case circuit breaker (MCCB).

*3 Magnetic contactor is selected based on the AC-1 class. The electrical durability of magnetic contactor is 500,000 times. When the magnetic contactor is used for emergency stop during motor driving, the electrical durability is 25 times.
If using an MC for emergency stop during motor driving, select an MC regarding the drive unit input side current as JEM1038-AC-3 class rated current.

*4 The power factor may be slightly lower.

NOTE



- Select a MCCB and a magnetic contactor according to the drive unit model, and cable and reactor according to the motor output.
- When the breaker on the drive unit input side trips, check for the wiring fault (short circuit), damage to internal parts of the drive unit, etc. Identify the cause of the trip, then remove the cause and power ON the breaker.

2.2 Installation of the drive units and precautions

(1) Installation of the drive unit


Enclosure surface mounting

Remove the front cover and wiring cover to mount the drive unit to the surface. (Remove the covers in the directions of the arrows.)

●FR-D720-0.2K to 0.75K-G


●FR-D720-1.5K to 3.7K-G

●FR-D740-0.4K to 3.7K-G




NOTE

- When encasing multiple drive units, install them in parallel as a cooling measure.
- Install the drive unit vertically.
- For heat dissipation and maintenance, allow minimum clearance shown in the figures below from the drive unit to the other devices and to the inner surface of the enclosure.



Measurement position
-10°C to +50°C
(non-freezing)

- When using the drive units at the surrounding air temperature of 40°C or less, the drive units can be installed without any clearance between them (0cm clearance).



(2) Environment

Before installation, check that the environment meets the specifications on *page 42*.




Note

- Install the drive unit on a strong surface securely and vertically with bolts.
- Leave enough clearances and take cooling measures.
- Avoid places where the drive unit is subjected to direct sunlight, high temperature and high humidity.
- Install the drive unit on a nonflammable wall surface.
- When designing or building an enclosure for the drive unit, carefully consider influencing factors such as heat generation of the contained devices and the operating environment.

2.3 Wiring

2.3.1 Terminal connection diagram




NOTE

- To prevent a malfunction caused by noise, separate the signal cables more than 10cm from the power cables. Also separate the main circuit wire of the input side and the output side.
- After wiring, wire offcuts must not be left in the drive unit.

Wire offcuts can cause an alarm, failure or malfunction. Always keep the drive unit clean. When drilling mounting holes in an enclosure etc., take caution not to allow chips and other foreign matter to enter the drive unit.

2.3.2 Terminal specifications


Type	Terminal Symbol	Terminal Name	Terminal Specification		
Main circuit terminal	R/L1, S/L2, T/L3	AC power input	Connect to the commercial power supply. Do not connect anything to these terminals when using the high power factor converter (FR-HC2) or power regeneration common converter (FR-CV).		
	U, V, W	Drive unit output	Connect a PM motor.		
	P/+, PR	Brake resistor connection	Connect a brake resistor (FR-ABR, MRS type, MYS type) across terminals P/+ and PR. (The brake resistor can not be connected to the 0.2K.)		
	P/+, N/-	Brake unit connection	Connect the brake unit (FR-BU2), power regeneration common converter (FR-CV) or high power factor converter (FR-HC2).		
	P/+, P1	DC reactor connection	Remove the jumper across terminals P/+ and P1 and connect a DC reactor.		
		Earth (Ground)	For earthing (grounding) the drive unit chassis. Must be earthed (grounded).		
Control circuit terminal/input signal	Contact input	STF	Forward rotation start	When the STF and STR signals are turned ON simultaneously, the stop command is given.	
		STR	Reverse rotation start		
		RH, RM, RL	Multi-speed selection	Multi-speed can be selected according to the combination of RH, RM and RL signals.	
	SD	Contact input common (sink) (initial setting)	Common terminal for contact input terminal (sink logic) and terminal FM.		
		External transistor common (source)	Connect this terminal to the power supply common terminal of a transistor output (open collector output) device, such as a programmable controller, in the source logic to avoid malfunction by undesirable current.		
		24VDC power supply common	Common output terminal for 24VDC 0.1A power supply (PC terminal). Isolated from terminals 5 and SE.		
	PC	External transistor common (sink) (initial setting)	Connect this terminal to the power supply common terminal of a transistor output (open collector output) device, such as a programmable controller, in the sink logic to avoid malfunction by undesirable current.		
		Contact input common (source)	Common terminal for contact input terminal (source logic).		
		24VDC power supply	Can be used as 24VDC 0.1A power supply.		
	Speed setting	10	Speed setting power supply	Used as power supply when connecting potentiometer for speed setting (speed setting) from outside of the drive unit.	5VDC permissible load current 10mA
			Speed setting (voltage)	Inputting 0 to 5VDC (or 0 to 10V) provides the maximum rotation speed at 5V (10V) and makes input and output proportional. Use Pr. 73 to switch between input 0 to 5VDC input (initial setting) and 0 to 10VDC.	Input resistance 10kΩ ± 1kΩ Permissible maximum voltage 20VDC
		4	Speed setting (current)	Inputting 4 to 20mAADC (or 0 to 5V, 0 to 10V) provides the maximum rotation speed at 20mA and makes input and output proportional. This input signal is valid only when the AU signal is ON (terminal 2 input is invalid). To use terminal 4 (initial setting is current input), set "4" in any of Pr.178 to Pr.182 (input terminal function selection) to assign the function, and turn ON AU signal. Use Pr. 267 to switch among input 4 to 20mA (initial setting), 0 to 5VDC and 0 to 10VDC. Set the voltage/current input switch in the "V" position to select voltage input (0 to 5V/0 to 10V).	Current input: Input resistance 249Ω ± 5Ω Maximum permissible current 30mA
			Speed setting common	Speed setting signal (terminal 2, 4) common terminal. Do not earth (ground).	Voltage input: Input resistance 10kΩ ± 1kΩ Permissible maximum voltage 20VDC
		5	Speed setting common	Speed setting signal (terminal 2, 4) common terminal. Do not earth (ground).	
	Control circuit terminal/output signal	Relay	A, B, C	Relay output (fault output)	1 changeover contact output indicates that the drive unit's protective function has activated and the output stopped. Fault: discontinuity across B-C (continuity across A-C), Normal: continuity across B-C (discontinuity across A-C)
Open collector		RUN	Drive unit running	Switched Low when the drive unit rotation speed is equal to or higher than the 1r/min. Switched High during stop or DC injection brake operation. (Low is when the open collector output transistor is ON (conducts). High is when the transistor is OFF (does not conduct).)	
		SE	Open collector output common	Common terminal of terminal RUN.	
Pulse		FM	For meter	Used to output a selected monitored item (such as Rotation speed) among several monitored items. (Not output during drive unit reset.) The output signal is proportional to the magnitude of the corresponding monitored item.	Permissible load current 1mA 1440 pulses/s at 3000r/min

2

Type	Terminal Symbol	Terminal Name	Terminal Specification
Communication	—	PU connector	With the PU connector, communication can be established through RS-485. <ul style="list-style-type: none"> •Conforming standard: EIA-485 (RS-485) •Transmission format: Multidrop link •Communication speed: 4800 to 38400bps •Overall length: 500m




NOTE

- To change the input specification for terminal 4, set *Pr. 267* and the voltage/current input switch correctly, then input the analog signal relevant to the setting. Applying a voltage with voltage/current input switch in "I" position (current input is selected) or a current with switch in "V" position (voltage input is selected) could cause component damage to the drive unit or analog circuit of output devices.
 - Connecting the power supply to the drive unit output terminals (U, V, W) will damage the drive unit. Do not perform such wiring.
 -  indicates that terminal functions can be selected using *Pr. 178 to Pr. 182, Pr. 190, Pr. 192, Pr. 197 (I/O terminal function selection)*.
 - The terminal names and functions shown here are the initial settings.
 - The terminals S1, S2, SC, and SO are for manufacturer setting. Do not connect anything to these. Doing so may cause a drive unit failure.
- Do not remove the shortening wires across the terminals S1 and SC and the terminals S2 and SC. Removing either of these shortening wires disables the drive unit operation.

2.3.3 Terminal arrangement of the main circuit terminal, power supply and the motor wiring

●Three-phase 200V/400V class



NOTE

- Make sure the power cables are connected to the R/L1, S/L2, T/L3. (Phase need not be matched.) Never connect the power cable to the U, V, W of the drive unit. Doing so will damage the drive unit.
- Connect the motor to U, V, W. Turning ON the forward rotation switch (signal) at this time rotates the motor counterclockwise when viewed from the load shaft.

(1) Cable size and other specifications of the main circuit terminals and the earthing terminal

Select the recommended cable size to ensure that a voltage drop will be 2% or less.

If the wiring distance is long between the drive unit and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low speed.

The following table indicates a selection example for the wiring length of 20m.

Three-phase 200V class (when input power supply is 220V)

Applicable Drive unit Model	Terminal Screw Size *4	Tightening Torque N·m	Crimping Terminal		Cable Size							
					HIV Cables, etc. (mm ²) *1		AWG *2		PVC Cables, etc. (mm ²) *3			
			R/L1 S/L2 T/L3	U, V, W	R/L1 S/L2 T/L3	U, V, W	Earthing (grounding) cable	R/L1 S/L2 T/L3	U, V, W	R/L1 S/L2 T/L3	U, V, W	Earthing (grounding) cable
FR-D720-0.2K to 0.75K-G	M3.5	1.2	2-3.5	2-3.5	2	2	2	14	14	2.5	2.5	2.5
FR-D720-1.5K-G, 3.7K-G	M4	1.5	2-4	2-4								

Three-phase 400V class (when input power supply is 440V)

Applicable Drive unit Model	Terminal Screw Size *4	Tightening Torque N·m	Crimping Terminal		Cable Size							
					HIV Cables, etc. (mm ²) *1		AWG *2		PVC Cables, etc. (mm ²) *3			
			R/L1 S/L2 T/L3	U, V, W	R/L1 S/L2 T/L3	U, V, W	Earthing (grounding) cable	R/L1 S/L2 T/L3	U, V, W	R/L1 S/L2 T/L3	U, V, W	Earthing (grounding) cable
FR-D740-0.4K to 3.7K-G	M4	1.5	2-4	2-4	2	2	2	14	14	2.5	2.5	2.5

- *1 The cable size is that of the cable (HIV cable (600V class 2 vinyl-insulated cable) etc.) with continuous maximum permissible temperature of 75°C. Assumes that the surrounding air temperature is 50°C or less and the wiring distance is 20m or less.
- *2 The recommended cable size is that of the cable (THHW cable) with continuous maximum permissible temperature of 75°C. Assumes that the surrounding air temperature is 40°C or less and the wiring distance is 20m or less. (For the use in the United States or Canada, refer to page 49.)
- *3 The recommended cable size is that of the cable (PVC cable) with continuous maximum permissible temperature of 70°C. Assumes that the surrounding air temperature is 40°C or less and the wiring distance is 20m or less. (Selection example for use mainly in Europe.)
- *4 The terminal screw size indicates the terminal size for R/L1, S/L2, T/L3, U, V, W, PR, P/+, N/-, P1 and a screw for earthing (grounding).



NOTE

- Tighten the terminal screw to the specified torque. A screw that has been tightened too loosely can cause a short circuit or malfunction. A screw that has been tightened too tightly can cause a short circuit or malfunction due to the unit breakage.
- Use crimping terminals with insulation sleeve to wire the power supply and motor.

The line voltage drop can be calculated by the following formula:

$$\text{Line voltage drop [V]} = \frac{\sqrt{3} \times \text{wire resistance [m}\Omega/\text{m]} \times \text{wiring distance [m]} \times \text{current [A]}}{1000}$$

Use a larger diameter cable when the wiring distance is long or when it is desired to decrease the voltage drop (torque reduction) in the low speed range.

(2) Total wiring length

Connect a PM motor within the total wiring length of 30m.

Use one PM motor for one drive unit. Multiple PM motors cannot be connected to a drive unit.




NOTE

Especially for long-distance wiring, the drive unit may be affected by a charging current caused by the stray capacitances of the wiring, leading to a malfunction of the overcurrent protective function, fast response current limit function, or stall prevention function or a malfunction or fault of the equipment connected on the drive unit output side. If malfunction of fast-response current limit function occurs, disable this function. If malfunction of stall prevention function occurs, increase the stall level. (Refer to Pr. 22 Stall prevention operation level and Pr. 156 Stall prevention operation selection in Chapter 4 of the Instruction Manual (Applied).)

2.3.4 Wiring of control circuit

(1) Control circuit terminal layout

Recommend wire size:
0.3mm² to 0.75mm²



NOTE

Do not remove the shortening wires across the terminals S1 and SC and the terminals S2 and SC. Removing either of these shortening wires disables the drive unit operation.


(2) Wiring method

●Wiring

Use crimp terminals and stripped wire for the control circuit wiring. For single wire, the stripped wire can be used without crimp terminal.

Connect the end of wires (crimp terminal or stranded wire) to the terminal block.


- Strip the signal wires as shown below. If too much of the wire is stripped, a short circuit may occur with neighboring wires. If not enough of the wire is stripped, wires may become loose and fall out. Twist the stripped end of wires to prevent them from fraying. Do not solder it.



- Crimp the terminals on the wire.

Insert wires to the crimp terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve.

Check the condition of the crimp terminals after crimping. Do not use the crimp terminals of which the crimping is inappropriate, or the face is damaged.



Crimp terminals commercially available (as of January 2017. The product may be changed without notice.)

●Phoenix Contact Co.,Ltd.

Wire Gauge (mm ²)	Ferrule Part No.			Crimping Tool Model No.
	With Insulation Sleeve	Without Insulation Sleeve	For UL Wire *1	
0.3	AI 0,34-10TQ	—	—	CRIMPFOX 6
0.5	AI 0,5-10WH	—	AI 0,5-10WH-GB	
0.75	AI 0,75-10GY	A 0,75-10	AI 0,75-10GY-GB	
1	AI 1-10RD	A1-10	AI 1-10RD/1000GB	
1.25, 1.5	AI 1,5-10BK	A1,5-10	AI 1,5-10BK/1000GB *2	
0.75 (for two wires)	AI-TWIN 2 x 0,75-10GY	—	—	


*1 A ferrule terminal with an insulation sleeve compatible with MTW wire which has a thick wire insulation

*2 Applicable for terminal A, B, and C.


●NICHIFU Co.,Ltd.

Wire Gauge (mm ²)	Blade Terminal Part No.	Insulation Cap Part No.	Crimping Tool Model No.
0.3 to 0.75	BT 0.75-11	VC 0.75	NH 69

3) Insert the wire into the terminal block.



When using single wire or stranded wire without crimp terminal, push an open/close button all the way down with a flathead screwdriver, and insert the wire.



2




NOTE

- When using stranded wire without a blade terminal, twist enough to avoid short circuit with neighboring terminals or wires.
- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause damage to drive unit or injury.

●Wire removal

Pull the wire with pushing the open/close button all the way down firmly with a flathead screwdriver.



NOTE

- Pulling out the terminal block forcefully without pushing the open/close button all the way down may damage the terminal block.
- Use a small flathead screwdriver (Tip thickness: 0.4mm/ tip width: 2.5mm). If a flathead screwdriver with a narrow tip is used, terminal block may be damaged.

Products available on the market: (as of February 2016)

Product	Type	Maker
Flathead screwdriver	SZF 0- 0,4 x 2,5	Phoenix Contact Co.,Ltd.


- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause damage to drive unit or injury.

(3) Control circuit common terminals (SD, 5, SE)

- Terminals SD, SE and 5 are common terminals for I/O signals. (All common terminals are isolated from each other.) Do not earth them. Avoid connecting the terminals SD and 5 and the terminals SE and 5.
- Terminal SD is a common terminal for the contact input terminals (STF, STR, RH, RM, RL) and pulse train output terminal (FM). The open collector circuit is isolated from the internal control circuit by photocoupler.
- Terminal 5 is a common terminal for the speed setting signals (terminals 2 or 4). It should be protected from external noise using a shielded or twisted cable.
- Terminal SE is a common terminal for the open collector output terminal (RUN). The contact input circuit is isolated from the internal control circuit by photocoupler.

(4) Wiring instructions

- It is recommended to use the cables of 0.3mm² to 0.75mm² gauge for connection to the control circuit terminals.
- The maximum wiring length should be 30m (200m for terminal FM).
- Do not short across terminals PC and SD. Drive unit may be damaged.
- Use two or more parallel micro-signal contacts or twin contacts to prevent contact faults when using contact inputs since the control circuit input signals are micro-currents.
- To suppress EMI, use shielded or twisted cables for the control circuit terminals and run them away from the main and power circuits (including the 200V relay sequence circuit). For the cables connected to the control circuit terminals, connect their shields to the common terminal of the connected control circuit terminal. When connecting an external power supply to the terminal PC, however, connect the shield of the power supply cable to the negative side of the external power supply. Do not directly earth (ground) the shield to the enclosure, etc.
- Always apply a voltage to the fault output terminals (A, B, C) via a relay coil, lamp, etc.
- When using an external power supply for transistor output, note the following points to prevent a malfunction caused by undesirable current.



Do not connect any terminal SD on the drive unit and the 0V terminal of the external power supply (when the sink logic is selected).

Do not connect terminal PC on the drive unit and the +24V terminal of the external power supply (when the source logic is selected).

Do not install an external power source in parallel with the internal 24VDC power source (connected to terminals PC and SD) to use them together.

Refer to Chapter 2 of the Instruction Manual (Applied) for the detail.

2.3.5 Assigning signals (output stop signal (MRS), reset signal (RES), etc.) to contact input terminals



POINT

- Use parameters (Pr.178 to Pr.182 input terminal function selection) to select and change the functions assigned to input terminals.
To assign the output stop signal (MRS) to the terminal RH, for example, assign "24" to Pr.182 RH terminal function selection. Refer to page 4 to change the parameter setting.
- Set Pr.160 Extended function display selection = "0" (extended parameters enabled).

Parameter	Name	Unit	Initial value	Range
178	STF terminal function selection	1	60	0: Low-speed operation command (RL) 23: Pre-excitation (LX) 1: Middle-speed operation command (RM) 24: Output stop (MRS) 2: High-speed operation command (RH) 25: Start self-holding selection (STOP)
179	STR terminal function selection	1	61	3: Second function selection (RT) 60: Forward rotation command (STF) *1 4: Terminal 4 input selection (AU) 61: Reverse rotation command (STR) *2 5: Jog operation selection (JOG) 62: Drive unit reset (RES) 7: External thermal relay input (OH) 64: PID forward/reverse action switchover (X64)
180	RL terminal function selection	1	0	8: 15-speed selection (REX) 65: PU/NET operation switchover (X65) 10: Drive unit run enable signal (X10) 66: External/NET operation switchover (X66) (FR-HC2/FR-CV connection) 67: Command source switchover (X67)
181	RM terminal function selection	1	1	12: PU operation external interlock (X12) 72: PID integral value reset (X72) 14: PID control valid terminal (X14) 9999: No function
182	RH terminal function selection	1	2	16: PU/External operation switchover (X16) *1 Assignable to the STF terminal (Pr.178) only. *2 Assignable to the STR terminal (Pr.179) only.

**NOTE**

- Changing the terminal assignment using Pr.178 to Pr.182 (input terminal function selection) may affect other functions. Set parameters after confirming the function of each terminal.


2.4 Connection of a dedicated external brake resistor (MRS type, MYS type, FR-ABR) (0.4K or higher)

Install a dedicated brake resistor (MRS type, MYS type, FR-ABR) outside when the motor driven by the drive unit is made to run by the load, quick deceleration is required, etc. Connect a dedicated brake resistor (MRS type, MYS type, FR-ABR) to terminal P/+ and PR. (For the locations of terminal P/+ and PR, refer to the terminal block layout (page 12).)

Set parameters below. (Refer to the Instruction Manual (Applied) for the parameter details.)

Connected Brake Resistor	Pr. 30 Regenerative function selection Setting	Pr. 70 Special regenerative brake duty Setting
MRS type, MYS type	0 (initial value)	—
MYS type (used at 100% torque/6%ED)	1	6%
FR-ABR	1	10%


- It is recommended to configure a sequence, which shuts off power in the input side of the drive unit by the external thermal relay as shown below, to prevent overheat and burnout of the brake resistor (MRS type, MYS type) and high duty brake resistor (FR-ABR) in case the regenerative brake transistor is damaged. (The brake resistor cannot be connected to the 0.2K.)



- *1 Refer to the table below for the type number of each capacity of thermal relay and the diagram below for the connection.
- *2 When the power supply is 400V class, install a step-down transformer.

Power Supply Voltage	Brake Resistor	Thermal Relay Type (Mitsubishi Electric Product)	Rated Operating Current
200V	MRS120W200	TH-T25-0.7A	120VAC: 2A (NO contact) / 3A (NC contact), 240VAC: 1A (NO contact) / 2A (NC contact) (AC15 class) 110VDC: 0.2A, 220VDC: 0.1A (DC13 class)
	MRS120W100	TH-T25-1.3A	
	MRS120W60	TH-T25-2.1A	
	MRS120W40	TH-T25-3.6A	
	MYS220W50 (two units in parallel)	TH-T25-5A	

Power Supply Voltage	High-Duty Brake Resistor	Thermal Relay Type (Mitsubishi Electric Product)	Rated Operating Current
200V	FR-ABR-0.4K	TH-T25-0.7A	120VAC: 2A (NO contact) / 3A (NC contact), 240VAC: 1A (NO contact) / 2A (NC contact) (AC15 class) 110VDC: 0.2A, 220VDC: 0.1A (DC13 class)
	FR-ABR-0.75K	TH-T25-1.3A	
	FR-ABR-2.2K	TH-T25-2.1A	
	FR-ABR-3.7K	TH-T25-3.6A	
400V	FR-ABR-H0.4K	TH-T25-0.24A	
	FR-ABR-H0.75K	TH-T25-0.35A	
	FR-ABR-H1.5K	TH-T25-0.9A	
	FR-ABR-H2.2K	TH-T25-1.3A	
	FR-ABR-H3.7K	TH-T25-2.1A	



NOTE

- The brake resistor connected should only be the dedicated brake resistor.
- Perform wiring and operation according to the Instruction Manual of each option unit.
- Brake resistor cannot be used with the brake unit, high power factor converter, power supply regeneration converter, etc.
- Do not use the brake resistor (MRS type, MYS type) with a lead wire extended.
- Do not connect a resistor directly to terminals P/+ and N/-. This could cause a fire.

3 PRECAUTIONS FOR USE OF THE DRIVE UNIT

This product is a highly reliable product, but incorrect peripheral circuit making or operation/handling method may shorten the product life or damage the product.

Before starting operation, always recheck the following items.

- (1) **Use crimp terminals with insulation sleeve to wire the power supply and motor.**
- (2) **Application of power to the output terminals (U, V, W) of the drive unit will damage the drive unit. Never perform such wiring.**
- (3) **After wiring, wire offcuts must not be left in the drive unit.**

Wire offcuts can cause an alarm, failure or malfunction. Always keep the drive unit clean.
When drilling mounting holes in an enclosure etc., take care not to allow chips and other foreign matter to enter the drive unit.
- (4) **Use cables of the size to make a voltage drop 2% or less.**

If the wiring distance is long between the drive unit and motor, a main circuit cable voltage drop will cause the motor torque to decrease especially at the output of a low speed. Refer to *page 14* for the recommended wire sizes.
- (5) **Keep the total wiring length within the specified length.**

Especially for long distance wiring, the equipment connected to the output side may malfunction or become faulty under the influence of a charging current due to the stray capacity of the wiring. Therefore, note the overall wiring length. (*Refer to page 15.*)
- (6) **Electromagnetic wave interference**

The input/output (main circuit) of the drive unit includes high frequency components, which may interfere with the communication devices (such as AM radios) used near the drive unit. In this case, install the FR-BIF optional capacitor type filter (for use in the input side only) or FR-BSF01 or FR-BLF line noise filter to minimize interference.
- (7) **Electrical corrosion of the bearing**

When a motor is driven by the drive unit, axial voltage is generated on the motor shaft, which may cause electrical corrosion of the bearing in rare cases depending on: the wiring, load, operating conditions of the motor, or the use of the capacitive filter*1.

The following shows examples of countermeasures for the drive unit.

 - Remove the capacitive filter.
 - Provide a common mode choke*2 on the output side of the drive unit. (This is effective regardless of the use of the capacitive filter.)

*1 Mitsubishi Electric capacitive filter: FR-BIF, SF[], FR-E5NF-[], FR-BFP2-[]
*2 Recommended common mode choke: FT-3KM F series FINEMET® common mode choke cores manufactured by Hitachi Metals, Ltd.
FINEMET is a registered trademark of Hitachi Metals, Ltd.
- (8) **Do not install a power factor correction capacitor, surge suppressor or capacitor type filter on the drive unit output side.**

This will cause the drive unit to trip or the capacitor and surge suppressor to be damaged. If any of the above devices are connected, immediately remove them.
- (9) **For some short time after the power is switched OFF, a high voltage remains in the smoothing capacitor.**

When accessing the drive unit for inspection, wait for at least 10 minutes after the power supply has been switched OFF, and then make sure that the voltage across the main circuit terminals P/+ and N/- of the drive unit is not more than 30VDC using a tester, etc.
- (10) **A short circuit or earth (ground) fault on the drive unit output side may damage the drive unit module.**
 - Fully check the insulation resistance of the circuit prior to drive unit operation since repeated short circuits caused by peripheral circuit inadequacy or an earth (ground) fault caused by wiring inadequacy or reduced motor insulation resistance may damage the drive unit module.
 - Fully check the to-earth (ground) insulation and phase to phase insulation of the drive unit output side before power-On. Especially for an old motor or use in hostile atmosphere, securely check the motor insulation resistance etc.

(11) Do not use the drive unit input side magnetic contactor to start/stop the drive unit.

Since repeated inrush currents at power ON will shorten the life of the converter circuit (switching life is about 1,000,000 times.), frequent starts and stops of the MC must be avoided. Turn ON/OFF the drive unit start controlling terminals (STF, STR) to run/stop the drive unit. (Refer to the Instruction Manual (Applied).)

(12) Across terminals P/+ and PR, connect only an external brake resistor.

- Do not connect a mechanical brake.
- The brake resistor cannot be connected to the 0.2K. Do not connect anything to terminals P/+ and PR. Also, never short between these terminals.

(13) Do not apply a voltage higher than the permissible voltage to the drive unit I/O signal circuits.

Application of a voltage higher than the permissible voltage to the drive unit I/O signal circuits or opposite polarity may damage the I/O devices. Especially check the wiring to prevent the speed setting potentiometer from being connected incorrectly to short terminals 10 and 5.

(14) If the machine must not be restarted when power is restored after a power failure, provide a magnetic contactor in the drive unit's input side and also make up a sequence which will not switch ON the start signal.

If the start signal (start switch) remains ON after a power failure, the drive unit will automatically restart as soon as the power is restored.

(15) Drive unit input side magnetic contactor (MC)

On the drive unit input side, connect a MC for the following purposes. (Refer to page 6 for selection.)

- 1) To release the drive unit from the power supply when a fault occurs or when the drive is not functioning (e.g. emergency stop operation). For example, MC avoids overheat or burnout of the brake resistor when heat capacity of the resistor is insufficient or brake regenerative transistor is damaged with short while connecting an optional brake resistor.
- 2) To prevent any accident due to an automatic restart at restoration of power after a drive unit stop made by a power failure
- 3) To separate the drive unit from the power supply to ensure safe maintenance and inspection work.

If using an MC for emergency stop during operation, select an MC regarding the drive unit input side current as JEM1038-AC-3 class rated current.

(16) Handling of drive unit output side magnetic contactor

Switch the magnetic contactor between the drive unit and motor only when both the drive unit and motor are at a stop. When the magnetic contactor is turned ON while the drive unit is operating, overcurrent protection of the drive unit and such will activate.

(17) Countermeasures against drive unit-generated EMI

If electromagnetic noise generated from the drive unit causes speed setting signal to fluctuate and motor rotation speed to be unstable when changing motor speed with analog signal, the following countermeasures are effective.

- Do not run the signal cables and power cables (drive unit I/O cables) in parallel with each other and do not bundle them.
- Run signal cables as far away as possible from power cables (drive unit I/O cables).
- Use shield cables as signal cables.
- Install a ferrite core on the signal cable (Example: ZCAT3035-1330 TDK).

(18) Instructions for overload operation

When performing operation of frequent start/stop of the drive unit, rise/fall in the temperature of the transistor element of the drive unit will repeat due to a repeated flow of large current, shortening the life from thermal fatigue. Since thermal fatigue is related to the amount of current, the life can be increased by reducing current at locked condition, starting current, etc. Decreasing current may increase the life. However, decreasing current will result in insufficient torque and the drive unit may not start. Reducing the current may extend the service life but may also cause torque shortage, which leads to a start failure. An effective measure is to use a drive unit and motor with higher capacities. Doing so will provide a margin to the load.

(19) Make sure that the specifications and rating match the system requirements.

4 FAILSAFE OF THE SYSTEM WHICH USES THE DRIVE UNIT

When a fault occurs, the drive unit trips to output a fault signal. However, a fault output signal may not be output at a drive unit fault occurrence when the detection circuit or output circuit fails, etc. Although Mitsubishi Electric assures best quality products, provide an interlock which uses drive unit status output signals to prevent accidents such as damage to machine when the drive unit fails for some reason and at the same time consider the system configuration where failsafe from outside the drive unit, without using the drive unit, is enabled even if the drive unit fails.

(1) Interlock method which uses the drive unit status output signals

By combining the drive unit status output signals to provide an interlock as shown below, a drive unit failure can be detected.

No.	Interlock Method	Check Method	Used Signals	Refer to
1)	Drive unit protective function operation	Operation check of an alarm contact Circuit error detection by negative logic	Fault (ALM) signal	Chapter 4 of the Instruction Manual (Applied).
2)	Drive unit operating status	Operation ready signal check	Operation ready (RY) signal	Chapter 4 of the Instruction Manual (Applied).
3)	Drive unit running status	Logic check of the start signal and running signal	Start signal (STF signal, STR signal) Drive unit running (RUN) signal	Chapter 4 of the Instruction Manual (Applied).
4)	Drive unit running status	Logic check of the start signal and output current	Start signal (STF signal, STR signal) Output current detection (Y12) signal	Chapter 4 of the Instruction Manual (Applied).

(2) Backup method outside the drive unit

Even if the interlock is provided by the drive unit status signal, enough failsafe is not ensured depending on the failure status of the drive unit itself. For example, when the drive unit CPU fails, even if the interlock is provided using the drive unit fault signal, start signal and RUN signal, there is a case where a fault signal is not output and RUN signal is kept output even if a drive unit fault occurs.


Provide a speed detector to detect the motor speed and current detector to detect the motor current and consider the backup system such as checking up as below according to the level of importance of the system.

1) Start signal and actual operation check

Check the motor running and motor current while the start signal is input to the drive unit by comparing the start signal to the drive unit and detected speed of the speed detector or detected current of the current detector. Note that the motor current runs as the motor is running for the period until the motor stops since the drive unit starts decelerating even if the start signal turns OFF. For the logic check, configure a sequence considering the drive unit deceleration time. In addition, it is recommended to check the three-phase current when using the current detector.

2) Command speed and actual operation check


Check if there is no gap between the actual speed and commanded speed by comparing the drive unit speed command and detected speed of the speed detector.



5 DRIVE THE MOTOR

The drive unit needs a speed command and a start command.

Speed command (set speed) determines the rotation speed of the motor. Turning ON the start command starts the motor to rotate.



REMARKS

- Set the required parameters according to the load and operating conditions. (Refer to page 29.)

5.1 Start/stop from the operation panel (PU operation)




POINT

From where is the speed command given?

- Operation at the speed set in the speed setting mode of the operation panel (Refer to 5.1.1 (refer to page 21)).
- Operation using the setting dial as the potentiometer (Refer to 5.1.2 (refer to page 22)).
- Change of speed with ON/OFF switches connected to terminals (Refer to 5.1.3 (refer to page 23)).
- Perform speed setting using voltage input signal (Refer to 5.1.4 (refer to page 24)).
- Perform speed setting using current input signal (Refer to 5.1.4 (refer to page 24)).

5.1.1 Setting the speed by the operation panel



Operation example Operate at 900r/min.

Operation

- Screen at power-ON
The monitor display appears.
- Operation mode change
Press **PU EXT** to choose the PU operation mode. [PU] indicator is lit.
- Speed setting
Turn the potentiometer to show the speed "900" (900r/min) you want to set. The indication blinks for about 5s. While the value is flashing, press **SET** to set the speed. "F" and "900" are displayed alternately. After about 3s of alternate display, the indication of the value goes back to "0" (monitor display). (If **SET** is not pressed, the indication of the value goes back to "0" after about 5s of flashing. In that case, turn the potentiometer again, and set the speed.)
- Start → acceleration → constant speed
Press **RUN** to start operation.
The speed value on the indication increases in Pr: 7 Acceleration time, and "900" (900r/min) appears. (To change the set speed, perform the operation in above step 3. Starting from the previously set speed.)
- Deceleration → stop
Press **STOP RESET** to stop. The speed value on the display decreases in Pr: 8 Deceleration time, and the motor stops rotating with "0" (0r/min) displayed.



REMARKS

- The potentiometer can also be used like a potentiometer to perform operation. (Refer to Chapter 4 of the Instruction Manual (Applied).)
- When you always operate in the PU operation mode at power-ON, set Pr:79 Operation mode selection = "1" to choose the PU operation mode always.

5.1.2 Using the setting dial like a potentiometer to perform operation







POINT

- Set "0" (extended parameter valid) in *Pr. 160 Extended function display selection*.
- Set "1" (setting dial potentiometer mode) in *Pr. 161 Speed setting/key lock operation selection*.


Operation example Change the speed from 0r/min to 1800r/min during operation

Operation

1.	Screen at power-ON The monitor display appears.
2.	Operation mode change Press  to choose the PU operation mode. PU indicator is lit.
3.	Selecting the setting dial mode Change the <i>Pr. 160</i> setting to "0" and the <i>Pr. 161</i> setting to "1". <i>(Refer to page 4 for change of the setting.)</i>
4.	Start Press  to start the speed.
5.	Speed setting Turn  until "1800" (1800/min) appears. The value in the flashing indication is set as the value of the set speed. You need not press  .



REMARKS

- If the indication changes from the blink of "1800" to the display of "0", the *Pr. 161 Speed setting/key lock operation selection* setting may not be "1".
- Independently of whether the drive unit is running or at a stop, the speed can be set by merely turning the .



NOTE

- When setting speed by turning setting dial, the speed goes up to the set value of *Pr. 1 Maximum setting* (initial value: 3000r/min). Adjust *Pr. 1 Maximum setting* setting according to the application.



5.1.3 Setting the speed by switches (three-speed setting) (Pr. 4 to Pr. 6)



POINT

- Use operation panel (**RUN**) to give a start command.
- Switch ON the RH, RM, or RL signal to give a speed command.
- Set "4" (External/PU combined operation mode 2) in Pr. 79 Operation mode selection.

[Connection diagram]



Operation example Operation at low speed (300r/min)

Operation

1. Screen at power-ON
The monitor display appears.
2. Easy operation mode setting
Press **PU/EXT** and **MODE** for 0.5s. " **79 - -** " appears, and the [PRM] indicator blinks.
3. Operation mode selection
Turn **SEL** until " **79 - 4** " appears. [PU] and [PRM] indicators blink.
4. Operation mode setting
Press **SET** to enter the setting. (Set "4" in Pr.79.)
" **79 - 4** " and " **79 - -** " are displayed alternately. [PU] and [EXT] indicators are lit.
5. Speed setting
Turn ON the low-speed switch (RL).
Start → acceleration → constant speed
6. Press **RUN** to start running.
The speed value on the indication increases in Pr. 7 Acceleration time, and " **300** " (300r/min) appears.
[RUN] indicator is lit during forward rotation operation and blinks slowly during reverse rotation operation.
7. Deceleration → stop
Press **STOP/RESET** to stop.
The speed value on the indication decreases in Pr. 8 Deceleration time, and the motor stops rotating with " **0** " (0r/min) displayed.
8. Speed setting (OFF)
Turn OFF the low-speed switch (RL).



REMARKS

- The initial values of the terminals RH, RM, RL are 3000r/min, 1500r/min, and 300r/min. (Use Pr. 4, Pr. 5 and Pr. 6 to change.)
- In the initial setting, when two or three of multi-speed settings are simultaneously selected, priority is given to the set speed of the lower signal.
For example, when the RH and RM signals turn ON, the RM signal (Pr. 5) has a higher priority.
- Maximum of 15-speed operation can be performed. (Refer to Chapter 4 of the Instruction Manual (Applied).)

5.1.4 Setting the speed by analog input (voltage input/current input)




POINT

- Use the operation panel (**RUN**) to give a start command.
- Use the (speed setting) potentiometer (voltage input) or 4-to-20mA input (current input) to give a speed command.
- Set "4" (External/PU combined operation mode 2) in Pr. 79 Operation mode selection.


[Connection example for voltage input]

(The drive unit supplies 5V power to the speed setting potentiometer. (terminal 10))



[Connection example for current input]

(Assign the AU signal in one of Pr. 178 to Pr. 182.)



Operation example Operate at 3000r/min.

Operation

5

- Screen at power-ON
The monitor display appears.
- Assignment of the AU signal (current input) (Refer to the step 3 for voltage input.)
Set Pr. 160 to "0" to activate extended parameters.
To assign the AU signal, set "4" in one of Pr. 178 to Pr. 182. (Refer to page 4 to change the setting.)
Turn ON the AU signal.
- Easy operation mode setting
Press **PU/EXT** and **MODE** for 0.5s. "09 - -" appears, and the [PRM] indicator blinks.
- Operation mode selection
Turn **SEL** until "09 - 4" appears. [PU] and [PRM] indicators blink.
- Operation mode setting
Press **SET** to enter the setting. (Set "4" in Pr.79.)
"09 - 4" and "09 - -" are displayed alternately. [PU] and [EXT] indicators are lit.
- Start
Press **RUN**. [RUN] blinks fast as no speed command is given.
- Acceleration → constant speed
For voltage input, turn the potentiometer (speed setting potentiometer) clockwise slowly to full.
For current input, input 20mA.
The speed value on the display increases in Pr. 7 Acceleration time, and "3000" (3000r/min) appears.
[RUN] indicator is lit during forward rotation operation and blinks slowly during reverse rotation operation.
- Deceleration
For voltage input, turn the potentiometer (speed setting potentiometer) counterclockwise slowly to full.
For current input, input 4mA.
The speed value on the display decreases in Pr. 8 Deceleration time, and the motor stops rotating with "0" (0r/min) displayed.
[RUN] blinks fast.
- Stop
Press **STOP/RESET**. [RUN] indicator turns OFF.



REMARKS

- The speed at the full clockwise turn of the potentiometer (speed setting potentiometer) (maximum potentiometer setting) is 3000r/min in the initial setting. (To change the setting, use Pr.125.) (Refer to page 28.)
- For current input, the speed at 20mA input is 3000r/min in the initial setting. (To change the setting, use Pr. 126.) (Refer to Chapter 4 of the Instruction Manual (Applied).)
- To input 10VDC to the terminal 2, set Pr. 73 Analog input selection = "0". The initial value is "1 (0 to 5V input)". (Refer to Chapter 4 of the Instruction Manual (Applied).)

5.2 Start and stop using terminals (External operation)



POINT

From where is the speed command given?

- Operation at the speed set in the speed setting mode of the operation panel Refer to 5.2.1 (refer to page 25).
- Give a speed command by switch (multi-speed setting) Refer to 5.2.2 (refer to page 26).
- Perform speed setting by a voltage input signal Refer to 5.2.3 (refer to page 27).
- Perform speed setting by a current input signal Refer to 5.2.3 (refer to page 27).


5.2.1 Setting the speed by the operation panel (Pr. 79 = 3)



POINT

- Switch ON the STF(STR) signal to give a start command.
- Use the operation panel to give a speed command.
- Set "3" (External/PU combined operation mode 1) in Pr. 79.

[Connection diagram]



Operation example Operate at 900r/min.

Operation

- Screen at power-ON
The monitor display appears.
- Easy operation mode setting
Press and for 0.5s. "79 - -" appears, and the [PRM] indicator blinks.
- Operation mode selection
Turn until "79 - 3" appears. [EXT] and [PRM] indicators blink.
- Operation mode setting
Press to enter the setting. (Set "3" in Pr.79.)
"79 - 3" and "79 - -" are displayed alternately. [PU] and [EXT] indicators are lit.
- Speed setting
Turn to show the speed "900" you want to set. The indication blinks for about 5s. While the indication is flashing, press to set the speed. "F" and "900" are displayed alternately. After about 3s of alternate display, the monitor display goes back to "0" (monitor display). (If is not pressed, the monitor display goes back to "0" (0r/min) after about 5s of flashing. In that case, turn again, and set the speed.)
- Start → acceleration → constant speed
Turn the start switch (STF or STR) ON.
The speed value on the display increases in Pr. 7 Acceleration time, and "900" (900r/min) appears. [RUN] indicator is lit during forward rotation operation and blinks during reverse rotation operation. (To change the set speed, perform the operation in above step 5. Starting from the previously set speed.)
- Deceleration → stop
Turn OFF the start switch (STF or STR). The speed value on the indication decreases in Pr. 8 Deceleration time, and the motor stops rotating with "0" (0r/min) displayed. [RUN] turns OFF.



5.2.2 Setting the speed by switches (three-speed setting) (Pr. 4 to Pr. 6)



POINT

- Switch ON the STF (STR) signal to give a start command.
- Switch ON the RH, RM, or RL signal to give a speed command.

[Connection diagram]



Operation example Operation at high speed (3000r/min)

Operation

1. Screen at power-ON
The monitor display appears.
2. Speed setting
Turn ON the high-speed switch (RH).
Start → Acceleration → constant speed
Turn ON the start switch (STF or STR). The speed value on the indication increases in Pr. 7 Acceleration time, and "3000"
(3000r/min) appears.
[RUN] indicator is lit during forward rotation operation and blinks during reverse rotation operation.
 - When RM is turned ON, 1500r/min is displayed. When RL is turned ON, 300r/min is displayed.
3. Deceleration → Stop
4. Turn OFF the start switch (STF or STR). The speed value on the indication decreases in Pr. 8 Deceleration time, and the motor stops rotating with "0" (0r/min) displayed. [RUN] turns OFF.
5. Speed setting(OFF)
Turn OFF the high-speed switch (RH).



REMARKS

- Initial values of terminals RH, RM, RL are 3000r/min, 1500r/min, and 300r/min. (To change, set Pr. 4, Pr. 5, and Pr. 6.)
- In the initial setting, when two or three of multi-speed settings are simultaneously selected, priority is given to the set speed of the lower signal.
For example, when the RH and RM signals turn ON, the RM signal (Pr. 5) has a higher priority.
- Maximum of 15-speed operation can be performed. (Refer to Chapter 4 of the Instruction Manual (Applied).)

5.2.3 Setting the speed by analog input (voltage input/current input)




POINT

- Turn ON the STF(STR) signal to give a start command.
- Use the potentiometer (speed setting potentiometer) (voltage input) or 4-to-20mA input (current input) to give a speed command.


[Connection example for voltage input]

(The drive unit supplies 5V power to the speed setting potentiometer. (terminal 10))



[Connection example for current input]

Assign the AU signal in one of Pr. 178 to Pr. 182.



Operation example Operate at 3000r/min.

Operation

1.	Screen at power-ON The monitor display appears.
2.	Assignment of the AU signal (current input) (Refer to the step 3 for voltage input.) Set Pr. 160 to "0" to activate extended parameters. To assign the AU signal, set "4" in one of Pr. 178 to Pr. 182. (Refer to page 4 to change the setting.) Turn ON the AU signal.
3.	Start Turn the start switch (STF or STR) ON. [RUN] blinks fast because the speed command is not given.
4.	Acceleration → constant speed For voltage input, turn the potentiometer (speed setting potentiometer) clockwise slowly to full. For current input, input 20mA. The speed value on the display increases in Pr. 7 Acceleration time, and "3000" (3000r/min) appears. [RUN] indicator is lit during forward rotation operation and blinks slowly during reverse rotation operation.
5.	Deceleration For voltage input, turn the potentiometer (speed setting potentiometer) counterclockwise slowly to full. For current input, input 4mA. The speed value on the display decreases in Pr. 8 Deceleration time, and the motor stops rotating with "0" (0r/min) displayed. [RUN] blinks fast.
6.	Stop Turn the start switch (STF or STR) OFF. [RUN] turns OFF.



REMARKS






- For voltage input, the speed (maximum potentiometer setting) at the full right turn of the (speed setting) potentiometer is 3000r/min in the initial setting. (To change the setting, use Pr.125.) (Refer to page 28.)
- For current input, the speed at 20mA input is 3000r/min in the initial setting. (To change the setting, use Pr. 126.) (Refer to Chapter 4 of the Instruction Manual (Applied).)
- To input 10VDC to the terminal 2, set Pr.73 Analog input selection = "0". The initial value is "1" (0 to 5V input). (Refer to Chapter 4 of the Instruction Manual (Applied).)
- To always select the External operation mode, set Pr. 79 Operation mode selection = "2 (External operation mode)".

5.2.4 Setting the speed at the maximum potentiometer indication

< How to change the maximum speed >


Changing example When you want to use 0 to 5VDC input speed setting potentiometer to change the speed at 5V from 3000r/min (initial value) to 2100r/min, make adjustment to output "2100r/min" at 5V voltage input. Set "2100r/min" in Pr. 125.

Operation


Parameter selection	
1.	Turn  until "P. 125" (Pr. 125) appears. Press  to show the present set value "3000" (3000r/min).
Changing the maximum speed	
2.	Turn  to change the set value to "2100"(2100r/min). Press  to enter. "2100" and "P. 125" are displayed alternately.
Mode/monitor check	
3.	Press  twice to choose the monitor/speed monitor.
Start	
4.	Turn the start switch (STF or STR) ON. [RUN] blinks fast because the speed command is not given.
Acceleration → constant speed	
5.	Turn the potentiometer (speed setting potentiometer) clockwise slowly to full. The speed value on the display increases in Pr. 7 Acceleration time, and "2100"(2100r/min) appears. [RUN] indicator is lit during forward rotation operation and blinks slowly during reverse rotation operation.
Deceleration	
6.	Turn the potentiometer (speed setting potentiometer) counterclockwise slowly to full. The speed value on the display decreases in Pr. 8 Deceleration time, and the motor stops rotating with "0" (0r/min) displayed. [RUN] blinks fast.
Stop	
7.	Turn the start switch (STF or STR) OFF. [RUN] turns OFF.


REMARKS


- Use calibration parameter C2 to set speed at 0V and calibration parameter C0 to adjust the meter.

( Refer to Chapter 4 of the Instruction Manual (Applied).)



- To input 10VDC to the terminal 2, set Pr.73 Analog input selection = "0". The initial value is "1 (0 to 5V input)".

( Refer to Chapter 4 of the Instruction Manual (Applied).)





- As other adjustment methods of speed setting voltage gain, there are methods to adjust with a voltage applied to across terminals 2 and 5 and a method to adjust at any point without a voltage applied. ( Refer to Chapter 4 of the Instruction Manual (Applied) for the setting method of calibration parameter C4.)


? Change the speed (3000r/min) at the maximum current input (20mA in the initial setting)

 Adjust it with Pr.126 Terminal 4 speed setting gain speed. ( Refer to Chapter 4 of the Instruction Manual (Applied).)

? Change the speed (0r/min) at the minimum current input (4mA in the initial setting)

 Adjust with the calibration parameter C5 Terminal 4 speed setting bias speed. ( Refer to Chapter 4 of the Instruction Manual (Applied).)

6 PARAMETERS

Simple variable-speed operation can be performed with the drive unit in the initial settings. Set the required parameters according to the load and operating conditions. Use the operation panel to set or change a parameter. (Refer to  Chapter 4 of the Instruction Manual (Applied) for the detailed description of parameters.)

6.1 Simple mode parameters



POINT

In the initial setting, only the simple mode parameters are displayed by the Pr.160 Extended function display selection setting. Change the Pr.160 Extended function display selection setting as required. (Refer to page 4 to change the parameter.)

Parameter Number	Name	Increments	Initial Value	Range	Application
1	Maximum setting	1r/min	3000r/min	0 to 12000r/min / 0 to 8000r/min *1	Use this parameter to set the upper limit for the rotation speed.
2	Minimum setting	1r/min	0r/min	0 to 3600r/min / 0 to 2400r/min *1	Use this parameter to set the lower limit for the rotation speed.
4	Multi-speed setting (high speed)	1r/min	3000r/min	0 to 12000r/min / 0 to 8000r/min *1	Use these parameters to change among pre-set operation speeds with the terminals. The speeds are pre-set with parameters.
5	Multi-speed setting (middle speed)	1r/min	1500r/min	0 to 12000r/min / 0 to 8000r/min *1	
6	Multi-speed setting (low speed)	1r/min	300r/min	0 to 12000r/min / 0 to 8000r/min *1	
7	Acceleration time	0.1s	5s	0 to 3600s	Use these parameters to set the acceleration/ deceleration time.
8	Deceleration time	0.1s	5s	0 to 3600s	
9	Electronic thermal O/L relay	0.01A	Rated motor current	0 to 500A	With this parameter, the drive unit protects the motor from heat. Set the rated motor current.
79	Operation mode selection	1	0	0	External/PU switchover mode
				1	Fixed to PU operation mode
				2	Fixed to External operation mode
				3	External/PU combined operation mode 1 (Start command from External, speed command from PU)
				4	External/PU combined operation mode 2 (Speed command from External, start command from PU)
				6	Switchover mode
				7	External operation mode (PU operation interlock)
125	Terminal 2 speed setting gain speed	1r/min	3000r/min	0 to 12000r/min / 0 to 8000r/min *1	Use this parameter to change the speed at the maximum potentiometer setting (5V in the initial setting)
126	Terminal 4 speed setting gain speed	1r/min	3000r/min	0 to 12000r/min / 0 to 8000r/min *1	Use this parameter to change the speed at the maximum current input (20mA in the initial setting)
160	Extended function display selection	1	9999	0	Simple mode + extended mode parameters are displayed.
				9999	Only the simple mode parameters are displayed.
999	Automatic parameter setting	1	9999	10, 9999	Communication parameter settings for Mitsubishi Electric's human machine interface (GOT) connection are changed as a batch.
Pr.CL	Parameter clear	1	0	0, 1	Setting "1" returns all parameters except calibration parameters to the initial values.
ALLC	All parameter clear	1	0	0, 1	Setting "1" returns all parameters to the initial values.
Er.CL	Fault history clear	1	0	0, 1	Setting "1" clears eight past faults.
Pr.CH	Initial value change list	—	—	—	Displays and sets the parameters changed from the initial value.
PM	PM parameter initialization	1	6004	6004, 8009, 9009 *2	The setting of the motor parameters can be changed to the initial setting required to control a PM motor.
AUTO	Automatic parameter setting	—	—	—	The setting of the communication parameters can be changed to the initial setting required for connection of the Mitsubishi Electric's human machine interface (GOT).

*1 The value left of the slash is for the 2.2K drive unit or lower. The one right of the slash is for the 3.7K drive unit.

*2 Settings "8009" and "9009" can be displayed after offline auto tuning is performed.

6.2 Parameter list



REMARKS

- ● indicates simple mode parameters.
- The parameters surrounded by a black border in the table allow its setting to be changed during operation even if "0" (initial value) is set in Pr. 77 Parameter write selection.

Parameter	Name	Setting Range	Initial Value
● 1	Maximum setting	0 to 1200r/min / 0 to 8000r/min +1	3000r/min
● 2	Minimum setting	0 to 3600r/min / 0 to 2400r/min +1	0r/min
● 4	Multi-speed setting (high speed)	0 to 12000r/min / 0 to 8000r/min +1	3000r/min
● 5	Multi-speed setting (middle speed)	0 to 12000r/min / 0 to 8000r/min +1	1500r/min
● 6	Multi-speed setting (low speed)	0 to 12000r/min / 0 to 8000r/min +1	300r/min
● 7	Acceleration time	0 to 3600s	5s
● 8	Deceleration time	0 to 3600s	5s
● 9	Electronic thermal O/L relay	0 to 500A	Rated motor current
10	Coasting speed	0 to 3600r/min / 0 to 2400r/min +1	90r/min
11	DC injection brake operation time	0 to 10s	0.5s
13	Starting speed	0 to 1800r/min / 0 to 1200r/min +1	15r/min
15	Jog speed setting	0 to 12000r/min / 0 to 8000r/min +1	150r/min
16	Jog acceleration/deceleration time	0 to 3600s	0.5s
17	MRS input selection	0, 2, 4	0
20	Acceleration/deceleration reference speed	30 to 12000r/min / 20 to 8000r/min +1	3000r/min
22	Stall prevention operation level	0 to 200%	150%
24	Multi-speed setting (speed 4)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
25	Multi-speed setting (speed 5)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
26	Multi-speed setting (speed 6)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
27	Multi-speed setting (speed 7)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
29	Acceleration/deceleration pattern selection	0 to 2	0
30	Regenerative function selection	0, 1	0
31	Speed jump 1A	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
32	Speed jump 1B	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
33	Speed jump 2A	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
34	Speed jump 2B	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
35	Speed jump 3A	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999

Parameter	Name	Setting Range	Initial Value
36	Speed jump 3B	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
37	Speed display	0, 0.01 to 9998	0
40	RUN key rotation direction selection	0, 1	0
41	Up-to-speed sensitivity	0 to 100%	10%
42	Speed detection	0 to 12000r/min / 0 to 8000r/min +1	180r/min
43	Speed detection for reverse rotation	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
44	Second acceleration/ deceleration time	0 to 3600s	5s
45	Second deceleration time	0 to 3600s, 9999	9999
48	Second stall prevention operation current	0 to 200%, 9999	9999
52	DU/PU main display data selection	0, 5, 8 to 12, 14, 20, 23 to 25, 52 to 55, 61, 62, 64, 100	0
54	FM terminal function selection	1 to 3, 5, 8 to 12, 14, 21, 24, 52, 53, 61, 62	1
55	Speed monitoring reference	0 to 12000r/min / 0 to 8000r/min +1	3000r/min
56	Current monitoring reference	0 to 500A	Rated motor current
59	Remote function selection	0 to 3	0
65	Retry selection	0 to 5	0
67	Number of retries at fault occurrence	0 to 10, 101 to 110	0
68	Retry waiting time	0.1 to 600s	1s
69	Retry count display erase	0	0
70	Special regenerative brake duty	0 to 30%	0%
71	Applied motor	1040, 8090, 9090	1040
73	Analog input selection	0, 1, 10, 11	1
74	Input filter time constant	0 to 8	1
75	Reset selection/disconnected PU detection/PU stop selection	0 to 3, 14 to 17	14
77	Parameter write selection	0 to 2	0
78	Reverse rotation prevention selection	0 to 2	0
● 79	Operation mode selection	0 to 4, 6, 7	0
80	Motor capacity	0.01 to 3.7kW	Motor capacity +2
81	Number of motor poles	2, 4, 6, 8, 10, 9999	9999
83	Rated motor voltage	0 to 1000V	200V / 400V +3
84 +5	Rated motor speed	300 to 6000r/min / 200 to 4000r/min +1, 9999	9999
90	Motor constant (R1)	0 to 50Ω, 9999	9999
92	Motor constant (Ld)	0 to 500mH, 9999	9999

Parameter	Name	Setting Range	Initial Value
93	Motor constant (Lq)	0 to 500mH, 9999	9999
96	Auto tuning setting/status	0, 1	0
117	PU communication station number	0 to 31 (0 to 247)	0
118	PU communication speed	48, 96, 192, 384	192
119	PU communication stop bit length	0, 1, 10, 11	1
120	PU communication parity check	0 to 2	2
121	Number of PU communication retries	0 to 10, 9999	1
122	PU communication check time interval	0, 0.1 to 999.8s, 9999	0s
123	PU communication waiting time setting	0 to 150ms, 9999	9999
124	PU communication CR/LF selection	0 to 2	1
⊙ 125	Terminal 2 speed setting gain speed	0 to 12000r/min / 0 to 8000r/min +1	3000r/min
⊙ 126	Terminal 4 speed setting gain speed	0 to 12000r/min / 0 to 8000r/min +1	3000r/min
127	PID control automatic switchover speed	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
128	PID action selection	0, 20, 21	0
129	PID proportional band	0.1 to 1000%, 9999	100%
130	PID integral time	0.1 to 3600s, 9999	1s
131	PID upper limit	0 to 100%, 9999	9999
132	PID lower limit	0 to 100%, 9999	9999
133	PID action set point	0 to 100%, 9999	9999
134	PID differential time	0.01 to 10s, 9999	9999
144	Speed setting switchover	2, 4, 6, 8, 10, 102, 104, 106, 108, 110	104/106 +1
145	PU display language selection	0 to 7	0
150	Output current detection level	0 to 200%	150%
151	Output current detection signal delay time	0 to 10s	0s
152	Zero current detection level	0 to 200%	5%
153	Zero current detection time	0 to 1s	0.5s
156	Stall prevention operation selection	0 to 31, 100, 101	0
157	OL signal output timer	0 to 25s, 9999	0s
⊙ 160	Extended function display selection	0, 9999	9999
161	Speed setting/key lock operation selection	0, 1, 10, 11	0
166	Output current detection signal retention time	0 to 10s, 9999	0.1s
167	Output current detection operation selection	0, 1, 10, 11	0
168	Parameter for manufacturer setting. Do not set.		
169	Parameter for manufacturer setting. Do not set.		
170	Watt-hour meter clear	0, 10, 9999	9999
171	Operation hour meter clear	0, 9999	9999

Parameter	Name	Setting Range	Initial Value
178	STF terminal function selection	0 to 5, 7, 8, 10, 12, 14, 16, 23 to 25,	60
179	STR terminal function selection	60(Pr.178),	61
180	RL terminal function selection	61(Pr.179),	0
181	RM terminal function selection	62, 64 to 67,	1
182	RH terminal function selection	72, 9999	2
190	RUN terminal function selection	0, 1, 3, 4, 7, 8, 11 to 16, 20, 21, 25, 26, 33, 37, 47, 48, 64, 70, 79, 90, 91, 93(Pr.190), 95, 96, 98 to 101, 103, 104, 107, 108,	0
192	A, B, C terminal function selection	111 to 116, 120, 121, 125, 126, 133, 137, 147, 148, 164, 170, 179, 190, 191, 193(Pr.190), 195, 196, 198, 199, 9999	99
232	Multi-speed setting (speed 8)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
233	Multi-speed setting (speed 9)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
234	Multi-speed setting (speed 10)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
235	Multi-speed setting (speed 11)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
236	Multi-speed setting (speed 12)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
237	Multi-speed setting (speed 13)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
238	Multi-speed setting (speed 14)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
239	Multi-speed setting (speed 15)	0 to 12000r/min / 0 to 8000r/min +1, 9999	9999
241	Analog input display unit switchover	0, 1	0
244	Cooling fan operation selection	0, 1	1
249	Earth (ground) fault detection at start	0, 1	0
250	Stop selection	0 to 100s, 1000 to 1100s, 8888, 9999	9999
251	Output phase loss protection selection	0, 1	1
255	Life alarm status display	(0 to 15)	0
256	Inrush current limit circuit life display	(0 to 100%)	100%
257	Control circuit capacitor life display	(0 to 100%)	100%
258	Main circuit capacitor life display	(0 to 100%)	100%
259	Main circuit capacitor life measuring	0, 1 (2, 3, 8, 9)	0
267	Terminal 4 input selection	0 to 2	0
268	Monitor decimal digits selection	0, 1, 9999	9999
269	Parameter for manufacturer setting. Do not set.		
281	Brake operation time at start	0 to 1s	0s

Parameter	Name	Setting Range	Initial Value
283	Brake operation time at stop	0 to 1s	0s
295	Magnitude of speed change setting	0, 0.01, 0.10, 1.00, 10.00	0
296	Password lock level	1 to 6, 101 to 106, 9999	9999
297	Password lock/unlock	1000 to 9998 (0 to 5, 9999)	9999
338	Communication operation command source	0, 1	0
339	Communication speed command source	0 to 2	0
340	Communication startup mode selection	0, 1, 10	0
342	Communication EEPROM write selection	0, 1	0
343	Communication error count	—	0
374	Overspeed detection level	0 to 12000r/min / 0 to 8000r/min ⁺¹	3450r/min
495	Remote output selection	0, 1, 10, 11	0
496	Remote output data 1	0 to 4095	0
502	Stop mode selection at communication error	0 to 3	0
503	Maintenance timer	0 (1 to 9998)	0
504	Maintenance timer alarm output set time	0 to 9998, 9999	9999
505	Speed setting reference	1 to 200Hz	100Hz/150Hz ⁺¹
520	Parameter for manufacturer setting. Do not set.		
549	Protocol selection	0, 1	0
551	PU mode operation command source selection	2, 4, 9999	9999
553	PID deviation limit	0 to 100%, 9999	9999
554	PID signal operation selection	0 to 3, 10 to 13	0
555	Current average time	0.1 to 1s	1s
556	Data output mask time	0 to 20s	0s
557	Current average value monitor signal output reference current	0 to 500A	Rated motor current
561	PTC thermistor protection level	0.5 to 30k Ω , 9999	9999
563	Energization time carrying-over times	(0 to 65535)	0
564	Operating time carrying-over times	(0 to 65535)	0
575	Output interruption detection time	0 to 3600s, 9999	1s
576	Output interruption detection level	0 to 12000r/min / 0 to 8000r/min ⁺¹	0r/min
577	Output interruption cancel level	900 to 1100%	1000%
600	Free thermal reduction speed 1	0 to 12000r/min / 0 to 8000r/min ⁺¹ , 9999	9999
601	Free thermal reduction ratio 1	1 to 100%	100%
602	Free thermal reduction speed 2	0 to 12000r/min / 0 to 8000r/min ⁺¹ , 9999	9999
603	Free thermal reduction ratio 2	1 to 100%	100%
604	Free thermal reduction speed 3	0 to 12000r/min / 0 to 8000r/min ⁺¹ , 9999	9999
643	Voltage compensation amount setting	0 to 150%, 9999	9999
658	Wiring resistance	0 to 5 Ω , 9999	9999
665	Regeneration avoidance speed gain	0 to 200%	100
672 ⁺⁵	Lq tuning target current adjustment coefficient	50 to 150%, 9999	9999

Parameter	Name	Setting Range	Initial Value
702	Maximum motor speed	0 to 6000r/min / 0 to 4000r/min ⁺¹ , 9999	9999
706	Induced voltage constant (ϕ f)	0 to 500mV ^{-s} /rad, 9999	9999
707	Motor inertia (integer)	10 to 999, 9999	9999
711	Motor Ld decay ratio	0 to 100%, 9999	9999
712	Motor Lq decay ratio	0 to 100%, 9999	9999
717 ⁺⁵	Starting resistance tuning compensation	0 to 200%, 9999	9999
721	Starting magnetic pole position detection pulse width	0 to 6000 μ s, 9999	9999
724 ⁺⁵	Motor inertia (exponent)	4 to 7, 9999	9999
725	Motor protection current level	0 to 500%, 9999	9999
726	Motor induced voltage constant (ϕ f) exponent	0 to 2, 9999	9999
736	Electromagnetic brake interlock time	0 to 1s	0s
779	Operation speed during communication error	0 to 12000r/min / 0 to 8000r/min ⁺¹ , 9999	9999
785	PM control torque boost	0 to 150%, 9999	9999
791	Acceleration time in low-speed range	0 to 3600s, 9999	9999
792	Deceleration time in low-speed range	0 to 3600s, 9999	9999
795	DC brake torque boost	0 to 150%, 9999	9999
799	Pulse increment setting for output power	0.1kWh, 1kWh, 10kWh, 100kWh, 1000kWh	1kWh
800	Control method selection	9, 30	30
820	Speed control P gain	0 to 1000%	15%
821	Speed control integral time	0 to 20s	0.333s
824	Torque control P gain (current loop proportional gain)	0 to 200%, 9999	9999
825	Torque control integral time (current loop integral time)	0 to 500ms, 9999	9999
859	Rated PM motor current	0 to 500A, 9999	9999
870	Speed detection hysteresis	0 to 150r/min / 0 to 100r/min ⁺¹	15r/min
872	Input phase loss protection selection	0, 1	0
882	Regeneration avoidance operation selection	0 to 2	0
883	Regeneration avoidance operation level	300 to 800V	400VDC/780VDC ⁺³
885	Regeneration avoidance compensation speed limit value	0 to 900r/min / 0 to 600r/min ⁺¹ , 9999	180r/min
886	Regeneration avoidance voltage gain	0 to 200%	100%
888	Free parameter 1	0 to 9999	9999
889	Free parameter 2	0 to 9999	9999
891	Cumulative power monitor digit shifted times	0 to 4, 9999	9999
C0 (900) ⁺⁴	FM terminal calibration	—	—
C2 (902) ⁺⁴	Terminal 2 speed setting bias speed	0 to 12000r/min / 0 to 8000r/min ⁺¹	0r/min
C3 (902) ⁺⁴	Terminal 2 speed setting bias	0 to 300%	0%
125 (903) ⁺⁴	Terminal 2 speed setting gain	0 to 12000r/min / 0 to 8000r/min ⁺¹	3000r/min

Parameter	Name	Setting Range	Initial Value
C4 (903) *4	Terminal 2 speed setting gain	0 to 300%	100%
C5 (904) *4	Terminal 4 speed setting bias speed	0 to 12000r/min / 0 to 8000r/min *1	0r/min
C6 (904) *4	Terminal 4 speed setting bias	0 to 300%	20%
126 (905) *4	Terminal 4 speed setting gain speed	0 to 12000r/min / 0 to 8000r/min *1	3000r/min
C7 (905) *4	Terminal 4 speed setting gain	0 to 300%	100%
C42 (934) *4	PID display bias coefficient	0 to 500, 9999	9999
C43 (934) *4	PID display bias analog value	0 to 300%	20%
C44 (935) *4	PID display gain coefficient	0 to 500, 9999	9999
C45 (935) *4	PID display gain analog value	0 to 300%	100%
990	PU buzzer control	0, 1	1
991	PU contrast adjustment	0 to 63	58
997	Fault initiation	16 to 18, 32 to 34, 48, 49, 64, 82, 96, 97, 112, 128, 129, 144, 145, 176 to 178, 192, 196, 197, 199, 201, 208, 230, 245, 9999	9999
998	PM parameter initialization	6004, 6104, 8009, 8109, 9009, 9109	6004
⊙ 999	Automatic parameter setting	10, 9999	9999
⊙ Pr.CL	Parameter clear	0, 1	0
⊙ ALLC	All parameter clear	0, 1	0
⊙ Er.CL	Fault history clear	0, 1	0
⊙ Pr.CH	Initial value change list	—	—
⊙ PM *6	PM parameter initialization	6004, 8009, 9009	6004
⊙ AUTO	Automatic parameter setting	—	—

- *1 The value left of the slash is for the 2.2K drive unit or lower. The one right of the slash is for the 3.7K drive unit.
- *2 The capacity of the S-PM geared motor is initially set to the next smaller size than the capacity of the drive unit.
- *3 The value left of the slash is for the 200V class drive unit. The one right of the slash is for the 400V class drive unit.
- *4 The parameter number in parentheses is the one for use with the parameter unit (FR-PU07).
- *5 While the parameter settings copied to the latest version drive unit (manufactured in April 2018 or later) are verified against the parameter settings copied to the parameter unit (FR-PU07) from the older version drive unit (manufactured in March 2018 or earlier) after the parameter settings are copied, a verification error about parameters marked with *5 will be displayed. However, these errors are not faults. Press "0" on the parameter unit to proceed the verification. (For information about Parameter copy and Parameter verification, refer to the Instruction Manual of the parameter unit.)
Copying the parameter settings from the latest version drive unit to the older version drive unit is prohibited. If doing so, reset the copied parameter settings by performing Parameter clear or All parameter clear.
- *6 Settings "8009" and "9009" can be displayed after offline auto tuning is performed.



REMARKS

- The unit for parameter setting and its setting range can be changed from "r/min" to "Hz". Use Pr.144 to change the setting.
- With operation panel, the value up to 9999 can be set. With parameter unit (FR-PU07), up to the highest value in the setting range can be set.
- A value exceeding 3000r/min can be also set, but the actual operation will be limited at 3000r/min, which is the upper speed limit of the motor.

7 TROUBLESHOOTING

When a fault occurs in the drive unit, the drive unit trips and the PU display automatically changes to one of the following fault or alarm indications.

If the fault does not correspond to any of the following faults or if you have any other problem, please contact your sales representative.

- Retention of fault output signal .. When the magnetic contactor (MC) provided on the input side of the drive unit is opened at a fault occurrence, the drive unit's control power will be lost and the fault output will not be held.
- Fault or alarm indication.....When a fault or alarm occurs, the operation panel display automatically switches to the fault or alarm indication.
- Resetting method.....When a fault occurs, the drive unit output is kept stopped. Unless reset, therefore, the drive unit cannot restart. (Refer to page 34.)
- When any fault occurs, take the appropriate corrective action, then reset the drive unit, and resume operation.
Not doing so may lead to the drive unit fault and damage.

drive unit fault or alarm indications are roughly categorized as below.

- (1) Error message
A message regarding operational fault and setting fault by the operation panel and parameter unit (FR-PU07) is displayed. The drive unit does not trip.
- (2) Warning
The drive unit does not trip even when a warning is displayed. However, failure to take appropriate measures will lead to a fault.
- (3) Alarm
The drive unit does not trip. You can also output an alarm signal by making parameter setting.
- (4) Fault
When a fault occurs, the drive unit trips and a fault signal is output.


REMARKS

- For the details of fault displays and other malfunctions, also refer to the Instruction Manual (Applied).
- Past eight faults can be displayed using the setting dial. (Refer to page 3 for the operation.)

7.1 Reset method of protective function

(1) Resetting the drive unit


The drive unit can be reset by performing any of the following operations. Note that the internal thermal integrated value of the electronic thermal relay function and the number of retries are cleared (erased) by resetting the drive unit. Drive unit recovers about 1s after the reset is released.

Operation 1: Using the operation panel, press  to reset the drive unit.

(This may only be performed when a fault occurs (refer to page 35 for fault).)

Operation 2: Switch power OFF once. After the indicator of the operation panel turns OFF, switch it ON again.

Operation 3: Turn ON the reset signal (RES) for more than 0.1s. (If the RES signal is kept ON, "Err." appears (blinks) to indicate that the drive unit is in a reset status.)



NOTE

- OFF status of the start signal must be confirmed before resetting the drive unit fault. Resetting drive unit fault with the start signal ON restarts the motor suddenly.

7.2 List of fault displays




When a fault occurs, the drive unit trips and the PU display automatically changes to one of the following fault or alarm indications.

The error message shows an operational error. The drive unit output is not shut off.

Warnings are messages given before faults occur. The drive unit output is not shut off.

Alarms warn the operator of failures with output signals. The drive unit output is not shut off.

When faults occur, the protective functions are activated to drive unit trip and output the fault signals.

Function Name	Description	Countermeasure	Display	
Error message	Operation panel lock	Operation has been attempted during the operation panel lock.	Press  for 2s to release lock.	HOL d
	Password locked	Reading/writing of a password-restricted parameter has been attempted.	Enter the password in Pr. 297 Password lock/unlock to unlock the password function before operating.	LOL d
	Write disable error	<ul style="list-style-type: none"> Parameter setting has been attempted although parameter writing is set to be disabled. Overlapping range has been set for the speed jump. PU and the drive unit cannot make normal communication. 	<ul style="list-style-type: none"> Check the setting of Pr. 77 Parameter write selection. Check the setting of Pr. 31 to Pr. 36 (speed jump). Check the connection of PU and the drive unit. 	Er 1
	Write error during operation	Parameter writing has been attempted while a value other than "2" is set in Pr. 77 Parameter write selection and the STF (STR) is ON.	<ul style="list-style-type: none"> Set "2" in Pr. 77 Parameter write selection. After stopping the operation, set parameters. 	Er 2
	Calibration error	Analog input bias and gain calibration values have been set too close.	Check the settings of calibration parameters C3, C4, C6 and C7 (calibration functions).	Er 3
	Mode designation error	<ul style="list-style-type: none"> Parameter setting has been attempted in the External or NET operation mode when Pr. 77 Parameter write selection is not "2." Parameter writing has been attempted when the command source is not at the operation panel. 	<ul style="list-style-type: none"> After setting the operation mode to the "PU operation mode", set parameters. Set "2" in Pr. 77 Parameter write selection. Remove the parameter unit (FR-PU07), then set the Pr. 551 PU mode operation command source selection = "9999 (initial setting)." Set Pr. 551 PU mode operation command source selection = "4." 	Er 4
	Drive unit reset	The reset signal (RES signal) is ON. (drive unit output is shutoff.)	<ul style="list-style-type: none"> Turn OFF the reset command. 	Er r.
Warning	Stall prevention (overcurrent)	The overcurrent stall prevention has been activated.	<ul style="list-style-type: none"> Set Pr.7 Acceleration time and Pr.8 Deceleration time longer. Reduce the load Set the stall prevention operation current in Pr. 22 Stall prevention operation level. (The acceleration/deceleration time may change.) Increase the stall prevention operation level with Pr. 22 Stall prevention operation level, or disable stall prevention with Pr. 156 Stall prevention operation selection. (Operation at OL occurrence can be selected using Pr. 156 Stall prevention operation selection.) Check the connection of the PM motor. 	OL
	Stall prevention (overvoltage)	The overvoltage stall prevention function or the regeneration avoidance function has been activated. (This warning is also output during the regeneration avoidance operation.)	Set the deceleration time longer.	oL
	Regenerative brake pre-alarm *2	The regenerative brake duty has reached 85% of the Pr. 70 Special regenerative brake duty setting or higher.	<ul style="list-style-type: none"> Set the deceleration time longer. Check the Pr.30 Regenerative function selection and Pr. 70 Special regenerative brake duty settings. 	r b
	Electronic thermal relay function pre-alarm *1	The cumulative value of the electronic thermal O/L relay has reached 85% of the Pr. 9 Electronic thermal O/L relay setting or higher.	<ul style="list-style-type: none"> Reduce the load and frequency of operation. Set an appropriate value in Pr. 9 Electronic thermal O/L relay. 	r H
	PU stop	 on the operation panel has been pressed during the External operation.	Turn the start signal OFF and release with  .	P S
	Maintenance signal output *2	The cumulative energization time has exceeded the maintenance output timer set value.	Setting "0" in Pr. 503 Maintenance timer erases the signal.	M F
	Undervoltage	The voltage at the main circuit power has been lowered.	Investigate the devices on the power supply line such as the power supply itself.	U U
SA	The shorting wire across the terminals S1 and SC or the terminals S2 and SC is disconnected.	Short across the terminals S1 and SC and the terminals S2 and SC with shortening wires.	S R	
Alarm	Fan alarm	The cooling fan is at a standstill although it is required to be operated. Cooling fan speed has decelerated.	Check for fan failure. Please contact your sales representative.	F n

	Function Name	Description	Countermeasure	Display
Fault	Overcurrent trip during acceleration	Overcurrent has occurred during acceleration.	<ul style="list-style-type: none"> • Set the acceleration time longer. (Shorten the downward acceleration time in vertical lift application.) • If "E.OC1" always appears at start, disconnect the motor once and restart the drive unit. If "E.OC1" still appears, the drive unit may be faulty. Contact your sales representative. • Check the wiring for output short circuit and ground fault. • Change the setting to enable the stall prevention operation. (Pr.156) • Lower the stall prevention operation level. • Choose drive unit and motor capacities that match. • If the motor is coasting, stop the motor, then input a start command. 	E.OC 1
	Overcurrent trip during constant speed	Overcurrent has occurred during constant speed operation.	<ul style="list-style-type: none"> • Keep the load stable • Check the wiring to avoid output short circuit or ground fault. • Change the setting to enable the stall prevention operation. (Pr.156) • Lower the stall prevention operation level. • Choose drive unit and motor capacities that match. • If the motor is coasting, stop the motor, then input a start command. 	E.OC 2
	Overcurrent trip during deceleration or stop	Overcurrent has occurred during deceleration or at a stop.	<ul style="list-style-type: none"> • Set the deceleration time longer. • Check the wiring to avoid output short circuit or ground fault. • Check if the mechanical brake is set to be activated too early. • Change the setting to enable the stall prevention operation. (Pr.156) • Lower the stall prevention operation level. • Choose drive unit and motor capacities that match. • If the motor is coasting, stop the motor, then input a start command. 	E.OC 3
	Regenerative overvoltage trip during acceleration	Overvoltage has occurred during acceleration.	<ul style="list-style-type: none"> • Set the acceleration time shorter. • Use the regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886). • Set the Pr. 22 Stall prevention operation level correctly. 	E.OV 1
	Regenerative overvoltage trip during constant speed	Overvoltage has occurred during constant speed operation.	<ul style="list-style-type: none"> • Keep the load stable • Use the regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886). • Use the brake resistor, brake unit or power regeneration common converter (FR-CV) as required. • Set the Pr. 22 Stall prevention operation level correctly. 	E.OV 2
	Regenerative overvoltage trip during deceleration or stop	Overvoltage has occurred during deceleration or at a stop.	<ul style="list-style-type: none"> • Set the deceleration time longer. (Set the deceleration time which matches the moment of inertia of the load.) • Make the brake cycle longer. • Use the regeneration avoidance function (Pr. 882, Pr. 883, Pr. 885, Pr. 886). • Use the brake resistor, brake unit or power regeneration common converter (FR-CV) as required. 	E.OV 3

Function Name	Description	Countermeasure	Display	
Fault	Drive unit overload trip (electronic thermal O/L relay function) *1	The electronic thermal relay function for drive unit element protection has been activated.	<ul style="list-style-type: none"> Set the acceleration time longer. Adjust the <i>Pr.785 PM control torque boost</i> and <i>Pr.795 DC brake torque boost</i> settings. Reduce the load. Set the surrounding air temperature to within the specifications. 	E _F H _F
	Motor overload trip (electronic thermal O/L relay function) *1	The electronic thermal relay function for motor protection has been activated.	<ul style="list-style-type: none"> Reduce the load. Adjust the <i>Pr.785 PM control torque boost</i> and <i>Pr.795 DC brake torque boost</i> settings. Set the stall prevention operation level accordingly. 	E _F H _M
	Heatsink overheat	The heatsink has overheated.	<ul style="list-style-type: none"> Set the surrounding air temperature to within the specifications. Clean the heatsink. Replace the cooling fan. 	E _F I _o
	Input phase loss *2	One of the three phases on the drive unit input side has been lost. It may also appear if phase-to-phase voltage of the three-phase power input has become largely unbalanced.	<ul style="list-style-type: none"> Wire the cables properly. Repair a break portion in the cable. Check the <i>Pr. 872 Input phase loss protection selection</i> setting. Set <i>Pr. 872 Input phase loss protection selection</i> = "0" (without input phase loss protection) when three-phase input voltage is largely unbalanced. 	E _I L _F
	Stall prevention stop	The rotation speed has dropped to 15r/min as a result of deceleration due to the excess motor load.	Reduce the load. (Check the <i>Pr. 22 Stall prevention operation level</i> setting.)	E _O L _F
	Loss of synchronism detection	<ul style="list-style-type: none"> Operation has gone out of synchronism. Operation was performed without connecting a motor. 	<ul style="list-style-type: none"> Set the acceleration time longer. Reduce the load. If the motor is coasting, stop the motor, then input a start command. Alternatively, use the automatic restart after instantaneous power failure/flying start function. According to the motor to be used, perform PM parameter initialization. When driving a motor other than the S-PM geared motor, perform offline auto tuning. Check the connection of the PM motor, or set the PM motor test operation. 	E _S O _F
	Brake transistor alarm detection	A fault has occurred in the brake circuit, such as a brake transistor breakage. (In this case, the drive unit must be powered off immediately.)	Replace the drive unit.	E _b E
	Output side earth (ground) fault overcurrent at start *2	An earth (ground) fault has occurred on the drive unit's output side (detected only at a start).	Remedy the ground fault portion.	E _b G _F
	Output phase loss	One of the three phases (U, V, W) on the drive unit's output side (load side) has been lost during drive unit operation.	<ul style="list-style-type: none"> Wire the cables properly. If the motor is coasting, stop the motor, then input a start command. 	E _b L _F
	External thermal relay operation *2	The external thermal relay connected to the OH signal has been activated.	<ul style="list-style-type: none"> Reduce the load and operate less frequently. Even if the relay contacts are reset automatically, the drive unit will not restart unless it is reset. 	E _O H _F
	PTC thermistor operation *2	Resistance of the PTC thermistor connected between the terminal 2 and terminal 10 has reached the <i>Pr.561 PTC thermistor protection level</i> setting or higher.	Reduce the load.	E _P T _C
Parameter storage device fault	Operation of the component where parameters are stored (control circuit board) has become abnormal.	Please contact your sales representative. When performing parameter writing frequently for communication purposes, set "1" in <i>Pr. 342 Communication EEPROM write selection</i> to enable RAM write. Note that powering OFF returns the drive unit to the status before RAM write.	E _b PE	

Function Name	Description	Countermeasure	Display	
Fault	PU disconnection	<ul style="list-style-type: none"> A communication error has occurred between the PU and the drive unit. The communication interval has exceeded the permissible time period during RS-485 communication via the PU connector. The number of communication errors has exceeded the number of retries. 	<ul style="list-style-type: none"> Connect the parameter unit cable securely. Check the communication data and communication settings. Increase the Pr. 122 PU communication check time interval setting. Or set "9999" (no communication check). 	ErPUE
	Retry count excess *2	Operation restart within the set number of retries has failed.	Eliminate the cause of the error preceding this error indication.	ErERF
	CPU fault	An error has occurred in the CPU and in the peripheral circuits.	<ul style="list-style-type: none"> Take measures against noises if there are devices producing excess electrical noises around the drive unit. If the situation does not improve after taking the above measure, please contact your sales representative. 	Er S / ErCPU
	Output current detection value exceeded *2	Output current has exceeded the output current detection level that is set in the parameter.	Check the settings of Pr. 150 Output current detection level, Pr. 151 Output current detection signal delay time, Pr. 166 Output current detection signal retention time, and Pr. 167 Output current detection operation selection.	ErCDB
	Inrush current limit circuit fault	The resistor of the inrush current limit circuit has overheated.	<p>Configure a circuit where frequent power ON/OFF is not repeated.</p> <p>If the situation does not improve after taking the above measure, please contact your sales representative.</p>	ErDH
	Analog input fault	A voltage (current) has been input to terminal 4 when the setting in Pr. 267 Terminal 4 input selection and the setting of voltage/current input switch are different.	Give a speed command by a current input or set Pr. 267 Terminal 4 input selection, and set the voltage/current input switch to voltage input.	ErA E
	Overspeed occurrence	The motor speed has exceeded the Pr. 374 Overspeed detection level.	Check that the Pr. 374 Overspeed detection level value is correct.	ErOS
	PID signal fault	PID upper limit (FUP), PID lower limit (FDN), or PID deviation limit (Y48) has turned ON.	Make correct settings for Pr.131 PID upper limit, Pr.132 PID lower limit, Pr. 553 PID deviation limit.	ErPI d
E.SAF	<ul style="list-style-type: none"> An internal circuit fault has occurred. Either the contact between terminals S1 and SC or terminals S2 and SC has opened. 	Short across the terminals S1 and SC and the terminals S2 and SC with shortening wires.	ErSAF	


If faults other than the above appear, contact your sales representative.

*1 Resetting the drive unit initializes the internal cumulative heat value of the electronic thermal relay function.

*2 This protective function is not available in the initial status.

7.3 Check first when you have a trouble

Description	Countermeasure
Motor does not start.	Check start and speed command sources and enter a start command (STF, etc.) and a speed command.
Motor or machine is making abnormal acoustic noise.	Take EMC measures if a steady operation cannot be performed due to EMI. Alternatively, set the Pr.74 Input filter time constant setting higher.
Drive unit generates abnormal noise.	Install the fan cover correctly.
Motor generates heat abnormally.	Clean the motor fan. Improve the environment.
Motor rotates in the opposite direction.	Connect phase sequence of the output cables (terminal U, V, W) to the motor correctly. Check the rotation direction specification of the motor's output shaft. Alternatively, check the connection of the start signal. (STF: forward rotation, STR: reverse rotation)
Speed greatly differs from the setting.	Check the settings of Pr.1 Maximum setting, Pr.2 Minimum setting, and calibration parameters C2 to C7.
Acceleration/deceleration is not smooth.	Reduce the load. Alternatively, increase the acceleration/deceleration time. Make adjustments to situate the machine equipment in a more stable place. Eliminate the load fluctuation. Use Pr.156 Stall prevention operation selection to disable stall prevention operation.
Speed varies during operation.	Check the speed setting signals.
Operation mode is not changed properly.	Turn OFF the start signal (STF or STR). Check if Pr.79 Operation mode selection is set appropriately.
Operation panel display is not operating.	Check the wiring and the installation.
Speed does not accelerate.	Check the settings of Pr.1 Maximum setting, Pr.2 Minimum setting, and calibration parameters C2 to C7.
Unable to write parameter setting.	Check Pr.77 Parameter write selection.

* For further information on troubleshooting, refer to the  Instruction Manual (Applied).

8 PRECAUTIONS FOR MAINTENANCE AND INSPECTION

The drive unit is a static unit mainly consisting of semiconductor devices. Daily inspection must be performed to prevent any fault from occurring due to the adverse effects of the operating environment, such as temperature, humidity, dust, dirt and vibration, changes in the parts with time, service life, and other factors.



REMARKS

• For maintenance/inspection and parts life, also refer to the Instruction Manual (Applied).

●Precautions for maintenance and inspection

For some short time after the power is switched OFF, a high voltage remains in the smoothing capacitor. When accessing the drive unit for inspection, wait for at least 10 minutes after the power supply has been switched OFF, and then make sure that the voltage across the main circuit terminals P/+ and N/- of the drive unit is not more than 30VDC using a tester, etc.

8.1 Inspection items

Area of Inspection	Inspection Item	Description	Interval		Corrective Action at Alarm Occurrence	Customer's Check	
			Daily	Periodic *3			
General	Surrounding environment	Check the surrounding air temperature, humidity, dirt, corrosive gas, oil mist, etc.	○		Improve environment		
	Overall unit	Check for unusual vibration and noise.	○		Check alarm location and retighten		
		Check for dirt, oil, and other foreign material.*1	○		Clean		
Power supply voltage	Check that the main circuit voltages are normal.*2	○		Inspect the power supply			
Main circuit	General	(1) Check with megger (across main circuit terminals and earth (ground) terminal). (2) Check for loose screws and bolts. (3) Check for overheat traces on the parts. (4) Check for stain		○	Contact the manufacturer Retighten Contact the manufacturer Clean		
		Conductors, cables	(1) Check conductors for distortion. (2) Check cable sheaths for breakage and deterioration (crack, discoloration, etc.)		○	Contact the manufacturer Contact the manufacturer	
			Terminal block	Check for damage.		○	Stop the device and contact the manufacturer.
		Smoothing aluminum electrolytic capacitor	(1) Check for liquid leakage. (2) Check for safety valve projection and bulge. (3) Visual check and judge by the life check of the main circuit capacitor (Refer to Chapter 4 of the Instruction Manual (Applied).)		○	Contact the manufacturer Contact the manufacturer	
	Relay		Check that the operation is normal and no chatter is heard.		○	Contact the manufacturer	
	Control circuit, Protective circuit	Operation check	(1) Check that the output voltages across phases with the drive unit operated alone is balanced (2) Check that no fault is found in protective and display circuits in a sequence protective operation test.		○	Contact the manufacturer Contact the manufacturer	
Overall			(1) Check for unusual odor and discoloration. (2) Check for serious rust development		○	Stop the device and contact the manufacturer. Contact the manufacturer	
		Aluminum electrolytic capacitor	(1) Check for liquid leakage in a capacitor and deformation trace (2) Visual check and judge by the life check of the main circuit capacitor (Refer to Chapter 4 of the Instruction Manual (Applied).)		○	Contact the manufacturer	
Cooling system			(1) Check for unusual vibration and noise. (2) Check for loose screws and bolts (3) Check for stain	○	○	Replace the fan Fix with the fan cover fixing screws Clean	
	Heatsink	(1) Check for clogging (2) Check for stain		○	Clean Clean		
Display	Indication	(1) Check that display is normal. (2) Check for stain		○	Contact the manufacturer Clean		
	Meter	Check that reading is normal		○	Stop the device and contact the manufacturer.		
Load motor	Operation check	Check for vibration and abnormal increase in operation noise		○	Stop the device and contact the manufacturer.		

*1 Oil component of the heat dissipation grease used inside the drive unit may leak out. The oil component, however, is not flammable, corrosive, nor conductive and is not harmful to humans. Wipe off such oil component.

*2 It is recommended to install a device to monitor voltage for checking the power supply voltage to the drive unit.

*3 One to two years of periodic inspection cycle is recommended. However, it differs according to the installation environment. Consult us for periodic inspection.

**NOTE**

- Continuous use of a leaked, deformed, or degraded smoothing aluminum electrolytic capacitor (refer to page 39) may lead to a burst, breakage or fire. Replace such a capacitor without delay.

8.2 Replacement of parts

The drive unit consists of many electronic parts such as semiconductor devices.

The following parts may deteriorate with age because of their structures or physical characteristics, leading to reduced performance or fault of the drive unit. For preventive maintenance, the parts must be replaced periodically.

Use the life check function as a guidance of parts replacement.

Part Name	Estimated Lifespan *1	Description
Cooling fan	10 years	Replace (as required)
Main circuit smoothing capacitor	10 years *2	Replace (as required)
On-board smoothing capacitor	10 years *2	Replace the board (as required)
Relays	—	as required

*1 Estimated Lifespan for when the yearly average surrounding air temperature is 40°C (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)

*2 Output current: 80% of the drive unit rated current

**NOTE**

For parts replacement, contact the nearest Mitsubishi Electric FA Center.

9 SPECIFICATIONS

9.1 Rating

● Three-phase 200V power supply

Model FR-D720-□K-G		0.2	0.4	0.75	1.5	2.2	3.7
Output	Rated capacity (kVA) ⁻¹	0.3	0.6	1.0	1.7	2.8	4.0
	Rated current (A)	1.4	2.5	4.2	7.0	10.0	16.5
	Overload current rating	150% 60s, 200% 0.5s (Rated motor current, inverse-time characteristics)					
Power supply	Rated input AC voltage/frequency	Three-phase 200 to 240V 50Hz/60Hz					
	Permissible AC voltage fluctuation	170 to 264V 50Hz/60Hz					
	Permissible frequency fluctuation	±5%					
	Power supply capacity (kVA) ⁻²	0.4	0.7	1.2	2.1	4.0	5.5
Protective structure (JEM1030)		Enclosed type (IP20)					
Cooling system		Self-cooling			Forced air cooling		
Approximate mass (kg)		0.5	0.8	1.0	1.4	1.4	1.8

● Three-phase 400V power supply

Model FR-D740-□K-G		0.4	0.75	1.5	2.2	3.7	
Output	Rated capacity (kVA) ⁻¹	0.4	0.9	1.7	2.7	3.8	
	Rated current (A)	1.2	2.2	3.6	5.0	8.0	
	Overload current rating	150% 60s, 200% 0.5s (Rated motor current, inverse-time characteristics)					
Power supply	Rated input AC voltage/frequency	Three-phase 380 to 480V 50Hz/60Hz					
	Permissible AC voltage fluctuation	325 to 528V 50Hz/60Hz					
	Permissible frequency fluctuation	±5%					
	Power supply capacity (kVA) ⁻²	0.9	1.5	2.5	5.5	9.5	
Protective structure (JEM1030)		Enclosed type (IP20)					
Cooling system		Self-cooling			Forced air cooling		
Approximate mass (kg)		1.3	1.3	1.4	1.5	1.5	

*1 The rated output capacity assumes the following output voltages: 230V for three-phase 200V, and 440V for three-phase 400V.

*2 The power supply capacity varies with the value of the power supply side drive unit impedance (including those of the input reactor and cables).

9.2 Common specifications

Control specifications	Control method	PM sensorless vector control (low-speed range: current synchronization operation)	
	Carrier frequencies	5kHz	
	Maximum speed	3000r/min (at 100Hz for 1.5kW S-PM geared motor or lower, or 150Hz for 2.2kW S-PM geared motor) *3	
	Speed setting resolution	Analog input	One thousandth (1/1000) of the speed setting gain speed (terminals 2 and 4: 10 bits, 0 to 10V) One five-hundredth (1/500) of the speed setting gain speed (terminals 2 and 4: 9 bits, 0 to 5V) One thousandth (1/1000) of the speed setting gain speed (terminal 4: 10 bits, 0 to 20mA)
		Digital input	1r/min
	Frequency accuracy	Analog input	Within $\pm 1\%$ of the maximum output frequency (25°C $\pm 10^\circ\text{C}$)
		Digital input	Within 0.01% of the set output frequency
	PM sensorless vector control range	1:10 (300r/min to 3000r/min) *3	
	Starting torque	100% (initial value)	
	Torque boost	PM control torque boost, DC injection brake torque boost	
Acceleration/deceleration time setting	0.1 to 3600s (acceleration and deceleration can be set individually). Linear and S-pattern acceleration/deceleration modes are available.		
Initial magnetic pole detection time	Approx. 0.1s (performed at start, at LX signal ON.)		
Stall prevention operation level	Operation current level (0 to 200%), and whether to use the function or not can be selected		
Environment	Surrounding air temperature	-10°C to +50°C maximum (non-freezing) *1	
	Ambient humidity	90%RH or less (non-condensing)	
	Storage temperature *2	-20°C to +65°C	
	Atmosphere	Indoors (without corrosive gas, flammable gas, oil mist, dust and dirt etc.)	
	Altitude/vibration	Maximum 1000m, 5.9m/s ² or less at 10 to 55Hz (directions of X, Y, Z axes)	

*1 When using the drive units at the surrounding air temperature of 40°C or less, the drive units can be installed closely attached (0cm clearance).


*2 Temperatures applicable for a short time, e.g. in transit.

*3 The maximum speed varies by motor type (rating).

9.3 Specifications of S-PM geared motors

9.3.1 Motor specifications

● Model names of S-PM geared motors



*1 For the model names of the flange types and brake-equipped types, refer to the catalog.
 *2 For the detail of the output-shaft rotation speed (reduction ratio), refer to the catalog.

● 200V class

Motor model	GV-□□kW	0.1	0.2	0.4	0.75	1.5	2.2
Compatible drive unit	FR-D720-□K-G	0.2	0.4	0.75	1.5	2.2	3.7
Continuous characteristic *1	Rated output (kW)	0.1	0.2	0.4	0.75	1.5	2.2
	Rated torque (N•m) *2	0.32	0.64	1.27	2.39	4.78	7.00
Rated speed (r/min) *3	3000						
Maximum speed (r/min) *3	3000						
Number of poles	4						6
Maximum torque	150% 60s						
Rated current (A)	0.55	1.05	1.6	2.8	5.5	9.4	
Structure	Totally enclosed self-cooling *4				Totally-enclosed fan-cooled		
Protective structure	IP44 (indoors), IP44 (outdoors) for semi-standard models						
Environment	Surrounding air temperature and humidity	0°C to +40°C (non-freezing), 90RH or less (non-condensing)					
	Vibration	4.9m/s ² (0.5G) for continuous operation, 9.8m/s ² (1G) for instantaneous operation					


● 400V class

Motor model	GV-□□kW	0.2	0.4	0.75	1.5	2.2
Compatible drive unit	FR-D740-□K-G	0.4	0.75	1.5	2.2	3.7
Continuous characteristic *1	Rated output (kW)	0.2	0.4	0.75	1.5	2.2
	Rated torque (N•m) *2	0.64	1.27	2.39	4.78	7.00
Rated speed (r/min) *3	3000					
Maximum speed (r/min) *3	3000					
Number of poles	4					6
Maximum torque	150% 60s					
Rated current (A)	0.5	0.75	1.4	2.8	4.7	
Structure	Totally enclosed self-cooling *4				Totally-enclosed fan-cooled	
Protective structure	IP44 (indoors), IP44 (outdoors) for semi-standard models					
Environment	Surrounding air temperature and humidity	0°C to +40°C (non-freezing), 90RH or less (non-condensing)				
	Vibration	4.9m/s ² (0.5G) for continuous operation, 9.8m/s ² (1G) for instantaneous operation				

*1 The above characteristics apply when the rated AC voltage is input from the drive unit (refer to page 42). Output and rated motor speed are not guaranteed when the power supply voltage drops.
 *2 The value at the motor shaft. The torque at the output shaft changes according to the reduction ratio and the reduction gear efficiency.
 *3 The value at the motor shaft. The speed of the output shaft changes according to the reduction ratio.
 *4 The 0.75kW motor with a brake has the totally enclosed fan-cooled type structure.


9.3.2 Motor torque characteristic

<<Initial setting ($Pr.785 = 9999 (= 100\%)$)>>




- In the low-speed range (less than 300r/min), the torque output can be increased up to 100% of the setting, but continuous operation is not possible.
- When the input voltage is low, the torque may be reduced.
- The operatable speed range at constant torque is 300r/min to 3000r/min. Continuous operation cannot be performed in 300r/min or less.

<<When $Pr.785 = 50\%$ >>



- Setting *Pr.785 PM control torque boost* to 50%* or less enables continuous operation at the speed less than 300r/min. However, the keep the short-time torque to *Pr.785* setting or lower.
 - * 80% for the FR-D720-1.5K-G or lower and the FR-D740-1.5K-G or lower
- When the input voltage is low, the torque may be reduced.
- The operatable speed range at constant torque is 300r/min to 3000r/min.

9.4 Outline dimension drawings



• Three-phase 200V class

Drive unit Model	W	W1	D
FR-D720-0.2K-G	68	56	80.5
FR-D720-0.4K-G			112.5
FR-D720-0.75K-G			132.5
FR-D720-1.5K-G	108	96	135.5
FR-D720-2.2K-G			142.5
FR-D720-3.7K-G	170	158	142.5

• Three-phase 400V class

Drive unit Model	W	W1	D
FR-D740-0.4K-G	108	96	129.5
FR-D740-0.75K-G			135.5
FR-D740-1.5K-G			155.5
FR-D740-2.2K-G			165.5
FR-D740-3.7K-G			

Appendix 1 Instructions for Compliance with the EU Directives

The EU Directives are issued to standardize different national regulations of the EU Member States and to facilitate free movement of the equipment, whose safety is ensured, in the EU territory.

Since 1996, compliance with the EMC Directive that is one of the EU Directives has been legally required. Since 1997, compliance with the Low Voltage Directive, another EU Directive, has been also legally required. When a manufacturer confirms its equipment to be compliant with the EMC Directive and the Low Voltage Directive, the manufacturer must declare the conformity and affix the CE marking.

● The authorized representative in the EU

The authorized representative in the EU is shown below.

Name: Mitsubishi Electric Europe B.V.

Address: Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany

● Note

We declare that this drive unit, when equipped with the dedicated EMC filter, conforms with the EMC Directive in industrial environments and affix the CE marking on the drive unit.

When using the drive unit in a residential area, take appropriate measures and ensure the conformity of the drive unit used in the residential area.

(1) EMC Directive

We declare that this drive unit, when equipped with the EMC Directive compliant EMC filter, conforms with the EMC Directive and affix the CE marking on the drive unit (except the single-phase 100V power supply model).

- EMC Directive: 2014/30/EU
- Standard(s): EN61800-3:2004+A1:2012 (Second environment / PDS Category "C3")

Note: First environment

Environment including buildings/facilities which are directly connected to a low voltage main supply which also supplies residential buildings.

Directly connected means that there is no intermediate transformer between these buildings.

Second environment

Environment including all buildings/facilities which are not directly connected to a low voltage main supply which also supplies residential buildings.

● Note

- * Set the EMC Directive compliant EMC filter to the drive unit. Insert line noise filters and ferrite cores to the power and control cables as required.
- * Connect the drive unit to an earthed power supply.
- * Install a motor, the EMC Directive compliant EMC filter, and a control cable according to the instructions written in the EMC Installation Guidelines (BCN-A21041-204). (Please contact your sales representative for the EMC Installation Guidelines.)
- * The cable length to the motor should be within 20m so that the EMC Directive compliant noise filter functions sufficiently.
- * Confirm that the final integrated system with the drive unit conforms with the EMC Directive.

(2) Low Voltage Directive


We have self-confirmed our drive units as products compliant to the Low Voltage Directive (Conforming standard EN 61800-5-1) and affix the CE marking on the drive units.

Outline of instructions

- * Do not use an earth leakage circuit breaker as an electric shock protector without connecting the equipment to the earth. Connect the equipment to the earth securely.
- * Wire the earth (ground) terminal independently. (Do not connect two or more cables to one terminal.)
- * Use the cable sizes on *page 14* under the following conditions.
 - Surrounding air temperature: 40°C maximum
 - If conditions are different from above, select appropriate wire according to EN60204.
- * Use a tinned (plating should not include zinc) crimping terminal to connect the earth cable. When tightening the screw, be careful not to damage the threads.

For use as a product compliant with the Low Voltage Directive, use PVC cable on *page 14*.

- * Use the moulded case circuit breaker and magnetic contactor which conform to the EN or IEC Standard.
- * When using an earth leakage circuit breaker, use a residual current operated protective device (RCD) of type B (breaker which can detect both AC and DC). If not, provide double or reinforced insulation between the drive unit and other equipment, or put a transformer between the main power supply and drive unit.
- * Use the drive unit under the conditions of overvoltage category II (usable regardless of the earth (ground) condition of the power supply), overvoltage category III (usable with the earthed-neutral system power supply, 400V class only) specified in IEC60664.
 - To use the drive unit under the conditions of pollution degree 3, install it in the enclosure of IP54 or higher.
 - To use the drive unit outside of an enclosure in the environment of pollution degree 2, fix the fan cover with fan cover fixing screws enclosed.



Example for FR-D720-2.2K-G

Note, the protection structure of the Drive unit units is considered to be an IP00.

- * On the input and output of the drive unit, use cables of the type and size set forth in EN60204.
- * The operating capacity of the relay outputs (terminal symbols A, B, C) should be 30VDC, 0.3A. (Relay output has basic isolation from the drive unit internal circuit.)
- * Control circuit terminals on *page 9* are safely isolated from the main circuit.
- * Environment

	Running	In Storage	During Transportation
Surrounding air temperature	-10°C to +50°C	-20°C to +65°C	-20°C to +65°C
Humidity	90% RH or less	90% RH or less	90% RH or less
Maximum Altitude	1000m	1000m	10000m

* For branch circuit protection, select an appropriate UL and cUL listed fuse with a cut-off speed of Class T, Class J, Class CC, or faster, or a UL 489 molded case circuit breaker (MCCB) in accordance with the following table.


FR-D720-□□K-G		0.2	0.4	0.75	1.5	2.2	3.7
Rated fuse voltage (V)		240V or more					
Fuse maximum allowable rating (A)*	Without power factor improving reactor	15	15	20	30	40	60
	With power factor improving reactor	15	15	20	20	30	50
Molded case circuit breaker (MCCB) Maximum allowable rating (A)*		15	15	15	20	25	40

FR-D740-□□K-G		0.4	0.75	1.5	2.2	3.7	
Rated fuse voltage (V)		480V or more					
Fuse maximum allowable rating (A)*	Without power factor improving reactor	6	10	15	20	30	
	With power factor improving reactor	6	10	10	15	25	
Molded case circuit breaker (MCCB) Maximum allowable rating (A)*		15	15	15	15	20	

* Maximum allowable rating by US National Electrical Code. Exact size must be chosen for each installation.

* When using the electronic thermal relay function as motor overload protection, set the rated motor current in *Pr. 9 Electronic thermal O/L relay*.

Electronic thermal relay function operation characteristic



The ratio of motor current to *Pr. 9 Electronic thermal O/L relay*

This function detects the overload of the motor, stops the operation of the drive unit's output transistor, and stops the output.

(The operation characteristic is shown on the left)

- *1 When 50% of the drive unit rated output current (current value) is set in *Pr. 9*
- *2 The % value denotes the percentage to the drive unit rated output current. It is not the percentage to the motor rated current.

* Short circuit current ratings

- 200V class

Suitable For Use in A Circuit Capable of Delivering Not More Than 5kA rms Symmetrical Amperes, 264V Maximum.

- 400V class

Suitable For Use in A Circuit Capable of Delivering Not More Than 5kA rms Symmetrical Amperes, 528V Maximum.

Appendix 2 Instructions for UL and cUL

(Standard to comply with: UL 508C, CSA C22.2 No. 274-13)

1. General precaution

CAUTION - Risk of Electric Shock -

The bus capacitor discharge time is 10 minutes. Before starting wiring or inspection, switch power off, wait for more than 10 minutes, and check for residual voltage between terminal P/+ and N/- with a meter etc., to avoid a hazard of electrical shock.

ATTENTION - Risque de choc électrique -

La durée de décharge du condensateur de bus est de 10 minutes. Avant de commencer le câblage ou l'inspection, mettez l'appareil hors tension et attendez plus de 10 minutes.

2. Installation

The below types of drive unit have been approved as products for use in enclosure and approval tests were conducted under the following conditions. Design the enclosure so that the surrounding air temperature, humidity and ambience of the drive unit will satisfy the specifications. (Refer to page 42.)

Branch Circuit Protection

Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code for the U.S. or the Canadian Electrical Code for Canada and any additional codes. As specified, UL Class T, Class J, Class CC fuses or any faster acting fuse with the appropriate rating or Listed UL 489 Molded Case Circuit Breaker (MCCB), or Type E combination motor controller must be employed.

FR-D720-□□K-G		0.2	0.4	0.75	1.5	2.2	3.7
Rated fuse voltage(V)		240V or more					
Fuse allowable rating (A)	Without power factor improving reactor	15	15	20	30	40	60
	With power factor improving reactor	15	15	20	20	30	50
Molded case circuit breaker (MCCB) Maximum allowable rating (A)*1, *2		15	15	15	20	25	40
Type E combination motor controller*3	Maximum current rating (A)	4	6.3	8	13	18	25
	Maximum SCCR (kA)*4	50	50	50	50	50	25

FR-D740-□□K-G		0.4	0.75	1.5	2.2	3.7
Rated fuse voltage(V)		480V or more				
Fuse allowable rating (A)	Without power factor improving reactor	6	10	15	20	30
	With power factor improving reactor	6	10	10	15	25
Molded case circuit breaker (MCCB) Maximum allowable rating (A)*1, *2		15	15	15	15	20
Type E combination motor controller*3	Maximum current rating (A)	2.5	4	6.3	10	18
	Maximum SCCR (kA)*4	50	50	50	50	50

*1 Maximum allowable rating by US National Electrical Code. Exact size must be chosen for each installation.

*2 Select an appropriate fuse or molded case circuit breaker with a rating that is suitable for the size of the cable.

*3 For UL/cUL certification, use the following product.

Model	Manufacturer	Rated Voltage, Vac
MMP-T32	Mitsubishi Electric Corp.	480Y/277

*4 Suitable for use in a circuit capable of delivering not more than 50 or 25 kA rms symmetrical amperes, 480Y/277 volts maximum when protected by the Type E combination motor controllers indicated in the above table.

3. Short circuit ratings

• 200V class

Suitable for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes, 264 V maximum.

• 400V class

Suitable for use in a circuit capable of delivering not more than 100 kA rms symmetrical amperes, 528 V maximum.

4. Wiring

Refer to the National Electrical Code (Article 310) regarding the allowable current of the cable. Select the cable size for 125% of the rated current according to the National Electrical Code (Article 430).

For wiring the input (R/L1, S/L2, T/L3) and output (U, V, W) terminals of the drive unit, use the UL Listed copper, stranded wires (rated at 75°C) and round crimping terminals. Crimp the crimping terminals with the crimping tool recommended by the terminal maker.

5. Motor overload protection

When using the electronic thermal relay function as motor overload protection, set the rated motor current to Pr. 9 Electronic thermal O/L relay (refer to page 48).



NOTE

- Motor over temperature sensing is not provided by the drive.

Appendix 3 SERIAL number check

Check the SERIAL number indicated on the drive unit rating plate or package. (*Refer to page 1.*)

Rating plate example

□	○	○	○○○○○○
Symbol	Year	Month	Control number
SERIAL (Serial No.)			

The SERIAL consists of one symbol, two characters indicating the production year and month, and six characters indicating the control number. Last digit of the production year is indicated as the Year, and the Month is indicated by 1 to 9, X (October), Y (November), and Z (December).

Appendix 4 Instructions for EAC



The product certified in compliance with the Eurasian Conformity has the EAC marking.

Note: EAC marking

In 2010, three countries (Russia, Belarus, and Kazakhstan) established a Customs Union for the purposes of revitalizing the economy by forming a large economic bloc by abolishing or reducing tariffs and unifying regulatory procedures for the handling of articles.

Products to be distributed over these three countries of the Customs Union must comply with the Customs Union Technical Regulations (CU-TR), and the EAC marking must be affixed to the products.

For information on the country of origin, manufacture year and month, and authorized sales representative (importer) in the CU area of this product, refer to the following:

- Country of origin indication
Check the rating plate of the product. (*Refer to page 1.*)
Example: MADE IN JAPAN
- Manufactured year and month
Check the SERIAL number (*refer to Appendix 4*) indicated on the rating plate (*refer to page 1*) of the product.
- Authorized sales representative (importer) in the CU area
The authorized sales representative (importer) in the CU area is shown below.
Name: Mitsubishi Electric (Russia) LLC
Address: 52, bld 1 Kosmodamianskaya Nab 115054, Moscow, Russia
Phone: +7 (495) 721-2070
Fax: +7 (495) 721-2071

Appendix 5 Restricted Use of Hazardous Substances in Electronic and Electrical Products

The mark of restricted use of hazardous substances in electronic and electrical products is applied to the product as follows based on the "Management Methods for the Restriction of the Use of Hazardous Substances in Electrical and Electronic Products" of the People's Republic of China.

电器电子产品有害物质限制使用标识要求



本产品中所含有的有害物质的名称、含量、含有部件如下表所示。

- 产品中所含有害物质的名称及含量

部件名称 *	有害物质 *1					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
电路板组件 (包括印刷电路板及其构成的零部件, 如电阻、电容、集成电路、连接器等)、电子部件	×	○	×	○	○	○
金属壳体、金属部件	×	○	○	○	○	○
树脂壳体、树脂部件	○	○	○	○	○	○
螺丝、电线	○	○	○	○	○	○

上表依据 SJ/T11364 的规定编制。

○: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T26572 规定的限量要求以下。

×: 表示该有害物质在该部件的至少一种均质材料中的含量超出 GB/T26572 规定的限量要求。

*1 即使表中记载为 ×, 根据产品型号, 也可能会有有害物质的含量为限制值以下的情况。

根据产品型号, 一部分部件可能不包含在产品中。

Appendix 6 Referenced Standard (Requirement of Chinese standardized law)

This Product is designed and manufactured accordance with following Chinese standards.

Electrical safety: GB12668.501

EMC: GB12668.3

REVISIONS

*The manual number is given on the bottom left of the back cover.

Revision Date	*Manual Number	Revision
Mar. 2012	IB(NA)-0600477ENG-A	First edition
May 2012	IB(NA)-0600477ENG-B	Modification Change in the India FA Center address
Apr. 2016	IB(NA)-0600477ENG-C	Addition <ul style="list-style-type: none"> • FR-D740-0.4K to 3.7K-G • Pr.281 Brake operation time at start • Pr.283 Brake operation time at stop • Pr.643 Voltage compensation amount setting • Pr.658 Wiring resistance • Setting values "10, 11" of Pr.167 Output current detection operation selection • Setting values "20, 37, 120, 137" of Pr.190 and Pr.192
May 2018	IB(NA)-0600477ENG-D	Addition <ul style="list-style-type: none"> • Pr.71, Pr.80, Pr.81, Pr.83, Pr.84, Pr.90, Pr.92, Pr.93, Pr.96, Pr.600 to Pr.604, Pr.672, Pr.702, Pr.706, Pr.707, Pr.711, Pr.712, Pr.717, Pr.721, Pr.724 to Pr.726, Pr.824, Pr.825, Pr.859, Pr.998 • Appendix6 Referenced Standard (Requirement of Chinese standardized law) Modification <ul style="list-style-type: none"> • Appendix 2 Instructions for UL and cUL

⚠ For Maximum Safety

- Mitsubishi Electric drive units are not designed or manufactured to be used in equipment or systems in situations that can affect or endanger human life.
- When considering this product for operation in special applications such as machinery or systems used in passenger transportation, medical, aerospace, atomic power, electric power, or submarine repeating applications, please contact your nearest Mitsubishi Electric sales representative.
- Although this product was manufactured under conditions of strict quality control, you are strongly advised to install safety devices to prevent serious accidents when it is used in facilities where breakdowns of the product are likely to cause a serious accident.
- Please do not use this product for loads other than the PM motor.

International FA Center

●Shanghai FA Center

mitsubishi electric automaiton (CHINA) LTD. Shanghai FA Center
Mitsubishi Electric Automation Center,
No.1386 Honggiao Road, Shanghai, China
TEL. 86-21-2322-3030
FAX. 86-21-2322-3000 (9611#)

●Beijing FA Center

mitsubishi electric automation (CHINA) LTD. Beijing FA Center
5/F, ONE INDIGO, 20 Jiuxianqiao Road
Chaoyang District, Beijing, China
TEL. 86-10-6518-8830
FAX. 86-10-6518-2938

●Tianjin FA Center

mitsubishi electric automation (CHINA) LTD. Tianjin FA Center
Room 2003 City Tower, No.35, Youyi Road,
Hexi District, Tianjin, China
TEL. 86-22-2813-1015
FAX. 86-22-2813-1017

●Guangzhou FA Center

mitsubishi electric automation (CHINA) LTD. Guangzhou FA Center
Room 1609, North Tower, The Hub Center,
No.1068, Xingang East Road, Haizhu District,
Guangzhou, China
TEL. 86-20-8923-6730
FAX. 86-20-8923-6715

●Korea FA Center

mitsubishi electric automation
KOREA CO., LTD.
8F, Gangseo Hangang Xi-tower A, 401,
Yangcheon-ro , Gangseo-Gu, Seoul 07528,
Korea
TEL. 82-2-3660-9630
FAX. 82-2-3664-0475

●Taipei FA Center

SETSUYO ENTERPRISE CO., LTD.
3F, No.105, Wugong 3rd Road, Wugu District,
New Taipei City 24889, Taiwan
TEL. 886-2-2299-9917
FAX. 886-2-2299-9963

●Taichung FA Center

mitsubishi electric taiwan CO.,LTD.
No.8-1, Industrial 16th Road, Taichung
Industrial Park, Taichung City 40768 Taiwan
TEL. 886-4-2359-0688
FAX. 886-4-2359-0689

●Thai FA Center

mitsubishi electric factory
AUTOMATION (THAILAND) CO., LTD.
12th Floor, SV City Building, Office Tower 1,
No. 896/19 and 20 Rama 3 Road, Kwaeng
Bangpongpan, Khet Yannawa, Bangkok
10120, Thailand
TEL. 66-2682-6522 to 31
FAX. 66-2682-6020

●ASEAN FA Center

mitsubishi electric asia pte. LTD.
307, Alexandra Road, Mitsubishi Electric
Building, Singapore 159943
TEL. 65-6470-2480
FAX. 65-6476-7439

●Indonesia FA Center

PT. MITSUBISHI ELECTRIC INDONESIA
Cikarang Office
Jl. Kenari Raya Blok G2-07A Delta Silicon 5,
Lippo Cikarang - Bekasi 17550, Indonesia
TEL. 62-21-2961-7797
FAX. 62-21-2961-7794

●Hanoi FA Center

mitsubishi electric vietnam
COMPANY LIMITED Hanoi Branch Office
6th Floor, Detech Tower, 8 Ton That Thuyet
Street, My Dinh 2 Ward, Nam Tu Liem
District, Hanoi, Vietnam
TEL. 84-4-3937-8075
FAX. 84-4-3937-8076

●Ho Chi Minh FA Center

mitsubishi electric vietnam
COMPANY LIMITED
Unit 01-04, 10th Floor, Vincom Center, 72 Le
Thanh Ton Street, District 1, Ho Chi Minh
City, Vietnam
TEL. 84-8-3910-5945
FAX. 84-8-3910-5947

●India Pune FA Center

mitsubishi electric india pvt. LTD.
Pune Branch
Emerald House, EL -3, J Block, M.I.D.C
Bhosari, Pune - 411026, Maharashtra, India
TEL. 91-20-2710-2000
FAX. 91-20-2710-2100

●India Gurgaon FA Center

mitsubishi electric india pvt. LTD.
Gurgaon Head Office
2nd Floor, Tower A & B, Cyber Greens, DLF
Cyber City, DLF Phase - III, Gurgaon -
122002 Haryana, India
TEL. 91-124-463-0300
FAX. 91-124-463-0399

●India Bangalore FA Center

mitsubishi electric india pvt. LTD.
Bangalore Branch
Prestige Emerald, 6th Floor, Municipal No. 2,
Madras Bank Road, Bangalore - 560001,
Karnataka, India
TEL. 91-80-4020-1600
FAX. 91-80-4020-1699

●India Chennai FA Center

mitsubishi electric india pvt. LTD.
Chennai Branch
Citilights Corporate Centre No.1,
Vivekananda Road, Srinivasa Nagar,
Chetpet, Chennai - 600031, Tamil Nadu,
India
TEL. 91-4445548772
FAX. 91-4445548773

●India Ahmedabad FA Center

mitsubishi electric india pvt. LTD.
Ahmedabad Branch
B/4, 3rd Floor, SAFAL Profitaire, Corporate
Road, Prahaladnagar, Satellite, Ahmedabad
- 380015, Gujarat, India
TEL. 91-7965120063
FAX. 91-79-6512-0063

●North America FA Center

mitsubishi electric automation,
INC.
500 Corporate Woods Parkway, Vernon
Hills, IL 60061, U.S.A.
TEL. 1-847-478-2334
FAX. 1-847-478-2253

●Mexico FA Center

mitsubishi electric automation,
INC. Queretaro Office
Parque Tecnológico Innovacion Queretaro
Lateral Carretera Estatal 431, Km 2 200,
Lote 91 Modulos 1 y 2 Hacienda la
Machorra, CP 76246, El Marques,
Queretaro, Mexico
TEL. 52-442-153-6014

●Mexico Monterrey FA Center

mitsubishi electric automation,
INC. Monterrey Office
Plaza Mirage, Av. Gonzalez 460 Sur, Local
28, Col. San Jeronimo, Monterrey, Nuevo
Leon, C.P. 64640, Mexico
TEL. 52-55-3067-7521

●Mexico City FA Center

mitsubishi electric automation,
INC. Mexico Branch
Mariano Escobedo #69, Col.Zona Industrial,
Tlalnepanitla Edo. Mexico, C.P.54030
TEL. 52-55-3067-7511

●Brazil FA Center

mitsubishi electric do brasil
COMERCIO E SERVICOS LDA.
Avenida Adelino Cardana, 293, 21 andar,
Bethaville, Barueri SP, Brazil
TEL. 55-11-4689-3000
FAX. 55-11-4689-3016

●Brazil Votorantim FA Center

MELCO CNC DO BRASIL COMERCIO E
SERVICOS S.A.
Avenida Gisele Constantino,1578, Parque
Bela Vista - Votorantim-SP, Brazil
TEL. 55-15-3023-9000
FAX. 55-15-3363-9911

●Europe FA Center

mitsubishi electric europe B.V.
Polish Branch
ul. Krakowska 50, 32-083 Balice, Poland
TEL. 48-12-347-65-81
FAX. 48-12-630-47-01

●Germany FA Center

mitsubishi electric europe B.V.
German Branch
Mitsubishi-Electric-Platz 1, 40882 Ratingen,
Germany
TEL. 49-2102-486-0
FAX. 49-2102-486-1120

●UK FA Center

mitsubishi electric europe B.V. UK
Branch
Travellers Lane, Hatfield, Hertfordshire,
AL10 8XB, UK
TEL. 44-1707-28-8780
FAX. 44-1707-27-8695

●Czech Republic FA Center

mitsubishi electric europe B.V.
Czech Branch
Pekarska 621/7, 155 00 Praha 5, Czech
Republic
TEL. 420-255 719 200
FAX. 420-251-551-471

●Italy FA Center

mitsubishi electric europe B.V.
Italian Branch
Centro Direzionale Colleoni - Palazzo Siro,
Viale Colleoni 7, 20864 Agrate Brianza (MB),
Italy
TEL. 39-039-60531
FAX. 39-039-6053-312

●Russia FA Center

mitsubishi electric (Russia) LLC St.
Petersburg Branch
Piskarevsky pr. 2, bld 2, lit "Sch", BC
"Benusa", office 720; 195027, St. Petersburg,
Russia
TEL. 7-812-633-3497
FAX. 7-812-633-3499

●Turkey FA Center

mitsubishi electric turkey A.S.
Umraniye Branch
Serifali Mahallesi Nutuk Sokak No:5, TR-
34775 Umraniye / Istanbul, Turkey
TEL. 90-216-526-3990
FAX. 90-216-526-3995

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN