


## Instructions AK-controller with USB-B





## **Driver installation**



Windows 7 and 8: See below


Windows 10: Driver is available in Windows 10 and will automatically install.

## Windows 7 (and 8):

1. Get the driver:

http://food-retail.danfoss.com/support-center/apps-and-software/ak-st-500/ (If the Service tool is installed with software version 3.45? Then go to point 4.)

- 2. Un zip
- 3. Place the driver in the folder "lib"



- 4. Power on the AK-controller and wait 10 sec.
- 5. Connect AK-controller to PC

