Drawings


EJX438A Diaphragm Sealed Gauge Pressure Transmitter (Transmitter body section)



[Style: S2]


SD 01C25J03-01E

Unit: mm (approx. inch)



*1: When electrical connection code 7 or C is selected, a blind plug is protruded up to 8 mm from the conduit connection.

• Terminal Configuration



• Terminal Wiring

SUPPLY	+	Power supply and output terminals
CHECK or ALARM	+ + + -	© External indicator (ammeter) terminals*1*2 or Status contact output terminals*2 (when /AL is specified)
Ground terminal		

- *1: When using an external indicator or check meter, the internal resistance must be 10 Ω or less. A check meter or indicator cannot be connected when /AL option is specified.
- *2: Not available for FOUNDATION Fieldbus and PROFIBUS PA communication types.