SIEMENS

Installation Instructions

Document No. 540-148 August 15, 2012

TALON® Analog Room Temperature Sensor, 10K Ω Thermistor

Product Description

These sensors work with Siemens controllers. The sensors use a 10K ohm thermistor to detect temperature. The effective sensing range is 55°F to 95°F (13°C to 35°C).

NOTE: Any of these sensors can be mounted on

electrical boxes, stud-type mounting brackets, or drywall. Obtain the necessary mounting hardware and follow the appropriate mounting procedures for the type of installation required.

Product Numbers

| Product N | Numbers | |
|-----------------|----------|--|
| TALON Logo** | No Logo | Description |
| 587-614B | 540-661B | Sensing only |
| 587-618B | 540-671B | Override and setpoint |
| 587-620CB | | Override, setpoint and temperature display, Celsius |
| 587-620FB | | Override, setpoint and temperature display, Fahrenheit |

Expected Installation Time

20 minutes

Caution Notation

| CAUTION: | A | Equipment damage or loss of data may occur if you do not follow the procedures as specified. |
|----------|---|--|
|----------|---|--|

Required Tools

- · Phillips size 1 or 2 screwdriver
- 1/16-inch Allen wrench, (Part Number 192-632, package of 5)
- Small and medium flat-blade screwdrivers
- Medium-duty electric drill
- 3/16-inch drill bit
- 1-inch hole saw
- Hammer
- Utility knife
- · Wire cutters
- Small level
- Tape measure
- · Marker or pencil

If using non-preterminated cables (or if cables are damaged), you also need:

- Room sensor connector tool (RJ-11 crimping tool)
- · Room sensor connector kit

Prerequisites

- Appropriate field wiring (standard six-conductor room sensor cables, plenum) within the maximum wiring run length for the individual field panel or equipment controller must be installed. The maximum recommended length is 100-feet (30.5 m).
- See Table 2 for cable product numbers.
- All wiring must comply with National Electric Code (NEC) and local regulations.




Figure 1. Room Temperature Sensor (Shows All Options).

Mounting Information

Locate the sensor:

- According to design specifications and local regulations.
- Where the air circulates around it freely (not in recessed areas or behind doors).
- Allowing a minimum of 4 inches (102 mm) free space above and below for proper airflow, the front cover removal tool, and the computer communication cable.
- Away from drafts caused by doors, windows, outside walls, air registers, pipes, return air plenums, etc.
- Away from heat sources such as strong lights, fireplaces, direct sunlight, etc.
- On an inside wall (preferably), about 5 feet (1.5 m) above the finished floor.

NOTE: While not recommended, if you must mount the sensor on exterior brick or cement-type walls. See Table 5 for Accessories.

Drywall Mounting (No Rough-in), Typical

 Using the sensor base plate as a template, mark the center (cable) hole (use a pencil to press through the rubber insulator) and the mounting hole locations. See Figure 2.



CAUTION:

For drywall mounting, only use the top and bottom holes.




Figure 2. Mounting and Center Hole Locations Dimensions in Inches (Millimeters).

- 2. Drill two 3/16-inch (4.8 mm) mounting holes.
- 3. Cut a 1-inch (25.4 mm) center hole with a hole saw. See Figure 2.
- If using screws to attach the sensor, insert two plastic wall anchors.
- If necessary, use a utility knife to cut a slit through the rubber insulator in the center hole of the sensor base plate. Pull about 3 inches (75 mm) of the cable through the mounting hardware in the order shown.
 See Figure 3.




Figure 3. Drywall Mounting (No Rough-in), Typical.

- Mount the sensor base plate on the wall, noting the UP arrow on the stabilizer plate:
 - Install the two mounting screws provided, the drive rivets provided, or spring clips, but do not tighten.



CAUTION:

Pounding too hard or over-tightening may cause the sensor base plate to crack or bend.

- b. Level the sensor base plate for appearance.
- Tighten the two mounting screws to the sensor base plate.
- If the cable is terminated, inspect the RJ-11 connector for damage.
- If the cable is non-terminated or if the RJ-11 was damaged, cut the cable, leaving about 3 inches (75 mm) on the sensor side of the drywall, and attach an RJ-11 connector with an RJ-11 crimping tool. On the RJ-11 connectors, ensure that pin Number 1 connects to the same wire at each end of the cable. See Figure 4.



CAUTION:

For retrofits: Before cutting the cable, make sure it is disconnected from the Room Temperature Sensor (RTS) port on the controller cable end.




Figure 4. Terminating the RJ-11 Connector.

Page 2 of 4 Siemens Industry, Inc.

Table 1. BACnet TEC or ATEC Controller Wiring Diagram.

| Pin | Wire | |
|--------------|--------|------------------|
| 1 Not Used | |] |
| 6 TX/RX | _ | |
| 3 Room Temp/ | Pair | Pair 1 |
| Setpoint, | | 3 Pair 2 |
| Override | ste | |
| 4 Common | wisted | Section 5 Pair 3 |
| 5 TX/RX | 7 - | 65 |
| 2 GND | | |

- 9. Plug the terminated cable into the RJ-11 port on the back of the printed circuit board (PCB).
- Feed the extra cable back through the hole in the rubber insulator.
- 11. Snap the sensor front to the sensor base plate:
 - a. Hook the sensor front to the bottom latches.
 - Push the top of the sensor front into place until it latches.
- 12. Tighten the sensor retaining screw with an Allen wrench. See Figure 3.
- 13. Connect the sensor to the RTS port on the controller.

The installation is now complete.

Electrical Box and Rough-in Mounting, Typical

- If a locator is attached to the rough-in device, remove the locator by removing the two screws and lightly rocking the locator to pull it free.
- Until the twist tie and pull about three inches (75 mm)
 of the sensor cable into the space.
- 3. If you have a single-sensor electrical box, install the electrical box adapter plate. See Figure 5.

If you have a double-sensor electrical box, install the required mounting plate(s).

If you use a universal adapter kit for a retrofit job, install the multi-slotted plate in place of the electrical box adapter plate. See Figure 5.




Figure 5. Electrical Box and Rough-in Mounting (Typical).

- 4. Pull the cable from the wall, through the required mounting hardware in the order shown.
- Install the two sensor mounting screws provided but do not tighten.
- Mount the sensor base plate on the wall, noting the UP arrow on the stabilizer plate:
 - a. Level the sensor base plate for appearance only.
 - b. Tighten the two mounting screws to the sensor base plate.



CAUTION:

Over-tightening may cause the sensor base plate to crack or bend.

7. Continue with *Drywall Mounting (No Rough-in, Typical)*, Steps 7 through 13.

The installation is now complete.

Accessories

Table 2. Room Sensor Pre-terminated Cables.

| Controller Product Number | Description |
|---------------------------------|-------------------------|
| Plenum | |
| 540-135 or | 25-foot (7.6 m) cable |
| 588-100A | with connections |
| 540-136 or | 50-foot (15.2 m) cable |
| 588-100B | with connections |
| 540-137 or | 100-foot (30.5 m) cable |
| 588-100C | with connections |

Siemens Industry, Inc.

Installation Instructions Document No. 540-148 August 15, 2012

Review Table 3 to verify that you have the appropriate mounting hardware.

For retrofit installations, normally follow the method used by the pre-existing device. You may need to replace existing mounting hardware. Always mount the sensor vertically.

Table 3. Mounting Accessories.

| P/N | Description | Used For | Reference |
|----------|---|---|------------------------|
| 182-621E | Gym Guard Kit, satin chrome | gyms and similar environments requiring a guard. (Incompatible with adapter bases and the extender ring.) | 155-222P25 (TB 193) |
| 182-683 | Metal (and Wood) Stud Mounting Bracket (pkg. 5) | Single-sensor rough-in installations. Kit includes locator. | 129-057 |
| 182-685 | Spring Clips: Finished Drywall Mounting Kit (10 pack) | Drywall mounting. | 129-073 |
| 192-506 | Electrical Box Adapter Plate Assembly Kit (pkg. 5) | Electrical boxes mounted flush with the wall and for gyms and similar environments requiring a guard. (Also see Part Number 544-782.) | Figure 5 |
| 192-860 | Finish Plate Kit 1 Gang 1 Sensor; stainless steel | Single-sensor, low-cost mounting. Plate is 3.7 × 5.1 inches (9.5 × 12.9 cm). | 155-252P25 (TB 238) |
| 536-666 | Mounting Strap | Standard light switch plate (field-supplied) to mount sensor on 2 x 4 electrical box. | 540-040; 540-237 |
| 544-782B | Single Adapter Base Mounting Kit, white | 2 x 4 boxes, all single sensor installations on walls with oversized holes, paint lines, etc., that need to be covered, and on exterior brick/cement-type walls. Kit includes Electrical Box Adapter Plate Assembly (Part Number 192-495. Adapter base is 3-1/2 x 5 inches (8.8 x 12.7 cm). | Figure 5 |
| 544-783B | Double Adapter Base Mounting Kit, white | 4 x 6 boxes and all double sensor installations on walls with oversized holes, paint lines, etc., that need to be covered, and on exterior brick/cement-type walls. Kit includes two mounting plates (Part Number 192-720). Adapter base is 5 x 7 inches (12.7 x 18 cm). | Figure 5 |
| 544-784 | Non-conduit Rough-in Kit, Double | Double-sensor non-conduit rough-in installations. Kit includes locator. | 540-784 |
| 544-785B | Extender Ring Kit | Exterior brick or cement-type walls; fits to back of sensor base plate. | _ |
| 544-800 | Universal Adapter Kit | Retrofitting a previous horizontal installation to a vertical one, or when the screw spacing does not fit the electrical box adapter plate. Kit includes multi-slotted adapter plate. | Figure 5 |
| 981-344 | Electrical Box Cover Plate Kit | 2 x 4 box rough-ins. Kit includes locator and connector. | — |

Information in this publication is based on current specifications. The company reserves the right to make changes in specifications and models as design improvements are introduced. TALON is a registered trademark of Siemens Industry, Inc. Other product or company names mentioned herein may be the trademarks of their respective owners. © 2012 Siemens Industry, Inc.